

```

; This is a CPM program to test some of the hardware on the Z80
; IBM-PC S-100 keyboard converter board and modify some of the software.
; This code will reside at 100H in your S-100 system RAM. The actual
; 2716 EPROM code will reside at near the beginning of the code with
; most of the diagnostic code above the EPROM code.
;
; The EPROM code will reside at 0H in RAM on the board without the diagnostic
; code. To remove the diagnostic code set DEBUG FALSE.
;
; For diagnostics you will need two input ports and one output to control the board.
; The port connections are shown on the S100Computers.com web site.
; They are called KEYCLEAR,KEYSTAT and KEYIN (see below).
; You will also need to use your "normal" CPM keyboard device to test this board.
; You cannot test this board and at the same time use it as the CPM keyboard
; input device.
;
;
; V2.1 Everything except caps lock does not work
; V2.2 Caps lock OK CTRL needs to be done
; V2.3 CAPS,CTRL done
; V2.4 F1,F2 function key strings added
;
FALSE EQU 0
TRUE EQU NOT FALSE
;
LF EQU 0AH
CR EQU 0DH
BELL EQU 07H
SPACE EQU 20H
TAB EQU 09H ;TAB ACROSS (8 SPACES FOR SD-BOARD)
;
DEBUG EQU TRUE ;Mods to the the EPROM code if we are debugging here
;
IF NOT DEBUG
STACK EQU 0FFFH ;Stack at top of RAM for real ROM code
ENDIF
;
CONT$A EQU 0F5H ;CTRL port for output to Video board keyboard input port
CONT$B EQU 0F7H ;CTRL port for IBM Keyboard input
CONT$C EQU 0F9H ;CTRL port for data port KEYCLEAR
CONT$D EQU 0FBH ;CTRL port for port KEYSTAT
;
IF DEBUG
KEYOUT EQU 01H ;Data port for direct output to SD Systems video board
KEYIN EQU 04H ;Raw data port for IMB keyboard (Diagnostic port)
KEYCLEAR EQU 07H ;Pulsing bit 0 high clears 74LS161 Shift Regs
KEYSTAT EQU 07H ;Input bit 0 is zero if IBMPC Key char ready
;to be read and translated
ELSE
KEYOUT EQU 0F4H ;Data port for output to Video board keyboard input port
KEYIN EQU 0F6H ;Data port for IMB keyboard input
KEYCLEAR EQU 0F8H ;Pulsing bit 0 high clears 74LS161 Shift Regs
KEYSTAT EQU 0FAH ;Input bit 0 is zero if IBMPC Key char ready
ENDIF
;
;----- ACTUAL EPROM CODE FOR THE BOARD -----
;
; The memory location "CASEFLAG" will contain various bit flages to indicate
; the current ASCII translation table being used(upper/lower case etc). They
; are also used to turn on/off the board indicator LED's.
; (Note a register could be set aside instead of a RAM location, but I wanted
; to have expandability for more complex translations later).
;
; Bit flags for CASEFLAG:-

```

```

;          Bit 0  not used (used to clear 74LS161 shift regs)
;          Bit 1  Strobe for data into Video board keyboard port
;          Bit 2  = 1 if Upper Case Lock is ON
;          Bit 3  = 1 if Shift key is currently HELD down
;          Bit 4  = 1 if Ctrl key is currently HELD down
;          Bit 5  = 1 if NUM LOCK is ON
;
; REMEMBER IX is not used for ANYTHING other than to point to CASEFLAG
;
;
IF          DEBUG          ;If debug/test version start at 100H so it can be loaded with CPM
          ORG          100H

;
Start:     LD          SP,STACK      ;need a CPM stack
          LD          HL,SIGNON
          CALL        PMSG
          CALL        SETUP_BUFFERS ;Setup IX to point to character output buffer
          CALL        CLEAR         ;Clear the shift registers

          JP          EPROM         ;<--- JUMP TO EPROM CODE

;
ELSE
          ORG          0H           ;The EPROM code will start here

;
          DI          ;Just in case
          LD          A,0FH         ;First setup the two Zilog PIO's
          OUT        (CONT$A),A    ;Mode 0 Output
          LD          A,03H
          OUT        (CONT$A),A

          LD          A,4FH         ;Mode 1 Input
          OUT        (CONT$B),A
          LD          A,03H
          OUT        (CONT$B),A

          LD          A,0FH         ;Mode 0 Output
          OUT        (CONT$C),A
          LD          A,03H
          OUT        (CONT$C),A

          LD          A,4FH         ;Mode 1 Input
          OUT        (CONT$D),A
          LD          A,03H
          OUT        (CONT$D),A

          IN          A,(KEYIN)    ;Clear out any junk
          IN          A,(KEYSTAT)

RAM0:     LD          HL,800H       ;Next clear RAM. This will allow DEBUG monitor (see below)
          XOR        A            ;show up any problem.
          LD          (HL),A       ;Zero RAM
          INC        HL
          LD          A,H
          CP          10H         ;Clear from 0800H to 0FFFH
          JR          NZ,RAM0
          JR          OVER

;
          ORG        38H          ;Reset location 0FFH (CPU jumps here if no RAM)
          LD          A,38H        ;Flag for no RAM (38 appears on HEX display, HALT LED comes on)
          OUT        (KEYOUT),A   ;Send 38H to HEX display to indicate a RAM problem
          HALT                 ;No Strobe, so Keyboard does not see it. Stop Everything

;
OVER:     LD          HL,800H      ;Check RAM.
RAM1:     LD          A,(HL)       ;Is it 0.
          OR          A           ;Zero RAM

```

```

JR      NZ, RAM_PROBLEM
INC
LD      A, H
CP      10H          ;Clear from 0800H to 0FFFH
JR      NZ, RAM1
LD      SP, STACK   ;Now setup a valid stack on the boards RAM (@ 0FFFH)
JR      RAM_OK
;
RAM_PROBLEM:
LD      A, 10H
OUT     (KEYOUT), A ;Send 10H to HEX display to indicate a RAM problem
HALT    ;No Strobe, so Keyboard does not see it. Stop Everything

RAM_OK:  LD      A, 11H
OUT     (KEYOUT), A ;Send 11H to HEX display to indicate a reset went OK.
        ;No Strobe, so Keyboard does not see it
LD      A, 80H
CALL    DELAY_LONG ;Check stack

LD      A, 12H
OUT     (KEYOUT), A ;Then send 12H to HEX display to indicate a reset went OK.
        ;No Strobe, so Keyboard does not see it

CALL    SETUP_BUFFERS ;Setup IX to point to character output buffer
CALL    CLEAR          ;Clear all shift registers

LD      A, 13H
OUT     (KEYOUT), A ;Then send 13H to HEX display to indicate we are ready to go.
        ;No Strobe, so Keyboard does not see it

ENDIF

EPROM:
LOOP:   CALL    GETSTAT          ;The MAIN LOOP. Anything at IBM Keyboard
CALL    Z, LOOP1
CALL    CRTOUT          ;>>> IF <<<, there is something in the que, send it
JR      LOOP           ;to the keyboard output port

LOOP1:  IN      A, (KEYIN)      ;Something at IBM keyboard port
IF
DEBUG
CALL    DIAGNOSTIC      ;Display raw data on consol

ENDIF

CP      0F0H          ;Is it an UP key
JR      NZ, DOWNKY     ;Must be a down key stroke
CALL    UPKEY          ;Special tratment for UP key scan codes
JR      SKIP

DOWNKY: LD      (DOWN_KEY), A    ;Store it
CP      58H          ;Is it CAPS Lock key
JP      Z, CAPSKEY
CP      12H          ;Is it a SHIFT key
JP      Z, SHIFTKEY
CP      59H          ;Is it the other SHIFT key
JP      Z, SHIFTKEY
CP      14H          ;Is it the CTRL key
JP      Z, CTRLKEY
CP      77H          ;Is it the NUM LOCK key
JP      Z, NUMKEY

CALL    TRANSLATE      ;IBM char in A, return with ASCII in C

LD      A, C
OR      A             ;Don't send NULL characters (SD System Board
JP      Z, SKIP       ;cannot seem to handle them!).
CALL    CHARTOBUFFER   ;Just put it in the 256 byte OUTBUFFER
SKIP:   CALL    CLEAR
RET

```

```

GETSTAT:  IN      A, (KEYSTAT)
          BIT      0,A          ;Bit 0 is Zero if a character is ready
          RET

SETUP_BUFFERS:
          XOR      A
          LD      (CASEFLAG),A      ;Will contain flags for LC, Shift, Ctrl etc.
          LD      IX,CASEFLAG ;IX will ALWAYS point to CASEFLAG
          EXX     ;Z80 Alt Reg set will hold the "OUT" Buffer data
          LD      DE,OUTBUFFER      ;DE' End of que - Always
          LD      BC,OUTBUFFER      ;BC' Start of que - Always
          LD      (DE),A            ;Flag as nothing there
          EXX
          RET

CLEAR:    PUSH    AF                ;Save value
          LD      A,(IX+0)          ;Routine to clear 74LS161 shift registers
          OR      1H                ;Need to raise bit 0, see below
          OUT     (KEYCLEAR),A      ;LED will also lightup for bits in CASEFLAG
          CALL   DELAY              ;Delay a little (seems to be required!)
          LD      A,(IX+0)          ;Bits 0 & 1 will always be 0
          OUT     (KEYCLEAR),A
          POP     AF
          RET

DELAY:    LD      A,0FFH            ;Slight time delay for hardware
DL1:      DEC     A
          JP     NZ,DL1
          RET

DELAY_LONG:                ;Delay based on value in [A]
          PUSH   BC
          LD     B,A
DEL1:     CALL   DELAY
          DJNZ  DEL1
          POP   BC
          RET

NUMKEY:   BIT     5,(IX+0)          ;Is the NUMBER LOCK already set
          JP     Z,NUMSET
          RES    5,(IX+0)
          CALL   CLEAR
          RET                    ;Note a RET will drop the stack back to the main Loop
NUMSET:   SET     5,(IX+0)          ;set, so trans sees it as NUMLOCK
          CALL   CLEAR
          RET

SHIFTKEY:
          SET    3,(IX+0)          ;Set the SHIFT key, so TRANSLATE sees scan as upper case
          CALL   CLEAR            ;in the tables below
          RET

CTRLKEY:
          SET    4,(IX+0)          ;Set the CTRL key, so TRANSLATE sees scan as ctrl keys
          CALL   CLEAR            ;in the tables below
          RET

CAPSKEY:  BIT     2,(IX+0)          ;Is the CAPS LOCK already set
          JP     Z,CAPSET
          RES    2,(IX+0)
          RES    3,(IX+0)          ;Also do clear the regular shift key flags
          CALL   CLEAR
          RET                    ;Note a RET will drop the stack back to the main Loop
CAPSET:   SET     2,(IX+0)          ;set, flag to indicate CAPS LOCK key down

```

```

CALL CLEAR
RET

UPKEY:
IF DEBUG ;Because we are bypassing the Z80/PIO we need special
LD A, (DOWN_KEY) ;code here for the Diagnostic version.
ELSE ;It's an UPKEY (0F0H), what was the last key
CALL CLEAR ;Clear the register
UPKEY1: CALL GETSTAT ;Wait to find which key we are shifting or ctrl-ing
JR NZ, UPKEY1 ;Note:- This is a better way. Fast typing misses keys
IN A, (KEYIN) ;in the diagnostic DOWN_KEY mode.
ENDIF

CP 14H ;Was the SHIFT or CTRL held down until now
JR Z, CLEAR_CTRL ;Note Alt keys are not used in this version
CP 12H
JR Z, CLEAR_SHIFT
CP 59H
JR Z, CLEAR_SHIFT
IF DEBUG
CP 0H ;This if for situations where the SHIFT/CTRL is held
JR Z, CLEAR_SHIFT ;down for multiple key strokes and then released.
JR Z, CLEAR_CTRL ;or simply pressed and released (Note both cleared)
ENDIF

NOSHIFT: XOR A
LD (DOWN_KEY), A
CALL CLEAR
RET ;Note a RET will drop the stack back to the main Loop

CLEAR_SHIFT:
RES 3, (IX+0)
JR NOSHIFT

CLEAR_CTRL:
RES 4, (IX+0)
JR NOSHIFT

;
;
CHARTOBUFFER: ;We get here knowing we have a character
EXX ;Get the alt reg's that contain the pointers
LD (DE), A
INC E ;update pointer (loop 256 bytes)
XOR A
LD (DE), A ;Flag for new end of que
EXX
RET

CRTOUT: EXX ;Send character to actual CRT board
LD A, (BC) ;EXX to get to pointers
CP 0H
JP Z, CRT1 ;nothing in que
LD A, (BC)
INC C ;Advance pointer
OUT (KEYOUT), A ;Show ASCII on Hex Display and send it
LD A, (IX+0) ;Need to send strobe bit (raise bit1)
OR 2H ;Note bit 0 will always be 0 in CASEFLAG
OUT (KEYCLEAR), A ;LEDs will stay the same
CALL DELAY
CALL DELAY
LD A, (IX+0) ;Bits 0 & 1 will always be zero
OUT (KEYCLEAR), A
CALL DELAY
CALL DELAY
CALL DELAY

KP2: IN A, (KEYSTAT)

```

```

        BIT      1,A
        JP       Z,KP2          ;Wait until ACK from SD Systems board returns HIGH
CRT1:   EXX
        RET

TRANSLATE:
        CP      0E0H          ;Convert PC Scan codes to ASCII characters
                                ;Is it the special "prfix" keys . (Print Scr, Scroll lock
                                ;Pause, Ins, Del,...the 4 arrow keys). All these begin with
                                ;E0H.
        JP      NZ,F1_F12_KEYS ;If so just skip them for now, they are done on the number pad.
        CALL   CLEAR          ;anyway
        LD      C,0
        RET

                                ;The function keys and number pad require special treatment
F1_F12_KEYS:
                                ;Translate the function keys into multi character strings.
        CP      05H          ;Function key F1 = "DIR *.*[ALL]"
        JR     NZ,NOTF1
        LD     HL,F1_STRING
F1_LOOP: LD     A,(HL)
        OR     A
        JR     Z,F1_DONE
        CALL  CHARTOBUFFER
        INC   HL
        JR     F1_LOOP
F1_DONE: CALL  CLEAR
        LD     C,0
        RET

NOTF1:  CP      06          ;Function key F2 = "PIP E:=A:*. *[V]"
        JR     NZ,NOTF2
        LD     HL,F2_STRING
F2_LOOP: LD     A,(HL)
        OR     A
        JP     Z,F1_DONE
        CALL  CHARTOBUFFER
        INC   HL
        JR     F2_LOOP

NOTF2:
                                ;<<<< Add more strings if needed later
                                ;Note fall through to NUM_PAD below

                                ;We treat the Number pad keys seperately because
                                ;they are independent of the Shift & Ctrl keys
NUM_PAD: BIT    5,(IX+0)      ;Special treatment for NUMLOCK Keys
        JP     Z,LOOKUP_TABLES
        CP     6CH          ;'7'
        JP     NZ,M1
        LD     C,'7'
        RET
M1:    CP     75H          ;'8'
        JP     NZ,M2
        LD     C,'8'
        RET
M2:    CP     7DH          ;'9'
        JP     NZ,M3
        LD     C,'9'
        RET
M3:    CP     6BH          ;'4'
        JP     NZ,M4
        LD     C,'4'
        RET
M4:    CP     73H          ;'5'
        JP     NZ,M5
        LD     C,'5'
        RET

```

```

M5:      CP      74H          ;'6'
        JP      NZ,M6
        LD      C,'6'
        RET
M6:      CP      69H          ;'1'
        JP      NZ,M7
        LD      C,'1'
        RET
M7:      CP      72H          ;'2'
        JP      NZ,M8
        LD      C,'2'
        RET
M8:      CP      7AH          ;'3'
        JP      NZ,M9
        LD      C,'3'
        RET
M9:      CP      70H          ;'0'
        JP      NZ,M10
        LD      C,'0'
        RET
M10:     CP      71H          ;'.'
        JP      NZ,M11
        LD      C','
        RET
M11:     CP      79H          ;'+'
        JP      NZ,M12
        LD      C,'+'
        RET
M12:     CP      7BH          ;'-'
        JP      NZ,M13
        LD      C,'-'
        RET
M13:     CP      7CH          ;'*'
        JP      NZ,M14
        LD      C,'*'
        RET
M14:     CP      4AH          ;'/'
        JP      NZ,LOOKUP_TABLES ;<<<< Must be a "regular" keyboard key
        LD      C,'/'
        RET

```

;

```

; There are 3 possible lookup tables for translating the scan code to ASCII
; depending on the status of the CTRL and Shift keys
; (Alt key's could be added later).

```

LOOKUP_TABLES:

```

        LD      B,0
        LD      C,A
        BIT    4,(IX+0)      ;Is it a CTRL key
        JP      Z,NOTCTRL
        LD      HL,CTRLTBL
        ADD    HL,BC
        LD      C,(HL)
        RET

```

NOTCTRL:

```

        BIT    2,(IX+0)      ;Is Caps Lock on
        JP      NZ,UCASE

        BIT    3,(IX+0)      ;Is Shift key down
        JP      NZ,UCASE
        LD      HL,IBM1TBL   ;LowerCase (Default)
        ADD    HL,BC
        LD      C,(HL)
        RET

```

UCASE: LD HL,IBM2TBL ;Upper case

```
ADD HL,BC
LD C,(HL)
RET
```

```
;
```

```
IBM1TBL:          ;The "Normal" table
                  ;00, 01, 02, 03, 04, 05, 06, 07, 08, 09, 0a, 0b, 0c, 0d, 0e, 0f
DEFB 0,'*', 0,'*', '*', '*', '*', '*', 0,'*', '*', '*', '*', 09H, '\', 00H

                  ;10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 1a, 1b, 1c, 1d, 1e, 1f
DEFB 0, 0, 0, 0, 0, 'q', 'l', 0, 0, 0, 'z', 's', 'a', 'w', '2', 0

                  ;20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 2a, 2b, 2c, 2d, 2e, 2f
DEFB 0, 'c', 'x', 'd', 'e', '4', '3', 0, 0, ' ', 'v', 'f', 't', 'r', '5', 0

                  ;30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 3a, 3b, 3c, 3d, 3e, 3f
DEFB 0, 'n', 'b', 'h', 'g', 'y', '6', 0, 0, 0, 'm', 'j', 'u', '7', '8', 0

                  ;40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 4a, 4b, 4c, 4d, 4e, 4f
DEFB 0, ' ', 'k', 'i', 'o', '0', '9', 0, 0, ' ', '/', 'l', ';', 'p', '- ', 0

                  ;50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 5a, 5b, 5c, 5d, 5e, 5f
DEFB 0, 0, 27H, 0, '[' , '=' , 0, 0, 0, 0, 0DH, ']' , 0, '\', 0, 0

                  ;60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 6a, 6b, 6c, 6d, 6e, 6f
DEFB 0, 0, 0, 0, 0, 0, 08H, 0, 0, 11H, 0, 13H, 10H, 0, 0, 0

                  ;70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 7a, 7b, 7c, 7d, 7e, 7f
DEFB 0BH, 7FH, 03H, 15H, 04H, 05H, 1BH, 00H, '*', 02H, 18H, 16H, 0CH, 17H, '*', 0

                  ;80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 8a, 8b, 8c, 8d, 8e, 8f
DEFB 0, 0, 0, '*', 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0
```

```
IBM2TBL:          ;If the shift key or caps lock key is on
                  ;00, 01, 02, 03, 04, 05, 06, 07, 08, 09, 0a, 0b, 0c, 0d, 0e, 0f
DEFB 0,'*', 0,'*', '*', '*', '*', '*', 0,'*', '*', '*', '*', 09H, '~', 00H

                  ;10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 1a, 1b, 1c, 1d, 1e, 1f
DEFB 0, 0, 0, 0, 0, 'Q', '!', 0, 0, 0, 'Z', 'S', 'A', 'W', '@', 0

                  ;20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 2a, 2b, 2c, 2d, 2e, 2f
DEFB 0, 'C', 'X', 'D', 'E', '$', '#', 0, 0, ' ', 'V', 'F', 'T', 'R', '%', 0

                  ;30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 3a, 3b, 3c, 3d, 3e, 3f
DEFB 0, 'N', 'B', 'H', 'G', 'Y', '^', 0, 0, 0, 'M', 'J', 'U', '&', '*', 0

                  ;40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 4a, 4b, 4c, 4d, 4e, 4f
DEFB 0, '<', 'K', 'I', 'O', 29H, '(', 0, 0, '>', '?', 'L', ':', 'P', '_ ', 0

                  ;50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 5a, 5b, 5c, 5d, 5e, 5f
DEFB 0, 0, 22H, 0, '{', '+', 0, 0, 0, 0, 0DH, '}', 0, '|', 0, 0

                  ;60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 6a, 6b, 6c, 6d, 6e, 6f
DEFB 0, 0, 0, 0, 0, 0, 08H, 0, 0, 11H, 0, 13H, 10H, 0, 0, 0

                  ;70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 7a, 7b, 7c, 7d, 7e, 7f
DEFB 0BH, 7FH, 03H, 15H, 04H, 05H, 1BH, 00H, '*', 02H, 18H, 16H, 0CH, 17H, '*', 0

                  ;80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 8a, 8b, 8c, 8d, 8e, 8f
DEFB 0, 0, 0, '*', 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0
```

```
CTRLTBL:         ;If the CTRL key is pressed
                  ;00, 01, 02, 03, 04, 05, 06, 07, 08, 09, 0a, 0b, 0c, 0d, 0e, 0f
DEFB 0,'*', 0,'*', '*', '*', '*', '*', 0,'*', '*', '*', '*', 09H, '~', 00H
```



```

;10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 1a, 1b, 1c, 1d, 1e, 1f
DEFB 0, 0, 0, 0, 0, 0,11H,'!', 0, 0, 0,1AH,13H,01H,17H,'@',0

;20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 2a, 2b, 2c, 2d, 2e, 2f
DEFB 0,03H,18H,04H,05H,'$', '#', 0, 0, ' ',16H,06H,14H,12H,'% ',0

;30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 3a, 3b, 3c, 3d, 3e, 3f
DEFB 0,0EH,02H,08H,07H,19H,'^', 0, 0, 0,0DH,0AH,15H,'&', '*',0

;40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 4a, 4b, 4c, 4d, 4e, 4f
DEFB 0,'<',0BH,09H,0FH,49H,'(', 0, 0,'>', '?',0CH,':',10H,'_',0

;50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 5a, 5b, 5c, 5d, 5e, 5f
DEFB 0, 0,22H, 0,1BH,'+', 0, 0, 0, 0,0DH,1DH, 0,1DH, 0,0

;60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 6a, 6b, 6c, 6d, 6e, 6f
DEFB 0, 0, 0, 0, 0, 0,08H, 0, 0,11H, 0,13H, 0,10H, 0, 0

;70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 7a, 7b, 7c, 7d, 7e, 7f
DEFB 0BH,7FH,03H,15H,04H,05H,1BH,00H,'*',06H,12H,01H,0CH,0EH,'*',0

;80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 8a, 8b, 8c, 8d, 8e, 8f
DEFB 0, 0, 0,'*', 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0

;
;
F1_STRING: DB 'DIR *.*[ALL]',CR,0 ;Show Directory
F2_STRING: DB 'PIP E:=A:*. *[V]',CR,0 ;Copy stuff across to memory disk

MSG0: DEFM 'IBM-> ASCII KEYBOARD ROM Controller John Monahan 15/2/2009'

IF NOT DEBUG
ORG 800H ;Hardware RAM chip will start here
ENDIF

OUTBUFFER: DEFS 257
DEFB '$'
CASEFLAG: DEFB 0H ;Flags for Shift, Numlock etc
DOWN_KEY: DEFB 0H ;Diagnostic program needs to store previous char
;
;
;
IF DEBUG
;
;-----DIAGNOSTIC TESTING CODE -----
;
DIAGNOSTIC:
LD D,A ;Store scan code in D
CALL CRLF
LD A,D
CP 0F0H ;Skip displaying Up key info
JR Z,NormalKey1
CP 77H ;Is it the NUM LOCK key
JR NZ,NotNum
LD HL,SCANCODENUM
CALL PMSG
JP NormalKey1
NotNum: CP 58H ;Is it CAPS Lock key
JP NZ,NotCaps
LD HL,SCANCODECAPS
CALL PMSG
JP NormalKey1
NotCaps:
CP 12H ;Is it a SHIFT key
JP NZ,NotShift1
LD HL,SCANSHIFTKEY

```

```

CALL    PMSG
JP      NormalKey1
NotShift1:
CP      59H          ;Is it the other SHIFT key
JP      NZ,NotShift2
LD      HL,SCANSHIFTKEY
CALL    PMSG
JP      NormalKey1
NotShift2:
CP      14H          ;Is it the CTRL key
JP      NZ,NormalKey
LD      HL,SCANCTRLKEY
CALL    PMSG
JP      NormalKey1
NormalKey:
LD      HL,SCANCODE
CALL    PMSG
LD      A,D
CALL    PACC          ;Show the scan code
LD      HL,SCANCODE1
CALL    PMSG
LD      A,D
CALL    ZBITS        ;Show the scan code in bits
LD      HL,SCANCODE2
CALL    PMSG
NormalKey1:
LD      A,D
RET
;
;
PMSG:   LD      A,(HL)    ;PRINT MESSAGE STRING in [HL] up to 0
OR      A
RET     Z
LD      C,A
CALL    CO
INC     HL
JP      PMSG
;
;Print the accumulator value on CRT in HEX-ASCII
PACC:   PUSH    AF
        PUSH    BC
        PUSH    AF
        RRCA
        RRCA
        RRCA
        RRCA
        CALL    ZCONV
        POP     AF
        CALL    ZCONV
        POP     BC
        POP     AF
        RET
ZCONV:  AND     A,0FH      ;HEX to ASCII
        ADD     90H
        DAA
        ADC     40H
        DAA
        LD      C,A
        CALL    CO
        RET
;
;DISPLAY BIT PATTERN IN [A]
;
ZBITS:  PUSH    AF

```

```

        PUSH    BC
        PUSH    DE
        LD      E,A
        LD      B,8
BQ2:    SLA     E
        LD      A,18H
        ADC     A
        LD      C,A
        CALL    CO
        DJNZ   BQ2
        POP     DE
        POP     BC
        POP     AF
        RET

;
; Display a character on the CRT in my case it's an SD Systems 8024 Video board.
;
CO:     IN      A,(0)          ;console output (arrive with character in C)
        AND     A,04H        ;Note character is in C and A on return.
        JR      Z,CO
        LD      A,C
        OUT     (1),A
        RET

;
CRLF   LD      C,CR
        CALL    CO
        LD      C,LF
        CALL    CO
        RET

;
;
SIGNON: DB      'Diagnostic Program for S-100 PC keyboard Converter Board V1.0',CR,LF
        DB      'Will test that the 74LS164 shift register circuitry is working OK',CR,LF
        DB      'Press any key on the PC keyboard',CR,LF,0
SCANCODE: DB    'Keyboard Scan code = ',0
SCANCODE1:DB    ' (' ,0
SCANCODE2:DB    ') Translated ASCII= ',0
SCANCODE3:DB    CR,LF,0
SCANCODEUP: DB  'Scan code for Up key',CR,LF,0
SCANCODENUM: DB 'Will translate from Number Lock Table',CR,LF,0
SCANCODECAPS: DB 'Scancode for Shift Lock key',CR,LF,0
SCANSHIFTKEY: DB 'Scancode for Shift Key',CR,Lf,0
SCANCTRLKEY: DB 'Scancode for Ctrl key',CR,LF,0
;
        DS      20H
STACK  DB      0H
ENDIF
;
;END

```