

```

;
; Test Program to interact with the CPM3 type BIOS for the S100Computers IDE intreface board
;=====
;
;   V1.7   3/1/2010   ;Removed Z80 Code (so it can be translated to 8086 code later)
;   V2.0   1/23/2011 ;Updated to accomidate two CF cards (Master/Slave) & better menu options
;           ;note I still have more work to do with this but what is here seem OK.
;   V2.1   2/5/2011 ;Menu driven, and added code to copy & restore disk data from another
;           ;"backup" partition on disk
;   V2.2   2/13/2011 ;Added Sec++ & Sec--
;   V2.3   2/15/2011 ;Re-did drive initilization (Pulse CF cards twice on reset line)
;   V2.4   2/16/2011 ;Correct small error for end of drive track check
;   V2.5   3/14/2011 ;Added BOOT CPM option, cleaned up some areas.
;   V2.6   3/15/2011 ;Re-dis reset line pulse. Correct CPM boot to Track 0 sector 1
;   V2.7   4/26/2011 ;Add code for two drive system
;   V2.8   4/27/2011 ;Format sectors with E5's and warn "formatting CURRENT drive".
;   V2.9   3/28/2011 ;Fixed initilization hanging if no drive present in drive #0 or #1 positions

;Ports for 8255 chip. Change these to specify where your 8255 is addressed,
;The first three control which 8255 ports have the control signals,
;upper and lower data bytes. The last one (IDEportCtrl), is for mode setting for the
;8255 to configure its actual I/O ports (A,B & C).
;
;Note most drives these days dont use the old Head,Track, Sector terminology. Instead
;we use "Logical Block Addressing" or LBA. This is what we use below. LBA treats the drive
; as one continous set of sectors, 0,1,2,3,... 3124,...etc. However as seen below we need to
;convert this LBA to heads,tracks and sectors to be compatible with CPM & MSDOS.

;NOTE: If you have only one drive/CF card, be sure it is in drive #0 (LHS of board). The IDE hardware gets
;confused if there is only a drive in slot #1.

; INCLUDE Z-80 MACRO LIBRARY:
MACLIB Z80 ;For the Z80 DJNZ opcode

IDEportA EQU 030H ;Lower 8 bits of IDE interface (8255)
IDEportB EQU 031H ;Upper 8 bits of IDE interface
IDEportC EQU 032H ;Control lines for IDE interface
IDEportCtrl EQU 033H ;8255 configuration port
IDEDrive EQU 034H ;Bit 0 = 0 Drive A, =1 Drive B

READcfg8255 EQU 10010010b ;Set 8255 IDEportC to output, IDEportA/B input
WRITEcfg8255 EQU 10000000b ;Set all three 8255 ports to output mode

;IDE control lines for use with IDEportC.

IDEa0line EQU 01H ;direct from 8255 to IDE interface
IDEa1line EQU 02H ;direct from 8255 to IDE interface

```

```

IDEa2line    EQU    04H    ;direct from 8255 to IDE interface
IDEcs0line   EQU    08H    ;inverter between 8255 and IDE interface
IDEcs1line   EQU    10H    ;inverter between 8255 and IDE interface
IDEwrline    EQU    20H    ;inverter between 8255 and IDE interface
IDERdline    EQU    40H    ;inverter between 8255 and IDE interface
IDERstline   EQU    80H    ;inverter between 8255 and IDE interface

```

```

;Symbolic constants for the IDE Drive registers, which makes the
;code more readable than always specifying the address bits

```

```

REGdata      EQU    IDEcs0line
REGerr       EQU    IDEcs0line + IDEa0line
REGsecct     EQU    IDEcs0line + IDEa1line
REGsector    EQU    IDEcs0line + IDEa1line + IDEa0line
REGcylinderLSB EQU    IDEcs0line + IDEa2line
REGcylinderMSB EQU    IDEcs0line + IDEa2line + IDEa0line
REGshd       EQU    IDEcs0line + IDEa2line + IDEa1line          ; (0EH)
REGcommand   EQU    IDEcs0line + IDEa2line + IDEa1line + IDEa0line ; (0FH)
REGstatus    EQU    IDEcs0line + IDEa2line + IDEa1line + IDEa0line
REGcontrol   EQU    IDEcs1line + IDEa2line + IDEa1line
REGastatus   EQU    IDEcs1line + IDEa2line + IDEa1line + IDEa0line

```

```

;IDE Command Constants. These should never change.

```

```

COMMANDrecal EQU    10H
COMMANDread  EQU    20H
COMMANDwrite EQU    30H
COMMANDdinit EQU    91H
COMMANDid    EQU    0E0H
COMMANDspindown EQU    0E0H
COMMANDspinup EQU    0E1H

```

```

; IDE Status Register:
; bit 7: Busy      1=busy, 0=not busy
; bit 6: Ready 1=ready for command, 0=not ready yet
; bit 5: DF 1=fault occurred insIDE drive
; bit 4: DSC 1=seek complete
; bit 3: DRQ 1=data request ready, 0=not ready to xfer yet
; bit 2: CORR 1=correctable error occurred
; bit 1: IDX vendor specific
; bit 0: ERR 1=error occurred

```

```

;Equates for display on SD Systems Video Board (Used In CPM Debugging mode only)
SCROLL      EQU    01H    ;Set scrool direction UP.
LF           EQU    0AH
CR           EQU    0DH
BS           EQU    08H    ;Back space (required for sector display)
BELL        EQU    07H

```

```

SPACE      EQU    20H
QUIT       EQU    11H    ;Turns off any screen enhancements (flashing, underline etc).
NO$ENHANCEMENT EQU    17H    ;Turns off whatever is on
FAST       EQU    10H    ;High speed scrool
TAB        EQU    09H    ;TAB ACROSS (8 SPACES FOR SD-BOARD)
ESC        EQU    1BH
CLEAR      EQU    1CH    ;SD Systems Video Board, Clear to EOL. (Use 80 spaces if EOL not available
                        ;on other video cards)

SEC$SIZE   EQU    512    ;Assume sector size as 512. (Not tested for other sizes)
MAXSEC     EQU    3DH    ;Sectors per track for CF my Memory drive, Kingston CF 8G. (For CPM format, 0-3CH)
                        ;This translates to LBA format of 1 to 3D sectors, for a total of 61 sectors/track.
                        ;This CF card actully has 3F sectors/track. Will use 3D for my CPM3 system because
                        ;my Seagate drive has 3D sectors/track. Don't want different CPM3.SYS files around
                        ;so this program as is will also work with a Seagate 6531 IDE drive

MAXTRK     EQU    0FFH   ;CPM3 allows up to 8MG so 0-256 "tracks"
BUFFER$ORG EQU    4000H ;<----- Will place all sector data here

CPM$BOOT$COUNT EQU    12    ;Allow up to 12 CPM sectors for CPMLDR
CPMLDR$ADDRESS EQU    BUFFER$ORG ;We cannot load the CPMLDR at 100H in RAM since this is where this program resides

RDCON      EQU    1      ;For CP/M I/O
WRCON      EQU    2
RESET$DISK EQU    0DH    ;Reset all CPM disks
PRINT      EQU    9
CONST      EQU    11    ;CONSOLE STAT
BDOS       EQU    5

FALSE EQU    0
TRUE  EQU    NOT FALSE

CPM        EQU    TRUE   ;TRUE if output via CPM, FALSE if direct to hardware
DEBUG      EQU    TRUE
CPM$TRANSLATE EQU    TRUE ;Translate Trk,Sec,Head to CPM TRACK# & SEC# on display

```

```

;-----
      ORG    100H      ;<--- For CPM

```

begin:

```

      LXI    SP,STACK
      LXI    D,SIGN$ON ;print a welcome message
      CALL  PSTRING
      JMP   OVER$TBL

```

;COMMAND BRANCH TABLE

```

TBL:  DW  DRIVE$A ; "A"  Select Drive A
      DW  DRIVE$B ; "B"  Select Drive B

```

```

DW CPMBOOT ; "C" LOAD CPM (If present)
DW DISPLAY ; "D" Sector contents display:- ON/OFF
DW RAMCLEAR ; "E" Clear RAM buffer
DW FORMAT ; "F" Format current disk
DW RESTORE ; "G" Restore backup
DW BACKUP ; "H" Backup partition
DW NEXT$SECT ; "I" Next Sector
DW PREV$SEC ; "J" Previous sector
DW ERROR ; "K"
DW SET$LBA ; "L" Set LBA value (Set Track,sector)
DW ERROR ; "M"
DW POWER$DOWN; "N" Power down hard disk command
DW ERROR ; "O"
DW ERROR ; "P"
DW ERROR ; "Q"
DW READ$SEC ; "R" Read sector to data buffer
DW SEQ$RD ; "S" Sequential sec read and display contents
DW ERROR ; "T"
DW POWER$UP ; "U" Power up hard disk command
DW N$RD$SEC ; "V" Read N sectors
DW WRITE$SEC ; "W" Write data buffer to current sector
DW N$WR$SEC ; "X" Write N sectors
DW COPY$AB ; "Y" Copy Drive A to Drive B
DW VERIFY$AB ; "Z" Verify Drive A:= Drive B:

```

OVER\$TBL:

```

MVI A,0
STA @CURRENT$DRIVE
OUT IDEdrive ;Select first drive

CALL CLEAR$ID$BUFFER ;Clear ID Buffer

CALL IDEinit ;initialize the board and first drive. If there is no drive abort
JZ DRIVE$1OK ;Ret with NZ flag set if error (probably no drive)

LXI D,INIT$1$ERROR
CALL PSTRING
JMP ABORT

```

DRIVE\$1OK: ;Select second drive

```

MVI A,1
STA @CURRENT$DRIVE
OUT IDEdrive

CALL CLEAR$ID$BUFFER ;Clear ID Buffer

CALL IDEinit ;Initialize the second drive. If there is no drive abort
JZ INIT$OK ;Ret with NZ flag set if error (probably no drive)

LXI D,INIT$2$ERROR ;Warn about second drive initialization failure, but continue

```

```

CALL PSTRING
JMP INIT$OK

```

```
ABORT:
```

```

IF CPM
MVI C,RESET$DISK ;Reset All disks in CPM
CALL BDOS
JMP 0H ;Jump to CP/M cold start address
ELSE
JMP 0F000H ;Else jump to monitor
ENDIF

```

```
INIT$OK:
```

```

MVI A,0
STA @CURRENT$DRIVE
OUT IDEDrive ;Select drive A at start

CALL driveid ;Get the drive ID info. If there is no drive, abort
JZ INIT$OK1

LXI D,ID$ERROR
CALL PSTRING
JMP ABORT

```

```
INIT$OK1: ;Print the drive #0 model number etc.
```

```

LXI H,IDbuffer + 12
MOV A,M ;If there are zero sectors (High byte) then something wrong
ORA A
JNZ INIT$OK2
INX H
MOV A,M ;(Low Byte)
ORA A
JNZ INIT$OK2 ;Looks like we have a valid IDE drive

LXI D,BAD$DRIVE
CALL PSTRING
JMP ABORT ;No drive #0 so abort (the board gets confused if there is just a drive #1)

```

```
INIT$OK2:
```

```

LXI D,DRIVE$INFO
CALL PSTRING
LXI D, msgmdl
CALL PSTRING
LXI H,IDbuffer + 54
MVI B,10 ;character count in words
CALL printname ;Print [HL], [B] X 2 characters
CALL ZCRLF
; print the drive's serial number
LXI D, msgsn

```

```

CALL PSTRING
LXI H, IDbuffer + 20
MVI B, 5 ;Character count in words
CALL printname
CALL ZCRLF
;Print the drive's firmware revision string

LXI D, msgrev
CALL PSTRING
LXI H, IDbuffer + 46
MVI B, 2
CALL printname ;Character count in words
CALL ZCRLF
;Print the drive's cylinder, head, and sector specs

LXI D, msgscy
CALL PSTRING
LXI H, IDbuffer + 2
CALL printparm
LXI D, msgghd
CALL PSTRING
LXI H, IDbuffer + 6
CALL printparm
LXI D, msgsc
CALL PSTRING
LXI H, IDbuffer + 12
CALL printparm
CALL ZCRLF
;Default position will be first block

LXI H, 0
SHLD @SEC ;Default to Track 0, Sec 0
SHLD @TRK
LXI H, buffer ;Set DMA address to buffer
SHLD @DMA

CALL IDEinit ;For some reason this need to be here after getting the drive ID.
;Otherwise sector #'s are off by one!

;----- MAIN LOOP -----
MAINLOOP: ;print main menu
LDA @CURRENT$DRIVE ;First show current drive
ORA A
JNZ DRIVE$B$MENU
LXI D, DRIVE$A$MSG
CALL PSTRING
JMP Display0
DRIVE$B$MENU:
LXI D, DRIVE$B$MSG
CALL PSTRING
Display0:
LDA @DisplayFlag ;Do we have detail sector data display flag on or off

```

```

ORA    A            ;NZ = on (Initially 0FFH so detailed sector display on)
JNZ    Display1
LXI    D,CMD$STRING1    ;List command options (Turn display option to on)
JP     Display2
Display1:
LXI    D,CMD$STRING2    ;List command options (Turn display option to off)
Display2:
CALL   PSTRING

CALL   wrlba            ;Update LBA on drive
CALL   DISPLAYposition ;Display current Track,sector,head#

LXI    D,Prompt        ;'>'
CALL   PSTRING

CALL   GETCMD          ;Simple UC character Input (Note, no fancy checking)
CPI    ESC              ;Abort if ESC
JZ     ABORT
CALL   upper
CALL   ZCRLF

SBI    '@'              ;Adjust to 0,1AH

ADD    A                ;X2
LXI    H,TBL            ;Get menu selection
ADD    L
MOV    L,A
MOV    A,M
INX   HL
MOV    H,M
MOV    L,A              ;Jump to table pointer
PCHL                      ;JMP (HL)

;----- MENU OPTIONS -----

READ$SEC:
LXI    H,buffer        ;Point to buffer
SHLD   @DMA

CALL   READSECTOR

JZ     main1b          ;Z means the sector read was OK
CALL   ZCRLF
JMP    MAINLOOP
main1b:
LXI    D, msgrd        ;Sector read OK
CALL   PSTRING

LDA    @DisplayFlag    ;Do we have detail sector data display flag on or off

```

```

ORA    A            ;NZ = on
JZ     MAINLOOP
LXI   H,buffer    ;Point to buffer. Show sector data flag is on
SHLD  @DMA
CALL  HEXDUMP      ;Show sector data
JMP   MAINLOOP

WRITE$SEC:        ;Write data in RAM buffer to sector @ LBA
LXI   D,msgsure   ;Are you sure?
CALL  PSTRING
CALL  ZCI
CALL  upper
CPI   'Y'
JNZ   main2c
CALL  ZCRLF

LXI   H,buffer    ;Point to buffer
SHLD  @DMA

CALL  WRITESECTOR

JZ     main2b      ;Z means the sector write was OK
CALL  ZCRLF
JMP   MAINLOOP
main2b: LXI   D, msgwr ;Sector written OK
CALL  PSTRING
main2c: JMP   MAINLOOP

SET$LBA:         ;Set the logical block address
LXI   D,GET$LBA
CALL  PSTRING
CALL  ghex32lba   ;Get new CPM style Track & Sector number and put them in RAM at @SEC & @TRK
jc    main3b     ;Ret C set if abort/error
CALL  wrlba      ;Update LBA on drive
main3b: CALL  ZCRLF
jmp   MAINLOOP

NEXT$SECT:
LDA   @SEC
INR   A
CPI   MAXSEC-1
JNC   RANGE$ERROR
STA   @SEC
CALL  wrlba      ;Update LBA on drive
CALL  ZCRLF
jmp   MAINLOOP
RANGE$ERROR:
LXI   D,RANGE$MSG
CALL  PSTRING

```



```

        jmp     MAINLOOP

PREV$SEC:
        LDA     @SEC
        ORA     A
        JZ      RANGE$ERROR
        DCR     A
        STA     @SEC
        CALL    wrlba      ;Update LBA on drive
        CALL    ZCRLF
        jmp     MAINLOOP

POWER$UP:
        CALL    spinup    ;Set the drive to spin up (for hard disk connections)
        jmp     MAINLOOP

POWER$DOWN:
        CALL    spindown  ;Set the drive to spin down (for hard disk connections)
        jmp     MAINLOOP

DISPLAY:
        LDA     @DisplayFlag ;Do we have detail sector data display flag on or off
        CMA     ;flip it
        STA     @DisplayFlag
        jmp     MAINLOOP    ;Update display and back to next menu command

SEQ$RD:
        CALL    SequentialReads ;Do sequential reads
        jmp     MAINLOOP

DRIVE$A:
        MVI     A,0        ;Select Drive A:
        STA     @CURRENT$DRIVE
        OUT     IDEDrive
        LXI     D,SETA$MSG
        CALL    PSTRING
        jmp     MAINLOOP

DRIVE$B:
        MVI     A,1        ;Select Drive B:
        STA     @CURRENT$DRIVE
        OUT     IDEDrive
        LXI     D,SETB$MSG
        CALL    PSTRING
        jmp     MAINLOOP

RAMCLEAR:
        LXI     H,buffer   ;Fill RAM buffer with 0's
        LXI     D,512      ;Point to buffer

```

```

        MVI    A,0          ;Fill area with 0's
CLEAR1:  MOV    M,A
        INX   H
        DCX   D
        MOV   A,E
        ANA   D
        JNZ   CLEAR1
        LXI   D,FILL$MSG
        CALL  PSTRING
        jmp   MAINLOOP

CPMBOOT:                ;Boot CPM from IDE system tracks -- if present
        MVI   A,0          ;Load from track 0,sec 1, head 0 (Always)
        STA   @SEC         ;Remember sectors are numbered +1
        XRA   A
        STA   @TRK+1
        STA   @TRK

        MVI   A,CPM$BOOT$COUNT ;Count of CPMLDR sectors (12)
        STA   @SECTOR$COUNT
        LXI   H,CPMLDR$ADDRESS ;DMA address where the CPMLDR resides in RAM (100H)
        SHLD  @DMA

NextRCPM:
        CALL  wrlba        ;Update LBA on drive
        CALL  DISPLAYposition ;Display current Track,sector,head#
        CALL  ZCRLF

        LHLD  @DMA
        CALL  READSECTOR   ;read a sector
        SHLD  @DMA

        LDA   @SECTOR$COUNT
        DCR   A
        STA   @SECTOR$COUNT
        JZ    LOAD$DONE

        LHLD  @SEC
        INX   H
        SHLD  @SEC         ;Note we assume we always will stay on track 0 in this special case
        JMP   NextRCPM

LOAD$DONE:
        MVI   E,REGstatus  ;Check the R/W status when done
        CALL  IDerd8D
        BIT   0,D
        JNZ   CPMloadErr   ;Z if no errors
        LXI   H,CPMLDR$ADDRESS
        MOV   A,M

```

```

CPI    31H          ;EXPECT TO HAVE 31H @80H IE. LD SP,80H
JNZ    CPMloadErr1 ;Z if no errors

LXI    D,MOVE$REQUEST      ;Ask if we can move data to 100H overwriting this program
CALL   PSTRING
CALL   ZCI
CALL   upper
CPI    'Y'
JNZ    MAINLOOP

LXI    H,CPM$MOVE$CODE     ;Need to put memory move code out of the way.
LXI    D,0H
LXI    B,(CPM$MOVE$CODE$END-CPM$MOVE$CODE)
LDIR
JMP    0H                 ;Now jump here where the code will move the CPMLDR (@3000H) to 100H

CPMloadErr1:
LXI    D,CPM$ERROR1       ;Drive data error
CALL   PSTRING
JMP    MAINLOOP

CPMloadErr:
LXI    D,CPM$ERROR        ;Drive Read Error
CALL   PSTRING
JMP    MAINLOOP

N$RD$SEC:
                ;Read N sectors >>>> NOTE no check is made to not overwrite
LXI    D,ReadN$MSG       ;CPM etc. in high RAM
CALL   PSTRING
CALL   GETHEX
JC     MAINLOOP         ;Abort if ESC (C flag set)

STA    @SECTOR$COUNT    ;store sector count
LXI    H,buffer          ;Point to buffer
SHLD   @DMA

NextRSec:
LXI    D,ReadingN$MSG
CALL   PSTRING
CALL   wrlba             ;Update LBA on drive
CALL   DISPLAYposition   ;Display current Track,sector,head#

LHLD   @DMA
CALL   READSECTOR
SHLD   @DMA

LDA    @SECTOR$COUNT
DCR    A
STA    @SECTOR$COUNT

```

```

JZ     MAINLOOP

LHLD  @SEC
INX   H
SHLD  @SEC
MOV   A,L           ;0 to 62 CPM Sectors
CPI   MAXSEC-1
JNZ   NextRSec

LXI   H,0           ;Back to CPM sector 0
SHLD  @SEC
LHLD  @TRK         ;Bump to next track
INX   H
SHLD  @TRK
MOV   A,L           ;0-FFH tracks (only)
JNZ   NextRSec

LXI   D,AtEnd      ;Tell us we are at end of disk
CALL  PSTRING
JMP   MAINLOOP

N$WR$SEC:           ;Write N sectors
LXI   D,msgsure    ;Are you sure?
CALL  PSTRING
CALL  ZCI
CALL  upper
CPI   'Y'
JNZ   main2c

LXI   D,WriteN$MSG
CALL  PSTRING
CALL  GETHEX
JC    MAINLOOP     ;Abort if ESC (C flag set)

STA   @SECTOR$COUNT ;store sector count
LXI   H,buffer     ;Point to buffer
SHLD  @DMA

NextWSec:
LXI   D,WritingN$MSG
CALL  PSTRING
CALL  wrlba        ;Update LBA on drive
CALL  DISPLAYposition ;Display current Track,sector,head#

LHLD  @DMA
CALL  WRITESECTOR  ;Actully, Sector/track values are already updated
SHLD  @DMA        ;above in wrlba, but WRITESECTOR is used in multiple places.
                        ;A repeat does no harm -- speed is not an issue here
LDA   @SECTOR$COUNT

```

```

DCR    A
STA    @SECTOR$COUNT
JZ     MAINLOOP

LHLD   @SEC
INX    H
SHLD   @SEC
MOV    A,L           ;0 to 62 CPM Sectors
CPI    MAXSEC-1
JNZ    NextWSec

LXI    H,0           ;Back to CPM sector 0
SHLD   @SEC
LHLD   @TRK         ;Bump to next track
INX    H
SHLD   @TRK
MOV    A,L           ;0-FFH tracks (only)
ORA    A
JNZ    NextWSec

LXI    D,AtEnd       ;Tell us we are at end of disk
CALL   PSTRING
JMP    MAINLOOP

```

```

FORMAT:                                     ;Format (Fill sectors with E5's for CPM directory empty)

```

```

LXI    D,FORMAT$MSG
CALL   PSTRING
LXI    D,msgsure    ;Are you sure?
CALL   PSTRING
CALL   ZCI
CALL   upper
CPI    'Y'
JNZ    MAINLOOP
LXI    H,buffer     ;Fill buffer with 0E5's (512 of them)
MVI    B,0
Fill0: MVI    A,0E5H ;<-- Sector fill character (0E5's for CPM)
MOV    M,A
INX    H
MOV    M,A
INX    H
DJNZ   Fill0
CALL   ZCRLF

```

```

NEXT$FORMAT:

```

```

LXI    H,buffer
SHLD   @DMA
CALL   WRITESECTOR ;Will return error if there was one
JZ     main9b      ;Z means the sector write was OK
CALL   ZCRLF

```

```

        JMP     MAINLOOP
main9b:  CALL    ZEOL           ;Clear line cursor is on
        CALL    DISPLAYposition ;Display actual current Track,sector,head#
        CALL    ZCSTS         ;Any keyboard character will stop display
        CPI     01H           ;CPM Says something there
        JNZ     WRNEXTSECl
        CALL    ZCI           ;Flush character
        LXI     D,CONTINUE$MSG
        CALL    PSTRING
        CALL    ZCI
        CPI     ESC
        JZ      MAINLOOP
        CALL    ZCRLF
WRNEXTSECl:
        LHLD   @SEC
        INX    H
        SHLD   @SEC          ;0 to MAXSEC CPM Sectors
        MOV    A,L
        CPI    MAXSEC
        JNZ    NEXT$FORMAT

        LXI    H,0           ;Back to CPM sector 0
        SHLD   @SEC
        LHLD   @TRK         ;Bump to next track
        INX    H
        SHLD   @TRK
        MOV    A,L           ;0-FFH tracks (only)
        CPI    MAXTRK
        JNZ    NEXT$FORMAT

        LXI    D,FormatDone ;Tell us we are all done.
        CALL    PSTRING
        JMP     MAINLOOP

BACKUP:                                     ;Backup the CPM partition to another area on the SAME CF-card/disk
        LXI    D,CopyMsg
        CALL    PSTRING
        CALL    ZCI
        CALL    upper
        CPI    'Y'
        JNZ    MAINLOOP

        LXI    H,0           ;Start with CPM sector 0
        SHLD   @SEC
        SHLD   @SEC1
        SHLD   @SEC2        ;and on second partition
        SHLD   @TRK         ;and track 0
        SHLD   @TRK1
        LXI    H,MAXTRK+0200H+1 ;<<<<< VIP This assumes CPM3 is on tracks 0-MAXTRK. (0-FFH) >>>>

```

```

SHLD  @TRK2          ;It skips an area to be safe. However if you have other stuff on this
                        ;CF card at that location (eg DOS partition) change this value

CALL  ZCRLF
CALL  ZCRLF

```

NextCopy1:

```

CALL  ZEOL           ;Clear line cursor is on
LXI   D,RBackup$MSG ;for each track update display
CALL  PSTRING
LDA   @TRK1+1        ;High TRK byte
CALL  phex
LDA   @TRK1          ;Low TRK byte
CALL  phex
LXI   D,WBackup$MSG
CALL  PSTRING
LDA   @TRK2+1        ;High TRK byte
CALL  phex
LDA   @TRK2          ;Low TRK byte
CALL  phex
LXI   D,H$Msg
CALL  PSTRING

```

NextCopy:

```

LDA   @SEC1
STA   @SEC
LHLD  @TRK1
SHLD  @TRK
CALL  wrlba          ;Update LBA on "1st" drive

LXI   H,buffer      ;Point to buffer
SHLD  @DMA
CALL  READSECTOR    ;Get sector data to buffer

LDA   @SEC2
STA   @SEC
LHLD  @TRK2
SHLD  @TRK
CALL  wrlba          ;Update LBA on "2nd" drive

LXI   H,buffer      ;Point to buffer
SHLD  @DMA
CALL  WRITESECTOR   ;Write buffer data to sector

CALL  ZCSTS          ;Any keyboard character will stop display
CPI   01H           ;CPM Says something there
JNZ   BKNEXTSEC1
CALL  ZCI            ;Flush character
LXI   D,CONTINUE$MSG
CALL  PSTRING
CALL  ZCI

```

```

CPI    ESC
JZ     MAINLOOP

BKNEXTSEC1:
LHLD  @SEC
INX   H
SHLD  @SEC1
SHLD  @SEC2
MOV   A,L           ;0 to 62 CPM Sectors
CPI   MAXSEC-1
JNZ   NextCopy

LXI   H,0           ;Back to CPM sector 0
SHLD  @SEC1
SHLD  @SEC2

LHLD  @TRK1        ;Bump to next track
INX   H
SHLD  @TRK1

LHLD  @TRK2        ;Bump to next track
INX   H
SHLD  @TRK2

LHLD  @TRK1        ;Check if we are done
MOV   A,L           ;0-FFH tracks (only)
CPI   MAXTRK
JNZ   NextCopy1

LXI   D,BackupDone ;Tell us we are all done.
CALL  PSTRING
JMP   MAINLOOP

RESTORE:
                                ;Restore disk from backup partition
LXI   D,RestoreMsg
CALL  PSTRING
CALL  ZCI
CALL  upper
CPI   'Y'
JNZ   MAINLOOP

LXI   H,0           ;Start with CPM sector 0
SHLD  @SEC
SHLD  @SEC1
SHLD  @SEC2        ;and on second partition
SHLD  @TRK         ;and track 0
SHLD  @TRK1
LXI   H,MAXTRK+0200H+1 ;<<<<< VIP This assumes CPM3 is on tracks 0-MAXTRK. (0-FFH) >>>>

```



```

SHLD  @TRK2          ;It skips an area to be safe. However if you have other stuff on this
                        ;CF card at that location (eg DOS partition) change this value

CALL  ZCRLF
CALL  ZCRLF

```

NextRestore1:

```

CALL  ZEOL           ;Clear line cursor is on
LXI   D,RBackup$MSG ;for each track update display
CALL  PSTRING
LDA   @TRK2+1       ;High TRK byte
CALL  phex
LDA   @TRK2         ;Low TRK byte
CALL  phex
LXI   D,WBackup$MSG
CALL  PSTRING
LDA   @TRK1+1       ;High TRK byte
CALL  phex
LDA   @TRK1         ;Low TRK byte
CALL  phex
LXI   D,H$Msg
CALL  PSTRING

```

NextRestore:

```

LDA   @SEC2         ;Point to backup partition
STA   @SEC
LHLD  @TRK2
SHLD  @TRK
CALL  wrlba         ;Update LBA on "1st" drive

LXI   H,buffer     ;Point to buffer
SHLD  @DMA
CALL  READSECTOR   ;Get sector data to buffer

LDA   @SEC1
STA   @SEC
LHLD  @TRK1
SHLD  @TRK
CALL  wrlba         ;Update LBA on "2nd" drive

LXI   H,buffer     ;Point to buffer
SHLD  @DMA
CALL  WRITESECTOR  ;Write buffer data to sector

CALL  ZCSTS        ;Any keyboard character will stop display
CPI   01H          ;CPM Says something there
JNZ   RESNEXTSEC1
CALL  ZCI          ;Flush character
LXI   D,CONTINUE$MSG
CALL  PSTRING
CALL  ZCI

```

```

CPI    ESC
JZ     MAINLOOP

RESNEXTSEC1:
LHLD  @SEC
INX   H
SHLD  @SEC1
SHLD  @SEC2
MOV   A,L           ;0 to 62 CPM Sectors
CPI   MAXSEC-1
JNZ   NextRestore

LXI   H,0           ;Back to CPM sector 0
SHLD  @SEC1
SHLD  @SEC2

LHLD  @TRK1         ;Bump to next track
INX   H
SHLD  @TRK1

LHLD  @TRK2         ;Bump to next track
INX   H
SHLD  @TRK2

LHLD  @TRK2         ;Check if we are done
MOV   A,L           ;0-FFH tracks (only)
CPI   MAXTRK
JNZ   NextRestore1

LXI   D,RestoreDone ;Tell us we are all done.
CALL  PSTRING
JMP   MAINLOOP

ERROR: LXI   D, msgErr ;CMD error msg
CALL  PSTRING
JMP   MAINLOOP

COPY$AB:           ;Copy Drive A: to Drive B:
LXI   D,DiskCopyMsg
CALL  PSTRING
CALL  ZCI
CALL  upper
CPI   'Y'
JNZ   MAINLOOP

LXI   H,0           ;Start with CPM sector 0
SHLD  @SEC
SHLD  @TRK         ;and track 0

```

```
CALL ZCRLF
CALL ZCRLF
```

```
NextDCopy1:
```

```
CALL ZEOL ;Clear line cursor is on
LXI D, CopyTrk$MSG ;for each track update display
CALL PSTRING
LDA @TRK+1 ;High TRK byte
CALL phex
LDA @TRK ;Low TRK byte
CALL phex
LXI D, H$Msg
CALL PSTRING
```

```
NextDCopy:
```

```
MVI A, 0 ;Login drive A:
STA @CURRENT$DRIVE
OUT IDEDrive

CALL wrlba ;Update LBA on "A:" drive

LXI H, buffer ;Point to buffer
SHLD @DMA
CALL READSECTOR ;Get sector data from A: drive to buffer

MVI A, 1 ;Login drive B:
STA @CURRENT$DRIVE
OUT IDEDrive

CALL wrlba ;Update LBA on "B:" drive

LXI H, buffer ;Point to buffer
SHLD @DMA
CALL WRITESECTOR ;Write buffer data to sector on B: drive

CALL ZCSTS ;Any keyboard character will stop display
CPI 01H ;CPM Says something there
JNZ BK$D$NEXTSEC1
CALL ZCI ;Flush character
LXI D, CONTINUE$MSG
CALL PSTRING
CALL ZCI
CPI ESC
JNZ BK$D$NEXTSEC1
MVI A, 0 ;Login drive A:
STA @CURRENT$DRIVE
OUT IDEDrive
JMP MAINLOOP
```

```

BK$D$NEXTSEC1:
    LHLD  @SEC
    INX   H
    SHLD  @SEC
    MOV   A,L           ;0 to 62 CPM Sectors
    CPI   MAXSEC-1
    JNZ   NextDCopy

    LXI   H,0           ;Back to CPM sector 0
    SHLD  @SEC

    LHLD  @TRK         ;Bump to next track
    INX   H
    SHLD  @TRK

                                ;Check if we are done
    MOV   A,L           ;0-FFH tracks (only)
    CPI   MAXTRK
    JNZ   NextDCopy1

    LXI   D,CopyDone   ;Tell us we are all done.
    CALL  PSTRING
    MVI   A,0           ;Login drive A:
    STA   @CURRENT$DRIVE
    OUT   IDEDrive
    JMP   MAINLOOP

VERIFY$AB:
                                ;Verify Drive A: = B:
    LXI   D,DiskVerifyMsg
    CALL  PSTRING

    LXI   H,0           ;Start with CPM sector 0
    SHLD  @SEC
    SHLD  @TRK         ;and track 0

    CALL  ZCRLF
    CALL  ZCRLF

NextVCopy1:
    CALL  ZEOL         ;Clear line cursor is on
    LXI   D,VerifyTrk$MSG ;for each track update display
    CALL  PSTRING
    LDA   @TRK+1       ;High TRK byte
    CALL  phex
    LDA   @TRK         ;Low TRK byte
    CALL  phex
    LXI   D,H$Msg
    CALL  PSTRING

```

```

NextVCopy:
    MVI    A,0          ;Login drive A:
    STA    @CURRENT$DRIVE
    OUT    IDEDrive

    CALL   wrlba        ;Update LBA on "A:" drive

    LXI    H,buffer    ;Point to buffer
    SHLD   @DMA
    CALL   READSECTOR  ;Get sector data from buffer A: drive

    MVI    A,1          ;Login drive B:
    STA    @CURRENT$DRIVE
    OUT    IDEDrive

    CALL   wrlba        ;Update LBA on "B:" drive

    LXI    H,buffer2   ;Point to buffer2
    SHLD   @DMA
    CALL   READSECTOR  ;Read buffer data from sector of B drive

    LXI    BC,512      ;Now check both buffers are identical
    LXI    H,buffer
    LXI    D,buffer2
NEXTV: LDAX  D
    CMP    M           ;Is [DE] = [HL]
    JNZ    COMPARE$ERROR
    INX    H
    INX    D
    DCX    B
    MOV    A,C
    ANA    B
    JZ     VERIFY$OK
    JMP    NEXTV

COMPARE$ERROR:
    LXI    D,VERIFY$ERR ;Indicate an error
    CALL   PSTRING
    LDA    @TRK+1       ;High TRK byte
    CALL   phex
    LDA    @TRK         ;Low TRK byte
    CALL   phex
    LXI    D,SEC$Msg
    CALL   PSTRING
    LDA    @SEC         ;Sector byte
    CALL   phex
    LXI    D,H$Msg
    CALL   PSTRING
    JMP    VER$OK1

```

```

VERIFY$OK:
    CALL ZCSTS          ;Any keyboard character will stop display
    CPI 01H            ;CPM Says something there
    JNZ BK$V$NEXTSEC1
    CALL ZCI           ;Flush character
VER$OK1:
    LXI D,CONTINUE$MSG
    CALL PSTRING
    CALL ZCI
    CPI ESC
    JNZ BK$V$NEXTSEC1
    MVI A,0            ;Login drive A:
    STA @CURRENT$DRIVE
    OUT IDEDrive
    JMP MAINLOOP

BK$V$NEXTSEC1:
    LHLD @SEC
    INX H
    SHLD @SEC
    MOV A,L            ;0 to 62 CPM Sectors
    CPI MAXSEC-1
    JNZ NextVCopy

    LXI H,0            ;Back to CPM sector 0
    SHLD @SEC

    LHLD @TRK          ;Bump to next track
    INX H
    SHLD @TRK

    MOV A,L            ;Check if we are done
    CPI MAXTRK         ;0-FFH tracks (only)
    JNZ NextVCopy1

    LXI D,VerifyDone  ;Tell us we are all done.
    CALL PSTRING
    MVI A,0            ;Login drive A:
    STA @CURRENT$DRIVE
    OUT IDEDrive
    JMP MAINLOOP

;----- Support Routines -----

driveid:CALL IDEwaitnotbusy ;Do the IDeIdentify drive command, and return with the buffer
                                ;filled with info about the drive
    RC                          ;If Busy return NZ
    MVI D,COMMANDid
    MVI E,REGcommand

```

```

CALL IDEwr8D          ;issue the command

CALL IDEwaitdrq      ;Wait for Busy=0, DRQ=1
JC SHOWerrors

MVI B,0              ;256 words
LXI H,IDbuffer       ;Store data here
CALL MoreRD16        ;Get 256 words of data from REGdata port to [HL]
RET

```

spinup:

```

MVI D,COMMANDspinup
spup2: MVI E,REGcommand
CALL IDEwr8D
CALL IDEwaitnotbusy
JC SHOWerrors
ORA A                ;Clear carry
ret

```

spindown: ;Tell the drive to spin down

```

CALL IDEwaitnotbusy
JC SHOWerrors
MVI D,COMMANDspindown
jmp spup2

```

SequentialReads:

```

CALL IDEwaitnotbusy ;sequentially read sectors one at a time from current position
JC SHOWerrors
CALL ZCRLF

```

NEXTSEC:

```

LXI H,buffer        ;Point to buffer
SHLD @DMA

CALL READSECTOR     ;If there are errors they will show up in READSECTOR
JZ SEQOK
LXI D,CONTINUE$MSG
CALL PSTRING
CALL ZCI
CPI ESC             ;Abort if ESC
RZ

```

SEQOK: CALL ZEOL ;Clear line cursor is on
CALL DISPLAYposition ;Display current Track,sector,head#

```

LXI H,buffer        ;Point to buffer
SHLD @DMA

```

```

LDA    @DisplayFlag ;Do we have detail sector data display flag on or off
ORA    A             ;NZ = on
CNZ    HEXDUMP
CALL   ZCRLF
CALL   ZCRLF
CALL   ZCRLF

CALL   ZCSTS        ;Any keyboard character will stop display
CPI    01H          ;CPM Says something there
JNZ    NEXTSEC1
CALL   ZCI           ;Flush character
LXI    D,CONTINUE$MSG
CALL   PSTRING
CALL   ZCI
CPI    ESC
RZ
CALL   ZCRLF
NEXTSEC1:
LHLD   @SEC
INX    H
SHLD   @SEC
MOV    A,L          ;0 to 62 CPM Sectors
CPI    MAXSEC-1
JNZ    NEXTSEC

LXI    H,0          ;Back to CPM sector 0
SHLD   @SEC
LHLD   @TRK         ;Bump to next track
INX    H
SHLD   @TRK
JMP    NEXTSEC      ;Note will go to last sec on disk unless stopped

DISPLAYposition:    ;Display current track,sector & head position
LXI    D,msgCPMTRK ;Display in LBA format
CALL   PSTRING      ;---- CPM FORMAT ----
LDA    @TRK+1       ;High TRK byte
CALL   phex
LDA    @TRK         ;Low TRK byte
CALL   phex

LXI    D,msgCPMSEC
CALL   PSTRING      ;SEC = (16 bits)
LDA    @SEC+1       ;High Sec
CALL   phex
LDA    @SEC         ;Low sec
CALL   phex
;---- LBA FORMAT ----
LXI    D, msgLBA

```



```

CALL PSTRING          ;(LBA = 00 (<-- Old "Heads" = 0 for these drives).
LDA @DRIVE$TRK+1 ;High "cylinder" byte
CALL phex
LDA @DRIVE$TRK      ;Low "cylinder" byte
CALL phex
LDA @DRIVE$SEC
CALL phex
LXI D, MSGBracket   ;)$
CALL PSTRING
RET

```

```

printname:           ;Send text up to [B]
INX H                ;Text is low byte high byte format
MOV C,M
CALL ZCO
DCX H
MOV C,M
CALL ZCO
INX H
INX H
DCR B
JNZ printname
ret

```

```

ZCRLF:
PUSH PSW
MVI C,CR
CALL ZCO
MVI C,LF
CALL ZCO
POP PSW
RET

```

```

ZEOL:                ;CR and clear current line
MVI C,CR
CALL ZCO
MVI C,CLEAR          ;Note hardware dependent, (Use 80 spaces if necessary)
CALL ZCO
RET

```

```

ZCSTS:
IF CPM
PUSH B
PUSH D
PUSH H
MVI C,CONST
CALL BDOS            ;Returns with 1 in [A] if character at keyboard
POP H
POP D

```

```

        POP    B
        CPI    1
        RET
ELSE
        IN     0H           ;Get Character in [A]
        ANI    02H
        RZ
        MVI    A,01H
        ORA    A
        RET
ENDIF

ZCO:           ;Write character that is in [C]
        IF    CPM
            PUSH    PSW
            PUSH    B
            PUSH    D
            PUSH    H
            MOV     E,C
            MVI    C,WRCON
            CALL   BDOS
            POP     H
            POP     D
            POP     B
            POP     PSW
            RET
        ELSE
            PUSH    PSW
ZCO1:    IN     0H           ;Show Character
            ANI    04H
            JZ     ZCO1
            MOV     A,C
            OUT    1H
            POP     PSW
            RET
        ENDIF

ZCI:           ;Return keyboard character in [A]
        IF    CPM
            PUSH    B
            PUSH    D
            PUSH    H
            MVI    C,RDCON
            CALL   BDOS
            POP     H
            POP     D
            POP     B
            RET
        ELSE

```

```
ZCI1: IN    0H          ;Get Character in [A]
      ANI   02H
      JZ    ZCI1
      IN    01H
      RET
ENDIF
```

```
;      Print a string in [DE] up to '$'
```

```
PSTRING:
IF CPM
      MVI   C,PRINT
      JMP   BDOS          ;PRINT MESSAGE,
ELSE
      PUSH  B
      PUSH  D
      PUSH  H
      XCHG
PSTRX: MOV   A,M
      CPI   '$'
      JZ    DONEP
      MOV   C,A
      CALL  ZCO
      INX   H
      JMP   PSTRX
DONEP: POP   H
      POP   D
      POP   B
      RET
ENDIF
```

```
SHOWerrors:
IF NOT DEBUG
      ORA   A          ;Set NZ flag
      STC   ;Set Carry Flag
      RET
ELSE
      CALL  ZCRLF
      MVI   E,REGstatus ;Get status in status register
      CALL  IDERd8D
      MOV   A,D
      ANI   1H
      JNZ   MoreError  ;Go to REGerr register for more info
                        ;All OK if 01000000
      PUSH  PSW        ;save for return below
      ANI   80H
      JZ    NOT7
      LXI   D,DRIVE$BUSY ;Drive Busy (bit 7) stuck high.  Status =
```

```

        CALL PSTRING
        JMP DONEERR
NOT7:   ANI 40H
        JNZ NOT6
        LXI D,DRIVE$NOT$READY ;Drive Not Ready (bit 6) stuck low. Status =
        CALL PSTRING
        JMP DONEERR
NOT6:   ANI 20H
        JNZ NOT5
        LXI D,DRIVE$WR$FAULT ;Drive write fault. Status =
        CALL PSTRING
        JMP DONEERR
NOT5    LXI D,UNKNOWN$ERROR
        CALL PSTRING
        JMP DONEERR

MoreError:
        ;Get here if bit 0 of the status register indicted a problem
        MVI E,REGerr ;Get error code in REGerr
        CALL IDerd8D
        MOV A,D
        PUSH PSW

        ANI 10H
        JZ NOTE4
        LXI D,SEC$NOT$FOUND
        CALL PSTRING
        JMP DONEERR

NOTE4:  ANI 80H
        JZ NOTE7
        LXI D,BAD$BLOCK
        CALL PSTRING
        JMP DONEERR
NOTE7:  ANI 40H
        JZ NOTE6
        LXI D,UNRECOVER$ERR
        CALL PSTRING
        JMP DONEERR
NOTE6:  ANI 4H
        JZ NOTE2
        LXI D,INVALID$CMD
        CALL PSTRING
        JMP DONEERR
NOTE2:  ANI 2H
        JZ NOTE1
        LXI D,TRK0$ERR
        CALL PSTRING
        JMP DONEERR
NOTE1:  LXI D,UNKNOWN$ERROR1
        CALL PSTRING

```

```

        JMP     DONEERR

DONEERR:POP  PSW
        PUSH  PSW
        CALL  ZBITS
        CALL  ZCRLF
        POP   PSW
        ORA  A           ;Set Z flag
        STC           ;Set Carry flag
        RET
ENDIF

;-----
; Print a 16 bit number in RAM located @ [HL]
; (Note Special Low Byte First. Used only for Drive ID)

printparm:
        INX     H           ;Index to high byte first
        MOV     a,M
        CALL   PHEX
        DCX     H           ;Now low byte
        MOV     a,M
        CALL   PHEX
        RET

; Print an 8 bit number, located in [A]
PHEX:  PUSH  PSW
        PUSH  B
        PUSH  PSW
        RRC
        RRC
        RRC
        RRC
        CALL  ZCONV
        POP   PSW
        CALL  ZCONV
        POP   B
        POP   PSW
        RET

ZCONV: ANI    0FH           ;HEX to ASCII and print it
        ADI    90H
        DAA
        ACI    40H
        DAA
        MOV    C,A
        CALL  ZCO
        RET

```

```

;DISPLAY BIT PATTERN IN [A]
ZBITS: PUSH PSW
      PUSH B
      PUSH D
      MOV E,A
      MVI B,8
BQ2:  DB 0CBH,23H
      SLAR E ;Z80 Op code for SLA A,E
      MVI A,18H
      ADC A
      MOV C,A
      CALL ZCO
      DJNZ BQ2
      POP D
      POP B
      POP PSW
      RET

ghex32lba: ;get CPM style Track# & Sector# data and convert to LBA format
      LXI D,ENTER$SECL ;Enter sector number
      CALL PSTRING
      CALL GETHEX ;get 2 HEX digits
      RC
      STA @SEC ;Note: no check data is < MAXSEC, sectors start 0,1,2,3....
      CALL ZCRLF

      LXI D,ENTER$TRKH ;Enter high byte track number
      CALL PSTRING
      CALL GETHEX ;get 2 HEX digits
      RC
      STA @TRK+1
      CALL ZCRLF

      LXI D,ENTER$TRKL ;Enter low byte track number
      CALL PSTRING
      CALL GETHEX ;get 2 more HEX digits
      RC
      STA @TRK
      CALL ZCRLF
      XRA A
      ORA A ;To return NC
      RET

GETHEX:
      CALL GETCMD ;Get a character from keyboard & ECHO
      CPI ESC
      JZ HEXABORT
      CPI '/' ;check 0-9, A-F
      JC HEXABORT

```

```

CPI    'F'+1
JNC    HEXABORT
CALL   ASBIN          ;Convert to binary
RLC    ;Shift to high nibble
RLC
RLC
RLC
MOV    B,A           ;Store it
CALL   GETCMD        ;Get 2nd character from keyboard & ECHO
CPI    ESC
JZ     HEXABORT
CPI    '/'           ;check 0-9, A-F
JC     HEXABORT
CPI    'F'+1
JNC    HEXABORT
CALL   ASBIN          ;Convert to binary
ORA    B             ;add in the first digit
ORA    A             ;To return NC
RET
HEXABORT:
STC    ;Set Carry flag
RET

GETCMD: CALL   ZCI          ;GET A CHARACTER, convert to UC, ECHO it
CALL   UPPER
CPI    ESC
RZ    ;Don't echo an ESC
IF NOT CPM
PUSH   PSW          ;Save it
PUSH   B
MOV    C,A
CALL   ZCO          ;Echo it
POP    B
POP    PSW          ;get it back
ENDIF
RET

UPPER: CPI    'a'          ;Convert LC to UC
RC    ;must be >= lowercase a
CPI    'z'+1        ; else go back...
RNC    ;must be <= lowercase z
SUI    'a'-'A'      ; else go back...
;subtract lowercase bias
RET

ASBIN: SUI    30H          ;ASCII TO BINARY CONVERSION ROUTINE
CPI    0AH
RM

```

```
SUI    07H
RET
```

```
HEXDUMP:                ;Print a hexdump of the data in the 512 byte buffer @[HL]
    PUSH    PSW          ;Save everything
    PUSH    B
    PUSH    D
    PUSH    H
```

```
    CALL    ZCRLF        ;CR/LF first
    MVI     D,32         ;Print 32 lines total
    MVI     B,16         ;16 characters across
    SHLD   @StartLineHex ;Save the buffer location for ASCII display below
    LXI     H,0
    SHLD   @BYTE$COUNT
```

```
SF172: CALL    ZCRLF
    LHLD   @BYTE$COUNT
    MOV    A,H
    CALL   PHEX        ;Print byte count in sector
    MOV    A,L
    CALL   PHEX
    PUSH   D
    LXI   D,16
    DAD   D
    POP   D
    SHLD  @BYTE$COUNT ;store for next time
    CALL  BLANK
    LHLD  @StartLineHex
    SHLD  @StartLineASCII ;Store for ASCII display below
SF175: MOV    A,M
    CALL   LBYTE        ;Display [A] on CRT/LCD
    INX   H
    DJNZ  SF175
    SHLD  @StartLineHex ;Save for next line later
    CALL  ShowAscii     ;Now translate to ASCII and display
    MVI   B,16         ;16 characters across for next line
    DCR   D
    JNZ   SF172        ;Have we done all 32 lines
```

```
;
    CALL   ZCRLF
    POP    H            ;Get back original registers
    POP    D
    POP    B
    POP    PSW
    RET
```

```
ShowAscii:                ;Now show as ascii info
    LHLD  @StartLineASCII
```



```

        MVI    B,16           ;16 ASCII characters across
XF172: CALL  BLANK          ;send a space character
        CALL  BLANK
XF175: MOV   A,M
        ANI   7FH
        CPI   ' '           ;FILTER OUT CONTROL CHARACTERS
        JNC   XT33
XT22:  MVI   A, '.'
XT33:  CPI   07CH
        JNC   XT22
        MOV   C,A           ;SET UP TO SEND
        PUSH  B
        CALL  ZCO
        POP   B
        INX   H             ;Next position in buffer
        DJNZ  XF175
        RET

;
BLANK:  PUSH  B
        PUSH  H
        MVI   C, ' '
        CALL  ZCO
        POP   H
        POP   B
        RET

;
LBYTE:  PUSH  PSW
        RRC
        RRC
        RRC
        RRC
        CALL  SF598
        POP   PSW
SF598:  CALL  ZCONV
        RET

;
;
;=====
;
;   IDE Drive BIOS Routines written in a format that can be used directly with CPM3
;
;=====
;
IDEinit:                ;Initilze the 8255 and drive then do a hard reset on the drive,
        MVI   A,READcfg8255 ;Config 8255 chip (10010010B), read mode on return
        OUT   IDEportCtrl  ;Config 8255 chip, READ mode

                                ;Hard reset the disk drive
                                ;For some reason some CF cards need to the RESET line
                                ;pulsed very carefully. You may need to play around

```

```

MVI    A,IDErstline ;with the pulse length. Symptoms are: incorrect data comming
OUT    IDEportC    ;back from a sector read (often due to the wrong sector being read)
                    ;I have a (negative)pulse of 2.7uSec. (10Mz Z80, two IO wait states).
MVI    B,20H      ;Which seem to work for the 5 different CF cards I have.
ResetDelay:
DCR    B
JNZ    ResetDelay ;Delay (reset pulse width)

XRA    A
OUT    IDEportC   ;No IDE control lines asserted (just bit 7 of port C)
CALL   DELAY$SHORT ;Short Delay

MVI    D,11100000b ;Data for IDE SDH reg (512bytes, LBA mode,single drive,head 0000)
                    ;For Trk,Sec,head (non LBA) use 10100000
                    ;Note. Cannot get LBA mode to work with an old Seagate Medalist 6531 drive.
                    ;have to use the non-LBA mode. (Common for old hard disks).

MVI    E,REGshd   ;00001110, (0EH) for CS0,A2,A1,
CALL   IDEwr8D    ;Write byte to select the MASTER device

MVI    B,02H      ;<<< Adjust delay time for hard disks to get up to speed (Currently ~ 2 seconds)
                    ;<<< This delay need to be much longer for actual Hard Disks, OK for CF Cards.
WaitInit:
MVI    E,REGstatus ;Get status after initilization
CALL   IDErd8D    ;Check Status (info in [D])
MOV    A,D
ANI    80H
RZ                    ;Return. Well check for errors when we get back
MVI    A,2
CALL   DELAY$LONG  ;Long delay, drive has to get up to speed
DCR    B
JNZ    WaitInit
XRA    A
DCR    A
RET                    ;Return NZ. Well check for errors when we get back

DELAY$LONG:          ;Long delay (Seconds)
STA    @DELAYStore
PUSH   B
LXI    B,0FFFFH    ;<<< May need to adjust delay time to allow cold drive to
DELAY2: LDA    @DELAYStore ; get up to speed.
DELAY1: DCR    A
JNZ    DELAY1
DCX    B
MOV    A,C
ORA    B
JNZ    DELAY2
POP    B
RET

```

```

DELAY$SHORT:                ;DELAY ~32 MS (DOES NOT SEEM TO BE CRITICAL)
    MVI    A,40
DELAY3:    MVI    B,0
MO:    DJNZ  M0
        DCR    A
        JNZ    DELAY3
        RET

                                ;Read a sector, specified by the 3 bytes in LBA
                                ;Z on success, NZ call error routine if problem
READSECTOR:
    CALL   wrlba                ;Tell which sector we want to read from.
                                ;Note: Translate first in case of an error otherwise we
                                ;will get stuck on bad sector
    CALL   IDEwaitnotbusy       ;make sure drive is ready
    JC     SHOWerrors           ;Returned with NZ set if error

    MVI    D,COMMANDread
    MVI    E,REGcommand
    CALL   IDEwr8D              ;Send sec read command to drive.
    CALL   IDEwaitdrq          ;wait until it's got the data
    JC     SHOWerrors

    LHLD   @DMA                ;DMA address
    MVI    B,0                 ;Read 512 bytes to [HL] (256X2 bytes)
MoreRD16:
    MVI    A,REGdata           ;REG regsiter address
    OUT    IDEportC

    ORI    IDerdline          ;08H+40H, Pulse RD line
    OUT    IDEportC

    IN     IDEportA           ;Read the lower byte first (Note very early versions had high byte then low byte
    MOV    M,A                ;this made sector data incompatable with other controllers).
    INX   H
    IN     IDEportB           ;THEN read the upper byte
    MOV    M,A
    INX   H

    MVI    A,REGdata           ;Deassert RD line
    OUT    IDEportC
    DJNZ  MoreRD16

    MVI    E,REGstatus
    CALL   IDerd8D
    MOV    A,D
    ANI   1H

```

```

CNZ   SHOWerrors   ;If error display status
RET

                                ;Write a sector, specified by the 3 bytes in LBA
                                ;Z on success, NZ to error routine if problem
WRITESECTOR:
CALL  wrlba           ;Tell which sector we want to read from.
                                ;Note: Translate first in case of an error otherwise we
                                ;will get stuck on bad sector
CALL  IDEwaitnotbusy ;make sure drive is ready
JC    SHOWerrors

MVI   D,COMMANDwrite
MVI   E,REGcommand
CALL  IDEwr8D        ;tell drive to write a sector
CALL  IDEwaitdrq    ;wait unit it wants the data
JC    SHOWerrors

LHLD  @DMA
MVI   B,0            ;256X2 bytes

MVI   A,WRITEcfg8255
OUT   IDEportCtrl

WRSEC1:  MOV    A,M
INX    H
OUT   IDEportA      ;Write the lower byte first (Note early versions had high byte then low byte
MOV    A,M          ;this made sector data incompatable with other controllers).
INX    H
OUT   IDEportB      ;THEN High byte on B

MVI   A,REGdata
PUSH  PSW
OUT   IDEportC      ;Send write command
ORI   IDEwrline     ;Send WR pulse
OUT   IDEportC
POP   PSW
OUT   IDEportC
DJNZ  WRSEC1

MVI   A,READcfg8255 ;Set 8255 back to read mode
OUT   IDEportCtrl

MVI   E,REGstatus
CALL  IDErd8D
MOV   A,D
ANI   1H
CNZ   SHOWerrors   ;If error display status
RET

```

```

wrlba:                ;Write the logical block address to the drive's registers
                    ;Note we do not need to set the upper nibble of the LBA
                    ;It will always be 0 for these small drives
LDA    @SEC          ;LBA mode Low sectors go directly
INR    A             ;Sectors are numbered 1 -- MAXSEC (even in LBA mode)
STA    @DRIVE$SEC    ;For Diagnostic Display Only
MOV    D,A
MVI    E,REGsector  ;Send info to drive
CALL   IDEwr8D      ;Note: For drive we will have 0 - MAXSEC sectors only

LHLD   @TRK
MOV    A,L
STA    @DRIVE$TRK
MOV    D,L           ;Send Low TRK#
MVI    E,REGcylinderLSB
CALL   IDEwr8D

MOV    A,H
STA    @DRIVE$TRK+1
MOV    D,H           ;Send High TRK#
MVI    E,REGcylinderMSB
CALL   IDEwr8D

MVI    D,1           ;For now, one sector at a time
MVI    E,REGsecCnt
CALL   IDEwr8D
RET

IDEwaitnotbusy:      ;ie Drive READY if 01000000
MVI    B,0FFH
MVI    A,0FFH       ;Delay, must be above 80H for 4MHz Z80. Leave longer for slower drives
STA    @DELAYStore

MoreWait:
MVI    E,REGstatus  ;wait for RDY bit to be set
CALL   IDErd8D
MOV    A,D
ANI    11000000B
XRI    01000000B
JZ     DoneNotbusy
DCR    B
JNZ    MoreWait
LDA    @DELAYStore  ;Check timeout delay
DCR    A
STA    @DELAYStore
JNZ    MoreWait
STC
ret

```

```

DoneNotBusy:
    ORA    A            ;Clear carry it indicate no error
    RET

                                ;Wait for the drive to be ready to transfer data.
                                ;Returns the drive's status in Acc

IDEwaitdrq:
    MVI    B,0FFH
    MVI    A,0FFH      ;Delay, must be above 80H for 4MHz Z80. Leave longer for slower drives
    STA    @DELAYStore

MoreDRQ:
    MVI    E,REGstatus ;wait for DRQ bit to be set
    CALL  IDERd8D
    MOV    A,D
    ANI    10001000B
    CPI    00001000B
    JZ     DoneDRQ
    DCR    B
    JNZ    MoreDRQ
    LDA    @DELAYStore ;Check timeout delay
    DCR    A
    STA    @DELAYStore
    JNZ    MoreDRQ
    STC
    RET      ;Set carry to indicate error

DoneDRQ:
    ORA    A            ;Clear carry
    RET

CLEAR$ID$BUFFER:            ;Clear the ID Buffer area
    LXI    H,IDBuffer
    LXI    B,512

CLEAR2:    MVI    A,' '
    MOV    M,A
    INX    H
    DCX    B
    MOV    A,C
    ORA    B
    JNZ    CLEAR2

    LXI    H,IDBuffer      ;Put in 0's for cylinder,heads,sectors etc
    LXI    B,14

CLEAR3:    MVI    A,0
    MOV    M,A
    INX    H
    DCX    B
    MOV    A,C
    ORA    B
    JNZ    CLEAR3

```

RET

```

;-----
; Low Level 8 bit R/W to the drive controller.  These are the routines that talk
; directly to the drive controller registers, via the 8255 chip.
; Note the 16 bit I/O to the drive (which is only for SEC R/W) is done directly
; in the routines READSECTOR & WRITESECTOR for speed reasons.
;
IDEr8D:                                ;READ 8 bits from IDE register in [E], return info in [D]
    MOV     A,E
    OUT     IDEportC                    ;drive address onto control lines

    ORI     IDErdline                    ;RD pulse pin (40H)
    OUT     IDEportC                    ;assert read pin

    IN      IDEportA
    MOV     D,A                          ;return with data in [D]

    MOV     A,E
    OUT     IDEportC                    ;<---Ken Robbins suggestion
                                        ;deassert RD pin

    XRA     A
    OUT     IDEportC                    ;Zero all port C lines
    ret

IDEwr8D:                                ;WRITE Data in [D] to IDE register in [E]
    MVI     A,WRITEcfg8255              ;Set 8255 to write mode
    OUT     IDEportCtrl

    MOV     A,D
    OUT     IDEportA                    ;Get data put it in 8255 A port

    MOV     A,E
    OUT     IDEportC                    ;select IDE register

    ORI     IDEwrline                    ;lower WR line
    OUT     IDEportC

    MOV     A,E
    OUT     IDEportC                    ;<-- Ken Robbins suggestion, raise WR line
                                        ;deassert RD pin

    XRA     A
    OUT     IDEportC                    ;Deselect all lines including WR line

    MVI     A,READcfg8255                ;Config 8255 chip, read mode on return
    OUT     IDEportCtrl
    RET

```

```

CPM$MOVE$CODE                ;This code is written to reside at 0H. Will be relocated by this
    LXI    H,BUFFER          ;this program to move the boot CPMLDR to 100H in RAM (Overwriting this program)
    LXI    D,100H
    LXI    B,(12*512)
    LDIR
    JMP    100H
CPM$MOVE$CODE$END:

SIGN$ON:    DB    CR,LF,'IDE Disk Drive Test Program 3/28/2012 (V2.9) '
            DB    '(Using CPM3 BIOS Routines)',CR,LF,LF
            DB    'CPM Track,Sectors --> LBA mode',LF,CR
            DB    'Initilizing IDE Board, one moment please...',CR,LF,'$'
INIT$1$ERROR: DB    'Initilizing of First Drive failed. Aborting Program.',BELL,CR,LF,LF,'$'
INIT$2$ERROR: DB    'Initilizing of Second Drive failed. (Possibly not present).',BELL,CR,LF,LF,'$'
ID$ERROR:   DB    'Error obtaining Drive ID.',BELL,CR,LF,'$'
INIT$DR$OK: DB    'Drive Initilized OK.',CR,LF,LF,'$'
BAD$DRIVE:  DB    CR,LF,'First Drive ID Information appears invalid. '
            DB    '(Drive possibly not present).',CR,LF
            DB    'Aborting program.',BELL,CR,LF,LF,'$'

DRIVE$INFO: DB    'Drive #0 ID Paramater Information:-',CR,LF,'$'
msgmdl:     DB    'Model: $'
msgsn:      DB    'S/N:  $'
msgrev:     DB    'Rev:  $'
msgcy:      DB    'Cylinders: $'
msghd:      DB    ', Heads: $'
msgsc:      DB    ', Sectors: $'
msgCPMTRK:  DB    'CPM TRK = $'
msgCPMSEC:  DB    ' CPM SEC = $'
msgLBA:     DB    ' (LBA = 00$'
MSGBracket  DB    ')$'

DRIVE$A$MSG DB    CR,LF,LF,' >>> DRIVE A: <<<$'
DRIVE$B$MSG DB    CR,LF,LF,' >>> DRIVE B: <<<$'
CMD$STRING1: DB    ' IDE Board Diagnostic MAIN MENU',CR,LF,LF
            DB    '(L) Set LBA value (R) Read Sector to Buffer (W) Write Buffer '
            DB    'to Sector',CR,LF
            DB    '(D) Set Display ON (S) Sequential Sec Read (F) Format Disk',CR,LF
            DB    '(V) Read N Sectors (X) Write N Sectors (H) Backup disk',CR,LF
            DB    '(G) Restore Backup (I) Next Sector '
            DB    '(J) Previous Sector',CR,LF
            DB    '(U) Power Up (N) Power Down (C) Boot CPM',CR,LF
            DB    '(A) Select Drive A (B) Select Drive B '
            DB    '(E) Clear Sector Buffer',CR,LF
            DB    '(Y) Copy A: to B: (Z) Verify A: = B: (ESC) Quit',CR,LF
            DB    LF,'Current settings:- $'

CMD$STRING2: DB    ' IDE Board Diagnostic MAIN MENU',CR,LF,LF
            DB    '(L) Set LBA value (R) Read Sector to Buffer (W) Write Buffer '
            DB    'to Sector',CR,LF

```



```

DB      '(D) Set Display OFF  (S) Sequential Sec Read  (F) Format Disk',CR,LF
DB      '(V) Read N Sectors  (X) Write N Sectors      (H) Backup disk',CR,LF
DB      '(G) Restore Backup  (I) Next Sector          '
DB      '(J) Previous Sector',CR,LF
DB      '(U) Power Up        (N) Power Down          (C) Boot CPM',CR,LF
DB      '(A) Select Drive A  (B) Select Drive B      '
DB      '(E) Clear Sector Buffer',CR,LF
DB      '(Y) Copy A: to B:   (Z) Verify A: = B:      (ESC) Quit',CR,LF
DB      LF,'Current settings:- $'

```

```

Prompt:      db      CR,LF,LF,'Please enter command >$'
msgsure:     DB      CR,LF,'Warning: this will change data on the drive, '
DB          'are you sure? (Y/N)...$'
msgrd:       DB      CR,LF,'Sector Read OK',CR,LF,'$'
msgwr:       DB      CR,LF,'Sector Write OK',CR,LF,'$'
GET$LBA:     DB      'Enter CPM style TRK & SEC values (in hex).',CR,LF,'$'
SEC$RW$ERROR DB      'Drive Error, Status Register = $'
ERR$REG$DATA DB      'Drive Error, Error Register = $'
ENTER$SECL  DB      'Starting sector number,(xxH) = $'
ENTER$TRKL  DB      'Track number (LOW byte, xxH) = $'
ENTER$TRKH  DB      'Track number (HIGH byte, xxH) = $'
ENTER$HEAD  DB      'Head number (01-0f) = $'
ENTER$COUNT DB      'Number of sectors to R/W = $'
DRIVE$BUSY  DB      'Drive Busy (bit 7) stuck high. Status = $'
DRIVE$NOT$READY DB      'Drive Ready (bit 6) stuck low. Status = $'
DRIVE$WR$FAULT DB      'Drive write fault. Status = $'
UNKNOWN$ERROR DB      'Unknown error in status register. Status = $'
BAD$BLOCK   DB      'Bad Sector ID. Error Register = $'
UNRECOVER$ERR DB      'Uncorrectable data error. Error Register = $'
READ$ID$ERROR DB      'Error setting up to read Drive ID',CR,LF,'$'
SEC$NOT$FOUND DB      'Sector not found. Error Register = $'
INVALID$CMD  DB      'Invalid Command. Error Register = $'
TRK0$ERR    DB      'Track Zero not found. Error Register = $'
UNKNOWN$ERROR1 DB      'Unknown Error. Error Register = $'
CONTINUE$MSG DB      CR,LF,'To Abort enter ESC. Any other key to continue. $'
FORMAT$MSG   DB      'FORMAT DISK. Fill all sectors with E5'
DB          '60H,'s on the CURRENT drive/CF card.$'
ReadN$MSG    DB      CR,LF,'Read multiple sectors from current disk/CF card to RAM buffer.'
DB          CR,LF,'How many 512 byte sectores (xx HEX):$'
WriteN$MSG   DB      CR,LF,'Write multiple sectors RAM buffer CURRENT disk/CF card.'
DB          CR,LF,'How many 512 byte sectores (xx HEX):$'
ReadingN$MSG DB      CR,LF,'Reading Sector at:- $'
WritingN$MSG DB      CR,LF,'Writing Sector at:- $'
msgErr       DB      CR,LF,'Sorry, that was not a valid menu option!$'
FormatDone   DB      CR,LF,'Disk Format Complete.',CR,LF,'$'
BackupDone   DB      CR,LF,'Disk partition copy complete.',CR,LF,'$'
CopyMsg      DB      CR,LF,'Copy disk partition to a second area on disk (CF card).'
DB          CR,LF,'>>> This assumes that tracks greater than MAXTRK '
DB          '(for CPM, 0FFH) are unused <<<'
DB          CR,LF,'>>> on this disk. Be sure you have nothing in this '

```

```

DB      '"Backup partition area". <<<'
DB      CR,LF,BELL,'Warning: This will change data in the partition area, '
DB      'are you sure? (Y/N)...$ '
AtEnd   DB      CR,LF,'At end of disk partition!',CR,LF,'$'
RBackup$MSG DB    'Reading track: $'
WBackup$MSG DB    'H. Writing track: $'
H$Msg   DB      'H$'
RestoreMsg DB    CR,LF,'Restore disk with data from backup partition on disk (CF card).'
DB      CR,LF,BELL,'Warning: This will change data on disk, '
DB      'are you sure? (Y/N)...$ '
RestoreDone DB   CR,LF,'Restore of disk data from backup partition complete.',CR,LF,'$'
RANGE$MSG DB    CR,LF,'Sector value out of range.',CR,LF,'$'
CPM$ERROR DB    CR,LF,'Error reading CPMLDR.',CR,LF,'$'
CPM$ERROR1 DB   CR,LF,'Data error reading CPMLDR. (The first byte loaded was not 31H).',CR,LF,'$'
MOVE$REQUEST DB  CR,LF,'The CPMLDR image is now at 3000H in RAM. '
DB      'To boot CPM you will have to'
DB      CR,LF,'overwrite this program at 100H. Do you wish to do so (Y/N)...$'
SETA$MSG DB    CR,LF,'Current Drive is now A: (Yellow LED)$'
SETB$MSG DB    CR,LF,'Current Drive is now B: (Green LED)$'
FILL$MSG DB    CR,LF,'Sector buffer in RAM filled with 0',27H,'s$'
DiskCopyMsg DB   CR,LF,'Copy disk partition of Drive A: to Drive B: (CF card).'
DB      CR,LF,BELL,'Warning: This will delete all data on Drive B:, '
DB      'are you sure? (Y/N)...$ '
CopyDone DB    CR,LF,'Disk copy of CPM disk A: to B: complete.',CR,LF,'$'
CopyTrk$MSG DB   'Copying track: $'

DiskVerifyMsg DB  CR,LF,'Verify disk partition Drive A: = Drive B: (CF card).$'
VerifyTrk$MSG DB  'Verifying track: $'
VerifyDone   DB   CR,LF,'Verify CPM disk A: = B: complete.',CR,LF,'$'
Verify$ERR   DB   CR,LF,BELL,'Verify error on Track $'
SEC$Msg      DB    'H Sector $'
; ----- RAM usage -----
RAMAREA      DB    '          RAM STORE AREA ----->'          ;useful for debugging
@DMA         DW    buffer
@DRIVE$SEC   DB    0H
@DRIVE$TRK   DW    0H
@DisplayFlag DB    OFFH          ;Display of sector data initially ON
@SEC         DW    0H
@TRK         DW    0H
@SEC1        DW    0H          ;For disk partition copy
@TRK1        DW    0H
@SEC2        DW    0H
@TRK2        DW    0H
@StartLineHex DW   0H
@StartLineASCII DW  0H
@BYTE$COUNT DW   0H
@SECTOR$COUNT DW  0H
@DELAYStore DB    0H
@CURRENT$DRIVE DB   0H

```

```

;
IDbuffer  DB      '          Start of ID buffer-->'
          DS      512
          DB      '<--End of ID buffer          '

          ORG     BUFFER$ORG                ;<--- In case we wish to use ZSID etc.

BUFFER:   DB      76H                      ;put a Z80 HALT instruction here in case we
          ;jump  to a sector in error
          DB      '<--Start buffer area'    ;a 512 byte buffer
          DS      476
          DB      'End of buffer-->'

          ;jump  to a sector in error
BUFFER2:  DB      '<--Start buffer2 area'   ;a 512 byte buffer
          DS      476
          DB      'End of buffer2-->'

STACK    DS      100H
          DW      0H

;END

```