

```

; This is an 8086/80386/80486 monitor for the 8088, 8086, 80286 or 80386 & 80486      ✓
; S100Computers.com boards
; It is a modification of the earlier 8086 monitor used with the S100Computers 8086 Board, ✓
; IDE Board,
; ZFDC board, MSDOS Support (PIC & RTC) Board and other hardware as well.
;
; John Monahan, San Ramon, CA Started, December 2012. (monahan@vitasoft.org)
;
; History
;
; V0.1 12/19/2012 ;Original version V8.8 8086 Monitor modified for 80386
; V0.2 12/24/2012 ;Started adding protected mode menu options
; V0.3 12/28/2012 ;Added ability to switch back to 80386 real mode from      ✓
; protected mode
; V0.4 12/31/2012 ;Added PM A,M,V,R menu commands
; V0.5 1/1/2013 ;Addeed Q, & F commands
; V0.6 1/2/2013 ;Added J,G,H commands
; V0.7 1/13/2013 ;Modified real mode interreupt testing commands. Orgin      ✓
; moved to F000:0H (from F000:8000H)
; V0.8 1/16/2013 ;RM mode soft interrupts working with relevent vector #      ✓
; display
; V0.9 1/17/2013 ;PM Interrupts tests added
; V0.91 1/19/2013 ;Set Date error with "E" comand corrected. Also RM display ✓
; all registes with "R" command
; V1.0 1/26/2013 ;Change default RAM loacations for GDT IDT etc. Set so it ✓
; can be easily loaded with PLOAD.COM
; V1.1 1/30/2013 ;Add Interrupt 0-3ffh in RAM. Correct PM Debug Interrupts
; V1.2 2/3/2013 ;Implemented Hardware breakpoints (DR0-3)
; V1.3 2/5/2013 ;Implemented XModem file transferrs (RM & PM) "W" menu      ✓
; option
; V1.31 2/8/2013 ;Fixed 80386 JZ,JNZ jumps so they are within range for 8086
; V1.32 2/10/2013 ;Minor cleanups including PATCH:
; V1.33 2/18/2013 ;Corrected Z menu option display
; V1.34 2/21/2013 ;Hardware test/read RAM above 16 MG ("E" command)
; V1.35 2/22/2013 ;Fixed PM Mem move error
; V1.36 4/17/2013 ;Fixed memory map displaying RAM and RAM testing above 16MG ✓
; for areas with no RAM chips
; V1.4 7/29/2013 ;European Cruise updates/cleanup
; V1.41 10/23/2013 ;Correct duplicate "ZFDC not present" messaaage upon      ✓
; initalization and Memory Compare display errors
; V1.42 12/18/2013 ;Added PM "Y" menu option to test running test code at any ✓
; location including a location above 16MB
; V1.43 3/16/2014 ;Added PM "J" command to test RAM 1-16MB extensively
; V1.44 3/20/2014 ;Changed "Z" to allow return Z80 master using V2-SMB ports
; V1.45 5/25/2014 ;Generalize memory testing (J command anywhere in RAM), ✓
; corrected XMODEM
; V1.46 5/27/2014 ;Redo Executing test code in RAM > 16 MB ("Y" command)
; V1.47 7/20/2014 ;Corrected IDE Menu X & Y commands display in menu
; V1.48 8/3/2014 ;Major changes/improvement to PM RAM testing routine
; V1.49 8/23/2014 ;Added loop RAM RD/WR test for hardware signal analysis ✓
; with logic probes etc.
; V1.5 2/7/2015 ;Changed initalization so Cyrix 80486 boots up correctly ✓
; (after IN AL,KEYIN, no immediate OUT 05H).
; V1.6 4/28/2015 ;Minor changes to use with 80486 CPU S100 board. Note for ✓
; the 80486, the 27C1001 ROM resides on the main CPU board.
; V1.7 6/19/2015 ;Added RAM Rd/Wr hardware signals test to main menu (H). ✓
; Moved HEX math to IDE menu.
; V1.71 6/21/2015 ;Fix bios keyboard interrupt test. Make sure 8259A is ✓
; activated.
; V1.72 10/26/2015 ;Add more PM RAM tests and running code in PM.
; V1.73 10/14/2016 ;Update Signon message. Call it 80386/80486 Monitor. Check ✓
; if onboard ROM on Baby 80486 board
; V1.74 7/15/2019 ;Corrections in Mem map and Dispaly DWORDS by Peter 'p2' De ✓
; Schrijver <p2@psychaos.be>
;

```

```
; To Do:-
; Caps Lock key is showing as ^ on for MS-DOS command line on Propeller & LAVA video boards (Fix on propeller board)
;
; Notes...
; The monitor should work fine with an 8086/80286 CPU for all menu options except the 32 bit protected mode menu section.
; However I have not checked this point out thoroughly. For these chips you should really use the 8086 monitor.
; Also it will not fit in the S100Computres/N8VEM boards 8086/8088's 32K address space with 28C256 EEPROMS.
; You will need to use 27C256 UV-EPROMS.
;
; This fairly extensive 80386/80486 monitor consists of 4 main sections. Section 4 assumes an 80386/80486
;
; Section 1. This is a classical monitor. Display, change RAM/ports etc.
; Section 2. This is a self-contained set of routines run diagnostic tests on the S100Computers/N8VEM IDE board.
; Section 3. This fairly complex section. It emulates most of the IBM-PC ROM BIOS interrupts (hard & soft) such that MS-DOS (V4.01)/FreeDOS can be run on the system - without any DOS modifications.
; Section 4. This is a section written in 32 bit code. It requires an 80386/80486 to run in Protected mode and has 0-4GB RAM addressing capability as well as interrupt processing (IDT table).
; The code runs at privilege level 0 with no assigned tasks.
;
; In general the 32 bit specific routines for the 80386/80486 all start with "P_" (e.g. P_EAX_HEXOUT). These must be used when the CPU is in protected mode. The most common error is calling a 16 bit routine instead of the equivalent 32 bit one when the CPU is in protected mode. This will usually result in a FAULT interrupt.
;
; In the final EEPROM it will be placed at F0000H, the stack is at DFFFCH, and the IDE Board RAM buffers/BP at DE000H.
; For debugging/testing this monitor will reside in RAM at E0000H (the stack is still at DFFFCH & IDE RAM buffer/BP at DE000H).
; For mode (PM), the GDT is at D0000H and the IDT is at D0100-D08FFH. I place the stack an BP here so that test versions of the monitor can be uploaded to E0000H by the monitor "W" command without overwriting the stack.
;
; This monitor needs a valid stack in RAM. It first checks if there is valid RAM in high memory below the ROM (The EEROM is usually at F0000H). If so it will set the SS to D000H and the SP to FFFCH. This puts it out of the way of everything in low RAM. If it does not detect RAM there, it will search for a valid segment from there in RAM downwards and put the stack at the first "top of RAM" available.
;
; That is the only RAM the main PM monitor needs. However the IDE drive diagnostic routines require much more (sector buffers etc.)
; I have set the BP to E000H. We use SS:BP throughout to access that RAM for the IDE Board diagnostic section.
;
; Remember also, that RAM 0-3FFH can be initilized to trap all interrupts in RM. If you want this, activate the SETUP_INT_TABLE routine at the start of this code. Otherwise they are not used/activated unless you use the "L" and "I" commands.
; In PM the ints are always active and will trap most errors and can be used for single stepping deugging etc.
;
; Most monitor commands are modeled after the old TDL/Zapple/Z80 commands. Because we are now dealing with potentially up
```

```
; to 4GB of RAM for many commands, the start, end RAM locations etc. can take up to 8
; digits!
; In Protected mode/80386/80486, the actual span/range for any command is NOT limited
; to 64K as for the 8086 monitor.
; In real mode however the limit is still 64K.
;
; The following example fills RAM with 76H from 1A000H to 21234H.
; F10000,200000,7676
; Of course for the lowest 64K of RAM the "normal" 4,3,2 or 1 byte formats can be
; used
; F123,456,76
;
; In general hitting the ESC key will abort any long display/command function.
; In all cases, to accept data, finish the entry with a CR.
; So if the display says "xxxxH" you enter up to 4 hex digits than a CR (No "H" is
; required).
;
; To test/load the monitor...
;
; There are a number of ways to test/run this monitor. Until you actually have this
; monitor in EEPROM, you
; can assemble it with a origin in low RAM (say MonitorORG = 4000H). Until you have
; a working version you should
; have your 80386/80486 (or 8086) after reset jump to the debugging monitor in low
; RAM. Use PCLOAD (see the S100Computersw.xom
; web site or see below, how to do this).
;
; The debugging version can be anywhere in RAM but the easiest location is something
; like 4000H. It needs to be
; well above 100H, because the Stack & Data areas are BELOW the ORG or the final
; EPROM code. These may have to be
; assigned different locations in the equates below if you don't have RAM at 0D0000H.
;
; Assemble to a binary file with the excellent/free MSDOS/FreeDOS, NASM.EXE Assembler
; NASM -f bin 8086.A86 -o 8086.bin -l 8086.lst
;
; This will make a 8 bit format .bin file
;
; Move it across to your CPM80 disk file system (Telnet/Modem/serial connection),
; whatever. I use my program PCLOAD.COM.
; This is a small CPM program that takes ModemZ file format data from a PC (the above
; .bin file) via a serial port and places it in the
; S100 bus RAM anywhere from 1000H up to 1MG. For locations greater than 64K it
; assumes a S100Computers Z80 CPU S100 board
; This board has a 16K window capability to access RAM > 64K. PCLOAD.COM can be
; downloaded from the S100Computers.com web site.
;
; After switching to your 8086/80386/80486 Board (IN port EDH), the CPU starting up
; initially from an reset will begin at
; @FFFF0H (F000:FFF0H) in RAM:. There you should have code to jump to the start of
; the monitor.
; If for example it resides in RAM at 4000H you should have the bytes:- EA 00 40 00
; 00.
;
; BTW, in the monitor code here, before such a jump, there is a small piece of code
; that reads bits 7&6 of the IOPORT
; and IF 0's just outputs a characater on the Console. This is a usefull hardware
; test
; when you are first building a board or testing hardware. See the end of the code
; here for more info. However you dont
; need this code if you are doing things by hand i.e. jumping to the the start of the
; monitor in low RAM.
; Finally (if installed in hardware), some diagnostic LED's can be turned on as the
; monitor loads. Again not necessary, but usefull.
;
; Once you have the Monitor itself working its own "W" command will read a modem
```

```

; serial port and upload a test version of the monitor
; into RAM (currently) configured to start at whatever 4K boundry you designate
; (usually E0000H). You don't need CPM or the Z80 card.
; When done, use the Master Z80 monitor "W" command to activate the 80386/80486
; board (not the "O" cmmand) if your code is in RAM.
;
; Note in the code there are a few FAR JMP's in the code, and in PM there are
; critical tables that must be positioned
; carefully. Be sure the equates below have the correct values.
;
; That said the whole monitor fits easily within one 8086 style segment. So for
; example it will run unchanged in RM at say:
; F000:0000H, E000:0000H, 1000:0000H.... etc. just make sure you have RAM below it
; configured for a stack.
; Remember PM mode requires careful positioning of the GDP and IDE tables.
;
; As soon as you get things going, burn a EEPROM version that resides at F000:0000H.
; After switching to your
; 80386/80486/8086 Board (IN port EDH, Master Z80 monitor "W" or in this case "O"
; command), the Monitor should immediately come up.
;
; To burn two 28C256 EEPROM's with a Wellon VP290 Programmer...
; Load .BIN file. Select Even bytes (1st of 2) for one ROM and "From File HEX address"
; " and "Buffer Address"
; leave 0000 in the dialog boxes, do not change "File Size (HEX) either".
; Repeat for ODD addresses. In each case the Edit Box code should appear from 0000H-
; 7FFFH if the ROM is read back.
;
; For the baby 80486 Board we will use only the top half of a 512X8 EEPROM
; To burn ONE Greenlant 29EE101 PROM (512X8 EEPROM) with a Wellon VP290 Programmer...
; Load FPGA_80486.BIN file. Ster Clear to 0's. Set Buffer address to 10000H, File
; address to 0H, File Size 20000H
; Confirm code begins at 1000H withing the EEPROM
; Ignore message from Wellon programmer saying ID does not match!
;
; Remember the Console OUT routines CAN be different, The "Normal" monitor and IDE
; diagnostic sections ALWAYS go through the
; Propeller driven (or any serial type) Console out routine (CO: etc.). This by
; default is also the case
; when the IBM-BIOS sections are activated. However if the Console output is
; redirected to the CGA/VGA board (INT 10H etc.),
; then CO: is not used. Instead CO: goes to the IBM BIOS video board output. This is
; controlled by the [CONSOLE_FLAG] byte in low RAM.
;
; Likewise, the Console IN routines CAN be different. The "Normal" monitor and IDE
; diagnostic sections ALWAYS go through the
; Propeller driven (or any serial type) Console IN routine (CI:, CICO, etc.).
; However when the IBM BIOS section is active (X Menu command,
; booting up MSDOS etc.), Keyboard input is ALWAYS interrupt driven, and requires the
; 8259A PIC etc. It uses the input from the
; propeller board, but each key press interrupt places the data in the IBM-PC style
; RAM buffer for later retrieval.
; If the 8259A interrupt functions are not working this section it will hang! You can
; use the 8259A diagnostics command
; (Main menu, "L" command) to debug this section beforehand.
;
; DEFINE ASCII CHARACTERS USED
SCROLL EQU 01H ; Set scrool direction UP.
BELL EQU 07H
SPACE EQU 20H
BS EQU 08H
TAB EQU 09H ; TAB ACROSS (8 SPACES FOR SD-BOARD)
CR EQU 0DH
LF EQU 0AH
FF EQU 0CH
QUIT EQU 11H ; Turns off any screen enhancements (flashing,

```



```

USB_RXE      EQU      80H      ;If Bit 7 = 0, data available to recieve by S-100  ✓
Computer
USB_TXE      EQU      40H      ;If Bit 6 = 0 data CAN be written for transmission  ✓
to PC

BASE_PORT    EQU      0A1H
MODEM_CTL_PORT EQU      BASE_PORT ;A1H
MODEM_SEND_MASK EQU      4
SEND_READY   EQU      4      ;VALUE WHEN READY
MODEM_RECV_MASK EQU      1
RECV_READY   EQU      1      ;BIT ON WHEN READY
MODEM_DATA_PORT EQU      BASE_PORT+2 ;A3H

RECVD_SECT_NO EQU      100H     ;BP Offset below stack for Recieved Sector Number
SECTNO       EQU      101H     ;BP Offset below stack for CURRENT SECTOR NUMBER
ERRCT        EQU      102H     ;BP Offset below stack for ERROR COUNT
MODEM_ERR_LIMIT EQU      8     ;Max number of Modem serial port re-reads before  ✓
aborting
MODEM_RTS_DELAY EQU      1     ;Time to check Modem RTS line (See XMODEM_LOAD &  ✓
P_XMODEM_LOAD). Not critical.

```

```

;----- S100Computers SMB Board -----

```

```

IOBYTE      EQU      0EFH      ;IOBYTE Port on S100Computers SMB Board.

;IOBYTE = SENSE SWITCHES AT PORT 0EFH
;
; In my system I use this switch for various options across a number of OS's etc. Only bits ✓
1,2,6&7 are relevent here.
; BIT MAP OF PORT 0EFH:----- X X X X X X X X (11111111=NORMAL CONFIG)
;                               | | | | | | | | ..For Z80 Monitor,           0=CONSOLE  ✓
;   DATA TO PRINTER ALSO      | | | | | | | | ....For 80386/80486 Monitor,  0=Force    ✓
;   Consol output to CGA/VGA Board | | | | | | | | .....For 80386/80486 Monitor, 0=Do not   ✓
;   initilize any onboard extra S100 ROMS | | | | | | | | .....Unused
;   LF's in CPM3                | | | | | | | | .....For CPM3,              0=Prevents  ✓
;   O via ACIA Serial port       | | | | | | | | .....For Z80 Monitor,       0=Consol I/ ✓
;   format of MDisk with CPM3    | | | | | | | | .....For CPM3,              0=Force    ✓
;   protect MDisk                | | | | | | | | .....For CPM3,              0=R/W      ✓
;   doing a JMPF to 0000:0500H after 8086 reset (to CPM86 boot)           For 80386/80486 Monitor, 0=Prevent  ✓
;   test is made to see if CPM86 Boot is in RAM at 500H (see Init:)       Default, a  ✓
;   force a hardware diagnostic test. (See code at FFFF0H)                 Note if 00xxxxxx       This will   ✓

```

```

;----- S100Computers MSDOS BOARD PORT ASSIGNMENTS ----- ✓
-

```

```

NS_EOI      equ      20h      ;Non specific end of interrupt command
MASTER_PIC_PORT equ      20h  ;Hardware port the 8259A is assigned (two ports 20H ✓
& 21H)

MasterICW1  equ      00010111B ;EDGE triggered, 4 bytes, single Master,ICW4 needed
MasterICW2  equ      8H      ;Base address for 8259A Int Table (IBM-PC uses 8X4 ✓
= 20H)

```

```

PM_MasterICW2    equ    108H/4      ;Protected Mode (PM), Base address for 8259A Int
    Table 108H/4
MasterICW3       equ    0H          ;No slave
MasterICW4       equ    00000011B   ;No special mode, non buffer, Auto EOI, 8086. ;<<<
    <,

CMOS_PORT        EQU    70H         ;Base Port for CMOS Chip
CMOS_VALID       EQU    0DH         ;To check DS12887 CMOS chip is present and OK (Note
    AT-BIOS uses 0EH)
CMOS_REGA        EQU    0AH         ;CMOS REGISTER A

TIMER            EQU    40H         ;Base port of 8254
TIM_CTL          EQU    43H
COUNTS_SEC      EQU    18
COUNTS_MIN      EQU    1092
COUNTS_HOUR     EQU    07H        ;Seems this value is used with AT/CMOS chip (was
    65543 on PC)

UPDATE_TIMER     EQU    80H

CMOS_SECONDS     EQU    0H          ;RAM offsets for CMOS Registers
CMOS_MINUTES     EQU    2H
CMOS_HOURS       EQU    4H

;----- S100Computers IDE BOARD PORT ASSIGNMENTS (30-34H) -----
;-----

;Ports for 8255 chip. Change these to specify where the 8255 is addressed,
;and which of the 8255's ports are connected to which IDE signals.
;The first three control which 8255 ports have the IDE control signals,
;upper and lower data bytes. The forth one is for mode setting for the
;8255 to configure its ports, which must correspond to the way that
;the first three lines define which ports are connected.

IDEportA         EQU    030H        ;lower 8 bits of IDE interface
IDEportB         EQU    031H        ;upper 8 bits of IDE interface
IDEportC         EQU    032H        ;control lines for IDE interface
IDEctrlPort      EQU    033H        ;8255 configuration port
IDEDrivePort     EQU    034H        ;To select the 1st or 2nd CF card/drive

IDE_Reset_Delay  EQU    020H        ;Time delay for reset/initilization (~66 uS, with
    8MHz 8086, with I/O wait state)
IDR_POWER_DELAY  EQU    03H         ;Delay to allow Hard disk to power up

READcfg8255     EQU    10010010b    ;Set 8255 IDEportC out, IDEportA/B input
WRITEcfg8255    EQU    10000000b    ;Set all three 8255 ports output

;IDE control lines for use with IDEportC.

IDEa0line        EQU    01H         ;direct from 8255 to IDE interface
IDEa1line        EQU    02H         ;direct from 8255 to IDE interface
IDEa2line        EQU    04H         ;direct from 8255 to IDE interface
IDEcs0line       EQU    08H         ;inverter between 8255 and IDE interface
IDEcs1line       EQU    10H         ;inverter between 8255 and IDE interface
IDEwrline        EQU    20H         ;inverter between 8255 and IDE interface
IDERdline        EQU    40H         ;inverter between 8255 and IDE interface
IDERstline       EQU    80H         ;inverter between 8255 and IDE interface
;
;Symbolic constants for the IDE Drive registers, this makes the
;code more readable than always specifying the address pins

REGdata          EQU    IDEcs0line
REGerr           EQU    IDEcs0line + IDEa0line
REGseccnt        EQU    IDEcs0line + IDEa1line
REGsector        EQU    IDEcs0line + IDEa1line + IDEa0line

```

```

REGcylinderLSB EQU IDEcs0line + IDEa2line
REGcylinderMSB EQU IDEcs0line + IDEa2line + IDEa0line
REGshd EQU IDEcs0line + IDEa2line + IDEa1line ; (0EH)
REGcommand EQU IDEcs0line + IDEa2line + IDEa1line + IDEa0line ; (0FH)
REGstatus EQU IDEcs0line + IDEa2line + IDEa1line + IDEa0line
REGcontrol EQU IDEcs1line + IDEa2line + IDEa1line
REGastatus EQU IDEcs1line + IDEa2line + IDEa1line + IDEa0line

;IDE Command Constants. These should never change.

COMMANDrecal EQU 10H
COMMANDread EQU 20H
COMMANDwrite EQU 30H
COMMANDinit EQU 91H
COMMANDid EQU 0ECH
COMMANDspindown EQU 0E0H
COMMANDspinup EQU 0E1H
;
; IDE Status Register:
; bit 7: Busy 1=busy, 0=not busy
; bit 6: Ready 1=ready for command, 0=not ready yet
; bit 5: DF 1=fault occured on the IDE drive
; bit 4: DSC 1=seek complete
; bit 3: DRQ 1=data request ready, 0=not ready to xfer yet
; bit 2: CORR 1=correctable error occured
; bit 1: IDX vendor specific
; bit 0: ERR 1=error occured

MAXSEC EQU 3DH ;Sectors per track for CF my Memory drive, Kingston
CF 8G. (CPM format, 0-3CH) ;translates to LBA format of 1 to 3D sectors, for a
total of 61 sectors/track. ;This CF card actully has 3F sectors/track. Will
use 3D for my CPM86 system because ;my Seagate drive has 3D sectors/track. Don't want
different CPM86.SYS files around ;so this program will also work with a Seagate 6531
IDE drive

DOS_MAXSEC EQU 3FH ;For MS-DOS BIOS Setting "Hard Disk" to Custom type
(CF Card, 63 Sectors/track)
DOS_MAXHEADS EQU 10H ;16 head(s)
DOS_MAXCYL_L EQU 0FFH ;Low Byte maximum cylinder (sent via INT 13H's in
CH)
DOS_MAXCYL EQU 1024 ;Max cylinders
DOS_MAXSEC_CYL EQU 0FFH ;3FH, maximum sector number (bits 5-0)+ two Cyl
High Bits (Sectors numbered 1....x)

;-----S100Computers PORTS FOR FOR Z80/WD2793 FDC Board

S100DATAA EQU 10H ;IN, S100 Data port to GET data to from FDC Board
S100DATAB EQU 10H ;OUT, S100 Data port to SEND data to FDC Board
S100STATUSA EQU 11H ;Status port for A
S100STATUSB EQU 11H ;Status port for B
RESETZFDCPORT EQU 13H ;Port to reset ZFDC Z80 CPU.

STATUSDELAY EQU 20 ;Time-out for waiting for ZFDC Board handshake
signal (Now, ~0.5 seconds @ 8MHz 8086)
SECTOR_TIMEOUT EQU 400H ;Value for sector R/W status check countdown (For 6
-8MHz 8086, not critical)

ZFDCUNINITIALIZED EQU 0FFH ;If ZFDC is not yet initilized
ZFDCNOTWORKING EQU 0FEH ;If ZFDC is not working
ZFDCNOTPRESENT EQU 0FDH ;If ZFDC board is absent
ZFDCINITIALIZED EQU 000H ;If ZFDC is initilized OK

```



```

STD8IBM      EQU      1      ;ZFDC Board Format table # for IBM 8" SDSS Disk
MSDOS2      EQU      13H    ;Disk format type # for ZFDC board (MS-DOS V2.0
Disk, 512 X 9 Sec/Track)
IBM144      EQU      15H    ;Disk format type # for 1.4M DDDS, 18 X 512 Byte
Sectors, 80 Tracks

CMD_SET_FORMAT EQU      4H    ;This will select a specified drive and assign a
disk format table to that drive
CMD_SET_DRIVE EQU      5H    ;This will select a specified drive (0,1,2,3)
CMD_SET_TRACK EQU      7H    ;This will set head request to a specified track
CMD_SET_SIDE EQU      8H    ;This will set side request to a specified side
CMD_SET_SECTOR EQU      9H  ;This will set sector request to a specified sector
CMD_SET_HOME EQU      0AH   ;This will set head request to Track 0 of CURRENT
drive
CMD_SEEEK_TRACK EQU      0EH  ;Seek to track to (IY+DRIVETRACK) with the track
verify bit set on CURRENT drive/format
CMD_FORMAT_TRACK EQU      16H ;Format the floppy disk in the of the CURRENT drive
using the current format assigned to that disk
CMD_HANDSHAKE EQU      21H   ;Handshake command only sent during board
initilization/testing

;These new commands are required for R/W MSDOS
Double sided disks
CMD_DOS_RD_MULTI_SEC EQU 2BH ;MS-DOS, Read data from multiple sectors starting
at the CURRENT sector.
CMD_DOS_WR_MULTI_SEC EQU 2CH ;MS-DOS, Write data to multiple sectors starting at
the CURRENT sector.
CMD_GET_SIDE EQU      2DH   ;Get the current selected side of the current
selected drive
CMD_DOS_SET_SECTOR EQU 2EH  ;MS-DOS, Set current sector for the next sec R/W

;Possible ERROR codes returned from the ZFDC Board:-
;These will be translated into ASCII strings in the error reporting function.
;See the ZFDC code for a complete set of possible error coded returned byt the ZFDC Board

NO_ERRORS_FLAG EQU      00H  ;No Errors flag for previous cmd, sent back to S-
100 BIOS
CONFIRM_FORMAT EQU      32H  ;Confirm disk format cmd request
DISK_WP_ERR EQU      31H    ;Sector write error, Disk is write protected
ABORT_FLAG EQU      3AH     ;Special error flag to signify the user aborted a
command

ZFDC_ABSENT EQU      3BH    ;If ZFDC Board is absent
ZFDC_INIT_ERROR EQU      3CH ;If ZFDC initilization error

TIMEOUT_ERROR EQU      3DH  ;Error flag to signify the previous command timed
out
CMD_RANGE_ERR EQU      3EH  ;CMD out or range.

MAX_ERRORS EQU      3FH    ;0 to 3FH errors only

;Meanings for disk status (as returned by IBM BIOS
ROM)
seekerr equ      40h      ;seek failed
hdwerr equ      20h      ;controller chip failed
crcerr equ      10h      ;crc error
dmaerr equ      09h     ;DMA across 64k boundary
wpterr equ      03h     ;write protected disk
rnferr equ      04h     ;sector not found
timerr equ      80h     ;Floppy time out error
cmderr equ      01h     ;Floppy bad command for controller

msize equ      280H      ;Total RAM memory size, (640K)

```

```

romdat      equ      0h                ;Data area for ROM usage (DS will be set to 0H for
data at 400H....)

;----- CGA/VGA/XVGA Video board equates -----
-----
c6845port   Equ      3d0h                ;base port for Lomas/CGA colour board
bw6845port  Equ      3b0h                ;base port for b/w card
Index_Reg_Count Equ    16                ;Count of 6845 Index registers

;----- LAVA-10 Video board equates -----

LavaStatus  EQU      090H                ;Status Port
LavaData    EQU      091H                ;Data port

;LAVA Commands:-
COPY$MEMORY EQU      010H
WRITE$MEMORY EQU     020H
READ$MEMORY  EQU     030H
DRAW$TEXT   EQU     040H
READ$CSR    EQU     036H
WRITE$CSR   EQU     022H

L_CRT_WIDTH EQU      800                ;Pixels across per line
L_CRT_HEIGHT EQU     600                ;Pixels (16 per line)
L_BELOW_SCREEN EQU   601                ;Area of LAVA screen RAM not visible (Use as a
clear buffer area, EOL etc)
L_CHARS_PER_LINE EQU  99                ;99X8 = 792
L_SCREEN_LINES EQU   37                ;37X16 = 592
L_CHAR_WIDTH  EQU     8                ;Character pixel width
L_CHAR_HEIGHT EQU    16                ;Character pixel height

L_WHITE_COLOR EQU    0FFFFH
L_BLACK_COLOR EQU    00000H
L_BLUE_COLOR  EQU    00F0FH
L_GREEN_COLOR EQU    008F0H

;-----Other Equates -----

HOLD_STATE   EQU      80H                ;Set Keyboard flag to indicate a Pause is required
NO_HOLD_STATE EQU     7FH                ;To clear the above flag

SW86         EQU      0EDH                ;INPUT FROM THIS PORT SWITCHES THE 8086/80286/80386
/80486 BACK to the Z80 in hardware on Old SMB (& CPU boards)
SW68K        EQU      0ECH                ;INPUT FROM THIS PORT SWITCHES IN THE 68000 CPU
Board Old SMB (& CPU boards)
SW_TMAX      EQU      0EEH                ;OUTPUT TO THIS PORT 01H, SWITCHES THE 8086 Family
of CPU boards in (using the new V2 or V3 SMB Boards (TMA0* goes low)).

STACK_SEG    EQU      0D000H            ;Normally the Stack will be at D000:FFFCH
STACK_POINTER equ     0FFFCH            ;With 1M RAM Stack will normally be at D000:FFFCH
BASE_POINTER  EQU     0E000H            ;Default BP at D000:E000H
CODE_LOAD_SIZE EQU    0F000H/2         ;Size (Words) of code to move from 0:100H in RAM up
to E000:0 to E000:F000H with PATCH "Y",command

START_P32_RAM_TEST EQU 02000000H        ; (32MG Static RAM Board for daughter 80386/80486
Board)
END_P16_RAM_TEST EQU  02FFFFFFFH
END_P32_RAM_TEST EQU  03FFFFFFFH

START_16_RAM_TEST EQU 00100000H         ; (16M Static RAM Board for S100 Bus)
END_8_RAM_TEST EQU   007FFFFFFFH

```

```

END_16_RAM_TEST EQU      00FFFFFFH

;----- 80386/80486 PROTECT MODE EQUATES -----
-----

PM_CS_386      EQU      8H          ;Protect mode 386 code segment offset in Global
Descriptor table (0-4GB)
PM_DS_386      EQU      10H         ;Protect mode 386 data segment offset in Global
Descriptor table (0-4GB)
RM_CS_386      EQU      18H         ;Real mode 386 code segment offset in Global
Descriptor table 64K @ F000:0H (or E000:0H)
RM_DS_386      EQU      20H         ;Real mode 386 data segment offset in Global
Descriptor table 64K @ F000:0H (or E000:0H)
PM_IDT_386     EQU      28H         ;Protect mode 386 code segment for IDT table Jumps

GDT_SEG        EQU      0D000H      ;Note GDT & IDT should be in a RAM location (D0000)
GDT_OFFSET     EQU      0H
GDT_BASE_ADDRESS EQU 0D0000H       ;Absolute 32 bit location of GDT

IDT_SEG        EQU      0D000H      ;IDT location (D0100 - D08FFH)
IDT_OFFSET     EQU      100H
IDT_BASE_ADDRESS EQU 0D0100H       ;Absolute 32 bit location of IDT

IDT_SIZE       EQU      800h        ;Max size for all possible interrupts in Protected
Mode (8*100H)

%if      MONITOR_ROM                ;For code in EEPROM at F0000H

PM_ROM_BASE EQU 0F0000H              ;Absolute position for 32 bit ROM code
ROM_BASE    EQU 0F000H              ;Seg offset for real mode 16 bit code
BASE_16_BIT EQU 0FH                ;Base [23..16] of GDT[3]
IDT_BASE    EQU 0FH                ;Base for PM_IDT_386

%else                                ;For Test code in RAM at E0000H

PM_ROM_BASE EQU 0E0000H              ;Absolute position for 32 bit RAM/Debug code
ROM_BASE    EQU 0E000H              ;Seg offset for real mode 16 bit code
BASE_16_BIT EQU 0EH                ;Base [23..16] of GDT[3]
IDT_BASE    EQU 0EH                ;Base for PM_IDT_386

%endif

; Note we leave the space E0000-EFFFFH empty so we can move test code monitor code into the
RAM area for testing without
; disturbing the GDT and IDT etc. by placing them at D0000H.

;===== Start of BIOS code segment =====
=====

CPU 8086          ;Allow 8086 Opcodes only (This insures JZ, JNZ etc
are within 128 byte range for the 8086)
[BITS 16]        ;Default 16 bit code

SECTION          .text
org      0H      ;<-- This must be 0. All addresses relative to this
location
RAM at E000:0000H with
will be placed at
;For debugging/testing this monitor will reside in
;the stack at D000:FFFCH. In the final EEPROM it
;F000:0000H and the stack still at D000:FFFCH.
;(The IBM PC starts its ROM monitor at F000:E000H).
;Note this monitor will run correctly at any 4K

```

```

boundary in RAM. For example
;to 8000H in RAM. Remember however the CPU starts
at FFFF0H. So you would
;have to have there EAH, 00H,00H,80H,00H to get it
to do a Far JMP to 8000H.
;Also be careful where the stack is. You are on
your own for PM paramater tables!

BEGIN:  jmp     INIT                ;Reset all registers, initilize hardware
        jmp     WARM_INIT          ;warm start
        jmp     CI                 ;console input
        jmp     RI                 ;reader output
        jmp     CO                 ;console output (Character in CL)
        jmp     POO                ;punch output
        jmp     LIST_OUT           ;printer output (Character in CL)
        jmp     CSTS               ;consol status
        jmp     CICO               ;console in with echo
        jmp     LIST_STATUS        ;printer status
        CALL    TRACE_MODE_ON      ;Set/Reset trace flag
        CALL    TRACE_MODE_OFF

INIT:   cld                        ;Set direction up. Through this monitor this is the
        default direction
        cli                        ;Disabel interrupts initially

        MOV     AL,00000000B        ;ALL LED's OFF initially (most were on with Z80),
for VISUAL DIAGNOSTIC show we are alive
        OUT     DIAG_LEDS,AL

        IN      AL,IOBYTE           ;If bit 7 of Port EFH is 0, then skip CPM86 Boot
check. (Note, If 0, RAM disk with CPM3 will appear write protected)
        AND     AL,80H             ;If bit 7 is 1 then see if CPM86/MSDOS is present
in RAM at 0000:0500H
        JZ      ToMonitor          ;IF so, then jump to that loction.

        MOV     BX,500H            ;Normally my CPM86.COM (or MSDOS.COM) program will
have 90H,90H in RAM at 500H.
;So in CPM+ one can type "CPM86" and boot up the
CPM86 system directly from CPM+

        MOV     AX,0               ;Check this value is here. If so, chances are we
have CPM86 or MSDOS loaded (but unutilized) in RAM
        MOV     DS,AX              ;If not then skip to this monitor
        CMP     word[BX],9090H     ;Was it a reset requiring CPM86.
        JNZ     ToMonitor          ;Set pointers for IBM-PC BIOS interrupt vectors in
low RAM

;NOTE: The only problem with the above is if you
reset your system and 90H,90H is still
in RAM at 500H, switching the 8086 back in (Z80 "O
" CMD) will probably crash as the monitor
will transfer control down to an already
initilized CPM86 system.
;The solution is simply first erase the 90H,90H in
RAM @ 500H or use the above IOBYTE switch method.
;If you don't like the above option, just comment
out this code and jump directly to "ToMonitor"

CPM86Boot:
        JMP     word 0000H:500H    ;Far Jump to 500H in RAM (where CPM86 resides)

ToMonitor:
        ;If not, then jump to this 8086 Monitor in ROM
        (Note many routines below circle back to here)
        cld                        ;Set direction up "UP" troughout this monitor, this
is the default direction

```



```

    mov     al,MasterICW1           ;from "locking up" after a power on).
    out     MASTER_PIC_PORT,al
    mov     al,MasterICW2           ;Ints start at 20H in RAM
    out     MASTER_PIC_PORT+1,al
    mov     al,MasterICW4           ;No slaves above, so 8259A does not expect ICW3
    out     MASTER_PIC_PORT+1,al

    mov     al,11111111b           ;Allow No Ints on 8259A for now
    out     MASTER_PIC_PORT+1,al

    MOV     AL,1111000B             ;4th LED ON, VISUAL DIAGNOSTIC
    OUT     DIAG_LEDS,AL

    mov     bx,SMMSG_REAL3
    call    SPEAK_STRING           ;Speak out signon the message

    MOV     AL,1111000B             ;5 LED's ON if speech sent
    OUT     DIAG_LEDS,AL

    mov     bx,SHOWSTACK
    call    PRINT_STRING           ;Show current stack position
    MOV     AX,SS
    CALL    AX_HEXOUT
    MOV     CL,':'
    CALL    CO
    MOV     AX,SP
    CALL    AX_HEXOUT
    CALL    CRLF

    %if     LOCAL_ROM               ;Are we reading from onboard ROM on Baby 80486
    mov     bx,ROM_MSG
    call    PRINT_STRING           ;Indicate we are running from onboard local ROM
    %endif
    ;     CALL     SETUP_INT_TABLE     ;Setup RM default INT jump table in RAM 0-3FFH

    mov     al,01111111b           ;Send 7FH to 8259A and check it is there
    out     MASTER_PIC_PORT+1,al
    in      AL,MASTER_PIC_PORT+1
    CMP     AL,01111111b           ;Should get same value back if 8259A is present
    JZ      PIC_OK

    mov     bx,NO_8259A_MSG
    call    PRINT_STRING           ;Send 8259A not found message
    ;Note up until now stack was not used

PIC_OK:  mov     al,11111111b           ;Allow No Ints on 8259A for now
    out     MASTER_PIC_PORT+1,al

    MOV     AL,1111100B             ;6 LED's off if 8259A section done
    OUT     DIAG_LEDS,AL

    IN      AL,KEYIN               ;Flush keyboard

WARM_INIT:
    cld                               ;Set direction up
    cli                               ;Disabel interrupts
    mov     ax,cs                    ;Note cs always will be F000H (or E000H when
    testing)
    mov     ds,ax                    ;DS & ES will be set to F000H as default values
    within this monitor
    mov     es,ax

MAINLOOP:
    mov     bx,CLEANUP
    call    PRINT_STRING           ;Clear line and '>'

```

```

call    CICO                ;Get a command from Console

mov     ah,0
cmp     al,'A'
jb     WARM_INIT           ;must be A to Z
cmp     al,'Z'
jg     WARM_INIT
sub     al,'A'              ;calculate offset
shl    al,1                ;X 2
add     ax,ctable
mov     bx,ax
mov     ax,[CS:BX]         ;Get location of routine
CALL    AX                  ;<-----This is the Main Monitor CMD call
jmp     WARM_INIT

```

```

;***** Basic Monitor Commands *****
;----- PRINT MENU ON CRT -----
;-----
KCMD:   MOV     BX,MAIN_MENU
        CALL    PRINT_STRING
        RET

;----- MAP the 1MG Address space -----
;-----
MAP:    call    CRLF                ;Display complete memory map with R=ram, P=PROM and
        ". " empty space
        mov     ax,0
        mov     ds,ax              ;Must start in first segment in DS:
        mov     dl,64              ;character count
        mov     dh,4               ;segment counter(4 lines per segment)
        mov     SI,ax              ;need to reset bx (ds = 0 already)
        call    SHOW_ADDRESS_DS    ;start with address, Send to console the address DS
        +SI

map1:   mov     ax,[SI]             ;remember ds is assumed
        not     ax                 ;complement data
        mov     [SI],ax
        cmp     ax,[SI]           ;did it change
        jne    not_ram
        not     ax                 ;correct data
        mov     [SI],ax
        mov     cl,'R'
        jmp     nextbk            ;get next block

not_ram:cmp     ax,0               ;ffff->0 must be ROM if not 0
        jne    prom
        mov     cl, '.'           ;no need to correct data for here
        jmp     nextbk            ;get next block

prom:   mov     cl,'p'
nextbk: call    CO                 ;send the R,P or ". "

        ADD     SI,100H           ;check every 100h at a time
        dec     dl                ;64X1000H across
        jnz    map1              ;one line of 64K done

        mov     dl,64             ;reset counter for next line
        dec     dh                ;segment counter

```

```

        jnz     noseg
        mov     ax,ds
        add     ax,1000h
        jc     mapdone
        mov     ds,ax
        mov     dh,4
noseg:  CALL    CRLF_CHECK           ;Print current address at start of each line, check
        for abort as well
        call   SHOW_ADDRESS_DS
        jmp    map1
mapdone:ret

```

```

;-----Fill memory with a constant value. Up to 64K bytes from xxxxxH to xxxxxH-----
-----

```

```

FILL:   CALL    GET5DIGITS           ;Get (up to) 20 bit parameter. 16 bit value (4
        digits) to DI.
                                           ;If 5 digits, then the first digit is put in ES
        (highest nibble)
        PUSH   ES
        PUSH   DI                   ;Save start address for now = ES:DI
        CALL   GET5DIGITS
        MOV    SI,DI                 ;Put end address in DS:SI
        MOV    AX,ES
        MOV    DS,AX                ;If 5 digits, then the first digit is put in DS
        POP    DI
        POP    ES                   ;Start=ES:DI  End=DS:SI
        CALL   CLENGTH              ;Length cx = (ds:si-es:di)+1, if >64K then err
        CALL   GET2DIGITS           ;Fill value to AL (CX unaltered)
                                           ;ES:DI = start address, (DS:SI = end address, not
        used), CX = count, AL = fill value
filoop: mov     [ES:DI],al           ;Note RAM is es:[di], count in CX
        inc     DI
        CMP    DI,0                 ;Check if we are crossing a segment boundary
        JNZ   filoop1
        MOV    AX,ES
        ADD    AX,1000H
        MOV    ES,AX
filoop1:loop   filoop              ;Dec CX to 0
        ret

```

```

;-----Display memory contents (bytes)

```

```

DISPLAY_RAM_BYTES:
        CALL   GET5DIGITS           ;Get (up to) 20 bit parameter. 16 bit value (4
        digits) to DI.
                                           ;If 5 digits, then the first digit is put in ES
        (highest nibble)
        PUSH   ES
        PUSH   DI                   ;Save start address for now.
        CALL   GET5DIGITS

```



```

        MOV     SI,DI                ;Put end address in SI
        MOV     AX,ES
        MOV     DS,AX                ;If 5 digits, then the first digit is put in DS

        POP     DI
        POP     ES                    ;Start=ES:DI  End=DS:SI

;
        AND     DI,0FFF0h            ;even up printout
        OR      SI,000Fh            ;also nice ending for Ray G.

        call    CLENGTH              ;Length cx = (ds:si-es:di)+1, if length > 64K then ✎
        err

dloop6: CALL    CRLF_CHECK            ;Note BX,CX is saved, ESC at keyboard will abort
        call    SHOW_ADDRESS_ES      ;Send start address

        MOV     DL,16                ;First print a line of 16 Hex byte values
        PUSH    CX
        PUSH    DI
        PUSH    ES

dloop1: mov     al,[es:di]            ;Will increment DI
        call    AL_HEXOUT
        call    BLANK
        call    Inc_DI_boundry_check ;Will increase DI
        DEC     DL                    ;Have we done 16 bytes yet
        jnz     dloop1

        ;Now print ascii for those 16 bytes
        mov     cx,6
        call    TABS

        MOV     DL,16                ;16 across again
        POP     ES
        POP     DI
        POP     CX

dloop2: mov     al,[es:DI]
        and     al,7fh
        cmp     al,' '                ;filter out control characters
        jnc     dloop3

dloop4: mov     al,'.'
dloop3: cmp     al,'~'
        jnc     dloop4
        PUSH    CX
        mov     cl,al
        call    CO
        POP     CX
        loop    dloop5                ;--CX has total byte count
        ret

dloop5: call    Inc_DI_boundry_check ;Have we done 16 bytes yet
        DEC     DL
        jnz     dloop2
        JMP     dloop6

Inc_DI_boundry_check:                ;Check if we are crossing a segment boundary
        inc     DI                    ;If so, inc [ES]
        CMP     DI,0
        JNZ     bounds1
        MOV     AX,ES
        ADD     AX,1000H
        MOV     ES,AX

bounds1:RET

Inc_SI_boundry_check:                ;Check if we are crossing a segment boundary
        inc     SI                    ;If so, inc [DS]

```

```

        CMP     DI,0
        JNZ     bounds2
        MOV     AX,DS
        ADD     AX,1000H
        MOV     DS,AX
bounds2:RET

;-----DISPLAY Words Memory -----
;
; This routine forces the CPU to do RAM word reads rather than a byte reads.
; It is used to test the hardware's ability to do 16 bit reads on odd and even
; addresses.
; This is very important. "Normal" byte reads will not show such a hardware problem.
; A block or RAM/ROM read with the "D" & "P" commands must be identical

DISPLAY_RAM_WORDS:
        CALL    GET5DIGITS           ;Get (up to) 20 bit parameter. 16 bit value (4
        digits) to DI.                ;If 5 digits, then the first digit is put in ES
        (highest nibble)
        PUSH    ES
        PUSH    DI                   ;Save start address for now.

        CALL    GET5DIGITS
        MOV     SI,DI                 ;Put end address in SI
        MOV     AX,ES
        MOV     DS,AX                ;If 5 digits, then the first digit is put in DS

        POP     DI
        POP     ES                   ;Start=ES:DI End=DS:SI

;
; AND     DI,0FFF0h                 ;even up printout
; OR      SI,000Fh                  ;also nice ending for Ray Gluck.

        call    CLENGTH               ;Length cx = (ds:si-es:di)+1, if length > 64K then
        err                                         ;
        shr     cx,1                  ;divide by 2 because words

wdloop6:CALL    CRLF_CHECK             ;Note BX,CX is saved, ESC at keyboard will abort
        call    SHOW_ADDRESS_ES       ;Send start address

        MOV     DL,8                  ;First print a line of 16/2 Hex byte values
        PUSH    CX
        PUSH    DI
        PUSH    ES

wdloop1:mov     ax,[es:di]             ;Will increment DI
        call    AL_HEXOUT
        call    BLANK
        mov     al,ah
        call    AL_HEXOUT
        call    BLANK
        call    Inc_DI_boundry_check   ;Will increase DI
        call    Inc_DI_boundry_check   ;Will increase DI
        DEC     DL                    ;Have we done 16 bytes yet
        jnz    wdloop1

;Now print ascii for those 16 bytes
        mov     cx,8
        call    TABS

        MOV     DL,8                  ;16/2 across again
        POP     ES
        POP     DI
        POP     CX

wdloop2:mov     ax,[es:DI]
        push    ax

```

```

        and     al,7fh
        cmp     al,' '           ;filter out control characters
        jnc     wdloop3
wdloop4:mov     al, '.'
wdloop3:cmp     al, '~'
        jnc     wdloop4
        PUSH    CX
        mov     cl,al
        call   CO
        POP     CX
        pop     ax

        mov     al,ah
        and     al,7fh
        cmp     al,' '           ;filter out control characters
        jnc     wdloop7
wdloop8:mov     al, '.'
wdloop7:cmp     al, '~'
        jnc     wdloop8
        PUSH    CX
        mov     cl,al
        call   CO
        POP     CX
        loop   wdloop5           ;--CX has total byte count
        ret

wdloop5:call    Inc_DI_boundry_check
        call    Inc_DI_boundry_check
        DEC     DL               ;Have we done 16 bytes yet
        jnz     wdloop2
        JMP     wdloop6

```

;-----MOVE Memory -----

```

MOVE:   CALL    GET5DIGITS           ;Get (up to) 20 bit parameter. 16 bit value (4
        digits) to DI.
                                           ;If 5 digits, then the first digit is put in ES
        (highest nibble)
        PUSH    ES                 ;Do everything relative to first ES value
        PUSH    DI                 ;Save start address for now.

        CALL    GET5DIGITS
        MOV     SI,DI              ;Put end address in SI
        MOV     AX,ES
        MOV     DS,AX             ;If 5 digits, then the first digit is put in DS

        POP     DI
        POP     ES                 ;Start=ES:DI  End=DS:SI

        call    CLENGTH           ;Length cx = (ds:si-es:di)+1, if length > 64K then
        err
                                           ;
        PUSH    ES
        PUSH    DI                 ;Save Start Address ES:DI
        PUSH    CX                 ;Save length

        CALL    GET5DIGITS           ;For Destination, get (up to) 20 bit parameter. 16
        bit value (4 digits) to DI.
        MOV     SI,DI              ;Put destination address in DS:SI
        MOV     AX,ES
        MOV     DS,AX             ;If 5 digits, then the first digit is put in DS

        POP     CX                 ;Get length

```

```

        POP     DI                ;Get start ES:DI destination DS:SI
        POP     ES                ;Get back the initial ES value (often 0)

MOVE1:  MOV     AL,[ES:DI]        ;Note cannot use MOVS opcode because of segment
        MOV     [DS:SI],AL
        CALL    Inc_DI_boundary_check ;Check if we are crossing a segment boundary
        CALL    Inc_SI_boundary_check
MOVE3:  LOOP   MOVE1
        RET

;-----SUBSTITUTE Memory -----
-

SUBSTITUTE:
        CALL    GET5DIGITS        ;Get (up to) 20 bit parameter. 16 bit value (4
        MOV     DI,DI            digits) to DI.
                                   ;If 5 digits, then the first digit is put in ES
        MOV     DI,DI            (highest nibble)
nusloop:CALL    CRLF
        call    SHOW_ADDRESS_ES
        mov     cx,8              ;Display 8 bytes per line
sloop:  call    BLANK
        mov     al,[es:DI]
        push   cx
        push   ax
        call   AL_HEXOUT
        mov    cl,'-'
        call   CO
        pop    ax
        pop    cx
        call   GET2DIGITS        ;Get 8 bit value (2 digits) to AL. (BX, CX & DX
        MOV     AH,AH            Unchanged), terminator in AH
        cmp    ah,CR             ;CR signals we are done
        je     qtest
        cmp    ah,ESC           ;Also ESC
        je     qtest
        cmp    ah,' '           ;is a SP so skip to next byte
        je     snext1
        mov    [es:DI],al
snext1: inc    DI
        CMP    DI,0
        JNZ   snext2
        MOV   AX,ES
        ADD   AX,1000H
        MOV   ES,AX
snext2: loop  sloop
        jmp   nusloop
qtest:  ret

;-----Verify Memory Contents -----

VERIFY: CALL    GET5DIGITS        ;Get (up to) 20 bit parameter. 16 bit value (4
        MOV     DI,DI            digits) to DI.
                                   ;If 5 digits, then the first digit is put in ES
        MOV     DI,DI            (highest nibble)
        PUSH   ES                ;Do everything relative to first ES value
        PUSH   DI                ;Save start address for now.
        CALL   GET5DIGITS

```

```

MOV     SI,DI                ;Put end address in DS:DI
MOV     AX,ES
MOV     DS,AX                ;If 5 digits, then the first digit is put in DS

POP     DI
POP     ES                    ;Start=ES:SI  End=DS:DI

call    CLENGTH              ;Length cx = (ds:si-es:di)+1, if length > 64K then ✎
err

PUSH    ES
PUSH    DI                    ;Save Start Address
PUSH    CX                    ;Save length

CALL    GET5DIGITS           ;For Destination, get (up to) 20 bit parameter. 16 ✎
bit value (4 digits) to DI.
MOV     SI,DI                ;Put destination address in DS:SI
MOV     AX,ES
MOV     DS,AX                ;If 5 digits, then the first digit is put in DS

POP     CX
POP     DI
POP     ES                    ;Get back the initial ES value (often 0)

MOV     BX,0                  ;Count of mis-matches

VERIFY1:MOV    AL,[ES:DI]     ;cannot use cmps because of segments
CMP     AL,[DS:SI]
JZ     MATCH_OK
call    verr
MATCH_OK:
INC     DI
CMP     DI,0                  ;Check if we are crossing a segment boundary
JNZ    VERIFY2
MOV     AX,ES
ADD     AX,1000H
MOV     ES,AX

VERIFY2:INC    SI
CMP     SI,0                  ;Check if we are crossing a segment boundary
JNZ    VERIFY3
MOV     AX,DS
ADD     AX,1000H
MOV     DS,AX

VERIFY3:LOOP   VERIFY1
CMP     BX,0                  ;Was there any errors
JNZ    TOTAL_MISMATCHES
MOV     BX,MATCHES_OK
CALL    PRINT_STRING
TOTAL_MISMATCHES:
RET

verr:   CMP     BX,0          ;Save count, print error
JNZ    SKIP_DIFF_MSG

PUSH    DS
MOV     AX,CS
MOV     DS,AX
MOV     BX,DIFF_Header_Msg
CALL    PRINT_STRING
POP     DS

SKIP_DIFF_MSG:
CALL    CRLF                  ;There is a mis-match show values
call    SHOW_ADDRESS_ES

```

```

    PUSH    CX

    MOV     CX,6
    call   TABS
    mov     al,[ES:DI]
    PUSH   AX
    call   AL_HEXOUT
    CALL   BLANK
    POP    AX
    call   AL_BINOUT

    MOV     CX,5
    call   TABS
    call   SHOW_ADDRESS_DS

    MOV     CX,6
    call   TABS
    mov     al,[ds:SI]
    PUSH   AX
    call   AL_HEXOUT
    CALL   BLANK
    POP    AX
    call   AL_BINOUT

    POP    CX
    call   CTRL_CHECK
    INC    BX                ;This prevents the header being show each time
    RET

;----- Simple test of RAM (Continuous)-----

TEST_RAM:
    mov     bx,JMSG                ;"Continous RAM 0-1MB hardware test."
    call   PRINT_STRING

    CALL   GET5DIGITS                ;Get (up to) 20 bit parameter. 16 bit value (4
digits) to DI.                                ✓
                                           ;If 5 digits, first digit entered to ES (Highest
nibble)                                       ✓
    PUSH   ES
    PUSH   DI                ;Save start address for now.

    CALL   GET5DIGITS
    MOV    SI,DI                ;Put end address in DS:SI
    MOV    AX,ES
    MOV    DS,AX                ;If 5 digits, then the first digit is put in DS

    POP    DI
    POP    ES                ;Start=ES:BX  End=DS:DX

    CALL   CLENGTH                ;Length cx = (ds:SI-es:DI)+1, if length > 64K then ✓
    err

    MOV    DX,0                ;Test loop count

    PUSH   CX                ;CX has length
    mov    bx,STARTJMSG        ;Test memory until ESC
    call   PRINT_STRING
    POP    CX

mtest1: push    cx
        push    di

mtloop: mov     al,[es:DI]
        mov     ah,al                ;Store value currently in RAM
        not    al

```

```

        mov     [es:DI],al
        mov     al,[es:DI]
        not     al
        cmp     al,ah
        jne     terr
        mov     [es:DI],ah
tnext:  inc     DI
        CMP     DI,0
        JNZ     tnext2
        mov     AX,ES
        ADD     ax,1000H
        MOV     ES,AX
tnext2: call    CTRL_CHECK           ;See if an abort is requested
        loop   mtloop              ;Repeat for "length" number of bytes

        mov     bx,RAM_Test_Count
        CALL    PRINT_STRING
        inc     dx
        MOV     AX,DX
        CALL    AX_HEXOUT
        mov     bx,H_MSG           ;H.
        CALL    PRINT_STRING
        pop     di                 ;Repeat the whole process
        pop     cx
        jmp     mtest1            ;test forever

terr:   push    DX
        mov     dx,ax              ;save data in dx
        CALL    CRLF
        call    SHOW_ADDRESS_ES
        mov     ax,dx              ;get back data
        xor     al,ah              ;identify bits
        mov     dx,ax
        call    AL_HEXOUT
        call    BLANK
        mov     ax,dx
        call    AL_BINOUT
        pop     dx
        jmp     tnext

;----- QUERY PORTS -----

QUERY:  call    CICO                ;is it input or output
        cmp     al,'I'
        jz     input
        cmp     al,'O'
        jz     output
        jmp     ERR                ;if not QI or QO then error

input:  call    GET4DIGITS           ;Get 8 or 16 bit value (2 or 4 digits) to DI,
        terminator in AH
        call    CRLF
        mov     dx,DI
        in     al,dx              ;Note will assume here we have just an 8 bit port
        push   ax
        call    AL_HEXOUT         ;Show value in HEX
        call    BLANK
        pop    ax
        call    AL_BINOUT         ;Show value in binary
        ret

```

```

output: call    GET4DIGITS                ;Get 8 or 16 bit value (2 or 4 digits) to DI,
        terminator in AH
        mov     dx,DI
        CALL   GET2DIGITS                ;Output value to AL (BX unaltered)
        PUSH   AX
        CALL   CRLF
        POP    AX
        out    dx,al                    ;Send 8 bit value in AL to port at [DX]
        RET

```

;----- GO TO A RAM LOCATION -----

```

GOTO:   mov     bx,GET_SEG_MSG            ;Segment=
        call   PRINT_STRING
        call   GET4DIGITS                ;Get (up to) 16 bit value (4 digits) to BX.
        PUSH   DI                        ;Save Segment (in [DI]) on stack

        mov     bx,GET_OFFS_MSG          ;Offset=
        call   PRINT_STRING
        call   GET4DIGITS                ;Get (up to) 16 bit value (4 digits) to BX.
        PUSH   DI                        ;Save Offset (in [DI]) on stack
        RETF                               ;Will pop offset, then CS and go there Note RETF!

```

;----- SWITCH CONTROL BACK TO Z80 (Master) -----

```

Z80:    in      al,SW86                  ;This switches control back over to Z80 using old
        SMB
        nop
        nop
        MOV     AL,00                    ;Utilize the more specific circuit on the V2-SMB
        OUT    SW_TMAX,AL                ;Make sure its bit 0 this raises TMA0*
        NOP
        NOP
        NOP
        NOP
        NOP
        NOP
        NOP
        NOP
        NOP
        JMP     BEGIN

```

;----- HEX MATH -----

```

HEXMATH:
        mov     bx,MATH_MSG              ;HEX MATH
        call   PRINT_STRING
        call   GET4DIGITS
        push   DI                        ;save data for the moment
        call   GET4DIGITS
        push   DI
        mov     bx,MATH_HEADER1
        call   PRINT_STRING
        pop    DI                        ;get back data2 (DI=data2)
        pop    BX                        ;and data1 (BX=data1)

        push   DI                        ;save them again for below
        push   BX

```



```

add     BX,DI
call    BX_HEXOUT           ;Show addition (data1+data2)
mov     bx,MATH_HEADER2
call    PRINT_STRING
pop     BX                   ;get back data1 one more time
pop     DI                   ;and data2
sub     bx,DI                ;data1-data2
call    BX_HEXOUT
MOV     BX,H_MSG_CRLF
call    PRINT_STRING
ret

```

```

;----- "PATCH" This is a quick and dirty patch to test RAM versions of this code loaded via CPM.

```

```

PATCH: MOV     AX,0E000H
MOV     ES,AX
MOV     DI,0000H           ;Will place code at E000:0H
XOR     AX,AX
MOV     DS,AX
MOV     SI,100H           ;Will load code from 0:100H (typically put here with CPM SID)
MOV     CX,CODE_LOAD_SIZE ;Size (Words) of code to move from 0:100H in RAM up to E000:0 to E000:F000H with PATCH "Y",command
STD
additions
CLI
REP     MOVSW              ;[DS:SI] -> [ES:DI], CX--

mov     bx,PATCH_1_MSG    ;Explain what was moved to where
call    PRINT_STRING
MOV     AX,SI
SUB     AX,2H
CALL    AX_HEXOUT
mov     bx,PATCH_2_MSG
call    PRINT_STRING
MOV     AX,DI
SUB     AX,2H
CALL    AX_HEXOUT
MOV     BX,PATCH_3_MSG
call    PRINT_STRING

JMP     word 0E000H:0000H ;Far Jump to E000H:0000H
;DB 0EAH,00H,00H,00H,0E0H

```

```

;----- Display all active IO input ports in the system -----
; 64K of 16 & 8 bit ports

```

```

INPORTS:mov     bx,PORTS_IN_MSG
call    PRINT_STRING
MOV     SI,0FFFFH        ;Display 12 lines, 4 ports across
MOV     BP,0000H        ;Will contain port number

LOOPIO: MOV     DX,BP
CMP     DL,SW86         ;INPUT FROM THIS PORT SWITCHES THE 80286 BACK TO THE Z80 (SKIP)
JZ     NEXT_P
CMP     DL,SW68K        ;INPUT FROM THIS PORT SWITCHES IN THE 68K CPU (Do not activate)
JZ     NEXT_P

IN     AX,DX            ;Is it 0FFFFH
CMP     AX,0FFFFH

```

```

        JZ      NEXT_P          ;If so skip

        MOV     AX,BP
        CALL   AX_HEXOUT      ;Print Port Address
        MOV     CL,'-'
        CALL   CO              ;Put in a "-->"
        MOV     CL,'>'
        CALL   CO
        MOV     DX,BP
        IN     AX,DX          ;Get port WORD data (note, 8 bits even port Input ↙
will be in AH)
        CALL   AX_HEXOUT
        CALL   BLANK
        MOV     CL,'-'
        CALL   CO              ;Put in a "-->"
        MOV     CL,'>'
        CALL   CO
        MOV     DX,BP
        IN     AL,DX          ;Get port BYTE data
        CALL   AL_HEXOUT

SKIP2:  CALL   BLANK          ;4 ports across
        CALL   BLANK

        INC     SI            ;Next cursor position count
        MOV     AX,SI
        AND     AX,0003H
        CMP     AX,0003H
        JNZ    NEXT_P
        CALL   CRLF

NEXT_P: INC     BP            ;Next Port until 0000H
        OR     BP,BP
        JZ     SKIP3
        MOV     AX,BP
        AND     AX,00FFH      ;256 ports at a time
        JNZ    LOOPIO
        mov    BX,MORE_MSG    ;Contineue (Y/N)
        call   PRINT_STRING
        call   CICO
        cmp    al,'Y'
        JNZ    SKIP3
        CALL   CRLF
        JMP    LOOPIO

SKIP3:  CALL   CRLF          ;Routine done/aborted
        RET

REGISTERS:                                ;RM Display 16 bits of all the 80386/80486 ↙
        Registers
        PUSH   AX            ;Save everything. Assume an 8086
        PUSH   BX
        PUSH   CX
        PUSH   DX
        PUSH   SI
        PUSH   DI
        PUSH   BP

        PUSHF
        PUSHF
        PUSH   SP          ;we will display reverse this order
        PUSH   BP
        PUSH   DI
        PUSH   SI

```

```
PUSH    DX
PUSH    CX
PUSH    BX
PUSH    AX

MOV     BX,INT_AX_MSG           ;"AX="
CALL    PRINT_STRING
POP     AX
CALL    AX_HEXOUT

MOV     BX,INT_BX_MSG           ;"H BX="
CALL    PRINT_STRING
POP     AX
CALL    AX_HEXOUT

MOV     BX,INT_CX_MSG           ;"H CX="
CALL    PRINT_STRING
POP     AX
CALL    AX_HEXOUT

MOV     BX,INT_DX_MSG           ;"H DX="
CALL    PRINT_STRING
POP     AX
CALL    AX_HEXOUT

MOV     BX,INT_SI_MSG           ;"SI="
CALL    PRINT_STRING
POP     AX
CALL    AX_HEXOUT

MOV     BX,INT_DI_MSG           ;"DI="
CALL    PRINT_STRING
POP     AX
CALL    AX_HEXOUT

MOV     BX,INT_BP_MSG           ;"BP="
CALL    PRINT_STRING
POP     AX
CALL    AX_HEXOUT

MOV     BX,INT_SP_MSG           ;"SP="
CALL    PRINT_STRING
POP     AX
ADD     AX,14                    ; Adjust because we first saved stuff above
(PUSHF)
CALL    AX_HEXOUT

MOV     BX,INT_FLAGS_MSG        ;[Flags]=
CALL    PRINT_STRING
POP     AX                        ;Flags to AX
MOV     AL,AH
CALL    AL_BINOUT                ;Output lower 16 bits
POP     AX
CALL    AL_BINOUT

MOV     BX,INT_CS_MSG           ;"CS="
CALL    PRINT_STRING
MOV     AX,CS
CALL    AX_HEXOUT

MOV     BX,INT_DS_MSG           ;"DS="
CALL    PRINT_STRING
MOV     AX,DS
CALL    AX_HEXOUT
```

```

MOV     BX,INT_ES_MSG           ;"ES="
CALL    PRINT_STRING
MOV     AX,ES
CALL    AX_HEXOUT

MOV     BX,INT_SS_MSG           ;"SS="
CALL    PRINT_STRING
MOV     AX,SS
CALL    AX_HEXOUT


MOV     BX,INT_FS_MSG           ;"FS="
CALL    PRINT_STRING
MOV     AX,FS
CALL    AX_HEXOUT

MOV     BX,INT_GS_MSG           ;"GS="
CALL    PRINT_STRING
MOV     AX,GS
CALL    AX_HEXOUT

MOV     BX,H_MSG_CRLF
CALL    PRINT_STRING

POP     BP                       ;Get Back Everything
POP     DI
POP     SI
POP     DX
POP     CX
POP     BX
POP     AX
RET

```

;----- THIS IS A ROUTINE TO SET THE CURRENT TIME & DATE FOR THE DALLAS RTC CHIP ON THE MS- DOS SUPPORT BOARD -----

SET_TIME_DATE:

```

CALL    RAW_GETTIME             ;First Show Time/Date
CALL    CRLF                     ;First set Time

MOV     BX,SET_TIME_MSG
CALL    PRINT_STRING
CALL    CICO
CMP     AL,'Y'
JZ     SET_TIME0
RET

```

SET_TIME0:

```

CALL    InputTime               ;CH = HOURS, CL = Minutes, DH = Seconds all in BCD
CALL    UPD_IN_PR               ;CHECK FOR UPDATE IN PROCESS
JNC     SET_TIME1               ;GO AROUND IF OK
JMP     RTC_ERROR               ;IF ERROR

```

SET_TIME1:

```

PUSH    DX                       ;Save Data
MOV     DL,-2                    ;-2 goes to 0 for PORT_INC_2
CLI                                           ;INTERRUPTS OFF DURING WRITES

CALL    PORT_INC_2               ;SET ADDRESS OF SECONDS
POP     DX
MOV     AL,DH
OUT     CMOS_PORT+1,AL           ;Send Seconds

CALL    PORT_INC_2               ;SET ADDRESS OF MINUTES
MOV     AL,CL

```

```

        OUT     CMOS_PORT+1,AL           ;Send Minutes

        CALL   PORT_INC_2               ;SET ADDRESS OF HOURS
        MOV    AL,CH
        OUT    CMOS_PORT+1,AL           ;Send Hours

        CALL   CRLF

        CALL   UPD_IN_PR                 ;Now Set date
        JNC   SET_DATE1                 ;CHECK FOR UPDATE IN PROCESS
        JNC   SET_DATE1                 ;GO AROUND IF OK
        JMP   RTC_ERROR                 ;IF ERROR

SET_DATE1:
        CALL   InputDate                 ;CH = CENTURY, CL = Year, DH = Month, DL = Day all ✓
        in BCD
        PUSH   DX
        PUSH   DX
        MOV    DL,6
        CLI                                     ;INTERRUPTS OFF DURING WRITES

        CALL   PORT_INC                 ;SET ADDRESS OF DAYS (Port 7)
        POP    DX
        MOV    AL,DL
        OUT    CMOS_PORT+1,AL           ;Send Days

        CALL   PORT_INC                 ;SET ADDRESS OF MONTHS
        POP    DX
        MOV    AL,DH
        OUT    CMOS_PORT+1,AL           ;Send Months

        CALL   PORT_INC                 ;SET ADDRESS OF YEARS
        MOV    AL,CL
        OUT    CMOS_PORT+1,AL           ;Send Seconds

        MOV    DL,31H
        CALL   PORT_INC                 ;POINT TO CENTURY BYTE SAVE AREA
        MOV    AL,CH
        OUT    CMOS_PORT+1,AL           ;Send Century

        JMP    RAW_GETTIME

;----- THIS IS A ROUTINE TO PLACE TIME & DATE ON CONSOLE AT THE CURRENT CURSOR POSITION --✓
-----

RAW_GETTIME:
        CALL   CRLF
        MOV    BX,Time_Msg
        CALL   PRINT_STRING
        CALL   LOAD_TIME
        CALL   DisplayTime

        MOV    BX,GAP_Msg
        CALL   PRINT_STRING

        MOV    BX,Date_Msg
        CALL   PRINT_STRING
        CALL   LOAD_DATE
        CALL   DisplayDate
        RET

LOAD_TIME:
        CALL   UPD_IN_PR                 ;Load up registers with TIME info
        JNC   RTC_2A                   ;CHECK FOR UPDATE IN PROCESS
        JNC   RTC_2A                   ;GO AROUND IF OK

```

```

        JMP      RTC_ERROR          ;IF ERROR

RTC_2A: MOV      DL,-2              ;-2 goes to 0 for PORT_INC_2
        CLI                      ;INTERRUPTS OFF DURING READ
        CALL    PORT_INC_2        ;SET ADDRESS OF SECONDS
        IN      AL,CMOS_PORT+1    ;Get BCD value returned
        MOV     DH,AL             ;SAVE IN DH
        CALL    PORT_INC_2        ;SET ADDRESS OF MINUTES
        IN      AL,CMOS_PORT+1    ;Get BCD value returned
        MOV     CL,AL            ;SAVE IN CL
        CALL    PORT_INC_2        ;SET ADDRESS OF HOURS
        IN      AL,CMOS_PORT+1    ;Get BCD value returned
        STI
        MOV     CH,AL            ;SAVE
        MOV     DL,0             ;SET DL TO ZERO
        CLC                      ;Clear carry flag to indicate all is OK
        RET

LOAD_DATE:                                ;Load up registers with Date info
        CALL    UPD_IN_PR         ;CHECK FOR UPDATE IN PROCESS
        JNC     RTC_2B           ;GO AROUND IF OK
        JMP     RTC_ERROR        ;IF ERROR

RTC_2B: MOV      DL,6
        CLI                      ;INTERRUPTS OFF DURING READ
        CALL    PORT_INC         ;POINT TO DAY
        IN      AL,CMOS_PORT+1
        MOV     CH,AL            ;TEMPORY SAVE HERE (Return in DL)

        CALL    PORT_INC         ;POINT TO MONTH
        IN      AL,CMOS_PORT+1
        MOV     DH,AL            ;SAVE

        CALL    PORT_INC         ;POINT TO YEAR
        IN      AL,CMOS_PORT+1
        MOV     CL,AL            ;SAVE
        MOV     DL,31H           ;POINT TO CENTURY BYTE SAVE AREA
        CALL    PORT_INC         ;
        IN      AL,CMOS_PORT+1   ;GET VALUE
        STI
        MOV     DL,CH            ;GET DAY BACK
        MOV     CH,AL
        CLC                      ;Clear carry flag to indicate all is OK
        RET

RTC_ERROR:
        MOV     BX,TIME_ERROR_MSG
        CALL    PRINT_STRING
        STI
        STC                      ;Set carry flag to indicate all is NOT OK
        RET                      ;Back to main menu

PORT_INC:
        INC     DL                ;INCREMENT ADDRESS
        MOV     AL,DL
        OUT    CMOS_PORT,AL
        RET

PORT_INC_2:
        ADD    DL,2              ;INCREMENT ADDRESS
        MOV     AL,DL
        OUT    CMOS_PORT,AL
        RET

INITIALIZE STATUS:
        PUSH   DX                ;Initilize the RTC
        ;SAVE

```

```

        MOV     DL,09H
        CLI                                 ;INTERRUPTS MASKED DURING RESET
        CALL    PORT_INC
        MOV     AL,26H
        OUT     CMOS_PORT+1,AL             ;INITIALIZE 'A' REGISTER
        CALL    PORT_INC
        MOV     AL,82H                     ;SET 'SET BIT' FOR CLOCK INITIALIZATION
                                                ;AND 24 HOUR MODE
        OUT     CMOS_PORT+1,AL             ;INITIALIZE 'B' REGISTER
        CALL    PORT_INC
        IN      AL,CMOS_PORT+1             ;READ REGISTER 'C' TO INITIALIZE
        CALL    PORT_INC
        IN      AL,CMOS_PORT+1             ;READ REGISTER 'D' TO INITIALIZE
        STI
        POP     DX                         ;RESTORE
        RET

UPD_IN_PR:                                ;Check we are ready to read clock
        PUSH    CX
        MOV     CX,600                     ;SET LOOP COUNT
UPDATE:  MOV     AL,0AH                     ;ADDRESS OF [A] REGISTER
                                                ;INTERRUPTS MASKED DURING RESET
        OUT     CMOS_PORT,AL
        JMP     $+2                         ;I/O TIME DELAY
        IN      AL,CMOS_PORT+1             ;READ IN REGISTER [A]
        TEST    AL,80H                     ;IF 8XH--> UIP BIT IS ON (CANNOT READ TIME)
        JZ     UPD_IN_PREND
        LOOP   UPDATE                       ;Try again
        STC                                     ;SET CARRY FOR ERROR
        XOR     AX,AX                       ;
UPD_IN_PREND:
        POP     CX                         ;RETURN
        RET

;Display time
;   Arrive with CH = HOURS IN BCD
;               CL = Minutes in BCD
;               DH = Seconds in BCD
DisplayTime:
        PUSH    BX
        PUSH    DX
        PUSH    CX
        MOV     AL,CH
        CALL    PRINT_REG                 ;Hours. Convert BCD to ASCII
        MOV     CL,':'
        CALL    CO
        POP     CX
        MOV     AL,CL
        CALL    PRINT_REG                 ;Minutes. Convert BCD to ASCII
        MOV     CL,':'
        CALL    CO
        POP     DX
        MOV     AL,DH
        CALL    PRINT_REG                 ;Seconds. Convert BCD to ASCII
        POP     BX
        RET

;Input time
;   Return CH = HOURS IN BCD
;          CL = Minutes in BCD
;          DH = Seconds in BCD
InputTime:
        PUSH    BX
        MOV     BX,Input_Hours_Msg

```

```

CALL    PRINT_STRING
CALL    GET2BCD                ;Return with 2 BCD digits in AL
MOV     CH,AL
PUSH    CX
MOV     BX,Input_Minutes_Msg
CALL    PRINT_STRING
CALL    GET2BCD                ;Return with 2 BCD digits in AL
POP     CX
MOV     CL,AL
PUSH    CX
MOV     BX,Input_Seconds_Msg
CALL    PRINT_STRING
CALL    GET2BCD                ;Return with 2 BCD digits in AL
MOV     DH,AL
PUSH    DX
POP     DX
POP     CX
POP     BX
RET

```

```
;Display date
```

```
;      Return  CH = CENTURY IN BCD
;              CL = Year in BCD
;              DH = Month in BCD
;              DL = Day in BCD
```

```
DisplayDate:
```

```

PUSH    BX                    ;Assume 8086
PUSH    DX
PUSH    DX
PUSH    CX
MOV     AL,CH
CALL    PRINT_REG             ;Century (19/20).  Convert BCD to ASCII
POP     CX
MOV     AL,CL
CALL    PRINT_REG             ;Year.  Convert BCD to ASCII
MOV     CL,'/'
CALL    CO
POP     DX
MOV     AL,DH
CALL    PRINT_REG             ;Month.  Convert BCD to ASCII
MOV     CL,'/'
CALL    CO
POP     DX
MOV     AL,DL
CALL    PRINT_REG             ;Day.  Convert BCD to ASCII
POP     BX
RET

```

```
PRINT_REG:
```

```

;Print BCD in [AL]
PUSH    AX
MOV     CL,4
RCR     AX,CL
AND     AL,0FH
ADD     AL,30H
MOV     CL,AL                ;Write high byte mins to CRT
CALL    CO
POP     AX
AND     AL,0FH
ADD     AL,30H
MOV     CL,AL
CALL    CO
RET

```

```
;Input Date
```



```

;      Return  CH = CENTURY IN BCD
;              CL = Year in BCD
;              DH = Month in BCD
;              DL = Day in BCD
InputDate:
    PUSH     BX
    MOV      BX,Input_Year_Msg
    CALL     PRINT_STRING
    CALL     GET2BCD                ;Return with 2 BCD digits in AL
    MOV      CL,AL
    MOV      CH,20H                ;Assume 20 for century
    PUSH     CX                    ;Save
    MOV      BX,Input_Month_Msg
    CALL     PRINT_STRING
    CALL     GET2BCD                ;Return with 2 BCD digits in AL
    MOV      DH,AL
    PUSH     DX                    ;Save
    MOV      BX,Input_Day_Msg
    CALL     PRINT_STRING
    CALL     GET2BCD                ;Return with 2 BCD digits in AL
    POP      DX                    ;Get back
    MOV      DL,AL
    POP      CX                    ;Get back
    POP      BX
    RET

GET2BCD:                ;Return with 2 BCD digits in AL
    CALL     CICO
    mov      ah,0
    CMP      AL,ESC                ;Abort if ESC
    JNZ     BCD_OK
    JMP     INIT                    ;Back to start of Monitor

BCD_OK: SUB      AL,'@'
    SHL     AL,1
    SHL     AL,1
    SHL     AL,1
    SHL     AL,1
    PUSH     AX
    CALL     CICO
    SUB     AL,'@'
    AND     AL,0FH
    MOV     CL,AL
    POP     AX
    OR     AL,CL
    RET

;----- Run diagnostic tests on the 8259A PIC. -----↵
;-----
;Configured below for the S100Computers PIC/RTC S-100 and MSDOS Support Boards
;We will fill out all 256 Interrupt vectors with a diagnostic routine to show
;what interrupt was triggered in case the hardware did not trigger the 8259A bit 1 INT ↵
input.

TEST_8259:                ;"L" Main menu option
    mov     bx,PIC_SIGNON        ;Send a 8259A Test signon message
    call    PRINT_STRING

    CALL     SETUP_INT_TABLE     ;Setup Int table (0-400H in RAM)

    mov     ax,cs                ;Note this is just a simplified sub-section↵
    of the SETUP_IBM_BIOS routine
    mov     ds,ax                ;DS is this ROM's CS

```

```

    sub     ax,ax
    mov     es,ax                ;ES: = 0H in RAM for STOW's below, DS: = CS
    : (here).
    CLD                          ;Default to direction up

    mov     di,3fcH              ;Int FFH seems to false trigger on 80386
    board (not on the 8086 board!)
    mov     ax,dummy_return      ;Have it point to Dummy return in this
    monitor
    stosw                         ;(AX->ES:DI used for final location)

    mov     cx,8                 ;Set all 8 hardware interrupts for 8259A
    (at I/O port address 20H)
    mov     si,vec_tbl_8259A     ;Move the pointers in the IBM-PC vec_tbl-
    8259A to low RAM starting at 20H
    mov     di,Start8259A_Ints   ;Note DS:(=CS:) is source, ES: is
    destination
T2_8259:movsw                    ;[DS:SI]->[ES:DI]
    inc     di                   ;Skip over the segment pointer (already
    done above), to next vector offset
    inc     di
    loop   T2_8259

    mov     cx,16                ;Set all 16 MS-DOS software interrupts
    locations (we need INT#16)
    mov     si,vec_tbl_soft_ints
    mov     di,CRTINT            ;Start location in low RAM
T3_8259:movsw                    ;DS:SI->[ES:DI]
    inc     di                   ;Skip over the segment pointer (already
    done above), to next vector offset
    inc     di
    loop   T3_8259

    mov     ax,keybuff           ;Keyboard buffer interrupt pointers
    mov     [es:bufhd],ax        ;Head of buffer = end of buffer
    mov     [es:buftl],ax        ;buffer end
    mov     byte [es:chrcnt],0   ;Character count, Note we use ES: not DS:

    mov     al,11111111b         ;Block all INTs initially
    out     MASTER_PIC_PORT+1,al

    mov     al,MasterICW1        ;Initilize the 8259A PIC Controller
    out     MASTER_PIC_PORT,al
    mov     al,MasterICW2        ;Ints starts at 20H in RAM
    out     MASTER_PIC_PORT+1,al
    mov     al,MasterICW4        ;No slaves above, so 8259 does not expect
    ICW3
    out     MASTER_PIC_PORT+1,al

    mov     al,11111101b         ;Allow V1 (ONLY) on 8259A
    out     MASTER_PIC_PORT+1,al
    sti

T51_8259:
    MOV     BX,IN_CHAR_MSG       ;'Type characters on keyboard'
    CALL    PRINT_STRING

T5_8259:
    MOV     AH,01H              ;Check if anything there
    int     16H                 ;Get Keyboard status. Console Input Handler
    (Software Interrupt 16H)
    JZ     T5_8259

    MOV     AH,0H               ;Get actual character from buffer
    int     16H                 ;Get Character. Console Input Handler
    (Software Interrupt 16H)

```

```

CMP     AL,ESC
JZ      T6_8259                ;We are done if an ESC character
MOV     CL,AL
CALL    CO                    ;Display character recieved
sti
JMP     T5_8259                ;Ints back on

```

```

T6_8259:
mov     al,11111111b          ;Do not Allow V1 on 8259A again
out     MASTER_PIC_PORT+1,al
cli
JMP     ToMonitor            ;Turn hardware int's back off

```

```

;----- REAL MODE INTERRUPT MODE JUMP TABLE -----
-----

```

```

RM_INT_JUMP_TABLE:          ;Unfortunately we have to do all
256 possible routines!
DB      6AH,0H                ;Quirk with NASM forces 80H and above to a
word so use DB's
jmp     word RM_Zero_INT_Routine ;0 Divide by 0
DB      6AH,1H                ; In every case below we push a byte on
the stack to identify the INT
jmp     word RM_TRACE_INT_Routine ;1 CPU Trace Interrupt
DB      6AH,2H
jmp     word RM_NMI_INT_Routine  ;2 NMI default INT
DB      6AH,3H
jmp     word RM_CC_INT_Routine   ;3 Software CC Interrupt
DB      6AH,4H
jmp     word RM_Overflow_INT_Routine ;4 Overflow INT
DB      6AH,5H
jmp     word RM_Bounds_INT_Routine ;5 Bounds Check, FAULT
DB      6AH,6H
jmp     word RM_Opcode_INT_Routine ;6 Invalid Opcode, FAULT
DB      6AH,7H
jmp     word RM_Device_INT_Routine ;7 Device not available, FAULT
DB      6AH,8H
jmp     word RM_DFault_INT_Routine ;8 Double fault Fault
DB      6AH,9H
jmp     word RM_MathSeg_INT_Routine ;9 Math Coprocessor Segment error
DB      6AH,0AH
jmp     word RM_TSS_INT_Routine  ;10 Invalid TSS (+ Error Number)
DB      6AH,0BH
jmp     word RM_Segment_INT_Routine ;11 Segment Error (+ Error Number)
DB      6AH,0CH
jmp     word RM_Stack_INT_Routine ;12 Stack Exception (+ Error Number)
DB      6AH,0DH
jmp     word RM_General_INT_Routine ;13 General Protection (+ Error Number)
DB      6AH,0EH
jmp     word RM_Page_INT_Routine ;14 Page error, FAULT
DB      6AH,0FH
jmp     word RM_Intel_INT_Routine ;15 Intel reserved TRAP

DB      6AH,10H
jmp     word RM_Coprocessor_INT_Routine ;16 Co-processor error, FAULT
DB      6AH,11H
jmp     word RM_Default_INT_Routine
DB      6AH,12H
jmp     word RM_Default_INT_Routine
DB      6AH,13H
jmp     word RM_Default_INT_Routine
DB      6AH,14H
jmp     word RM_Default_INT_Routine

```

```
DB      6AH,15H
jmp     word RM_Default_INT_Routine
DB      6AH,16H
jmp     word RM_Default_INT_Routine
DB      6AH,17H
jmp     word RM_Default_INT_Routine
DB      6AH,18H
jmp     word RM_Default_INT_Routine
DB      6AH,19H
jmp     word RM_Default_INT_Routine
DB      6AH,1AH
jmp     word RM_Default_INT_Routine
DB      6AH,1BH
jmp     word RM_Default_INT_Routine
DB      6AH,1CH
jmp     word RM_Default_INT_Routine
DB      6AH,1DH
jmp     word RM_Default_INT_Routine
DB      6AH,1EH
jmp     word RM_Default_INT_Routine
DB      6AH,1FH
jmp     word RM_Default_INT_Routine

DB      6AH,20H
jmp     word RM_Default_INT_Routine
DB      6AH,21H
jmp     word RM_Default_INT_Routine
DB      6AH,22H
jmp     word RM_Default_INT_Routine
DB      6AH,23H
jmp     word RM_Default_INT_Routine
DB      6AH,24H
jmp     word RM_Default_INT_Routine
DB      6AH,25H
jmp     word RM_Default_INT_Routine
DB      6AH,26H
jmp     word RM_Default_INT_Routine
DB      6AH,27H
jmp     word RM_Default_INT_Routine
DB      6AH,28H
jmp     word RM_Default_INT_Routine
DB      6AH,29H
jmp     word RM_Default_INT_Routine
DB      6AH,2AH
jmp     word RM_Default_INT_Routine
DB      6AH,2BH
jmp     word RM_Default_INT_Routine
DB      6AH,2CH
jmp     word RM_Default_INT_Routine
DB      6AH,2DH
jmp     word RM_Default_INT_Routine
DB      6AH,2EH
jmp     word RM_Default_INT_Routine
DB      6AH,2FH
jmp     word RM_Default_INT_Routine

DB      6AH,30H
jmp     word RM_Default_INT_Routine
DB      6AH,31H
jmp     word RM_Default_INT_Routine
DB      6AH,32H
jmp     word RM_Default_INT_Routine
DB      6AH,33H
jmp     word RM_Default_INT_Routine
DB      6AH,34H
jmp     word RM_Default_INT_Routine
```

```
DB      6AH,35H
jmp     word RM_Default_INT_Routine
DB      6AH,36H
jmp     word RM_Default_INT_Routine
DB      6AH,37H
jmp     word RM_Default_INT_Routine
DB      6AH,38H
jmp     word RM_Default_INT_Routine
DB      6AH,39H
jmp     word RM_Default_INT_Routine
DB      6AH,3AH
jmp     word RM_Default_INT_Routine
DB      6AH,3BH
jmp     word RM_Default_INT_Routine
DB      6AH,3CH
jmp     word RM_Default_INT_Routine
DB      6AH,3DH
jmp     word RM_Default_INT_Routine
DB      6AH,3EH
jmp     word RM_Default_INT_Routine
DB      6AH,3FH
jmp     word RM_Default_INT_Routine

DB      6AH,40H
jmp     word RM_Default_INT_Routine
DB      6AH,41H
jmp     word RM_Default_INT_Routine
DB      6AH,42H
jmp     word RM_Default_INT_Routine
DB      6AH,43H
jmp     word RM_Default_INT_Routine
DB      6AH,44H
jmp     word RM_Default_INT_Routine
DB      6AH,45H
jmp     word RM_Default_INT_Routine
DB      6AH,46H
jmp     word RM_Default_INT_Routine
DB      6AH,47H
jmp     word RM_Default_INT_Routine
DB      6AH,48H
jmp     word RM_Default_INT_Routine
DB      6AH,49H
jmp     word RM_Default_INT_Routine
DB      6AH,4AH
jmp     word RM_Default_INT_Routine
DB      6AH,4BH
jmp     word RM_Default_INT_Routine
DB      6AH,4CH
jmp     word RM_Default_INT_Routine
DB      6AH,4DH
jmp     word RM_Default_INT_Routine
DB      6AH,4EH
jmp     word RM_Default_INT_Routine
DB      6AH,4FH
jmp     word RM_Default_INT_Routine

DB      6AH,50H
jmp     word RM_Default_INT_Routine
DB      6AH,51H
jmp     word RM_Default_INT_Routine
DB      6AH,52H
jmp     word RM_Default_INT_Routine
DB      6AH,53H
jmp     word RM_Default_INT_Routine
DB      6AH,54H
jmp     word RM_Default_INT_Routine
```

```
DB      6AH,55H
jmp     word RM_Default_INT_Routine
DB      6AH,56H
jmp     word RM_Default_INT_Routine
DB      6AH,57H
jmp     word RM_Default_INT_Routine
DB      6AH,58H
jmp     word RM_Default_INT_Routine
DB      6AH,59H
jmp     word RM_Default_INT_Routine
DB      6AH,5AH
jmp     word RM_Default_INT_Routine
DB      6AH,5BH
jmp     word RM_Default_INT_Routine
DB      6AH,5CH
jmp     word RM_Default_INT_Routine
DB      6AH,5DH
jmp     word RM_Default_INT_Routine
DB      6AH,5EH
jmp     word RM_Default_INT_Routine
DB      6AH,5FH
jmp     word RM_Default_INT_Routine

DB      6AH,60H
jmp     word RM_Default_INT_Routine
DB      6AH,61H
jmp     word RM_Default_INT_Routine
DB      6AH,62H
jmp     word RM_Default_INT_Routine
DB      6AH,63H
jmp     word RM_Default_INT_Routine
DB      6AH,64H
jmp     word RM_Default_INT_Routine
DB      6AH,65H
jmp     word RM_Default_INT_Routine
DB      6AH,66H
jmp     word RM_Default_INT_Routine
DB      6AH,67H
jmp     word RM_Default_INT_Routine
DB      6AH,68H
jmp     word RM_Default_INT_Routine
DB      6AH,69H
jmp     word RM_Default_INT_Routine
DB      6AH,6AH
jmp     word RM_Default_INT_Routine
DB      6AH,6BH
jmp     word RM_Default_INT_Routine
DB      6AH,6CH
jmp     word RM_Default_INT_Routine
DB      6AH,6DH
jmp     word RM_Default_INT_Routine
DB      6AH,6EH
jmp     word RM_Default_INT_Routine
DB      6AH,6FH
jmp     word RM_Default_INT_Routine

DB      6AH,70H
jmp     word RM_Default_INT_Routine
DB      6AH,71H
jmp     word RM_Default_INT_Routine
DB      6AH,72H
jmp     word RM_Default_INT_Routine
DB      6AH,73H
jmp     word RM_Default_INT_Routine
DB      6AH,74H
jmp     word RM_Default_INT_Routine
```

```
DB      6AH,75H
jmp     word RM_Default_INT_Routine
DB      6AH,76H
jmp     word RM_Default_INT_Routine
DB      6AH,77H
jmp     word RM_Default_INT_Routine
DB      6AH,78H
jmp     word RM_Default_INT_Routine
DB      6AH,79H
jmp     word RM_Default_INT_Routine
DB      6AH,7AH
jmp     word RM_Default_INT_Routine
DB      6AH,7BH
jmp     word RM_Default_INT_Routine
DB      6AH,7CH
jmp     word RM_Default_INT_Routine
DB      6AH,7DH
jmp     word RM_Default_INT_Routine
DB      6AH,7EH
jmp     word RM_Default_INT_Routine
DB      6AH,7FH
jmp     word RM_Default_INT_Routine

DB      6AH,80H                ;Quirk with NASM forces 80H and above to a ↵
word!
jmp     word RM_Default_INT_Routine ;So use DB's
DB      6AH,81H
jmp     word RM_Default_INT_Routine
DB      6AH,82H
jmp     word RM_Default_INT_Routine
DB      6AH,83H
jmp     word RM_Default_INT_Routine
DB      6AH,84H
jmp     word RM_Default_INT_Routine
DB      6AH,85H
jmp     word RM_Default_INT_Routine
DB      6AH,86H
jmp     word RM_Default_INT_Routine
DB      6AH,87H
jmp     word RM_Default_INT_Routine
DB      6AH,88H
jmp     word RM_Default_INT_Routine
DB      6AH,89H
jmp     word RM_Default_INT_Routine
DB      6AH,8AH
jmp     word RM_Default_INT_Routine
DB      6AH,8BH
jmp     word RM_Default_INT_Routine
DB      6AH,8CH
jmp     word RM_Default_INT_Routine
DB      6AH,8DH
jmp     word RM_Default_INT_Routine
DB      6AH,8EH
jmp     word RM_Default_INT_Routine
DB      6AH,8FH
jmp     word RM_Default_INT_Routine

DB      6AH,90H
jmp     word RM_Default_INT_Routine
DB      6AH,91H
jmp     word RM_Default_INT_Routine
DB      6AH,92H
jmp     word RM_Default_INT_Routine
DB      6AH,93H
jmp     word RM_Default_INT_Routine
DB      6AH,94H
```

```
    jmp     word RM_Default_INT_Routine
    DB     6AH,95H
    jmp     word RM_Default_INT_Routine
    DB     6AH,96H
    jmp     word RM_Default_INT_Routine
    DB     6AH,97H
    jmp     word RM_Default_INT_Routine
    DB     6AH,98H
    jmp     word RM_Default_INT_Routine
    DB     6AH,99H
    jmp     word RM_Default_INT_Routine
    DB     6AH,9AH
    jmp     word RM_Default_INT_Routine
    DB     6AH,9BH
    jmp     word RM_Default_INT_Routine
    DB     6AH,9CH
    jmp     word RM_Default_INT_Routine
    DB     6AH,9DH
    jmp     word RM_Default_INT_Routine
    DB     6AH,9EH
    jmp     word RM_Default_INT_Routine
    DB     6AH,9FH
    jmp     word RM_Default_INT_Routine

    DB     6AH,0A0H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0A1H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0A2H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0A3H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0A4H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0A5H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0A6H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0A7H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0A8H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0A9H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0AAH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0ABH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0ACH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0ADH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0AEH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0AFH
    jmp     word RM_Default_INT_Routine

    DB     6AH,0B0H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0B1H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0B2H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0B3H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0B4H
```



```
    jmp     word RM_Default_INT_Routine
    DB     6AH,0B5H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0B6H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0B7H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0B8H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0B9H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0BAH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0BBH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0BCH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0BDH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0BEH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0BFH
    jmp     word RM_Default_INT_Routine

    DB     6AH,0C0H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0C1H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0C2H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0C3H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0C4H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0C5H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0C6H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0C7H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0C8H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0C9H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0CAH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0CBH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0CCH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0CDH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0CEH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0CFH
    jmp     word RM_Default_INT_Routine

    DB     6AH,0D0H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0D1H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0D2H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0D3H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0D4H
```

```
    jmp     word RM_Default_INT_Routine
    DB     6AH,0D5H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0D6H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0D7H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0D8H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0D9H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0DAH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0DBH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0DCH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0DDH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0DEH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0DFH
    jmp     word RM_Default_INT_Routine

    DB     6AH,0E0H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0E1H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0E2H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0E3H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0E4H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0E5H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0E6H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0E7H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0E8H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0E9H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0EAH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0EBH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0ECH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0EDH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0EEH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0EFH
    jmp     word RM_Default_INT_Routine

    DB     6AH,0F0H
    jmp     word word RM_Default_INT_Routine
    DB     6AH,0F1H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0F2H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0F3H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0F4H
```

```

    jmp     word RM_Default_INT_Routine
    DB     6AH,0F5H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0F6H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0F7H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0F8H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0F9H
    jmp     word RM_Default_INT_Routine
    DB     6AH,0FAH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0FBH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0FCH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0FDH
    jmp     word RM_Default_INT_Routine
    DB     6AH,0FEH
    jmp     word RM_Default_INT_Routine
    IRET
)
;For 0FFH just return. (Noise on INTA line?

RM_Default_INT_Routine:
;Unless told otherwise, all the above Ints
    will come here.
    PUSH   AX
;Save what will be changed. (Note. IRET has
    already saves the flags)
    PUSH   BX
    PUSH   BP
    MOV    BP,SP
    MOV    BX,UNASSIGNED_1_INT_MSG
; "Un-assigned Int #"
    CALL   PRINT_STRING
;Note PRINT_STRING always uses the CS:
    override for the BX pointer
    MOV    AX,[BP+6]
;Get INT# send by the above INT Jump
    CALL   AL_HEXOUT
    MOV    BX,H_MSG_CRLF
    POP    BP

INT_INFO_DONE:
;General INT Fault return
    CALL   PRINT_STRING
    POP    BX
    POP    AX
    ADD    SP,2
;Balance up stack,return
    IRET
;Remember the byte saved on the stack is
    extended to a word by the CPU

RM_Zero_INT_Routine:
;Int #0, Divide by Zero, (Return address to
    error, so ABORT)
    PUSH   AX
    PUSH   BX
;Note BP is not saved
    MOV    BX,DIVIDE_MSG
;"Divide by 0 INT #0"

INT_HALT:
    CALL   PRINT_STRING
    MOV    BX,CPU_HALTED_MSG
;The CPU is Halted +CRLF
    CALL   PRINT_STRING
    POP    BX
    POP    AX
;In case further INT's
    ADD    SP,2
;Balance up stack,return
    HLT
;Halt for all FAULTS (does not matter Stack
    is messed up, we will reset CPU)

RM_NMI_INT_Routine:
;NMI Trap (INT#2)
    PUSH   AX
    PUSH   BX

```

```
        MOV     BX,NMI_FAULT_MSG
        JMP     INT_INFO_DONE

RM_Overflow_INT_Routine:                ;Int #4, Overflow TRAP
        PUSH   AX
        PUSH   BX
        MOV    BX,OVERFLOW_ERR_MSG
        JMP    INT_INFO_DONE

RM_Bounds_INT_Routine:                  ;Int #5, Bounds Check, (Return address to error, so ABORT)
        PUSH   AX
        PUSH   BX
        MOV    BX,BOUNDS_ERR_MSG
        JMP    INT_HALT

RM_Opcode_INT_Routine:                  ;Int #6, Invalid Opcode, (Return address to error, so ABORT)
        PUSH   AX
        PUSH   BX
        MOV    BX,INVALID_ERR_MSG
        JMP    INT_HALT

RM_Device_INT_Routine:                  ;Int #7, Math Coprocessor not available, (Return address to error, so ABORT)
        PUSH   AX
        PUSH   BX
        MOV    BX,DEVICE_ERR_MSG
        JMP    INT_HALT

RM_DFault_INT_Routine:                  ;Int #8, Double, (Return address to error, so ABORT)
        PUSH   AX
        PUSH   BX
        MOV    BX,DOUBLE_ERR_MSG
        JMP    INT_HALT

RM_MathSeg_INT_Routine:                  ;Int #9, No Coprocessor, (ABORT anyway)
        PUSH   AX
        PUSH   BX
        MOV    BX,COPROCESSOR_ERR_MSG
        JMP    INT_HALT

RM_TSS_INT_Routine:                    ;Int #10, Invalid TSS
        PUSH   AX
        PUSH   BX
        MOV    BX,INVALID_TSS_ERR_MSG
        JMP    INT_HALT

RM_Segment_INT_Routine:                  ;Int #11, Segment not present
        PUSH   AX
        PUSH   BX
        MOV    BX,SEGMENT_ERR_MSG
        JMP    INT_HALT

RM_Stack_INT_Routine:                   ;Int #12, Stack Exception
        PUSH   AX
        PUSH   BX
        MOV    BX,STACK_ERR_MSG
        JMP    INT_HALT

RM_General_INT_Routine:                  ;Int #13, General protection error (+ ERROR #)
        PUSH   AX
        PUSH   BX
        MOV    BX,GENERAL_ERR_MSG
```

```

        JMP      INT_HALT

RM_Page_INT_Routine:                        ;Int #14, Page fault
        PUSH    AX
        PUSH    BX
        MOV     BX,PAGE_ERR_MSG
        JMP     INT_INFO_DONE

RM_Intel_INT_Routine:                       ;Int #15, Intel reserved Int
        PUSH    AX
        PUSH    BX
        MOV     BX,RESERVED_ERR_MSG
        JMP     INT_INFO_DONE

RM_Coprocessor_INT_Routine:                 ;Int #16 Cprocessor Error
        PUSH    AX
        PUSH    BX
        MOV     BX,COPROCESSOR_ERR_MSG
        JMP     INT_HALT

RM_CC_INT_Routine:                          ;INT #3, Software CC Interrupt
        CALL    REGISTERS                    ;Display Real Mode Registers
        PUSH    AX
        PUSH    BX
        PUSH    CX
        PUSH    BP
        MOV     BP,SP
        MOV     BX,IP_ADDRESS_MSG           ;IP=
        CALL    PRINT_STRING
        MOV     AX,[BP+12]                   ;Get return IP address on stack, SEGMENT
        CALL    AX_HEXOUT
        MOV     CL,':'
        CALL    CO
        MOV     AX,[BP+10]                   ;Get return IP address on stack, OFFSET
        CALL    AX_HEXOUT
        MOV     BX,H_MSG_CRLF
        CALL    PRINT_STRING
        POP     BP
        POP     CX
        POP     BX
        POP     AX
        ADD     SP,2                           ;Balance up stack,return
        IRET                                ;Remember the byte saved on the stack is
        extended to a word by the CPU

RM_TRACE_INT_Routine:                       ;INT#1, trace mode
        CALL    REGISTERS                    ;Display Real Mode Registers
        PUSH    AX
        PUSH    BX
        PUSH    CX
        PUSH    BP
        MOV     BP,SP
        MOV     BX,IP_ADDRESS_MSG           ;IP=
        CALL    PRINT_STRING
        MOV     AX,[BP+12]                   ;Get return IP address on stack, SEGMENT
        CALL    AX_HEXOUT
        MOV     CL,':'
        CALL    CO
        MOV     AX,[BP+10]                   ;Get return IP address on stack, OFFSET
        CALL    AX_HEXOUT
        MOV     BX,H_MSG_CRLF
        CALL    PRINT_STRING

```



```

        JZ      BAD_SOFT_40_CHECK
        CMP      AL,0F0H
        JZ      BAD_SOFT_F0_CHECK
        JMP      NOT_FAULTS

DIVIDE_CHECK:
        CALL     CRLF
        MOV      AX,0FFFFH
        MOV      BX,0
        DIV      BX                ;Try divide by 0
        CALL     CRLF
        JMP      SOFT_INTS        ;Normally will not get here

OVERFLOW_CHECK:
        CALL     CRLF
        INT      4
        CALL     CRLF
        JMP      SOFT_INTS

INVALID_CHECK:
        CALL     CRLF
        INT      6
        CALL     CRLF
        JMP      SOFT_INTS

BAD_GP_FAULT_CHECK:
        CALL     CRLF
        INT      0DH
        CALL     CRLF
        JMP      SOFT_INTS

BAD_SOFT_40_CHECK:
        CALL     CRLF
        INT      40H
        CALL     CRLF
        JMP      SOFT_INTS

BAD_SOFT_F0_CHECK:
        CALL     CRLF
        INT      0F0H
        CALL     CRLF
        JMP      SOFT_INTS

NOT_FAULTS:
        CALL     CRLF
        MOV      BX,INT_RANGE_MSG
        CALL     PRINT_STRING
        JMP      SOFT_INTS

INTS_DONE:
        RET

;----- Routine to Setup the RM Interrupt jump table in RAM (0-400H) ✓
;-----

SETUP_INT_TABLE:                                ;Note we assume INTS are turned off
        PUSHF
        PUSH     AX
        PUSH     BX
        PUSH     CX
        PUSH     DS
        PUSH     ES
        PUSH     SI
        PUSH     DI

        mov     ax,cs                            ;Note this is just a simplified sub-section ✓
        of the SETUP_IBM_BIOS routine
        mov     ds,ax                            ;DS is this ROM's CS
        sub     ax,ax
        mov     es,ax                            ;ES: = 0H in RAM for STOW's below, DS: = CS ✓
        : (here) .

```

```

        CLD                ;Default to direction up
        CLI                ;Just in case

        mov     cx,256     ;Fill all 8086 interrupts initially with a
default error trapping pointer
        sub     di,di      ;Clear destination register start at RAM 0H
        sub     bx,bx      ;Start at location 0
SETI1:  mov     ax,bx
        add     AX,RM_INT_JUMP_TABLE ;set to illustrate non assigned int
        stosw                ;Remember ES: is used for final location
with STOSW
        mov     ax,cs      ;Interrupt segment pointer to here (always
the same).
        stosw                ;<-- Note the default segment will be this
CS for all ints below
        add     bx,5       ;Point to next int routine below in the 256
list
        loop   SETI1

        POP     DI
        POP     SI
        POP     ES
        POP     DS
        POP     CX
        POP     BX
        POP     AX
        POPF
        RET

```

```

;----- LOAD XMODEM FILE via CONSOLE-IO PORT -----
-----

```

```

XMODEM_LOAD:
        mov     bx,MODEM_SIGNON ;Send Modem signon message
        call   PRINT_STRING
        CLD                ;Default to direction up
        CLI                ;No hardware Ints

        mov     ax,cs        ;Just in case different
        mov     ds,ax        ;DS is this ROM's CS

        PUSH   BP
        MOV    BP,SP         ;Will store certain variables well below stack
        MOV    byte [BP-RECVD_SECT_NO],0
        MOV    byte [BP-SECTNO],0
        MOV    byte [BP-ERRCT],0

        CALL   INIT_SCC     ;MASTER RESET THE ZILOG SCC
                        ;GOBBLE UP GARBAGE CHARS FROM THE LINE
        mov     bx,RAM_DESTINATION ;Ask for destination
        call   PRINT_STRING
        CALL   GET5DIGITS   ;Get (up to) 20 bit parameter. 16 bit value (4
digits) to DI.
                        ;If 5 digits, then the first digit is put in ES
(highest nibble)
        CMP    AL,ESC
        JZ     MODEM_DONE

        mov     bx,WHEN_READY_MSG ;Hit any key when ready
        call   PRINT_STRING
        CALL   CI
        CALL   CRLF

        MOV    CH,MODEM_RTS_DELAY ;TIMEOUT DELAY
        CALL   RECV

```



```

        MOV     BX,START_POINTER           ;"Will load data starting at RAM location "
        CALL   PRINT_STRING
        call   SHOW_ADDRESS_ES_NOSPACE ;Show address
        MOV     BX,H_MSG_CRLF
        CALL   PRINT_STRING
        CALL   CRLF

        MOV     BX,DOWNLOAD_MSG           ;Speak "Downloading file"
        CALL   SPEAK_STRING

RECV_LOOP:
        XOR     AX,AX                     ;<<< MAIN RECIEVE LOOP
        MOV     [BP-ERRCT],AL             ;GET 0
        MOV     [BP-ERRCT],AL             ;Start error count with 0
RECV_HDR:
        PUSH   BX
        MOV     BX,RMSG                   ;Reading sector message
        CALL   PRINT_STRING
        MOV     AL,[BP-SECTNO]
        INC     AL
        CALL   AL_HEXOUT
        MOV     BX,RAM_MSG                 ;"H. IF OK, will write to RAM location"
        CALL   PRINT_STRING
        call   SHOW_ADDRESS_ES_NOSPACE ;Show address
        MOV     BX,H_MSG
        CALL   PRINT_STRING
        POP    BX

        MOV     CH,(20*MODEM_RTS_DELAY) ;20 SEC TIMEOUT
        CALL   RECV
        JNB    RHNTO                       ;WE ARE OK, NO TIMEOUT

RECV_HDR_TIMEOUT:
        MOV     BX,TOUTM                   ;PRINT TIMEOUT MESSAGE
        CALL   PRINT_STRING
        MOV     AL,[BP-ERRCT]
        CALL   AL_HEXOUT                   ;FALL INTO CR/LF
        CALL   CRLF

RECV_SECT_ERR:
        MOV     CH,MODEM_RTS_DELAY         ;PURGE THE LINE OF INPUT CHARS
        CALL   RECV                       ;~1 SEC W/NO CHARS
        JNB    RECV_SECT_ERR               ;LOOP UNTIL SENDER DONE
        MOV     AL,NAK
        CALL   SEND                         ;SEND NAK
        MOV     AL,[BP-ERRCT]
        INC    AL                           ;Inc Error Count (ERRCT)
        MOV     [BP-ERRCT],AL
        CMP    AL,MODEM_ERR_LIMIT         ;Currently set for 5 trys
        JB    RECV_HDR                     ;Go try again
        CALL   CHECK_FOR_QUIT
        JZ    RECV_HDR                     ;Try again
        MOV     BX,BAD_HEADER
        CALL   PRINT_STRING
        JMP    MODEM_DONE                   ;Abort back to Monitor start

RHNTO:  CMP    AL,SOH                       ;GOT CHAR - MUST BE SOH
        JZ    GOT_SOH
        OR     AL,AL                       ;00 FROM SPEED CHECK?
        JNZ   L_2
        JMP   RECV_HDR

L_2:   CMP    AL,EOT
        JNZ   L_3
        JMP   GOT_EOT

L_3:   CALL   AL_HEXOUT
        MOV     BX,ERRSOH                   ;'H Received',CR,LF,'Did not get Correct SOH'
        CALL   PRINT_STRING

```

```

        JMP      RECV_SECT_ERR

GOT_SOH:
        MOV     CH,MODEM_RTS_DELAY      ;We got correct SOH so now get data
        CALL   RECV
        JB     RECV_HDR_TIMEOUT
        MOV     DH,AL                    ;D=BLK #
        MOV     CH,MODEM_RTS_DELAY
        CALL   RECV                      ;GET CMA'D SECT #
        JB     RECV_HDR_TIMEOUT
        NOT     AL
        CMP     AL,DH                    ;GOOD SECTOR #?
        JZ     RECV_SECTOR
                                           ;GOT BAD SECTOR #
        MOV     BX,MODEM_ERR2            ;'++BAD SECTOR # IN HDR'
        CALL   PRINT_STRING
        JMP     RECV_SECT_ERR

RECV_SECTOR:
                                           ;Now get 128 Bytes
        MOV     AL,DH                    ;GET SECTOR #
        MOV     [BP-RECVD_SECT_NO],AL
        MOV     CL,0                      ;INIT CKSUM
        MOV     BL,80H                    ;128 Byte sectors always

RECV_CHAR:
        MOV     CH,MODEM_RTS_DELAY      ;~1 SEC TIMEOUT
        CALL   RECV                      ;GET CHAR
        JNB    MODL_4
        JMP     RECV_HDR_TIMEOUT
MODL_4:  MOV     [ES:DI],AL                ;<<< STORE CHAR >>>
        INC     DI
        DEC     BL                        ;128 Bytes done yet?
        JNZ    RECV_CHAR
                                           ;NEXT VERIFY CHECKSUM
        MOV     DH,CL                    ;SAVE CHECKSUM
        MOV     CH,MODEM_RTS_DELAY      ;TIMEOUT
        CALL   RECV                      ;GET CHECKSUM
        JNB    MODL_5
        JMP     RECV_HDR_TIMEOUT
MODL_5:  CMP     AL,DH                      ;CHECK
        JNZ    RECV_CKSUM_ERR
        MOV     AL,[BP-RECVD_SECT_NO]    ;GOT A SECTOR, WRITE IF = 1+PREV SECTOR
        MOV     CH,AL                    ;SAVE IT
        MOV     AL,[BP-SECTNO]          ;GET PREV
        INC     AL                        ;CALC NEXT SECTOR #
        CMP     AL,CH                    ;MATCH?
        JNZ    DO_ACK
        MOV     AL,[BP-RECVD_SECT_NO]    ;Indicate we transferred a sector
        MOV     [BP-SECTNO],AL          ;UPDATE SECTOR #
DO_ACK:  MOV     AL,ACK
        CALL   SEND
        JMP     RECV_LOOP

RECV_CKSUM_ERR:
        MOV     BX,MODEM_ERR3
        CALL   PRINT_STRING
        JMP     RECV_SECT_ERR

GOT_EOT:
                                           ;DONE - CLOSE UP SHOP
        MOV     AL,ACK                    ;ACK THE EOT
        CALL   SEND
        CALL   CRLF
        MOV     BX,FINISH_MSG            ;Speek downloading finished

```

```

        CALL    SPEAK_STRING
        MOV     BX,TRANS_DONE
EXIT2:  CALL    PRINT_STRING
MODEM_DONE:
        XOR     AL,AL
        POP     BP                ;RESTORE IT
        RET

EXIT1:  MOV     BX,ABORT_MSG
        JMP     EXIT2

                                           ;INITITIALIZE THE ZILOG SCC SERIAL PORT
INIT_SCC:
        MOV     BX,SSC_MSG_INIT    ;Say Initalizing ACIA/SCC
        CALL    PRINT_STRING
        MOV     CH,14              ;Byte count (14), for below
        MOV     BX,SCCINIT        ;Table of Zilog SCC Initalization values
SCC_1:  MOV     AL,[CS:BX]
        OUT     MODEM_CTL_PORT,AL  ;Program the SCC Channel B (A1,A3 or 10,12H) for
19K Baud
        INC     BX
        DEC     CH
        JNZ     SCC_1
        MOV     BX,SPEED_MSG      ;Speak, baud rate set
        CALL    SPEAK_STRING
        RET

                                           ;---- SERIAL PORT GET CHARACTER ROUTINE ----
RECV:   PUSH    DX                ;SAVE
        MOV     AL,5H             ;Lower RTS line
        OUT     MODEM_CTL_PORT,AL ;Sel Reg 5
        MOV     AL,11101010B     ;EAH
        OUT     MODEM_CTL_PORT,AL
        NOP
        NOP
MSEC:   MOV     DX,8000H          ;~0.1 SEC DCR COUNT
MWTI:   IN      AL,MODEM_CTL_PORT
        AND     AL,MODEM_RECV_MASK
        CMP     AL,RECV_READY
        JZ      MCHAR            ;GOT CHAR
        DEC     DX                ;COUNT DOWN
        JNZ     MWTI            ;FOR TIMEOUT
        DEC     CH                ;DCR # OF SECONDS
        JNZ     MSEC            ;MODEM TIMED OUT RECEIVING
        POP     DX                ;RESTORE DX
        STC
        RET                    ;CARRY SHOWS TIMEOUT

MCHAR:  IN      AL,MODEM_DATA_PORT
        POP     DX                ;RESTORE DE
        LAHF
                                           ;CALC CHECKSUM
        XCHG   AL,AH
        PUSH   AX
        XCHG   AL,AH
        ADD    AL,CL
        MOV    CL,AL
        POP    AX
        XCHG   AL,AH
        OR     AL,AL                ;TURN OFF CARRY TO SHOW NO TIMEOUT
        RET

                                           ;---- SERIAL PORT SEND CHARACTER ROUTINE ----
SEND:   LAHF
        XCHG   AL,AH
        PUSH   AX
        XCHG   AL,AH
        ADD    AL,CL                ;CALC CKSUM

```

```

        MOV     CL,AL
SENDW:  IN      AL,MODEM_CTL_PORT      ;Don't worry PC is always fast enough
        AND     AL,MODEM_SEND_MASK
        CMP     AL,SEND_READY
        JNZ     SENDW
        POP     AX                      ;GET CHAR
        XCHG   AL,AH
        SAHF
        OUT     MODEM_DATA_PORT,AL     ;Raise RTS line to prevent the next character
arriving
        MOV     AL,5H                  ;while the Z80 is busy processing info
        OUT     MODEM_CTL_PORT,AL     ;Sel Reg 5
        MOV     AL,11101000B          ;E8H
        OUT     MODEM_CTL_PORT,AL
        RET

CHECK_FOR_QUIT:                          ;MULTIPLE ERRORS, ASK IF TIME TO QUIT
        XOR     AL,AL                  ;GET 0
        MOV     [BP-ERRCT],AL         ;RESET ERROR COUNT
        MOV     BX,QUITM
        CALL    PRINT_STRING
        CALL    CICO
        PUSH   AX
        CALL    CRLF
        POP    AX
        CMP    AL,'R'
        JZ     DONE_CHECK
        CMP    AL,'Q'
        JZ     NOT_DONE_CHECK
        CMP    AL,ESC
        JZ     NOT_DONE_CHECK
        JMP    CHECK_FOR_QUIT

NOT_DONE_CHECK:
        OR     AL,AL                  ;TURN OFF ZERO FLAG
DONE_CHECK:
        RET

;*****
;
;   Module to Test and diagnose the www.S100Computers.com IDE Board
;
;   Instead of using the CPM86 style DS:[BX] format, we will use SS:[BP] so the the
buffers
;   can reside at the top segment of available RAM. Normally this will be F000:7000H
but the monitor
;   will not assume the full 1MG address space is available.
;   See the monitor initialization section where BP is setup.
;
;*****
;*****

MYIDE:  MOV     BP,DISPLAY_FLAG        ;Do we have detail sector data display flag on or
off
        MOV     AL,0FFH                ;Set default to detailed sector display
        MOV     [BP],AL

        MOV     BX,IDE_HARDWARE        ;"Initilizing IDE Drive hardware"

```

```

CALL    PRINT_STRING

CALL    CLEAR$ID$BUFFER           ;Clear ID Buffer

CALL    SET_DRIVE_A               ;Select the first Drive/CF card
CALL    IDEinit                   ;Initialize the board and drive #0. If there is no
drive abort                       ✓
JZ      INIT1_OK

MOV     BX,INIT_1_ERROR
CALL   PRINT_STRING
JMP    INIT

INIT1_OK:
CALL   CLEAR$ID$BUFFER           ;Clear ID Buffer

CALL   SET_DRIVE_B               ;Select the second Drive/CF card (Do not mess with
CPM Drive 0)                       ✓
CALL   IDEinit                   ;Initialize drive #1. If there is no drive abort
JZ     INIT2_OK

CALL   CLEAR$ID$BUFFER           ;Clear ID Buffer

MOV     BX,INIT_2_ERROR           ;Warn second IDE drive did not initilize
CALL   PRINT_STRING              ;Since first drive was OK we will still go to
INIT2_OK                           ✓

INIT2_OK:
CALL   SET_DRIVE_A               ;Back to first drive/CF Card

CALL   DRIVE_ID                  ;Get the drive 0 ID info. If there is no drive just
abort                               ✓
JZ     INIT3_OK

MOV     BX,BAD_DRIVE              ;"Error obtaining the Drive ID"
CALL   PRINT_STRING
JMP    INIT

INIT3_OK:
                                           ;Check we have a valid IDE drive
MOV     BP,(IDE_Buffer+12)        ;Note always SS: = CS:
MOV     AX,[BP]
OR      AX,AX
                                           ;If there are zero sectors then something wrong
JNZ    INIT4_OK

MOV     BX,BAD_DRIVE              ;"Error obtaining first Drive ID"
CALL   PRINT_STRING
JMP    INIT

INIT4_OK:
MOV     BP,RAM_DMA                ;Set default position will be first sector block
MOV     word[BP],IDE_Buffer       ;DMA always initially to IDE_Buffer,

MOV     BP,RAM_SEC
MOV     word[BP],0H               ;Sec 0
MOV     BP,RAM_TRK
MOV     word[BP],0H              ;Track 0

CALL   IDEinit                   ;For some reason this need to be here after getting
the drive ID.                       ✓

                                           ;otherwise sector #'s are off by one! (Probably
because on non-LBA reads)           ✓
CALL   WR_LBA                     ;Update LBA on "1st" drive

```

```

;----- MAIN IDE DRIVE DIAGNOSTIC MENU -----

IDE_LOOP:
    MOV     AX,CS                ;Just in case somehow they changed somewhere below
    MOV     DS,AX
    MOV     ES,AX

    MOV     BX,IDE_SIGNON0      ;List IDE command options
    CALL    PRINT_STRING

    MOV     BP,CURRENT_IDE_DRIVE
    MOV     AL,[BP]
    OR      AL,AL
    JNZ     SIGN_B
    MOV     BX,CURRENT_MSG_A
    JMP     IDE_LOOP0
SIGN_B:   MOV     BX,CURRENT_MSG_B
IDE_LOOP0:
    CALL    PRINT_STRING

    MOV     BX,IDE_SIGNON4      ;List IDE command options
    CALL    PRINT_STRING

    MOV     BP,DISPLAY_FLAG     ;Do we have detail sector data display flag ON or  ↵
    OFF
    MOV     AL,[BP]             ;NZ = on
    OR      AL,AL
    JNZ     IDE_LOOP1
    MOV     BX,IDE_SIGNON1      ;"ON"
    JMP     IDE_LOOP2
IDE_LOOP1:
    MOV     BX,IDE_SIGNON2      ;"OFF"
IDE_LOOP2:
    CALL    PRINT_STRING

    MOV     BX,IDE_SIGNON3      ;List IDE command options
    CALL    PRINT_STRING

    CALL    DISPLAY_POSITION     ;Display current Track,sector,head#

    CALL    CRLF
    MOV     BX,IDE_MENU         ;Enter a command
    CALL    PRINT_STRING

    call    CICO                 ;Get a command from Console
    mov     ah,0
    CMP     AL,ESC              ;Abort if ESC
    JNZ     NOT_ESC
    JMP     INIT                 ;Back to start of Monitor

NOT_ESC: cmp     al,'A'           ;Find menu option from table
        jb     IDE_LOOP         ;must be A to Z
        cmp     al,'Z'
        jg     IDE_LOOP
        sub     al,'A'           ;calculate offset
        shl     al,1            ;X 2
        add     ax,IDE_TABLE     ;Note DS:=CS:
        mov     bx,ax
        CALL    CRLF
        mov     ax,[cs:bx]      ;get location of routine CS:[BX]
        call    ax              ;<----- This is the IDE Menu CMD call
        jmp     IDE_LOOP        ;finished

```

```

;
INDIVIDUAL IDE DRIVE MENU COMMANDS

```

```

;-----Select Drive/CF card -----
SET_DRIVE_A:                                ;Select First Drive
    MOV     AL,0
SELECT_DRIVE:
    MOV     BP,CURRENT_IDE_DRIVE
    MOV     [BP],AL
    OUT     IDEDrivePort,AL                ;Select Drive 0 or 1
    RET

SET_DRIVE_B:                                ;Select Drive 1
    MOV     AL,1
    JMP     SELECT_DRIVE

;----- Do the IDentify drive command, and display the IDE_Buffer -----
DRIVE_ID:
    CALL    IDEwaitnotbusy
    JNB     L_5
    XOR     AX,AX
    DEC     AX                                ;NZ if error
    RET                                ;If Busy return NZ

L_5:    MOV     DH,COMMANDid
    MOV     DL,REGcommand
    CALL    IDEwr8D                            ;issue the command

    CALL    IDEwaitdrq                        ;Wait for Busy=0, DRQ=1
    JNB     L_6
    JMP     SHOWerrors

L_6:    MOV     CH,0                            ;256 words
    MOV     BP,IDE_Buffer                    ;Store data here (remember CS: = SS:)
    CALL    MoreRD16                          ;Get 256 words of data from REGdata port to ss:[BP]

    MOV     BX,msgmdl                            ;print the drive's model number
    CALL    PRINT_STRING
    MOV     BP,(IDE_Buffer + 54)
    MOV     CH,10                              ;Character count in words
    CALL    Print_ID_Info                      ;Print [HL], [B] X 2 characters
    CALL    CRLF

                                                ; print the drive's serial number
    MOV     BX,msgsn
    CALL    PRINT_STRING
    MOV     BP,(IDE_Buffer + 20)
    MOV     CH,5                              ;Character count in words
    CALL    Print_ID_Info
    CALL    CRLF

                                                ;PRINT_STRING the drive's firmware revision string
    MOV     BX,msgrev
    CALL    PRINT_STRING
    MOV     BP,(IDE_Buffer + 46)
    MOV     CH,2
    CALL    Print_ID_Info                      ;Character count in words
    CALL    CRLF

                                                ;print the drive's cylinder, head, and sector specs
    MOV     BX,msgcyl
    CALL    PRINT_STRING
    MOV     BP,(IDE_Buffer + 2)
    CALL    Print_ID_HEX
    MOV     BX,msghd
    CALL    PRINT_STRING
    MOV     BP,(IDE_Buffer + 6)
    CALL    Print_ID_HEX
    MOV     BX,msgsc

```

```

CALL    PRINT_STRING
MOV     BP,(IDE_Buffer + 12)    ;Sectors/track
CALL    Print_ID_HEX
CALL    CRLF
XOR     AX,AX                    ;Ret Z
RET

```

; Print a string located [BP] (Used only by the above DISK ID routine)

```

Print_ID_Info:
MOV     CL,[BP+1]                ;Text is low byte high byte format
CALL    CO
MOV     CL,[BP]
CALL    CO
INC     BP
INC     BP
DEC     CH
JNZ     Print_ID_Info
RET

```

; Print a 16 bit number, located [BP] (Used only by the above DISK ID routine)
; (Note Special Low Byte First. Used only for Drive ID)

```

Print_ID_HEX:
MOV     AL,[BP+1]                ;Index to high byte first
CALL    AL_HEXOUT
MOV     AL,[BP]                  ;Now low byte
CALL    AL_HEXOUT
RET

```

;----- Read the current selected sector (based on LBA) to the IDE Buffer

```

READ_SEC:
MOV     AX,CS
MOV     DS,AX
MOV     BP,RAM_DMA
MOV     word [BP],IDE_Buffer    ;DMA initially to IDE_Buffer

CALL    READSECTOR

JZ     Main1B
CALL    CRLF                    ;Here if there was a problem
RET

```

```

Main1B: MOV     BX,msgrd            ;Sector read OK
CALL    PRINT_STRING

MOV     BP,DISPLAY_FLAG        ;Do we have detail sector data display flag on or off
MOV     AL,[BP]                ;NZ = on
OR     AL,AL
JNZ     SHOW_SEC_RDATA
RET

```

```

SHOW_SEC_RDATA:
MOV     BP,RAM_DMA
MOV     word [BP],IDE_Buffer    ;DMA initially to IDE_Buffer
CALL    DISPLAY_SEC
MOV     BX,CR_To_Continue
CALL    PRINT_STRING
CALL    CI
RET

```

;----- Write the current selected sector (based on LBA) from the IDE Buffer

```

WRITE_SEC:

```



```

    MOV     AX,CS
    MOV     DS,AX
    MOV     BX,CONFIRM_WR_MSG      ;Are you sure?
    CALL    PRINT_STRING
    CALL    CICO
    CMP     AL,'Y'
    JZ      WR_SEC_OK1
    CALL    CRLF                    ;Here if there was a problem
    RET

WR_SEC_OK1:
    MOV     BP,RAM_DMA
    MOV     word [BP],IDE_Buffer    ;DMA initially to IDE_Buffer

    CALL    WRITESECTOR            ;Will write whatever is in the IDE_Buffer

    JZ      Main2B
    CALL    CRLF                    ;Here if there was a problem
    RET

Main2B:  MOV     BX,msgrd            ;Sector written OK
    CALL    PRINT_STRING

    MOV     BP,DISPLAY_FLAG        ;Do we have detail sector data display flag on or off
    MOV     off
    MOV     AL,[BP]                ;NZ = on
    OR      AL,AL
    JNZ     SHOW_SEC_WDATA
    RET

SHOW_SEC_WDATA:
    MOV     BP,RAM_DMA
    MOV     word [BP],IDE_Buffer    ;DMA initially to IDE_Buffer
    CALL    DISPLAY_SEC
    MOV     BX,CR_To_Continue
    CALL    PRINT_STRING
    CALL    CI
    RET

;----- Set a new LBA value from imputed Track/Sec info. Send to drive
SET_LBA:MOV     AX,CS
    MOV     DS,AX
    MOV     BX,SET_LBA_MSG          ;Set new LBA and send to drive
    CALL    PRINT_STRING
    CALL    GEN_HEX32_LBA           ;Get new CPM style Track & Sector number and put
them in RAM at RAM_SEC & RAM_TRK
    JB      main3b                  ;Ret C set if abort/error
    CALL    WR_LBA                  ;Update LBA on drive
main3b:  CALL    CRLF
    RET

;----- Toggle detailed sector display on/off
DISPLAY:
    MOV     AX,CS
    MOV     DS,AX
    MOV     BP,DISPLAY_FLAG        ;Do we have detail sector data display flag on or off
    MOV     AL,[BP]                ;NZ = on
    NOT     AL
    MOV     [BP],AL
    RET

;----- Point current sector to next sector

```

```

NEXT_SECT:
    CALL    GET_NEXT_SECT
    JNZ    AT_END
    RET

AT_END:
    MOV     BX,AT_END_MSG           ;Tell us we are at end of disk
    CALL    PRINT_STRING
    RET

;----- Point current sector to previous sector
PREV_SECT:
    CALL    GET_PREV_SECT
    JNZ    AT_START
    RET

AT_START:
    MOV     BX,AT_START_MSG        ;Tell us we are at start of disk
    CALL    PRINT_STRING
    RET

;----- Sequentially read sectors from disk starting at current LBA position
SEQ_SEC_RD:
    MOV     AX,CS
    MOV     DS,AX
    CALL    IDEwaitnotbusy
    JNB    MORE_SEC
    JMP     SHOWerrors

MORE_SEC:
    CALL    CRLF
    MOV     BP,RAM_DMA             ;Set DMA initially to IDE_Buffer

    MOV     CL,'<'
    CALL    CO
    MOV     AX,BP
    CALL    AX_HEXOUT

    MOV     word [BP],IDE_Buffer
    MOV     CL,'.'
    CALL    CO
    MOV     AX,[BP]
    CALL    AX_HEXOUT
    MOV     CL,'>'
    CALL    CO

    CALL    READSECTOR             ;If there are errors they will show up in
    READSECTOR
    JZ     SEQOK

    MOV     BX,CONTINUE_MSG        ;If an error ask if we wish to continue
    CALL    PRINT_STRING
    CALL    CICO
    CMP     AL,ESC                 ;Abort if ESC
    JNZ    SEQOK
    RET

SEQOK:  CALL    DISPLAY_POSITION    ;Display current Track,sector,head#

    MOV     BP,DISPLAY_FLAG        ;Do we have detail sector data display flag on or
off
    MOV     AL,[BP]                ;NZ = on
    OR     AL,AL
    JZ     MORES2
    MOV     BP,RAM_DMA             ;Point DMA to IDE_Buffer again
    MOV     word [BP],IDE_Buffer
    CALL    DISPLAY_SEC

```

```

MORES2: CALL    CSTS                ;Any keyboard character will stop display
        JZ     NO_WAIT
        CALL   CI
        MOV    BX,CONTINUE_MSG
        CALL   PRINT_STRING
        CALL   CI
        CMP    AL,ESC
        JNZ   NO_WAIT
        RET                    ;Bug, is returning to monitor, must be a stack
        problem!
NO_WAIT:CALL   GET_NEXT_SECT        ;Point LBA to next sector
        JZ     MORE_SEC            ;Note will go to last sec on disk unless stopped
        RET

;----- Read N Sectors to disk
;Note unlike the normal sector read, this routine increments the DMA address after each
        sector read

N_RD_SEC:
        MOV    AX,CS
        MOV    DS,AX
        MOV    BX,READN_MSG
        CALL   PRINT_STRING
        CALL   GET2DIGITS          ;Hex to AL

        MOV    BP,SECTOR_COUNT     ;store sector count
        MOV    [BP],AL

        MOV    BP,RAM_DMA_STORE
        MOV    word [BP],IDE_Buffer ;DMA_STORE initially to IDE_Buffer

NextRSec:
        MOV    BX, READN_S_MSG
        CALL   PRINT_STRING
        CALL   WR_LBA              ;Update LBA on drive
        CALL   DISPLAY_POSITION    ;Display current Track,sector,head#

        MOV    BP,RAM_DMA_STORE
        MOV    AX,[BP]             ;Get last value of DMA address
        MOV    BP,RAM_DMA
        MOV    [BP],AX            ;Store it in DMA address

        CALL   READSECTOR          ;Actully, Sector/track values are already updated

        MOV    BP,RAM_DMA
        MOV    AX,[BP]             ;Store it in DMA_STORE address
        MOV    BP,RAM_DMA_STORE
        MOV    [BP],AX

        MOV    BP,SECTOR_COUNT
        MOV    AL,[BP]
        DEC    AL
        MOV    [BP],AL
        JNZ   NEXT_SEC_NRD
        RET

NEXT_SEC_NRD:
        CALL   GET_NEXT_SECT
        JZ     NextRSec
        MOV    BX,AT_END_MSG       ;Tell us we are at end of disk
        CALL   PRINT_STRING

```

```
RET
```

```
;----- Write N Sectors to disk
;Note unlike the normal sector write routine, this routine increments the DMA address after
each write.
```

```
N_WR_SEC:
```

```
MOV     AX,CS
MOV     DS,AX
MOV     BX,CONFIRM_WR_MSG      ;Are you sure?
CALL    PRINT_STRING
CALL    CICO
CMP     AL,'Y'
JZ      WR_SEC_OK2
CALL    CRLF                    ;Here if there was a problem
RET
```

```
WR_SEC_OK2:
```

```
MOV     BX,WRITEN_MSG
CALL    PRINT_STRING
CALL    GET2DIGITS              ;Hex to AL

MOV     BP,SECTOR_COUNT        ;store sector count
MOV     [BP],AL

MOV     BP,RAM_DMA_STORE
MOV     word [BP],IDE_Buffer    ;DMA_STORE initially to IDE_Buffer
```

```
NextWSec:
```

```
MOV     BX, WRITEN_S_MSG
CALL    PRINT_STRING
CALL    WR_LBA                  ;Update LBA on drive
CALL    DISPLAY_POSITION        ;Display current Track,sector,head#

MOV     BP,RAM_DMA_STORE
MOV     AX,[BP]                 ;Get last value of DMA address
MOV     BP,RAM_DMA
MOV     [BP],AX                ;Store it in DMA address

CALL    WRITESECTOR            ;Actully, Sector/track values are already updated

MOV     BP,RAM_DMA
MOV     AX,[BP]                 ;Store it in DMA_STORE address
MOV     BP,RAM_DMA_STORE
MOV     [BP],AX

MOV     BP,SECTOR_COUNT
MOV     AL,[BP]
DEC     AL
MOV     [BP],AL
JNZ     NEXT_SEC_NWR
RET
```

```
NEXT_SEC_NWR:
```

```
CALL    GET_NEXT_SECT
JZ      NextWSec
MOV     BX,AT_END_MSG          ;Tell us we are at end of disk
CALL    PRINT_STRING
RET
```

```
;----- Format current disk
```

```
FORMAT:
```

```
MOV     AX,CS
```

```

        MOV     DS,AX
        MOV     BP,CURRENT_IDE_DRIVE
        MOV     AL,[BP]
        OR      AL,AL
        JNZ     FORM_B
        MOV     BX,FORMAT_MSG_A
        JMP     FORM_X
FORM_B: MOV     BX,FORMAT_MSG_B
FORM_X: CALL    PRINT_STRING
        MOV     BX,CONFIRM_WR_MSG      ;Are you sure?
        CALL    PRINT_STRING
        CALL    CICO
        CMP     AL,'Y'
        JZ      FORMAT_OK
        RET

FORMAT_OK:
        MOV     AX,0                    ;Back to CPM sector 0
        MOV     BP,RAM_SEC              ;Get Current Sector
        MOV     [BP],AX                 ;0 to CPM Sectors

        MOV     BP,RAM_TRK              ;And track
        MOV     [BP],AX

        MOV     AX,0E5E5H                ;First set Sector pattern to E5's
        CALL    RAM_FILL
        CALL    CRLF

NEXT_FORMAT:
        MOV     BP, RAM_DMA              ;Point DMA to the area
        MOV     word [BP],IDE_Buffer

        CALL    WRITESECTOR              ;Will return error if there was one
        JZ      NEXTF1                   ;Z means the sector write was OK

        MOV     BX,FORMAT_ERR            ;Indicate an error
        CALL    PRINT_STRING
        CALL    SHOW_TRACK_SEC           ;Show current location of error
        CALL    CRLF
        JMP     FNEXTSEC3

NEXTF1: MOV     BP,RAM_SEC                ;Get Current Sector
        MOV     AX,[BP]
        OR      AX,AX                    ;At start of each track give an update
        JNZ     FNEXTSEC2

        CALL    SHOW_TRACK

FNEXTSEC2:
        CALL    CSTS                      ;Any keyboard character will stop display
        JZ      FNEXTSEC1
        CALL    CI                          ;Flush character

FNEXTSEC3:
        MOV     BX,CONTINUE_MSG
        CALL    PRINT_STRING
        CALL    CICO
        CMP     AL,ESC
        JNZ     FNEXTSEC1

F_DONE: MOV     AL,0                      ;Login drive A:
        CALL    SELECT_DRIVE
        MOV     BP,CURRENT_IDE_DRIVE
        MOV     [BP],AL
        RET

FNEXTSEC1:
        CALL    GET_NEXT_SECT

```

```

JZ     NEXT_FORMAT
MOV    BX,AT_END_MSG           ;Tell us we are at end of disk
CALL   PRINT_STRING
JMP    F_DONE

```

```

;----- Copy Drive A: to Drive B: -----
COPY_AB:

```

```

MOV    AX,CS
MOV    DS,AX
MOV    BX,DiskCopyMsg
CALL   PRINT_STRING
CALL   CICO
CMP    AL,'Y'
JZ     COPY_AB1
JMP    C_DONE

```

```

COPY_AB1:
MOV    BP, RAM_SEC             ;Start with CPM sector 0
MOV    AX,0
MOV    [BP],AX
MOV    BP, RAM_TRK            ;Start with CPM Track 0
MOV    AX,0
MOV    [BP],AX                ;High & Low Track to 0
CALL   CRLF
CALL   CRLF

```

```

NextDCopy:
MOV    AL,0                    ;Login drive A:
CALL   SELECT_DRIVE

CALL   WR_LBA                  ;Update LBA on "A:" drive

MOV    BP, RAM_DMA
MOV    word [BP], IDE_Buffer    ;DMA initially to IDE_Buffer

CALL   READSECTOR              ;Get sector data from A: drive to buffer

MOV    AL,1                    ;Login drive B:
CALL   SELECT_DRIVE

CALL   WR_LBA                  ;Update LBA on "B:" drive

MOV    BP, RAM_DMA
MOV    word [BP], IDE_Buffer    ;DMA initially to IDE_Buffer

CALL   WRITESECTOR             ;Write buffer data to sector on B: drive
JZ     COPY_OK1

MOV    BX, COPY_ERR            ;Indicate an error
CALL   PRINT_STRING
CALL   SHOW_TRACK_SEC          ;Show current location of error
CALL   CRLF
JMP    COPY_OK3

```

```

COPY_OK1:
MOV    BP, RAM_SEC             ;Get Current Sector
MOV    AX, [BP]
OR     AX, AX                   ;At start of each track give an update
JNZ    COPY_OK2

CALL   SHOW_TRACK

```

```

COPY_OK2:
CALL   CSTS                    ;Any keyboard character will stop display
JZ     C_NEXTSEC1
CALL   CI                       ;Flush character

```

```

COPY_OK3:
    MOV     BX,CONTINUE_MSG
    CALL   PRINT_STRING
    CALL   CICO
    CMP    AL,ESC
    JNZ   C_NEXTSEC1
C_DONE:  MOV    AL,0                      ;Login drive A:
    CALL   SELECT_DRIVE
    MOV    BP,CURRENT_IDE_DRIVE
    MOV    [BP],AL
    RET

C_NEXTSEC1:
    CALL   GET_NEXT_SECT                ;Update to next sector/track
    JNZ   C_NEXTSEC2
    JMP   NextDCopy

C_NEXTSEC2:
    MOV    BX,CopyDone                  ;Tell us we are all done.
    CALL   PRINT_STRING
    JMP   C_DONE

;----- Verify Drive A: = B: -----
VERIFY_AB:
    MOV    AX,CS
    MOV    DS,AX
    MOV    BX,DiskVerifyMsg
    CALL   PRINT_STRING

    MOV    BP,RAM_SEC                   ;Start with CPM sector 0
    MOV    AX,0
    MOV    [BP],AX
    MOV    BP,RAM_TRK                  ;Start with CPM Track 0
    MOV    AX,0
    MOV    [BP],AX                     ;High & Low Track to 0

    CALL   CRLF
    CALL   CRLF

NextVCopy:
    MOV    AL,0                          ;Login drive A:
    CALL   SELECT_DRIVE

    CALL   WR_LBA                        ;Update LBA on "A:" drive

    MOV    BP,RAM_DMA
    MOV    word [BP],IDE_Buffer          ;DMA initially to IDE_Buffer

    CALL   READSECTOR                   ;Get sector data from A: drive to buffer

    MOV    AL,1                          ;Login drive B:
    CALL   SELECT_DRIVE

    CALL   WR_LBA                        ;Update LBA on "B:" drive

    MOV    BP,RAM_DMA
    MOV    word [BP],IDE_Buffer2        ;DMA initially to IDE_Buffer2

    CALL   READSECTOR

    MOV    DI,IDE_Buffer2
    MOV    SI,IDE_Buffer
    MOV    CX,512                        ;Length of sector in words

NEXT_CMP:

```

```

        MOV     AL, [SS:DI]           ;Note we have to use SS:
        CMP     AL, [SS:SI]
        JNZ    VER_ERROR
        INC     DI
        INC     SI
        LOOP   NEXT_CMP             ;CX will contain count of words done so far, (0 if ✓
done OK)
        JMP     VERIFY_OK

VER_ERROR:
        MOV     BX,VERIFY_ERR       ;Indicate an error
        CALL   PRINT_STRING
        CALL   SHOW_TRACK_SEC       ;Show current location of error
        MOV     BX,DRIVE1_MSG       ;' Drive A',CR,LF
        CALL   PRINT_STRING

        MOV     SI,IDE_Buffer
        MOV     CX,512              ;Length of sector in words
VER_SOURCE:
        MOV     AL, [SS:SI]         ;Note we have to use SS:
        CALL   AL_HEXOUT
        INC     SI
        LOOP   VER_SOURCE
        CALL   CRLF
        CALL   SHOW_TRACK_SEC       ;Show current location of error
        MOV     BX,DRIVE2_MSG       ;' Drive B',CR,LF
        CALL   PRINT_STRING

        MOV     SI,IDE_Buffer2
        MOV     CX,512              ;Length of sector in words
VER_DEST:
        MOV     AL, [SS:DI]         ;Note we have to use SS:
        CALL   AL_HEXOUT
        INC     DI
        LOOP   VER_DEST
        CALL   CRLF
        JMP     VERIFYT             ;Do not ask for a continue message here. Just ✓
continue

;If you want it change to VERIFYT1

VERIFY_OK:
        MOV     BP,RAM_SEC          ;Get Current Sector
        MOV     AX,[BP]
        OR     AX,AX                ;At start of each track give an update
        JNZ    VERIFYT

        CALL   SHOW_TRACK

VERIFYT:CALL   CSTS                  ;Any keyboard character will stop display
        JZ     V_NEXTSEC1
        CALL   CI                    ;Flush character
VERIFYT1:
        MOV     BX,CONTINUE_MSG
        CALL   PRINT_STRING
        CALL   CICO
        CMP     AL,ESC
        JNZ    V_NEXTSEC1
        JMP     V_NEXTSEC3
V_NEXTSEC1:
        CALL   GET_NEXT_SECT        ;Update to next sector/track
        JNZ    V_NEXTSEC2
        JMP     NextVCopy
V_NEXTSEC2:
        MOV     BX,VerifyDone       ;Tell us we are all done.
        CALL   PRINT_STRING
V_NEXTSEC3:
        MOV     AL,0                ;Login drive A:

```



```

CALL    SELECT_DRIVE
MOV     BP,CURRENT_IDE_DRIVE
MOV     [BP],AL
RET

```

;----- Fill RAM buffer with 0's

```

RAMCLEAR:
MOV     AX,CS
MOV     DS,AX
MOV     AX,0

RAM_FILL:
MOV     BP,IDE_Buffer
MOV     CX,256                ;512 bytes total
CLEAR1: MOV     [BP],AX        ;Note this will be SS:BP
INC     BP
INC     BP
LOOP    CLEAR1

MOV     BX,FILL_MSG
CALL    PRINT_STRING
RET

```

;----- Power up a Hard Disk

```

SPINUP: MOV     DH,COMMANDspinup
spup2:  MOV     DL,REGcommand
CALL    IDEwr8D
CALL    IDEwaitnotbusy
JNB    L_7
JMP    SHOWerrors
L_7:    OR      AL,AL          ;Clear carry
RET

```

;----- Tell the Hard disk to power down

```

SPINDOWN:
CALL    IDEwaitnotbusy
JNB    L_8
JMP    SHOWerrors
L_8:    MOV     DH,COMMANDspindown
JMP    spup2

```

;----- Back to parent 8086 Monitor commands

```

QUIT_IDE:
JMP     INIT

```

;===== Support Routines FOR IDE MODULE =====

;Generate an LBA sector number with data input from CPM style Track# & Sector#

```

GEN_HEX32_LBA:
MOV     BX,ENTERRAM_SECL      ;Enter sector number, low
CALL    PRINT_STRING
CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX
Unchanged)
MOV     BP,RAM_SEC

```

```

MOV     [BP],AL           ;Note: no check that data is < MAXSEC
CALL    CRLF

MOV     BX,ENTERRAM_TRKL ;Enter low byte track number
CALL    PRINT_STRING
CALL    GET2DIGITS       ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     BP,RAM_TRK
MOV     [BP],AL
CALL    CRLF

MOV     BX,ENTERRAM_TRKH ;Enter high byte track number
CALL    PRINT_STRING
CALL    GET2DIGITS       ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     BP,RAM_TRK+1
MOV     [BP],AL
XOR     AL,AL
OR      AL,AL             ;To return NC
RET

DISPLAY_POSITION:        ;Display current track,sector & head position
MOV     BX,msgCPMTRK     ;Display in LBA format
CALL    PRINT_STRING     ;---- CPM FORMAT ----
MOV     BP,RAM_TRK+1
MOV     AL,[BP]          ;High TRK byte
CALL    AL_HEXOUT
DEC     BP
MOV     AL,[BP]          ;Low TRK byte
CALL    AL_HEXOUT

MOV     BX,msgCPMSEC
CALL    PRINT_STRING     ;SEC = (16 bits)
MOV     BP,RAM_SEC+1    ;High Sec
MOV     AL,[BP]
CALL    AL_HEXOUT
DEC     BP
MOV     AL,[BP]          ;Low sec
CALL    AL_HEXOUT

;---- LBA FORMAT ----
MOV     BX,msgLBA
CALL    PRINT_STRING     ;(LBA = 00 (<-- Old "Heads" = 0 for these drives).

MOV     BP,RAM_DRIVE_TRK+1 ;High "cylinder" byte
MOV     AL,[BP]
CALL    AL_HEXOUT
DEC     BP
MOV     AL,[BP]          ;Low "cylinder" byte
CALL    AL_HEXOUT

MOV     BP,RAM_DRIVE_SEC
MOV     AL,[BP]
CALL    AL_HEXOUT
MOV     BX,MSGBracket    ;)$
CALL    PRINT_STRING
RET

SHOW_TRACK_SEC:         ;Display current (CPM) track,sector
MOV     BX,msgCPMTRK
CALL    PRINT_STRING     ;---- CPM FORMAT ----
MOV     BP,RAM_TRK+1
MOV     AL,[BP]          ;High TRK byte
CALL    AL_HEXOUT
DEC     BP

```

```

        MOV     AL,[BP]                ;Low TRK byte
        CALL   AL_HEXOUT
        MOV     BX,msgCPMSEC
        CALL   PRINT_STRING

        MOV     BP,RAM_SEC             ;Low Sec (Only)
        MOV     AX,[BP]
        CALL   AL_HEXOUT
        MOV     BX,H_MSG
        CALL   PRINT_STRING
        RET

SHOW_TRACK:
        MOV     BX,msgCPMTRK
        CALL   PRINT_STRING           ;---- CPM FORMAT ----
        MOV     BP,RAM_TRK+1
        MOV     AL,[BP]               ;High TRK byte
        CALL   AL_HEXOUT
        MOV     BP,RAM_TRK
        MOV     AL,[BP]               ;Low TRK byte
        CALL   AL_HEXOUT
        MOV     BX,OK_CR_MSG
        CALL   PRINT_STRING           ;---- CPM FORMAT ----
        RET

DISPLAY_SEC:                           ;Print a DISPLAY_SEC of the data in the 512 byte
        IDE_Buffer (RAM_DMA)
        CALL   CRLF                   ;Note written so it can be easily converted to a
        "normal: DS: based" routine
        MOV     BP,RAM_DMA            ;Get Current DMA Address
        MOV     SI,[BP]               ;Both DS:DI & SI point to buffer
        MOV     DI,SI
        MOV     DH,32                 ;print 32 lines

SF172:  CALL   CRLF
        call   SHOW_ADDRESS_SS        ;Show SS:SI
        mov    cx,2                    ;send 2 spaces
        call   TABS
        MOV    DL,16                   ;32 characters across
SF175:  MOV    AL,[SS:SI]
        CALL   AL_HEXOUT               ;Display A on CRT/LCD
        MOV    AL,'~'
        CALL   CO
        INC    SI
        DEC    DL
        JNZ   SF175

        mov    cx,3                    ;first send 3 spaces
        call   TABS

        MOV    DL,16                   ;24 across again
Sloop2: mov    al,[SS:DI]
        and    al,7fh
        cmp    al,' '                  ;filter out control characters
        jnc   Sloop3
Sloop4: mov    al,'.'
Sloop3: cmp    al,'~'
        jnc   Sloop4
        mov    cl,al
        call   CO
        INC    DI
        DEC    DL
        JNZ   Sloop2
        DEC    DH
        JNZ   SF172                   ;--DH has total byte count

```

```

        CALL    CRLF
        ret

;Point to next sector.  Ret Z if all OK NZ if at end of disk
GET_NEXT_SECT:
        MOV     BP, RAM_SEC           ;Get Current Sector
        MOV     AX, [BP]
        INC     AX
        MOV     [BP], AX             ;0 to MAXSEC CPM Sectors
        CMP     AX, MAXSEC-1         ;Assumes < 255 sec /track
        JNZ     NEXT_SEC_DONE

        MOV     AX, 0                 ;Back to CPM sector 0
        MOV     [BP], AX

        MOV     BP, RAM_TRK          ;Bump to next track
        MOV     AX, [BP]
        INC     AX
        CMP     AX, 100H              ;Tracks 0-0FFH only
        JZ      AT_DISK_END
        MOV     [BP], AX

NEXT_SEC_DONE:
        CALL    WR_LBA                ;Update the LBC pointer
        XOR     AX, AX
        RET                            ;Ret z if all OK

AT_DISK_END:
        XOR     AX, AX
        DEC     AX
        RET

;Point to previous sector.  Ret Z if all OK
GET_PREV_SECT:
        MOV     BP, RAM_SEC           ;Get Current Sector
        MOV     AX, [BP]
        CMP     AX, 0
        JZ      PREVIOUS_TRACK
        DEC     AX
        MOV     [BP], AX             ;0 to MAXSEC CPM Sectors
        JMP     PREVIOUS_SEC_DONE

PREVIOUS_TRACK:
        MOV     AX, MAXSEC-1          ;Back to CPM last sector on previous track
        MOV     [BP], AX

        MOV     BP, RAM_TRK          ;Bump to next track
        MOV     AX, [BP]
        CMP     AX, 0                 ;If On track 0 already then problem
        JNZ     AT_00
        DEC     AX
        MOV     [BP], AX

PREVIOUS_SEC_DONE:
        CALL    WR_LBA                ;Update the LBC pointer
        XOR     AX, AX                ;Return Z if all OK
        RET

AT_00:  MOV     BX, ATHOME_MSG
        CALL    PRINT_STRING
        XOR     AX, AX
        DEC     ax                    ;NZ if problem
        RET

;
SHOWerrors:

```

```

CALL    CRLF
MOV     DL,REGstatus           ;Get status in status register
CALL   IDERd8D
MOV     AL,DH
AND     AL,1H
JNZ     MoreError             ;Go to REGerr register for more info
                                       ;All OK if 01000000

PUSHF                                ;<<< Save for return below
AND     AL,80H
JZ      NOT7
MOV     BX,DRIVE_BUSY         ;Drive Busy (bit 7) stuck high.  Status =
CALL   PRINT_STRING
JMP     DONEERR

NOT7:   AND     AL,40H
JNZ     NOT6
MOV     BX,DRIVE_NOT_READY    ;Drive Not Ready (bit 6) stuck low.  Status =
CALL   PRINT_STRING
JMP     DONEERR

NOT6:   AND     AL,20H
JNZ     NOT5
MOV     BX,DRIVE_WR_FAULT     ;Drive write fault.  Status =
CALL   PRINT_STRING
JMP     DONEERR

NOT5:   MOV     BX,UNKNOWN_ERROR
CALL   PRINT_STRING
JMP     DONEERR

MoreError:                               ;Get here if bit 0 of the status register indicted ✓
a problem
MOV     DL,REGerr             ;Get error code in REGerr
CALL   IDERd8D
MOV     AL,DH
PUSHF                                ;<<<< Save flags for below

AND     AL,10H
JZ      NOTE4
MOV     BX,SEC_NOT_FOUND
CALL   PRINT_STRING
JMP     DONEERR

NOTE4:  AND     AL,80H
JZ      NOTE7
MOV     BX,BAD_BLOCK
CALL   PRINT_STRING
JMP     DONEERR

NOTE7:  AND     AL,40H
JZ      NOTE6
MOV     BX,UNRECOVER_ERR
CALL   PRINT_STRING
JMP     DONEERR

NOTE6:  AND     AL,4H
JZ      NOTE2
MOV     BX,INVALID_CMD
CALL   PRINT_STRING
JMP     DONEERR

NOTE2:  AND     AL,2H
JZ      NOTE1
MOV     BX,TRK0_ERR
CALL   PRINT_STRING

```

```

        JMP     DONEERR

NOTE1:  MOV     BX,UNKNOWN_ERROR1
        CALL   PRINT_STRING
        JMP     DONEERR

DONEERR:POPF                     ;>>>> get back flags
        PUSH  AX
        CALL  AL_BINOUT           ;Show error bit pattern
        CALL  CRLF
        POP   AX
        XCHG AL,AH
        OR    AL,AL               ;Set Z flag
        STC                               ;Set Carry flag
        RET

;=====
; IDE Drive BIOS Routines written in a format that can be used with CPM86 (Note MSDOS/DOS
; has its own
; modules see further below. However instead of using DS:[BX] (as we do in the CPM86 BIOS),
; throughout we
; will use SS:[BP] so the the buffers can reside at the top segment of available RAM.
; Normally this will be D000:E000H but the monitor will not assume that there is a
; full 1MG address space available and may put them lower. See monitor initialization code
; at start.
;=====

IDEinit:                               ;Initilze the 8255 and drive then do a hard reset
        on the drive,                 ;By default the drive will come up initilized in
                                       ;LBA mode.
        MOV     AL,READcfg8255         ;10010010b
        OUT    IDECtrlPort,AL        ;Config 8255 chip, READ mode

        MOV     AL,IDERstline
        OUT    IDEportC,AL           ;Hard reset the disk drive

        MOV     CH,IDE_Reset_Delay    ;;Time delay for reset/initilization (~66 uS, with
        8MHz 8086, 1 I/O wait state)

ResetDelay:
        DEC     CH
        JNZ    ResetDelay            ;Delay (IDE reset pulse width)
        XOR     AL,AL
        OUT    IDEportC,AL          ;No IDE control lines asserted

        CALL   DELAY_SHORT           ;Allow time for CF/Drive to recover

        MOV     DH,11100000b         ;Data for IDE SDH reg (512bytes, LBA mode,single
        drive,head 0000)
;        MOV     DH,10100000b         ;For Trk,Sec,head (non LBA) use 10100000 (This is
        the mode we use for MSDOS)
;        ;Note. Cannot get LBA mode to work with an old
        Seagate Medalist 6531 drive.
;        ;have to use the non-LBA mode. (Common for old hard
        disks).
        MOV     DL,REGshd            ;00001110, (0EH) for CS0,A2,A1,
        CALL   IDEwr8D              ;Write byte to select the MASTER device

        MOV     CH,IDR_POWER_DELAY   ;03H,<<< May need to adjust delay time with some
        old drives.

WaitInit:

```

```

        MOV     DL,REGstatus           ;Get status after initialization
        CALL   IDErd8D                ;Check Status (info in [DH])
        MOV     AL,DH
        AND     AL,80H
        JZ      DoneInit              ;Return if ready bit is zero
        CALL   DELAY_LONG             ;Long delay, drive has to get up to speed
        DEC     CH
        JNZ     WaitInit
        XOR     AL,AL
        DEC     AL
        RET                               ;Return NZ. Well check for errors when we get back
DoneInit:
        RET                               ;Return Z indicating all is well

DELAY_LONG:                            ;Long delay (Seconds) for hard disk to get up to speed
        speed
        PUSH   CX
        PUSH   DX
        MOV    CX,0FFFFH
DELAY2:  MOV    DH,2                    ;May need to adjust delay time to allow cold drive
        to
DELAY1:  DEC    DH                      ;to speed
        JNZ   DELAY1
        DEC   CX
        JNZ   DELAY2
        POP   DX
        POP   CX
        RET

DELAY_SHORT:
        MOV    AX,8000H                ;DELAY ~32 MS (DOES NOT SEEM TO BE CRITICAL)
DELAY3:  DEC    AX
        JNZ   DELAY3
        RET

;Read a sector, specified by the 4 bytes in LBA
;Z on success, NZ call error routine if problem
READSECTOR:
        CALL   WR_LBA                 ;Tell which sector we want to read from.
;Note: Translate first in case of an error
        otherwise we
;will get stuck on bad sector
        CALL   IDEwaitnotbusy        ;make sure drive is ready
        JNB   L_19
        JMP   SHOWerrors              ;Returned with NZ set if error

L_19:   MOV    DH,COMMANDread
        MOV    DL,REGcommand
        CALL   IDEwr8D                ;Send sec read command to drive.
        CALL   IDEwaitdrq            ;wait until it's got the data
        JNB   L_20
        JMP   SHOWerrors

L_20:   MOV    BP, RAM_DMA             ;Get Current DMA Address at SS:RAM_DMA
        MOV    AX,[BP]                ;Note SS: is assumed here
        MOV    BP,AX
        MOV    CH,0                   ;Read 512 bytes to [HL] (256X2 bytes)

MoreRD16:
        MOV    AL,REGdata             ;REG register address
        OUT   IDEportC,AL

        OR     AL,IDErdline           ;08H+40H, Pulse RD line

```

```

        OUT     IDEportC,AL

        IN     AL,IDEportA           ;Read the lower byte first
        MOV    [BP],AL
        INC    BP
        IN     AL,IDEportB         ;THEN read the upper byte
        MOV    [BP],AL
        INC    BP

        MOV    AL,REGdata           ;Deassert RD line
        OUT    IDEportC,AL
        DEC    CH
        JNZ    MoreRD16

        MOV    DL,REGstatus
        CALL   IDERd8D
        MOV    AL,DH
        AND    AL,1H
        JZ     L_21
        CALL   SHOWerrors           ;If error display status
L_21:   RET

                                           ;Write a sector, specified by the 3 bytes in LBA (
                                           ;Z on success, NZ to error routine if problem
WRITESECTOR:
        CALL   WR_LBA               ;Tell which sector we want to read from.
                                           ;Note: Translate first in case of an error
        otherwise we
                                           ;will get stuck on bad sector
        CALL   IDEwaitnotbusy       ;make sure drive is ready
        JNB   L_22
        JMP   SHOWerrors

L_22:   MOV    DH,COMMANDwrite
        MOV    DL,REGcommand
        CALL   IDEwr8D              ;tell drive to write a sector
        CALL   IDEwaitdrq          ;wait unit it wants the data
        JNB   L_23
        JMP   SHOWerrors

L_23:   MOV    BP, RAM_DMA           ;Get Current DMA Address
        MOV    AX,[BP]
        MOV    BP,AX
        MOV    CH,0                 ;256X2 bytes

        MOV    AL,WRITEcfg8255
        OUT    IDECtrlPort,AL

WRSEC1_IDE:
        MOV    AL,[BP]
        INC    BP
        OUT    IDEportA,AL         ;Write the lower byte first
        MOV    AL,[BP]
        INC    BP
        OUT    IDEportB,AL         ;THEN High byte on B

        MOV    AL,REGdata
        PUSH   AX
        OUT    IDEportC,AL         ;Send write command
        OR     AL,IDEwrline        ;Send WR pulse
        OUT    IDEportC,AL
        POP    AX
        OUT    IDEportC,AL         ;Send write command
        DEC    CH

```



```

        JNZ      WRSEC1_IDE

        MOV     AL,READcfg8255      ;Set 8255 back to read mode
        OUT     IDECtrlPort,AL

        MOV     DL,REGstatus
        CALL    IDErd8D
        MOV     AL,DH
        AND     AL,1H
        JZ      L_24
        CALL    SHOWerrors         ;If error display status
L_24:   RET

WR_LBA:                                ;Write the logical block address to the drive's registers ✓
        LBA                                ;Note we do not need to set the upper nibble of the
        no High Cylinder                ;It will always be 0 for these small CPM drives (so
                                        ;numbers etc).
        MOV     BP,RAM_SEC
        MOV     AX,[BP]              ;LBA mode, Low sectors go directly
        INC     AX                    ;Sectors are numbered 1 -- MAXSEC (even in LBA mode) ✓
        MOV     BP,RAM_DRIVE_SEC
        MOV     [BP],AL              ;For Diagnostic Diaplay Only
        MOV     DH,AL
        MOV     DL,REGsector         ;Send info to drive
        CALL    IDEwr8D              ;Write to 8255 A Register
                                        ;Note: For drive we will have 0 - MAXSEC sectors only ✓

        MOV     BP,RAM_TRK
        MOV     AX,[BP]
        MOV     BP,RAM_DRIVE_TRK
        MOV     [BP],AL
        MOV     DH,AL                ;Send Low TRK#
        MOV     DL,REGcylinderLSB
        CALL    IDEwr8D              ;Write to 8255 A Register

        MOV     BP,RAM_DRIVE_TRK+1
        MOV     [BP],AH
        MOV     DH,AH                ;Send High TRK#
        MOV     DL,REGcylinderMSB
        CALL    IDEwr8D              ;Send High TRK# (in DH) to IDE Drive
        CALL    IDEwr8D_X            ;Special write to 8255 B Register (Not A) to update LED HEX Display ✓
                                        ;High 8 bits ignored by IDE drive

        MOV     DH,1                  ;For CPM, one sector at a time
        MOV     DL,REGsecCnt
        CALL    IDEwr8D              ;Write to 8255 A Register
        RET

                                        ;Special version for MS-DOS system BIOS ✓
        (see IBM BIOS Section)

DOS_WR_LBA:                             ;This will display Head, Cylinder and Sector on the LED HEX display ✓
        MOV     DH,[CURRENT_HEAD]    ;instead of LBA sector numbers.
        AND     DH,0FH                ;OR in head info to lower 4 bits
        OR      DH,1010000B           ;Just in case
        MOV     DL,REGshd             ;Set to >>>>> NON-LBA mode <<<<<
        CALL    IDEwr8D              ;Send "Head #" (in DH) to IDE drive

```

```

MOV     DH, [CURRENT_TRACK_HIGH]           ;Send High TRK#
MOV     DL, REGcylinderMSB
CALL    IDEwr8D                             ;Send High TRK# (in DH) to IDE Drive

MOV     DH, [CURRENT_HEAD]                 ;Get head info to lower 8 bits of the
special                                     ;
AND     DH, 0FH                             ;top two LED HEX displays.
SHL     DH, 1                               ;These 8 (high) data lines are ignored by
the IDE drive                               ;
SHL     DH, 1
SHL     DH, 1
SHL     DH, 1
OR      DH, [CURRENT_TRACK_HIGH]           ;Will display the Head in top nibble and
the two bits of the HIGH bits               ;
MOV     DL, REGcylinderMSB                 ;of the high cylinder in the low nibble.
CALL    IDEwr8D_X                           ;Special output to 8255 B Register (Not A)
to update LED HEX Display ONLY              ;

MOV     DH, [CURRENT_TRACK]                ;Get low Track #
MOV     DL, REGcylinderLSB                 ;Send Low TRK# (in DH)
CALL    IDEwr8D                             ;Special write to 8255 B Register (Not A)

MOV     DH, [CURRENT_SECTOR]               ;Bits 0-5 only (currently 1-17)
MOV     DL, REGsector                       ;Send "Sector#"
CALL    IDEwr8D                             ;Write to 8255 A Register

MOV     DH, [SECTORS_TO_DO]                ;# of CONTIGOUS sectors to send
MOV     DL, REGsecCnt                       ;
CALL    IDEwr8D                             ;Write to 8255 A Register
RET

IDEwaitnotbusy:                             ;Drive READY if 01000000
MOV     CH, 0FFH
MOV     AH, 0FFH                             ;Delay, must be above 80H for 4MHz Z80. Leave
longer for slower drives                    ;
PUSH    BX                                   ;AH is not changed in IDErd8D below
MoreWait:
MOV     DL, REGstatus                       ;wait for RDY bit to be set
CALL    IDErd8D                             ;Note AH or CH are unchanged
MOV     AL, DH
AND     AL, 11000000B
XOR     AL, 01000000B
JZ      DONE_NOT_BUSY
DEC     CH
JNZ     MoreWait
DEC     AH
JNZ     MoreWait
STC                                     ;Set carry to indicate an error
POP     BX
RET

DONE_NOT_BUSY:
OR      AL, AL                               ;Clear carry it indicate no error
POP     BX
RET

IDEwaitdrq:                                 ;Wait for the drive to be ready to transfer data.
;Returns the drive's status in Acc
MOV     CH, 0FFH
MOV     AL, 0FFH                             ;Delay, must be above 80H for 4MHz Z80. Leave
longer for slower drives                    ;
PUSH    BX
MoreDRQ:
MOV     DL, REGstatus                       ;wait for DRQ bit to be set

```

```

        CALL    IDErd8D                ;Note AH or CH are unchanged
        MOV     AL,DH
        AND    AL,10001000B
        CMP    AL,00001000B
        JZ     DoneDRQ
        DEC    CH
        JNZ    MoreDRQ
        DEC    AH
        JNZ    MoreDRQ
        STC                                ;Set carry to indicate error
        POP    BX
        RET
DoneDRQ:
        OR     AL,AL                    ;Clear carry
        POP    BX
        RET

CLEAR$ID$BUFFER:                      ;Clear the ID Buffer area
        MOV    AX,2020H                ;Clear to spaces
        MOV    BP,IDE_Buffer           ;Remember CS: = SS
        MOV    CX,256                  ;512 bytes total
CLEAR2: MOV    [BP],AX                 ;Note this will be SS:[BP]
        INC    BP
        INC    BP
        LOOP   CLEAR2

        MOV    AX,0H                   ;Put in 0's for cylinder,heads,sectors etc
        MOV    BP,IDE_Buffer
        MOV    CX,7                    ;14 bytes total
CLEAR3: MOV    [BP],AX                 ;Note this will be SS:[BP]
        INC    BP
        INC    BP
        LOOP   CLEAR3
        RET

;-----
; Low Level 8 bit R/W to the drive controller.  These are the routines that talk
; directly to the drive controller registers, via the 8255 chip.
; Note the 16 bit Sector I/O to the drive is done directly
; in the routines READSECTOR & WRITESECTOR for speed reasons.

IDEr8D:                                ;READ 8 bits from IDE register @ [DL], return info
        in    [DH]
        MOV    AL,DL                    ;select IDE register
        OUT    IDEportC,AL              ;drive address onto control lines

        OR    AL,IDERdline              ;RD pulse pin (40H)
        OUT    IDEportC,AL              ;Assert read pin

        IN    AL,IDEportA
        MOV    DH,AL                    ;return with data in [DH]

        MOV    AL,DL                    ;<---Ken Robbins suggestion
        OUT    IDEportC,AL              ;Drive address onto control lines

        XOR    AL,AL
        OUT    IDEportC,AL              ;Zero all port C lines
        RET

IDEwr8D:                                ;WRITE Data in [DH] to IDE register @ [DL]
        MOV    AL,WRITEcfg8255          ;Set 8255 to write mode
        OUT    IDECtrlPort,AL

```

```

MOV     AL,DH                ;Get data put it in 8255 A port
OUT     IDEportA,AL

MOV     AL,DL                ;select IDE register
OUT     IDEportC,AL

OR      AL,IDEwrline        ;lower WR line
OUT     IDEportC,AL

MOV     AL,DL                ;<-- Ken Robbins suggestion, raise WR line
OUT     IDEportC,AL        ;deassert RD pin

XOR     AL,AL                ;Deselect all lines including WR line
OUT     IDEportC,AL

MOV     AL,READcfg8255      ;Config 8255 chip, read mode on return
OUT     IDECtrlPort,AL
RET

IDEwr8D_X:                    ;WRITE Data in [DH] to IDE register @ [DL]
MOV     AL,WRITEcfg8255     ;Set 8255 to write mode
OUT     IDECtrlPort,AL

MOV     AL,DH                ;Get data and put it in 8255 >>>> Port B <<<<
OUT     IDEportB,AL

MOV     AL,DL                ;select IDE register
OUT     IDEportC,AL

OR      AL,IDEwrline        ;lower WR line
OUT     IDEportC,AL

MOV     AL,DL                ;<-- Ken Robbins suggestion, raise WR line
OUT     IDEportC,AL        ;Deassert RD pin

XOR     AL,AL                ;Deselect all lines including WR line
OUT     IDEportC,AL

MOV     AL,READcfg8255      ;Config 8255 chip, read mode on return
OUT     IDECtrlPort,AL
RET

;*****
;
; "BIOS" section to allow MS-DOS 4.1 to run on non-IBM hardware.
; 8086 assembly language for the CP/M-86 assembler. This is a highly
; modified version of a BIOS first written by LogiCom Inc back in 1985.
;
; It enables a standard IBM-PC PC-DOS V2.1 to run with S100Computers/N8VEM Boards.
;
;*****
;
; The normal interrupts for the IBM, and their entry points
; in this code are as follows:
;
; Int   Name                BIOS entry
; 0     Divide by zero      DUMMY_RETURN
; 1     Single Step         DUMMY_RETURN

```

```

; 2 Non-maskable NMIINT
; 3 Breakpoint DUMMY_RETURN
; 4 Overflow DUMMY_RETURN
; 5 Print Screen DUMMY_RETURN
; 6 Reserved DUMMY_RETURN
; 7 Reserved DUMMY_RETURN
; 8 Timer Tic TIMER
; 9 Keypressed KEYHND
; A Reserved DUMMY_RETURN
; B Comm Hardware DUMMY_RETURN \ Normal location for
; C Comm Hardware DUMMY_RETURN / IBM hardware interrupts
; D Disk Hardware DUMMY_RETURN /
; E Diskette Hardware DUMMY_RETURN /
; F Printer Hardware DUMMY_RETURN /

; 10 Video Output CONOUT (10 through 1F are
; 11 Equipment check EQUIP software interrupts)
; 12 Memory Size MEMSIZ
; 13 Disk I/O DISKIO <----- ALL DISK IO (Floppy & HDISK)
; 14 Comm I/O COMMIO
; 15 Cassette I/O DUMMY_RETURN
; 16 Keyboard I/O CONIN
; 17 Printer I/O LSTOUT
; 18 Basic DUMMY_RETURN
; 19 Bootstrap BOOT_DOS_INT
; 1A Time of Day TIME_OF_DAY
; 1B Keyboard Break DUMMY_RETURN
; 1C User timer tic DUMMY_RETURN
; 1D Video Init. VIDEO_PARM
; 1E Diskette ParmS DISK_BASE (Pointer only)
; 1F Graphics Char 0
;
; 40 Copy of Disk/IO DISKIO (for systems with a HDISK)

```

IBM_BIOS:

```

cli ;No interrupts yet please
MOV BX,IBM_SIGNON_MSG ;Announce we are here
CALL PRINT_STRING ;Note PRINT_STRING always uses the CS: override for
the BX pointer

push DS
XOR AX,AX ;Set DS to data area for ROM usage in low RAM @
400H....)
MOV DS,AX
mov byte [DEBUG_FLAG],0 ;Debug mode normally off
POP DS

CALL SETUP_IBM_BIOS ;Initilize RAM and hardware

```

IBM_LOOP:

```

CALL CRLF
MOV BX,IBM_MENU1 ;Enter start of menu
CALL PRINT_STRING

XOR AX,AX ;Set DS to data area for ROM usage in low RAM @
400H....)
MOV DS,AX
CMP byte [DEBUG_FLAG],0H ;Debug mode (normally off)
POP DS

JNZ MENU_ON
MOV BX,IBM_MENU_OFF ;Enter "OFF"
CALL PRINT_STRING
JMP IBM_LOOP1

```

MENU_ON:

```

        MOV     BX,IBM_MENU_ON           ;Enter "ON"
        CALL   PRINT_STRING

IBM_LOOP1:
        MOV     BX,IBM_MENU2           ;Enter the rest of the menu
        CALL   PRINT_STRING

        MOV     AX,CS
        MOV     DS,AX                 ;Just to be safe for below

        call   CICO                   ;Get a command from Console
        mov     ah,0
        CMP     AL,ESC                 ;Abort if ESC
        JNZ     NOT_ESC_IBM
        JMP     INIT                   ;Back to start of Monitor

NOT_ESC_IBM:
        cmp     al,'A'                 ;Find meuu option from table
        jb     IBM_LOOP                ;must be A to Z
        cmp     al,'Z'
        jg     IBM_LOOP
        sub     al,'A'                 ;calculate offset
        shl     al,1                   ;X 2
        add     ax,IBM_TABLE           ;Note DS:=CS: in this monitor by default
        mov     bx,ax
        CALL   CRLF
        mov     ax,[cs:bx]             ;get location of routine CS:[BX]
        call   ax                       ;<----- This is the PC-BIOS Menu CMD call
        jmp    IBM_LOOP                ;finished

;----- Initilize RAM and hardware to look like an IBM-PC setup
;XXXX:
;
SETUP_IBM_BIOS:
        mov     ax,cs
        mov     ds,ax                 ;DS is this ROM's CS

        sub     ax,ax
        mov     es,ax                 ;ES: = 0H in RAM for STOW's below
        CLD                             ;Default to direction up

        CALL   SETUP_INT_TABLE         ;Fill all RM 8086 interrupts initially with a      ✓
        default error trapping pointer

        mov     di,3fcH                ;Int FFH seems to false trigger on 80386 board (not ✓
        the 8086 board!)
        mov     ax,dummy_return         ;Have it point to Dummy return in this monitor
        stosw                          ;(ES: used for final location)

        mov     di,PrintScreen         ;Setup PrintScreen vector in low RAM (at 14H)
        mov     ax,PrintScreenRoutine  ;Have it point to the relevent return in this      ✓
        monitor
        stosw                          ;(ES: used for final location)

        mov     cx,8                   ;Set all 8 hardware interrupts for 8259A (at I/O      ✓
        port address 20H)
        mov     si,vec_tbl_8259A       ;Move the pointers in vec_tbl-8259A to low RAM      ✓
        starting at 20H
        mov     di,Start8259A_Ints     ;Note DS:(=CS:) is source, ES: is destination

iloop1: movsw
        inc     di                       ;Skip over the segment pointer (already done above) ✓
        , to next vector offset
        inc     di
        loop   iloop1

        mov     cx,16                   ;Set all 16 software interrupts

```

```

        mov     si,vec_tbl_soft_ints
        mov     di,CRTINT                ;Start location in low RAM
iloop2: movsw                               ;Note DS: (=CS:) is source,   ES: is destination
        inc     di                        ;Skip over the segment pointer (already done above)
        , to next vector offset
        inc     di
        loop    iloop2

        MOV     CX,IVGA_VAL_LEN           ;Some RAM variables need to be initilized for S-100
        Lomas  CGA Board (@0:449H)
        MOV     SI,INITIAL_VGA_VALUES
        MOV     DI,CRT_MODE              ;0:449H
iloop3: movsw                               ;Note DS: (=CS:) is source,   ES: is destination
        loop    iloop3                   ;To be safe, do not use "rep" in case marginal
        EPROM's cannot handle speed.

        IN      AL,IOBYTE
        TEST    AL,2                     ;Bit 1 of IOBYTE Port will force output to CGA/VGA
        JNZ    NO_FORCE_CGA_DISPLAY     ;is there a request to switch CRT outputs
        MOV     word [ES:CONSOL_FLAG],1 ;1= Force console output to CGA/VGA Video Board
        upon  MS_DOS Bootup,
TO_VGA: MOV     BX,VIDIO_VGA_MSG         ;Video to VGA
        CALL    PRINT_STRING
        JMP     DONE_SWAP

NO_FORCE_CGA_DISPLAY:
        CMP     word [ES:CONSOL_FLAG],1 ;Already requested by "B" menu main command?
        JZ      TO_VGA

        CMP     word [ES:CONSOL_FLAG],2 ;Is output already set for LAVA board by "B" menu
        main command?
        JNZ    TO_PROP_BRD              ;Not 2, then definately not LAVA

        MOV     BX,VIDIO_LAVA_MSG        ;Announce we are going to Lava Board. (There is a 1
        /32K chance RAM had 02H at CONSOL_FLAG at startup)
        CALL    PRINT_STRING             ;Note PRINT_STRING always uses the CS: override for
        the BX pointer
        JMP     DONE_SWAP

TO_PROP_BRD:
        MOV     word [ES:CONSOL_FLAG],0 ;Default, Force Console output to Propeller Video
        Board if anything else
DONE_SWAP:

        ;The 496H-490H area needs to be 0's for MS-DOS 4.01
        ;Clear the whole IBM-AT "extra store area" to 0's
        ;It seems MSDOS V4.01 counts on at least the
        diskette area being 0's
        mov     cx,(496H-490H)           ;It hangs on a boot otherwise! Count of bytes in
        the area
        mov     di,DSK_STATE
        xor     AX,AX
iloop4: MOV     [ES:DI],AX                ;ES: = 0, is destination
        inc     di                        ;Skip over the segment pointer (already done above)
        , to next vector offset
        inc     di
        loop    iloop4

        ;Now a few special case situations...
        ;Note, in every case ES:=0, is destination segment

        MOV     AX,CRT_CHAR_GEN          ;7CH, Upper 128 Bytes of 256 Byte character set
        mov     DI,EXT_CHAR_PTR         ;(1FH*4) (Note no valid table is actually present
        for 8088/8086 EEPROMS)
        stosw

        MOV     AX,OLD_DISKIO           ;100H, We need to handle software Int 40H (The

```

```

relocated old INT 13H PC Bios Floppy I/O)
mov     DI,OLD_DISK_VEC           ; (40H*4)
stosw

MOV     AX,FDISK_3PARAM_TBL       ;We need to move the boot diskette paramater table ✓
to Int 1EH*4 area. (Use 1.44M 3" Floppy)
mov     DI,FDISK_PARAMS
stosw

MOV     AX,HDISK_PARM_TBL        ;104H, Setup the default HARD DISK #1, table ✓
PTR     offset
mov     DI,HDISK_PARAMS          ; (41H*4),
stosw

MOV     AX,CRT_CHAR_GEN          ;10CH, 256 Byte character set
mov     DI,EXT_CHAR_PTR2        ; (43H*4)
stosw

MOV     AX,HDISK_PARM_TBL        ;118H, Setup the same default HARD DISK #2, table ✓
PTR     offset
mov     DI,HDISK2_PARAMS         ; (46H*4)
stosw                               ;ES: 0, is destination segment

;Now set up the memory variables
XOR     AX,AX                    ;NOW set DS: (=0) to data area for ROM usage in low ✓
RAM @400H for the rest below
MOV     DS,AX
mov     word [expram],msize-64    ;show expansion ram size
mov     word [memrsz],msize       ;and total memory size (640K)
mov     word [EQFLAG],0100001001100001B ;set equipment flag so IBM is happy

;bit 0    disk drives present
;bit 1    8087 Present
;bit 2    Mouse present
;bit 3    ----
;bits 4,5 default to colour card
;         00 EGA
;         01 40X25 Color
;         10 80X25 Color
;         11 80X25 Monochrome
;bits 6,7 floppy drives -1 (if bit 0 =1)
;bit 8    DMA support installed (PCjr, ✓

Tandy)

;bits 9,10,11 number of serial ports
;bit 12   no game adaptor
;bit 13   serial printer attachd (PCjr)
;bits 14,15 no of printers

mov     ax,keybuff               ;keyboard interrupt pointers
mov     [bufhd],ax              ;Note counting on ES: = 0
mov     [buftl],ax
mov     byte [chrnt],0

mov     byte [VERIFY_FLAG],0    ;Initially set for sector reads (rather ✓
than sector verifys)

;Initilize hardware to emulate IBM-PC settings
mov     bx,PIC_INIT_MSG         ;Send a signon about initilizing the 8259A
call    PRINT_STRING

mov     al,MasterICW1           ;Initilize the 8259A PIC Controller
out     MASTER_PIC_PORT,al
mov     al,MasterICW2           ;Ints starts at 20H in RAM
out     MASTER_PIC_PORT+1,al
mov     al,MasterICW4           ;No slaves above, so 8259 does not expect ICW3

```



```

out    MASTER_PIC_PORT+1,al

mov    al,11111111b           ;No V0 & V1 for now
out    MASTER_PIC_PORT+1,al

                                ;Initilize the timer
MOV    AL,36H                 ;Sel TIM 0, LSB,MSB,Mode 3
OUT    TIM_CTL,AL             ;Write to Timer mode register (43H)
MOV    AL,0
OUT    TIMER,AL               ;LSB = 0
OUT    TIMER,AL               ;MSB = 0

                                ;Next move the current time into the system tick ✓
bytes in low RAM
usage in low RAM (400H)
                                ;Remember DS: is already set to data area for ROM ✓

mov    word [timlow],0        ;Default setup timer/RTC default values
mov    word [timhi],0
mov    word [timofl],0        ;Set clock tick info to 0 in low ram

MOV    AL,CMOS_VALID          ;Before getting current CMOS time check chip is ✓
there and working
OUT    CMOS_PORT,AL
JMP    SHORT $+2              ;Delay
IN     AL,CMOS_PORT+1
SUB    AL,80H                 ;Check bad battery is OK. (Note different from AT. ✓
Dallas DS12887 says valid = 80H)
JNZ    TOD_ERROR              ;If Not valid leave timer at 0

SUB    CX,CX
UIP:  MOV    AL,CMOS_REGA
OUT    CMOS_PORT,AL
JMP    SHORT $+2              ;Slight delay
IN     AL,CMOS_PORT+1
TEST   AL,UPDATE_TIMER
JZ     READ_SECONDS
LOOP   UIP
JMP    TOD_ERROR1            ;CMOS clock "stuck"
READ_SECONDS:
MOV    AL,CMOS_SECONDS
OUT    CMOS_PORT,AL
JMP    SHORT $+2              ;Slight delay
IN     AL,CMOS_PORT+1

CMP    AL,059H                ;within range 0-59
JA     TOD_ERROR2

CALL   CVT_BINARY
MOV    BL,COUNTS_SEC
MUL    BL
MOV    CX,AX
MOV    AL,CMOS_MINUTES
OUT    CMOS_PORT,AL
JMP    SHORT $+2
IN     AL,CMOS_PORT+1

CMP    AL,059H                ;Within range 0-59
JA     TOD_ERROR2

CALL   CVT_BINARY
MOV    BX,COUNTS_MIN          ;1092
MUL    BX
ADD    AX,CX
MOV    CX,AX
MOV    AL,CMOS_HOURS

```

```

        OUT     CMOS_PORT,AL
        JMP     SHORT $+2
        IN     AL,CMOS_PORT+1
        CMP     AL,023H                ;0-23
        JA     TOD_ERROR2
        CALL    CVT_BINARY
        MOV     DX,AX
        MOV     BL,COUNTS_HOUR        ;7
        MUL    BL
        ADD    AX,CX
        ADC    DX,0000H
        mov     [timhi],DX            ;Store in RAM
        mov     [timlow],AX

;     mov     DX,0080H
;     mov     AX,340H
;     mov     [timhi],DX            ;Store in RAM
;     mov     [timlow],AX

        JMP     TOD_DONE

TOD_ERROR:
        MOV     BX,CMOS_CLOCK_MSG    ;Error reading CMOS Clock chip
        CALL    PRINT_STRING
        JMP     TOD_DONE
TOD_ERROR1:
        MOV     BX,CMOS_STUCK_MSG    ;Error reading CMOS Clock chip
        CALL    PRINT_STRING
        JMP     TOD_DONE
TOD_ERROR2:
        MOV     BX,CMOS_RANGE_MSG    ;Error reading CMOS Clock chip
        CALL    PRINT_STRING
        JMP     TOD_DONE

TOD_DONE:
        CLI
        IN     AL,MASTER_PIC_PORT+1  ;Allow timer tick
        AND    AL,0FEH
        OUT    MASTER_PIC_PORT+1,AL
        STI

INIT_VGA:                                ;We will try and initilize the CGA/VGA video board ✓
        RAM area/ports anyway (even if not used)
        MOV     AX,0B800H                ;Segment of CGA Board RAM
        mov     di,[EQFLAG]
        and     di,30h                    ;Isolate crt switches (This is what IBM PC has - ✓
        not     used here!)

;bits 4,5  default to colour card
;           00 EGA
;           01 40X25 Color
;           10 80X25 Color
;           11 80X25 Monochrome

        cmp     di,30h
        jne    INIT_VGA1
        mov     ax,0B000h                ;Segment for Monochrome card

INIT_VGA1:
        mov     es,ax                    ;Set ES: to point to video area
        MOV     AL,03H                    ;Default to 80X25 Color
        MOV     DI,0                      ;CGA/VGA Board. If B/W card then DI = 30H

        CALL    VGA_INIT                  ;<<<<<< Initilize the video board to 80X25 ✓
        >>>>>>

;This seem OK because IBM-CGA board comes up fine ✓
with the
;ISA->S100 Adaptor board. Also the Lomas S-100 CGA ✓

```

board comes up fine.

```

MOV     AH,0H                ;Initilize Serial Port (Used for debugging display ✓
if required)
MOV     AL,80H               ;This sets for 9600 Baud. (However we will run at ✓
38,400, see INT 14H)
MOV     DX,0
int     14H                  ;Serial out Handler (Software Interrupt 14H)

IN      AL,IOBYTE            ;Allow IOBYTE to abort initilizing extra ROMS ✓
starting at C0000H
TEST    AL,4
JNZ     VGA_ROM_CHECK        ;<<< Check for VGA ROM >>>
RET                                           ;Else skip/ignore looking for a VGA ROM

                                           ;Next, check if the is an extra ROM's/Software on ✓
board. This follows the IBM                               ;format by looking at C0000H-F6000H (on 2K pages) ✓
for 55H,AAH and (length/512)                            ;in the 3rd byte. (Note this BIOS is larger, should ✓
stop at D0000H)                                          ;We will just force initilization of the one VGA ✓
ROM if present, at C0000H                               ;Can add more if required later.

                                           ;If a valid "ROM" then we do a Call Far to ✓
byte 3 in that ROM/Code.                                ;It assumes that the code there will finish ✓
VGA_ROM_CHECK:                                         ;Will just look for Video ROM, so start at ✓
with a far return.
MOV     DX,0C000H          ;DS=C000H
C0000H
MOV     DS,DX
SUB     BX,BX
MOV     AX,[BX]           ;[DS:BX] C000:0H
CMP     AX,0AA55H         ;Is the indicator flag there ✓

JNZ     NO_ROM

MOV     BX,ROMCHECK_MSG   ;Announce we found a ROM at C000:0H
CALL    PRINT_STRING      ;Remember PRINT_STRING always uses the CS: ✓
override for the BX pointer

                                           ;so no need to mess with DS

MOV     AX,40H            ;Set ES=DSEG
MOV     ES,AX            ;ES=40H
PUSH    DX                ;Set things up just like IBM did (Just in ✓
case)!
MOV     word [ES:IO_ROM_INIT],0003H ;Offset @ 467H
MOV     [ES:IO_ROM_SEG],DS      ;Load segment @ 469H

CALL    0C000H:0003H      ;<<< Initilize EGA/VGA ROM >>>
                                           ;Note we assume there are no other extra ✓

ROM's

PUSH    AX                ;Just in case values are needed
PUSH    BX
MOV     BX,ROMCHECK_MSG_OK ;VGA ROM Initilized, returned back to BIOS.
CALL    PRINT_STRING      ;Note PRINT_STRING always uses the CS: ✓
override for the BX pointer
POP     BX
POP     AX

POP     DX                ;From above

mov     ax,40h            ;Test for EGA/VGA
mov     es,ax

```

```

mov     ah,12h
mov     bx,0FF10h
int     10h                ;Video Get EGA Info
cmp     bh,0FFh           ;If EGA or later present BH != FFh
je      not_ega
and     byte[es:EQFLAG],11001111b ;Set video flag in equipment list to EGA/
VGA                                          
                                           ;bits 4,5  default to colour card
                                           ;           00 EGA
                                           ;           01 40X25 Color
                                           ;           10 80X25 Color
                                           ;           11 80X25 Monochrome

not_ega:
mov     ah,1
mov     ch,0F0h
int     10h                ;Set cursor type
call    clear_screen      ;clear display
push   cs
pop     ds
RET

NO_ROM:
MOV     BX,NO_VGA_MSG      ;Announce no VGA ROM present
CALL    PRINT_STRING      ;Note PRINT_STRING always uses the CS:
override for the BX pointer
RET

clear_screen:
mov     dx,184Fh          ; Lower right corner of scroll
xor     cx,cx             ; Upper left corner of scroll
mov     ax,600h           ; Blank entire window
mov     bh,7              ; Set regular cursor
int     10h               ; Call video service scroll
mov     ah,2              ; Set cursor position
xor     dx,dx             ; upper left corner
mov     bh,0              ; page 0
int     10h               ; call video service
mov     ax,0500h          ; Set active display page zero
int     10h
ret

CVT_BINARY:                ;Convert BCD in [AL] to Binary in [AL]
PUSH   CX
PUSH   AX
AND    AX,0FH
MOV    CX,AX              ;Save low digit
POP    AX
PUSH   CX                ;On Stack
MOV    CL,4
ROR   AX,CL
AND   AL,0FH

MOV    CL,10
MUL   CL

POP    CX
ADD   AX,CX              ;Add in low digit
POP    CX
RET

```

```
;----- Menu CMD to Boot MS-DOS from a Floppy Disk using this BIOS
```



```

        CALL    PRINT_STRING

Next_Key1:
        MOV     AH,01H                ;Check if anything there
        int    16H                    ;Get Keyboard status. Console Input Handler
        (Software Interrupt 16H)
        JZ     Next_Key1

        MOV     AH,0H                ;Get actual character from buffer
        int    16H                    ;Get Character. Console Input Handler (Software
        Interrupt 16H)

        CMP     AL,ESC
        JZ     Key_Done
        MOV     CL,AL
        CALL    CO                    ;Send direct to Console
        CALL    BLANK
        CALL    AL_HEXOUT              ;Display the hex character recieved
        JMP     Next_Key

Key_Done:
        mov    al,11111111b           ;Do not Allow V1 on 8259A again
        out    MASTER_PIC_PORT+1,al
        cli
        JMP     IBM_BIOS

;----- Menu CMD to test Console out code using this BIOS (Note 8259A must be present)

MENU_CO_TEST:
        MOV     BX,CO_TEST_MSG        ;Keyboard test
        CALL    PRINT_STRING

        mov    al,11111101b           ;Allow V1 on 8259A now in case it's not already on
        out    MASTER_PIC_PORT+1,al

        sti                                ;Enable hardware interrupts

Next_CO:MOV     BX,IN_CHAR_MSG         ;Input characters =
        CALL    PRINT_STRING
        CALL    CI                    ;Return the char in AL
        CMP     AL,ESC
        JZ     CO_Done
        PUSH    AX
        MOV     CL,AL
        CALL    CO
        MOV     BX,OUT_CHAR_MSG       ;"<---- Character recieved",CR,LF, Char displayed
        via Int 10H ="
        CALL    PRINT_STRING
        POP     AX

        MOV     AH,0EH                ;AH=0EH = TTY output, char in AL

        int    10H                    ;Console out Handler (Software Interrupt 10H)

        CALL    CRLF
        JMP     Next_CO

CO_Done:
        cli                                ;Turn hardware int's back off
        JMP     IBM_BIOS

```

```

;----- Menu CMD to test combined key-in / video out using this BIOS

```

```

MENU_BUFF_IO:
    MOV     BX,BUFF_TEST_MSG           ;Keyboard buffer test
    CALL    PRINT_STRING

    mov     al,11111101b               ;Allow V1 on 8259A now
    out     MASTER_PIC_PORT+1,al

    sti                                          ;Enable hardware interrupts

Next_CI:
    MOV     AH,01H                     ;Check if anything there
    int     16H                         ;Get Keyboard status. Console Input Handler
    (Software Interrupt 16H)
    JZ      Next_CI

    MOV     AH,0H                       ;Get actual character from buffer to AL
    int     16H                         ;Get Character. Console Input Handler (Software
    Interrupt 16H)

    CMP     AL,ESC
    JZ      CO_Done

    MOV     AH,0EH                       ;AH=0EH = TTY output, char in AL
    int     10H                         ;Console out Handler (Software Interrupt 10H)
    JMP     Next_CI

;----- Menu CMD to test Serial Port character output using this BIOS to a serial
terminal
;      Make sure you have the Baud rate is the same on both ends. (We will leave it
at 38,4000 Baud)

MENU_SIO_TEST:
    MOV     BX,SIO_TEST_MSG ;Output to Serial port test
    CALL    PRINT_STRING

    MOV     AH,0H                       ;AH=0 Initilize Port
    MOV     AL,80H                       ;This sets for 9600 Baud. However we will run at 38
,400 (see INT 14H)
    MOV     DX,0

    int     14H                         ;Serial out Handler (Software Interrupt 14H)

    OR      AH,AH                       ;Any errors
    JZ      Next_SIO

    PUSH    AX
    MOV     BX,SIO_INIT_ERR             ;Error initilizing Serial port
    CALL    PRINT_STRING
    POP     AX
    MOV     AL,AH
    CALL    AL_HEXOUT
    MOV     BX,H_MSG_CRLF
    CALL    PRINT_STRING
    JMP     IBM_BIOS

Next_SIO:
    CALL    CI                           ;Return the char in AL
    CMP     AL,ESC
    JZ      SIO_DoneTest

    PUSH    AX
    MOV     CL,AL
    CALL    CO
    POP     AX

```

```

MOV     AH,01H                ;AH=char output, char in AL
MOV     DX,0

int     14H                   ;Serial out Handler   (Software Interrupt 14H)

OR      AH,AH                 ;Any errors
JZ      Next_SIO
PUSH    AX
MOV     BX,SIO_ERR           ;Error sending to Serial port
CALL    PRINT_STRING
POP     AX
MOV     AL,AH
CALL    AL_HEXOUT
MOV     BX,H_MSG_CRLF
CALL    PRINT_STRING
JMP     IBM_BIOS

SIO_DoneTest:
JMP     IBM_BIOS

;----- Menu CMD to test Timer code using this BIOS

MENU_TIMER_TEST:
MOV     BX,TIMER_TEST_MSG    ;Timer test
CALL    PRINT_STRING

mov     al,11111110b         ;Allow V0 on 8259A now
out     MASTER_PIC_PORT+1,al

sti                                           ;Enable hardware interrupts

Next_Timer:
MOV     BX,TIMER_DATA_MSG    ;Get Timer values
CALL    PRINT_STRING

CALL    CI                     ;Return the char in AL
CMP     AL,ESC
JZ      Timer_Done

MOV     BX,TIMER_LOW_MSG     ;timlow =
CALL    PRINT_STRING
PUSH    DS
XOR     AX,AX                 ;Set DS to data area for ROM usage in low RAM @
400H....)
MOV     DS,AX
mov     AX,[timlow]
CALL    AX_HEXOUT

MOV     BX,TIMER_HIGH_MSG    ;timhi =
CALL    PRINT_STRING
mov     AX,[timhi]
CALL    AX_HEXOUT

MOV     BX,TIMER_OFLOW_MSG   ;timofl =
CALL    PRINT_STRING
mov     AX,[timofl]
CALL    AX_HEXOUT
MOV     BX,H_MSG             ;"H$"
CALL    PRINT_STRING
POP     DS
JMP     Next_Timer

Timer_Done:
mov     al,11111111b         ;Do not Allow V0 on 8259A again
out     MASTER_PIC_PORT+1,al

```



```

cli                                ;Turn hardware int's back off
JMP     IBM_BIOS

;----- Menu CMD to test Floppy Disk (5") sequential sector reads using this BIOS
; Will read sequentially up to 9 X 512 byte sectors from 5" DDDS 360K floppy (9
;   Sec/Track)
;   into RAM using the ZFDC controller board. (IBM says never more than
;   9 sectors at a time for this type of disk, actually never changes the track #,
;   but the
;   ZFDC can handle this if it did anyway!)
; Will always read into RAM starting at 500H using the ZFDC controller board

FSEQ_5RD_TEST:
PUSH    DS                        ;Save Monitor current DS
XOR     AX,AX                    ;Set DS to data area for ROM usage in low RAM @
400H....)
MOV     DS,AX

MOV     BX,SEC_5RD_MSG           ;Say Reading sectors
CALL    PRINT_STRING

MOV     AL,0H                    ;Flag to indicate ZFDC board is NOT Initilized
MOV     [ZFDC_INIT_FLAG],AL     ;DS is already set for low RAM area

CALL    INIT_ZFDC                ;Initilize the ZFDC board hardware

CMP     byte [ZFDC_INIT_FLAG],0FFH ;Is Board initilized correctly
JZ      ZFDC_5OK1
POP     DS                        ;Balance up Monitor stack
JMP     IBM_BIOS

ZFDC_5OK1:
mov     dl,01H                  ;Drive 1, side A
mov     ah,0H

int     13h                     ;AH=0, reset floppy disk system

JNC     RESET_5OK1
MOV     BX,RESET_FAIL_MSG
CALL    PRINT_STRING
POP     DS                        ;Balance up stack
JMP     IBM_BIOS

RESET_5OK1:
MOV     BX,SIDE_REQUEST_MSG
CALL    PRINT_STRING
call    CICO                     ;Get a command from Console
PUSH    AX
MOV     BX,CRLFMSG              ;"CR,LF"
CALL    PRINT_STRING
POP     AX
CMP     AL,'B'
JZ      B5_SIDE
MOV     BX,SIDE_A_SET_MSG
CALL    PRINT_STRING
MOV     DX,0001H                ;Side A (DL bit 7 = 0 so Floppy disk)
JMP     OVER5_SIDE
B5_SIDE:MOV BX,SIDE_B_SET_MSG
CALL    PRINT_STRING
MOV     DX,0101H                ;Side B, Disk 1 (ZFDC #2)

OVER5_SIDE:
PUSH    DX                        ;Save side info for below

```

```

MOV     BX,ENTERRAM_FTRKL      ;"Track number, (xxH)"
CALL    PRINT_STRING
CALL    GET2DIGITS            ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     CH,AL
PUSH    CX                    ;Save for below
MOV     BX,H_MSG_CRLF        ;"H CR,LF"
CALL    PRINT_STRING

MOV     BX,ENTERRAM_SECL     ;"Starting sector number, (xxH) = "
CALL    PRINT_STRING
CALL    GET2DIGITS            ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
POP     CX
MOV     CL,AL
PUSH    CX                    ;Save Track & Sec for below
MOV     BX,H_MSG_CRLF        ;"H CR,LF"
CALL    PRINT_STRING

SEQ_5OK4:
MOV     BX,ENTER_COUNT       ;Enter # of sectors
CALL    PRINT_STRING
CALL    GET2DIGITS            ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
CMP     AL,09
JBE     S5OK3
S5OK5: MOV     BX,OVER_COUNT_10
CALL    PRINT_STRING
JMP     SEQ_5OK4              ;Try again
S5OK3: OR     AL,AL
JZ      S5OK5

PUSH    AX                    ;Save sector count (already in AL)
MOV     BX,H_MSG_CRLF        ;"H CR,LF"
CALL    PRINT_STRING

SUB     AX,AX
MOV     ES,AX
MOV     BX,500H                ;Will always dump data to 0000:500H
POP     AX
POP     CX                    ;Track, Sec
POP     DX                    ;Side & Drive 0
mov     ah,02h                ;Read x sectors (IBM has a max of 15 sectors/call  ✓
fot IBM-AT)                    ;on a 1.2M Floppy disk in their IBM PC-AT Bios. I  ✓

assume 18 for 1.44 Disk)        ;(This is where MS-DOS loads MSDOS.SYS from on  ✓

disk)
int     13H                    ;AH=2, CX=0001, read 6 byte sectors -- as in early  ✓
MSDOS systems!

JNC     SEQ_5OK1              ;If NC then no errors
MOV     BX,SQRD5FAILMSG
CALL    PRINT_STRING
POP     DS                    ;Balance up Monitor stack
JMP     IBM_BIOS              ;Will return back up to start of Monitor

SEQ_5OK1:
MOV     BX,SQRD5OKMSG
CALL    PRINT_STRING

MOV     CX,16                  ;Display the first 16 bytes at ES:BX in RAM
SUB     AX,AX
MOV     ES,AX
MOV     BX,500H                ;Will always dump data to 0000:500H

```

```

CALL    SIMPLE_SECTOR_DUMP        ;Dump first CX bytes of sector data at ES:BX on CRT
POP     DS                        ;Balance up stack
JMP     IBM_BIOS                  ;All done

;----- Menu CMD to test Floppy Disk (3") sequential sector reads using this BIOS
;      Will read sequentially 18 X 512 byte sectors from 3" DDDS 1.44M floppy (18 Sec
;      /Track)
;      into RAM using the ZFDC controller board. (IBM says never more than
;      18 sectors at a time for this type of disk)
;      Will always read into RAM starting at 500H using the ZFDC controller board

FSEQ_3RD_TEST:
PUSH    DS                        ;Save Monitor current DS
XOR     AX,AX                    ;Set DS to data area for ROM usage in low RAM @
400H....)
MOV     DS,AX

MOV     BX,SEC_3RD_MSG           ;Say Reading sectors
CALL    PRINT_STRING

MOV     AL,0H                    ;Flag to indicate ZFDC board is NOT Initilized
MOV     [ZFDC_INIT_FLAG],AL     ;DS is already set for low RAM area

CALL    INIT_ZFDC                ;Initilize the ZFDC board hardware

CMP     byte [ZFDC_INIT_FLAG],0FFH ;Is Board initilized correctly
JZ      ZFDC_3OK1
POP     DS                        ;Balance up stack
JMP     IBM_BIOS

ZFDC_3OK1:
mov     dl,0H                    ;Drive 0, side A
mov     ah,0H

int     13H                      ;AH=0, reset floppy disk system

JNC     RESET_3OK1
MOV     BX,RESET_FAIL_MSG
CALL    PRINT_STRING
POP     DS                        ;Balance up stack
JMP     IBM_BIOS

RESET_3OK1:
MOV     BX,SIDE_REQUEST_MSG
CALL    PRINT_STRING
call    CICO                      ;Get a command from Console
PUSH    AX
MOV     BX,CRLFMSG                ;"CR,LF"
CALL    PRINT_STRING
POP     AX
CMP     AL,'B'
JZ      B3_SIDE
MOV     BX,SIDE_A_SET_MSG
CALL    PRINT_STRING
MOV     DX,0000H                  ;Side A (DL bit 7 = 0 so Floppy disk)
JMP     OVER3_SIDE
B3_SIDE:MOV BX,SIDE_B_SET_MSG
CALL    PRINT_STRING
MOV     DX,0100H                  ;Side B, Disk 0

OVER3_SIDE:
PUSH    DX                        ;Save side for below

```

```

MOV     BX,ENTERRAM_FTRKL      ;"Track number, (xxH)"
CALL    PRINT_STRING
CALL    GET2DIGITS            ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     CH,AL
PUSH    CX                    ;Save for below
MOV     BX,H_MSG_CRLF         ;"H CR,LF"
CALL    PRINT_STRING

MOV     BX,ENTERRAM_SECL      ;"Starting sector number, (xxH) = "
CALL    PRINT_STRING
CALL    GET2DIGITS            ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
POP     CX
MOV     CL,AL
PUSH    CX                    ;Save Track & Sec for below
MOV     BX,H_MSG_CRLF         ;"H CR,LF"
CALL    PRINT_STRING

SEQ_3OK4:
MOV     BX,ENTER_COUNT        ;Enter # of sectors
CALL    PRINT_STRING
CALL    GET2DIGITS            ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
CMP     AL,18
JBE     S3OK3
S3OK5: MOV     BX,OVER_COUNT_19
CALL    PRINT_STRING
JMP     SEQ_3OK4              ;Try again
S3OK3: OR     AL,AL
JZ      S3OK5

PUSH    AX                    ;Save sector count (already in AL)
MOV     BX,H_MSG_CRLF         ;"H CR,LF"
CALL    PRINT_STRING

SUB     AX,AX
MOV     ES,AX
MOV     BX,500H                ;Will always dump data to 0000:500H
POP     AX
POP     CX                    ;Track, Sec
POP     DX                    ;Side & Drive 0
mov     ah,02h                ;Read x sectors (IBM has a max of 15 sectors/call  ✓
fot IBM-AT)                    ;on a 1.2M Floppy disk in their IBM PC-AT Bios. I  ✓

assume 18 for 1.44 Disk)        ;(This is where MS-DOS loads MSDOS.SYS from on  ✓
disk)
int     13H                   ;AH=2, CX=0001, read 6 byte sectors -- as in early  ✓
MSDOS systems!

JNC     SEQ_3OK1              ;If NC then no errors
MOV     BX,SQRD5FAILMSG
CALL    PRINT_STRING
POP     DS                    ;Balance up stack
JMP     IBM_BIOS              ;Will return back up to start of Monitor

SEQ_3OK1:
MOV     BX,SQRD3OKMSG         ;Read sectors from 3" 1.44M Floppy disk OK
CALL    PRINT_STRING

MOV     CX,16                  ;Display the first 16 bytes at ES:BX in RAM
SUB     AX,AX
MOV     ES,AX
MOV     BX,500H                ;Will always dump data to 0000:500H

```

```

        CALL     SIMPLE_SECTOR_DUMP      ;Dump first CX bytes of sector data at ES:BX on CRT
        POP      DS                      ;Balance up stack
        JMP      IBM_BIOS                ;All done

;----- Menu CMD to test HDISK sequential sector READ's using this BIOS
; Will read 512 byte sectors from 2nd IDE CF-Card
; into RAM starting at 500H using the IDE controller board
HSEQ_RD_TEST:
        PUSH     DS                      ;Save Monitor current DS
        XOR      AX,AX                  ;Set DS to data area for ROM usage in low RAM @
        400H....)
        MOV      DS,AX

        MOV      BX,SEC_HDRD_MSG        ;Say Reading sectors
        CALL     PRINT_STRING
        MOV      BX,ONE_MOMENT_MSG      ;One moment while IDE disk is being initilized
        CALL     PRINT_STRING

        CALL     SET_DRIVE_B            ;Select the second Drive/CF card
        CALL     IDEinit                ;Initialize drive 1. If there is no drive abort
        JZ       HSEQ_RD1

        MOV      BX,INIT_2_ERROR        ;Warn second IDE drive did not initilize
        CALL     PRINT_STRING
        POP      DS                    ;From above at start
        JMP      IBM_BIOS              ;Will return back up to start of Monitor

HSEQ_RD1:
        mov      dl,80H                 ;Hard Disk
        mov      ah,0H
        int      13h                   ;AH=0, reset floppy disk system

        JNC      HRESET_OK1
        MOV      BX,HRESET_FAIL_MSG     ;"Reset of HDisk Failed"
        CALL     PRINT_STRING
        POP      DS                    ;From above at start
        JMP      IBM_BIOS              ;Will return back up to start of Monitor

HRESET_OK1:
        XOR      AX,AX                 ;Set DS to data area for ROM usage in low RAM @
        400H....)
        MOV      DS,AX

        MOV      BX,HRESET_OK_MSG      ;"Reset of HDisk OK"
        CALL     PRINT_STRING

AGAIN:  MOV      BX,ENTERRAM_HEAD        ;"Starting HEAD number,(xxH) = "
        CALL     PRINT_STRING
        CALL     GET2DIGITS             ;Get 8 bit value (2 digits) to AL. (BX, CX & DX
        Unchanged)
        AND      AL,0FH
        MOV      [CURRENT_HEAD],AL
        MOV      BX,H_MSG_CRLF         ;"H CR,LF"
        CALL     PRINT_STRING

        MOV      BX,ENTERRAM_FTRKL     ;"Track number,(xxH)"
        CALL     PRINT_STRING
        CALL     GET2DIGITS             ;Get 8 bit value (2 digits) to AL. (BX, CX & DX
        Unchanged)
        MOV      [CURRENT_TRACK],AL
        MOV      BX,H_MSG_CRLF         ;"H CR,LF"
        CALL     PRINT_STRING

```

```

MOV     BX,ENTERRAM_SECL      ;"Starting sector number,(xxH) = "
CALL    PRINT_STRING
CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
AND     AL,00111111B
MOV     [CURRENT_SECTOR],AL
MOV     BX,H_MSG_CRLF        ;"H  CR,LF"
CALL    PRINT_STRING

MOV     BX,ENTER_COUNT      ;Enter # of sectors
CALL    PRINT_STRING
CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     [SECTORS_TO_DO],AL
MOV     BX,H_MSG_CRLF        ;"H  CR,LF"
CALL    PRINT_STRING

MOV     BX,LOOP_ESC_MSG     ;"Will continously loop until ESC to abort "
CALL    PRINT_STRING
CALL    CI                   ;Wait for CR to start
CMP     AL,CR
JZ      XSEQ_50K4
POP     DS                   ;From above at start
JMP     IBM_BIOS             ;Will return back up to start of Monitor

XSEQ_50K4:
SUB     AX,AX
MOV     ES,AX
MOV     DS,AX
MOV     BX,500H              ;Will always dump data to 0000:500H

MOV     AH,02                ;Read sector(s)
MOV     AL,[SECTORS_TO_DO]
MOV     CH,[CURRENT_TRACK]
MOV     CL,[CURRENT_SECTOR]
MOV     DH,[CURRENT_HEAD]
MOV     DL,80H

INT     13H                  ;Disk I/O Int

JNC     READ_OK
JMP     RD_ERROR

READ_OK:
MOV     BX,SEC_READ_OK      ;Sector(s) read OK
CALL    PRINT_STRING

MOV     CX,16                ;Display the first 16 bytes at ES:BX in RAM
SUB     AX,AX
MOV     ES,AX
MOV     DS,AX                ;Just to be safe below also
MOV     BX,500H              ;Will always dump data to 0000:500H

CALL    SIMPLE_SECTOR_DUMP   ;Dump first CX bytes of sector data at ES:BX on CRT ✓

CALL    CSTS                 ;Any keyboard character will stop display
JZ      HSEC_R7
CALL    CI
MOV     BX,CONTINUE_MSG
CALL    PRINT_STRING
CALL    CI
CMP     AL,ESC
JZ      IBM_BIOS1

HSEC_R7:
CALL    CRLF

```

```

    MOV     CL,[CURRENT_SECTOR]
    INC     CL
    CMP     CL,DOS_MAXSEC           ;1-63 Sectors for custom Drive
    JLE     R_SAME_HEAD
    MOV     DH,[CURRENT_HEAD]
    INC     DH
    CMP     DH,DOS_MAXHEADS-1     ;(0...15), 16 heads Total for custom Drive
    JLE     R_SAME_TRACK
    MOV     byte [CURRENT_SECTOR],1 ;Back to sector 1
    MOV     byte [CURRENT_HEAD],0  ;back to head 0
    MOV     CH,[CURRENT_TRACK]    ;Next track
    INC     CH
    MOV     [CURRENT_TRACK],CH
    JMP     XSEQ_50K4             ;Do next sector block

R_SAME_TRACK:
    MOV     byte [CURRENT_SECTOR],1 ;Back to sector 1
    MOV     [CURRENT_HEAD],DH      ;Next head
    JMP     XSEQ_50K4             ;Do next sector block

R_SAME_HEAD:
    MOV     [CURRENT_SECTOR],CL
    JMP     XSEQ_50K4             ;Do next sector block

IBM_BIOS1:
    POP     DS
    JMP     IBM_BIOS

RD_ERROR:
    MOV     BX,RD_ERR_MSG          ;"Read Error Sector Head ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_HEAD]
    CALL    AL_HEXOUT
    MOV     BX,TRACK_MSG           ;"H  Track ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_TRACK]
    CALL    AL_HEXOUT
    MOV     BX,SEC_MSG            ;"H  Sector ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_SECTOR]
    CALL    AL_HEXOUT
    MOV     BX,H_MSG_CRLF         ;"H  CR,LF"
    CALL    PRINT_STRING
    POP     DS                     ;Balance up stack
    JMP     IBM_BIOS

;----- IBM Menu CMD to check Sector R/W functions on IDE Board using INT 13H.

HSEC_RW_TEST:
    PUSH    DS
    MOV     BX,HRW_TEST_MSG       ;Test Sector INT 13H Reade Write on Drive #2
    CALL    PRINT_STRING

    CALL    CICO
    CMP     AL,'Y'
    JZ     HSEC_RW0
    POP     DS                     ;Balance up stack
    JMP     IBM_BIOS

HSEC_RW0:
    MOV     BX,ONE_MOMENT_MSG     ;One moment while IDE disk is being initilized
    CALL    PRINT_STRING

```

```

CALL    SET_DRIVE_B           ;Select the second Drive/CF card
CALL    IDEinit               ;Initialize drive 1. If there is no drive abort
JZ      HSEC_RW1

MOV     BX,INIT_2_ERROR       ;Warn second IDE drive did not initilize
CALL    PRINT_STRING
POP     DS                     ;Balance up stack
JMP     IBM_BIOS

HSEC_RW1:
mov     dl,80H                ;Reset Hard Disk
mov     ah,0H
int     13h                   ;AH=0, reset floppy disk system

JNC     HSEC_RW2
MOV     BX,HRESET_FAIL_MSG    ;"Reset of HDisk Failed"
CALL    PRINT_STRING
POP     DS                     ;From above at start
JMP     IBM_BIOS              ;Will return back up to start of Monitor

HSEC_RW2:
XOR     AX,AX                 ;Set DS to data area for ROM usage in low RAM @
400H....)
MOV     DS,AX

MOV     BX,HRESET_OK_MSG     ;"Reset of HDisk OK"
CALL    PRINT_STRING

HSEC_RW3:
MOV     BX,ENTERRAM_HEAD     ;"Starting HEAD number, (xxH) = "
CALL    PRINT_STRING
CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX
Unchanged)
AND     AL,0FH
MOV     [CURRENT_HEAD],AL
MOV     BX,H_MSG_CRLF        ;"H CR,LF"
CALL    PRINT_STRING

MOV     BX,ENTERRAM_FTRKL    ;"Track number, (xxH)"
CALL    PRINT_STRING
CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX
Unchanged)
MOV     [CURRENT_TRACK],AL
MOV     BX,H_MSG_CRLF        ;"H CR,LF"
CALL    PRINT_STRING

MOV     BX,ENTERRAM_SECL     ;"Starting sector number, (xxH) = "
CALL    PRINT_STRING
CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX
Unchanged)
AND     AL,00111111B
MOV     [CURRENT_SECTOR],AL
MOV     BX,H_MSG_CRLF        ;"H CR,LF"
CALL    PRINT_STRING

MOV     BX,ENTER_COUNT       ;Enter # of sectors
CALL    PRINT_STRING
CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX
Unchanged)
MOV     [SECTORS_TO_DO],AL
MOV     BX,H_MSG_CRLF        ;"H CR,LF"
CALL    PRINT_STRING

MOV     BX,LOOP_ESC_MSG     ;"Will continously loop until ESC to abort "
CALL    PRINT_STRING
CALL    CI                     ;Wait for CR to start

```



```

        CMP     AL,CR
        JZ      HSEC_RW4
        POP     DS                      ;From above at start
        JMP     IBM_BIOS                ;Will return back up to start of Monitor

HSEC_RW4:
        SUB     AX,AX
        MOV     ES,AX
        MOV     DS,AX                  ;just in case
        MOV     BX,500H                ;Will always dump data to 0000:500H

        MOV     AH,02                  ;Read sector(s)
        MOV     AL,[SECTORS_TO_DO]
        MOV     CH,[CURRENT_TRACK]
        MOV     CL,[CURRENT_SECTOR]
        MOV     DH,[CURRENT_HEAD]
        MOV     DL,80H

        INT     13H                    ;Disk I/O Int

        JNC     HSEC_RW5
        JMP     RD_ERROR

HSEC_RW5:
        MOV     CX,16                  ;Display the first 16 bytes at ES:BX in RAM
        SUB     AX,AX
        MOV     ES,AX
        MOV     DS,AX                  ;Just in case
        MOV     BX,500H                ;Will always dump data to 0000:500H

        CALL    SIMPLE_SECTOR_DUMP     ;Dump first CX bytes of sector data at ES:BX on CRT ✓

        SUB     AX,AX                  ;Now WRITE the secti=or back
        MOV     ES,AX
        MOV     DS,AX                  ;just in case
        MOV     BX,500H                ;Will always dump data to 0000:500H

        MOV     AH,03                  ;Write sector(s)
        MOV     AL,[SECTORS_TO_DO]
        MOV     CH,[CURRENT_TRACK]
        MOV     CL,[CURRENT_SECTOR]
        MOV     DH,[CURRENT_HEAD]
        MOV     DL,80H

        INT     13H                    ;Write sector(s)

        JNC     HSEC_RW6
        JMP     WR_ERROR

HSEC_RW6:
        MOV     BX,SEC_BACK_OK         ;Sector(s) written BACK OK
        CALL    PRINT_STRING

        CALL    CSTS                    ;Any keyboard character will stop display
        JZ      HSEC_RW7
        CALL    CI
        MOV     BX,CONTINUE_MSG
        CALL    PRINT_STRING
        CALL    CI
        CMP     AL,ESC
        JZ      IBM_BIOS2

HSEC_RW7:
        CALL    CRLF
        MOV     CL,[CURRENT_SECTOR]
        INC     CL

```

```

    CMP     CL,DOS_MAXSEC           ;1-63 Sectors for custom Drive
    JLE     WR_SAME_HEAD
    MOV     DH,[CURRENT_HEAD]
    INC     DH
    CMP     DH,DOS_MAXHEADS-1      ;(0...15), 16 heads Total for custom Drive
    JLE     WR_SAME_TRACK
    MOV     byte [CURRENT_SECTOR],1 ;Back to sector 1
    MOV     byte [CURRENT_HEAD],0  ;back to head 0
    MOV     CH,[CURRENT_TRACK]     ;Next track
    INC     CH
    MOV     [CURRENT_TRACK],CH
    JMP     HSEC_RW4               ;Do next sector block

WR_SAME_TRACK:
    MOV     byte [CURRENT_SECTOR],1 ;Back to sector 1
    MOV     [CURRENT_HEAD],DH      ;Next head
    JMP     HSEC_RW4               ;Do next sector block

WR_SAME_HEAD:
    MOV     [CURRENT_SECTOR],CL
    JMP     HSEC_RW4               ;Do next sector block

IBM_BIOS2:
    POP     DS
    JMP     IBM_BIOS

WR_ERROR:
    MOV     BX,WR_ERR_MSG           ;"Write Error Sector Head ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_HEAD]
    CALL    AL_HEXOUT
    MOV     BX,TRACK_MSG           ;"H Track ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_TRACK]
    CALL    AL_HEXOUT
    MOV     BX,SEC_MSG            ;"H Sector ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_SECTOR]
    CALL    AL_HEXOUT
    MOV     BX,H_MSG_CRLF         ;"H CR,LF"
    CALL    PRINT_STRING
    POP     DS                     ;Balance up stack
    JMP     IBM_BIOS

;----- IBM Menu CMD to check HEX display / LBA selection on IDE Board.
;          Should show High Cylinder, Low Cylinder and Sector # in Hex Display on IDE Board
;

LBA_DISPLAY_TEST:
    MOV     BX,LBA_TEST_MSG       ;Test LBA on Drive #2
    CALL    PRINT_STRING

    CALL    SET_DRIVE_B           ;Select the second Drive/CF card
    CALL    IDEinit               ;Initialize drive 1. If there is no drive abort
    JZ     LBA_002

    MOV     BX,INIT_2_ERROR       ;Warn second IDE drive did not initilize
    CALL    PRINT_STRING
    POP     DS
    JMP     IBM_BIOS

LBA_002:
    CALL    CRLF
    MOV     DH,1110000B           ;<<<< Set to LBA mode, head 0

```

```

MOV     DL,REGshd           ;Send "Head #" (in DH)
CALL    IDEwr8D            ;Write to 8255 A Register

MOV     BX,TRKH_NUM        ;Enter High byte track number
CALL    PRINT_STRING
CALL    GET2DIGITS        ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     DH,AL
MOV     DL,REGcylinderMSB
CALL    IDEwr8D           ;Send High TRK# (in DH)
CALL    IDEwr8D_X        ;Special write to 8255 B Register (Not A) to update ✓
    LED HEX Display
                                ;High 8 bits ignored by IDE drive

MOV     BX,TRKL_NUM        ;"Low Track number, (xxH) "
CALL    PRINT_STRING
CALL    GET2DIGITS        ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     DH,AL             ;Get low Track #
MOV     DL,REGcylinderLSB ;Send Low TRK# (in DH)
CALL    IDEwr8D           ;Special write to 8255 A

MOV     BX,SECTOR_NUM      ;"Sector number, (xxH) = "
CALL    PRINT_STRING
CALL    GET2DIGITS        ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     DH,AL             ;Sector 1, Bits 0-5 only (currently 1-17)
MOV     DL,REGsector      ;Send "Sector#"
CALL    IDEwr8D           ;Write to 8255 A Register

MOV     AL,READcfg8255     ;Set 8255 back to read mode
OUT     IDECtrlPort,AL
MOV     BX,CHECK_DISPLAY_MSG ;Check display
CALL    PRINT_STRING
RET                                     ;We arrive here from IDE Menu, return

```

```

;----- IBM Menu CMD to check HEX display CHS selection on IDE Board.
;          Should show Cylinder, Head and Sector # in Hex Display on IDE Board

```

CHS_DISPLAY_TEST:

```

MOV     BX,CHS_TEST_MSG   ;Test CHS on Drive #2
CALL    PRINT_STRING

CALL    SET_DRIVE_B       ;Select the second Drive/CF card
CALL    IDEinit           ;Initialize drive 1. If there is no drive abort
JZ     CHS_002

MOV     BX,INIT_2_ERROR   ;Warn second IDE drive did not initialize
CALL    PRINT_STRING
POP     DS
JMP     IBM_BIOS

```

CHS_002:

```

CALL    CRLF
OR     DH,10100000B       ;Set to >>>> NON-LBA mode <<<<<
MOV     DL,REGshd        ;Send "Head #" (in DH)
CALL    IDEwr8D          ;Write to 8255 A Register

MOV     BX,TRKH_NUM      ;"Cylinder number High, (xxH)
CALL    PRINT_STRING
CALL    GET2DIGITS        ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
AND     AL,00000011B     ;Only 2 bits accepted
MOV     DH,AL

```

```

PUSH    AX                ;Save for below
MOV     DL,REGcylinderMSB
CALL    IDEwr8D           ;Send High TRK# (in DH) to IDE Drive

MOV     BX,HEAD_NUM      ;Enter Head number (0-FH)
CALL    PRINT_STRING
CALL    GET2DIGITS       ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     DH,AL
AND     DH,0FH           ;top two LED HEX displays.
SHL     DH,1             ;These 8 (high) data lines are ignored by the IDE  ✓
drive
SHL     DH,1
SHL     DH,1
SHL     DH,1
POP     AX                ;Get the tow bits of the high cylinder
OR      DH,AL
MOV     DL,REGcylinderMSB ;of the high cylinder in the low nibble.
CALL    IDEwr8D_X        ;Special output to 8255 B Register (Not A) to  ✓
update LED HEX Display ONLY

MOV     BX,TRKL_NUM      ;"Low Cylinder number,(xxH)"
CALL    PRINT_STRING
CALL    GET2DIGITS       ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     DH,AL            ;Get low Track #
MOV     DL,REGcylinderLSB ;Send Low TRK# (in DH)
CALL    IDEwr8D          ;Special write to 8255 A

MOV     BX,SECTOR_NUM    ;"Sector number,(xxH) = "
CALL    PRINT_STRING
CALL    GET2DIGITS       ;Get 8 bit value (2 digits) to AL. (BX, CX & DX  ✓
Unchanged)
MOV     DH,AL            ;Sector 1, Bits 0-5 only (currently 1-17)
MOV     DL,REGsector     ;Send "Sector#"
CALL    IDEwr8D          ;Write to 8255 A Register

MOV     AL,READcfg8255    ;Set 8255 back to read mode
OUT     IDECtrlPort,AL
MOV     BX,CHECK_DISPLAY_MSG ;Check display
CALL    PRINT_STRING
JMP     IBM_BIOS         ;Will return back up to start IBM Menu

```

```

;----- Menu command to dump a floppy BOOT sector on the CRT
; Note must have a functional INT 13H routine for this section to work

```

DUMP_B_SEC:

```

PUSH    DS                ;Save Monitor current DS
XOR     AX,AX             ;Set DS to data area for ROM usage in low RAM  ✓
(400H)
MOV     DS,AX

MOV     BX,BOOT_3RD_MSG   ;Say Reading Boot sector
CALL    PRINT_STRING

MOV     AL,0H             ;Flag to indicate ZFDC board is NOT  ✓
Initilized
MOV     [ZFDC_INIT_FLAG],AL ;DS is already set for low RAM area

CALL    INIT_ZFDC         ;Initilize the ZFDC board hardware

CMP     byte [ZFDC_INIT_FLAG],0FFH ;Is Board initilized correctly
JZ      BS_ZFDC_3OK1

```

```

        pop     ds                    ;Balance up Monitor stack
        JMP     IBM_BIOS

BS_ZFDC_3OK1:
        MOV     BX,DRIVE_SELECT_MSG    ;Floppy disk A: or B:
        CALL    PRINT_STRING

        call    CICO                    ;Get a command from Console
        PUSH   AX
        MOV     BX,CRLFMSG              ;"CR,LF"
        CALL    PRINT_STRING
        POP     AX
        CMP     AL,'B'
        JZ      B_DRIVE_SEL
        MOV     DX,0000H                ;Side A, Disk 0
        JMP     OVER_DRIVE_SEL
B_DRIVE_SEL:
        MOV     DX,00001H               ;Side A, Disk 1
OVER_DRIVE_SEL:
        PUSH   DX                        ;Save side for below

        mov     ah,0H
        int     13h                      ;AH=0, reset floppy disk system

        JNC     BS_RESET_3OK1
        MOV     BX,RESET_FAIL_MSG
        CALL    PRINT_STRING
        pop     dx
        pop     ds                        ;Balance up stack
        JMP     IBM_BIOS

BS_RESET_3OK1:
        SUB     AX,AX
        MOV     ES,AX
        MOV     BX,500H                  ;Will always dump data to 0000:500H

        POP     DX                        ;Side & Drive 0
        MOV     CX,0001                  ;1st sector on track 0
        MOV     AL,1                      ;1 sector
        mov     ah,02h                    ;Read 1 sector

        int     13H

        JNC     BS_SEQ_3OK1              ;If NC then no errors
        MOV     BX,BOOT_INFO_FAIL_MSG
        pop     ds                        ;Balance up Monitor stack
        JMP     IBM_BIOS                  ;Will return back up to start of Monitor

BS_SEQ_3OK1:
        MOV     BX,BOOT_INFOOKMSG
        CALL    PRINT_STRING

        SUB     AX,AX
        MOV     DS,AX
        MOV     SI,500H                  ;Will always dump data to 0000:500H

        LODSB                             ;WRITE 1 BYTE BYTE, DS:[SI++] -> AL
        CALL    AL_HEXOUT
        LODSB
        CALL    AL_HEXOUT
        LODSB
        CALL    AL_HEXOUT
        MOV     BX,JMP_MSG                ;" BOOT JUMP VECTOR"
        CALL    PRINT_STRING

```

```

MOV     DL,8
BS_1:  LODSB                    ;Get a byte from RAM, DS:[SI++] -> AL
MOV     CL,AL
CALL    CO
DEC     DL
JNZ     BS_1
MOV     BX,NAME_MSG           ;"   OEM NAME"
CALL    PRINT_STRING

LODSW
CALL    AX_HEXOUT
MOV     BX,BYTES_MSG          ;"   Bytes/Sec"
CALL    PRINT_STRING
LODSB
CALL    AL_HEXOUT
MOV     BX,CLUSTER_MSG       ;"   Sec/Cluster"
CALL    PRINT_STRING
LODSW
CALL    AX_HEXOUT
MOV     BX,RES_MSG           ;"   Reserved Sectors"
CALL    PRINT_STRING
LODSB
CALL    AL_HEXOUT
MOV     BX,FATS_MSG          ;"   FATS"
CALL    PRINT_STRING
LODSW
CALL    AX_HEXOUT
MOV     BX,ROOT_MSG          ;"   Root Dir Entries"
CALL    PRINT_STRING
LODSW
CALL    AX_HEXOUT
MOV     BX,SECTORS_MSG       ;"   Sectors"
CALL    PRINT_STRING
LODSB
CALL    AL_HEXOUT
MOV     BX,MEDIA_MSG         ;"   Media Byte"
CALL    PRINT_STRING
LODSW
CALL    AX_HEXOUT
MOV     BX,FAT_SEC_MSG       ;"   FAT Sectors"
CALL    PRINT_STRING
LODSW
CALL    AX_HEXOUT
MOV     BX,SEC_TRK_MSG       ;"   Sectors/Track"
CALL    PRINT_STRING
LODSW
CALL    AX_HEXOUT
MOV     BX,HEADS_MSG         ;"   Heads"
CALL    PRINT_STRING
LODSW
CALL    AX_HEXOUT
LODSW
CALL    AX_HEXOUT
MOV     BX,HIDDEN_MSG        ;"   Hidden Sectors"
CALL    PRINT_STRING
LODSW
CALL    AX_HEXOUT
LODSW
CALL    AX_HEXOUT
MOV     BX,HUGE_MSG          ;"   Huge Sectors"
CALL    PRINT_STRING
LODSB
CALL    AL_HEXOUT
MOV     BX,DRIVE_NO_MSG      ;"   Drive #"
CALL    PRINT_STRING

```

```

        LODSB
        CALL    AL_HEXOUT
        MOV     BX,RESERVED_MSG           ;"   Reserved"
        CALL    PRINT_STRING
        LODSB
        CALL    AL_HEXOUT
        MOV     BX,BOOT_SIG_MSG         ;"   Boot Signature"
        CALL    PRINT_STRING
        LODSW
        CALL    AX_HEXOUT
        LODSW
        CALL    AX_HEXOUT
        MOV     BX,VOL_ID_MSG           ;"   Volunme ID"
        CALL    PRINT_STRING

        MOV     DL,11
BS_2:   LODSB                             ;Get a byte from RAM, DS:[SI++] -> AL
        MOV     CL,AL
        CALL    CO
        DEC     DL
        JNZ    BS_2
        MOV     BX,VOLUME_MSG          ;"   Volume Label"
        CALL    PRINT_STRING

        MOV     DL,8
BS_3:   LODSB                             ;Get a byte from RAM, DS:[SI++] -> AL
        CALL    AL_HEXOUT
        DEC     DL
        JNZ    BS_3
        MOV     BX,SYS_TYPE_MSG        ;"   File Sys Type"
        CALL    PRINT_STRING

        pop     ds                       ;Balance up Monitor DS from stack
        JMP     IBM_BIOS                 ;All done

;
;----- Menu command to dump the Hard Disk MBR (Master Boot Record) Info on the
        CRT
;
;       Note must have a functional INT 13H routine for this section to work

DUMP_MBR:
        PUSH    DS                       ;Save Monitor current DS
        XOR     AX,AX                     ;Set DS to data area for ROM usage in low RAM
        (400H)
        MOV     DS,AX

        MOV     BX,BOOT_MBR_MSG         ;Say Reading MBR sector
        CALL    PRINT_STRING

        CALL    SET_DRIVE_B             ;Select the second Drive/CF card
        CALL    IDEinit                 ;Initialize drive 1. If there is no drive abort
        JZ     MBR_002

        MOV     BX,INIT_2_ERROR         ;Warn second IDE drive did not initilize
        CALL    PRINT_STRING
        POP     DS
        JMP     IBM_BIOS

MBR_002:
        SUB     AX,AX
        MOV     ES,AX
        MOV     BX,500H                 ;Will always dump data to 0000:500H

        MOV     DX,0080H                ;Head 0, HDIdk 0
        MOV     CX,0001                 ;1st sector on track 0

```

```

MOV     AL,1                ;read 1 sector
mov     ah,02h             ;Read 1 sector

int     13H

JNC     MBR_003            ;If NC then no errors
MOV     BX,BOOT_MBR_FAIL_MSG
pop     ds                 ;Balance up Monitor stack
JMP     IBM_BIOS           ;Will return back up to start of Monitor

MBR_003:
MOV     BX,MBR_INFOOKMSG
CALL    PRINT_STRING

SUB     AX,AX
MOV     DS,AX
MOV     SI,500H + 1B8H     ;Will always dump data to 0000:500H

LODSB                      ;WRITE 1 BYTE BYTE, DS:[SI++] -> AL
CALL    AL_HEXOUT
LODSB
CALL    AL_HEXOUT
LODSB
CALL    AL_HEXOUT
LODSB
CALL    AL_HEXOUT
MOV     BX,DISK_SIG_MSG   ;" Disk Signature (Optional)"
CALL    PRINT_STRING

LODSB
CALL    AL_HEXOUT
LODSB
CALL    AL_HEXOUT
MOV     BX,NULS_MSG       ;" Usually Nulls (Optional)"
CALL    PRINT_STRING

LODSB                       ;0
CALL    AL_HEXOUT
MOV     BX,STATUS_MSG     ;"          Status Byte"
CALL    PRINT_STRING
MOV     BX,PT1_MSG        ;"First Partition Table "
CALL    PRINT_STRING
CALL    DUMP_PTBL

LODSB                       ;0
CALL    AL_HEXOUT
MOV     BX,STATUS_MSG     ;"          Status Byte"
CALL    PRINT_STRING
MOV     BX,PT2_MSG        ;"Second Partition Table "
CALL    PRINT_STRING
CALL    DUMP_PTBL

LODSB                       ;0
CALL    AL_HEXOUT
MOV     BX,STATUS_MSG     ;"          Status Byte"
CALL    PRINT_STRING
MOV     BX,PT3_MSG        ;"Third Partition Table "
CALL    PRINT_STRING
CALL    DUMP_PTBL

LODSB                       ;0
CALL    AL_HEXOUT
MOV     BX,STATUS_MSG     ;"          Status Byte"
CALL    PRINT_STRING
MOV     BX,PT4_MSG        ;"Forth Partition Table "
CALL    PRINT_STRING

```



```

        CALL    DUMP_PTBL

        LODSW
        CALL    AX_HEXOUT
        MOV     BX,SIGNATURE_MSG           ;" LBR Signature Word "
        CALL    PRINT_STRING

        pop     ds                         ;Balance up Monitor DS from stack
        JMP     IBM_BIOS                   ;All done

DUMP_PTBL:
        LODSB                                ;1-3
        CALL    AL_HEXOUT
        LODSB
        CALL    AL_HEXOUT
        LODSB
        CALL    AL_HEXOUT
        MOV     BX,STLBA_MSG               ;"          Start CHS Address"
        CALL    PRINT_STRING

        LODSB                                ;4
        CALL    AL_HEXOUT
        MOV     BX,PAR_TYPE_MSG           ;"          Partition Type"
        CALL    PRINT_STRING

        LODSB                                ;5-7
        CALL    AL_HEXOUT
        LODSB
        CALL    AL_HEXOUT
        LODSB
        CALL    AL_HEXOUT
        MOV     BX,ECHS_MSG               ;"          End CHS Address"
        CALL    PRINT_STRING

        LODSW                                ;8-B
        CALL    AX_HEXOUT
        LODSW
        CALL    AX_HEXOUT
        MOV     BX,SLB_MSG                ;"          Start LBA Address"
        CALL    PRINT_STRING

        LODSW                                ;C-F
        CALL    AX_HEXOUT
        LODSW
        CALL    AX_HEXOUT
        MOV     BX,ELBA_MSG               ;"          End LBA Address"
        CALL    PRINT_STRING
        RET

;----- Menu CMD to turn on/off BIOS dump info for reads/writes using this BIOS
;   DEBUG_FLAG = 0  if no debugging info sent to serial terminal
;   DEBUG_FLAG = 1  send just INT's info
;   DEBUG_FLAG = 2  send more detailed information

DEBUG_ON_OFF:
        push    ds
        XOR     AX,AX                     ;Set DS to data area for ROM usage in low RAM @
        MOV     DS,AX
        MOV     BX,DEBUG_SET_MSG

```

```

CALL    PRINT_STRING
call    CICO                      ;Look for 0,1 2 (only)
CMP     AL,'1'
MOV     byte [DEBUG_FLAG],01H
MOV     BX,DUMP_ON1_MSG
JZ      DUMP_DONE

CMP     AL,'2'
MOV     byte [DEBUG_FLAG],02H
MOV     BX,DUMP_ON2_MSG
JZ      DUMP_DONE

CMP     AL,'3'
MOV     byte [DEBUG_FLAG],03H
MOV     BX,DUMP_ON3_MSG
JZ      DUMP_DONE

MOV     byte [DEBUG_FLAG],0
MOV     BX,DUMP_OFF_MSG

```

DUMP_DONE:

```

CALL    PRINT_STRING
POP     DS
RET

```

```

;*****
;
;   Bootstrap Handler      (IBM-PC Software Interrupt 19H)
;
;   SYSTEM - BOOTSTRAP LOADER
;
;   For a floppy the BIOS will try to read sector 1, head 0, track 0 from drive A:
;   to 0000h:7C00h.  If this fails we will just abort.
;
;   For the IDE/CF Cards the BIOS will try to read sector 1, head 0, track 0 from
;   drive #2 of the IDE Board to 0000h:7C00h.  If this fails we will just abort.
;
;   For a hard disk, the BIOS will read sector 1, head 0, track 0 of the 2nd CF-Card
;   on the Dual IDE board. This sector should contain a master bootstrap loader and
;   a partition table (see http://www.ctyme.com/intr/rb-2270.htm#Table650).
;
;   After loading the master boot sector at 0000h:7C00h,
;   the master bootstrap loader is given control with:-
;
;           CS:IP = 0000h:7C00h.
;           DH = access bits 7-6,4-0: Don't care
;           bit 5:=0 device supported by INT 13.
;           DL = boot drive
;                   00h first floppy
;                   80h first hard disk
;
;   True IBM PCs and most clones issue an INT 18 (cassette) if neither floppy nor hard
;   disk have a valid boot sector. We will just abort.
;
;   To accomplish a warm boot equivalent to Ctrl-Alt-Del, store 1234h in
;   0040h:0072h and jump to FFFF:0000h.  For a cold boot equivalent to
;   a reset, store 0000h at 0040h:0072h before jumping..
;
;   BUG: If when loading the remainder of the DOS system files fails, various versions
;   of IBMBIO.COM/IO.SYS incorrectly restore INT 1E before calling INT 19, assuming
;   that the boot sector had stored the contents of INT 1E at DS:SI instead of on
;   the stack as it actually does.

```

```

;*****
BOOT_DOS_INT:
    STI                ;Bootstrap Handler (Interrupt 19H)
    CMP     DL,80H     ;Floppy or HD? (80H = First HD)
    JNZ     BOOT_FLOPPY
    JMP     BOOT_HDISK ;Z then BOOT FLOPPY. Note if called, ZFDC Board
    MUST be active (IDE may be offline)

BOOT_FLOPPY:
    PUSH    DS        ;Save current DS on stack
    XOR     AX,AX     ;Set DS to data area for ROM usage in low RAM @
    400H....)
    MOV     DS,AX

    MOV     AL,0H     ;Flag to indicate ZFDC board is NOT
    Initilized
    MOV     [ZFDC_INIT_FLAG],AL

    CALL    INIT_ZFDC ;Initilize the ZFDC board hardware (360K &
    1.44M disks)

    CMP     byte [ZFDC_INIT_FLAG],0FFH ;Is Board initilized correctly
    POP     DS        ;Balance up stack
    JZ     ZFDC_OK
    JMP     IBM_BIOS  ;Return will drop back to IBM_BIOS location

ZFDC_OK:
    CALL    SET_DRIVE_B ;Select the second Drive/CF card
    CALL    IDEinit    ;Initialize drive 1. If there is no drive abort
    JZ     FH_RESET_OK

    MOV     BX,INIT_2_ERROR ;Warn second IDE drive did not initilize
    CALL    PRINT_STRING ;Continue anyway with ZFDC/Floppy

FH_RESET_OK:
    sub     ax,ax
    mov     ds,ax      ;DS -> 0
    mov     dx,0080H  ;DL = 80L will always boot from IDE #2 disk for
    now.

    mov     ah,0
    int     13h      ;AH=0, reset floppy disk system

    JNC     F_RESET_OK
    MOV     BX,RESET_FAIL_MSG
    CALL    PRINT_STRING
    JMP     IBM_BIOS ;Will return back up to IBM_BIOS location

F_RESET_OK:
    XOR     AX,AX
    mov     DS,AX
    mov     ES,AX     ;DS = ES = 0000H
    mov     ax,201h   ;read one sector
    mov     bx,DOS_BOOT_LOC ;set ES:BX to data destination 7C00H (BB,00,7c)
    mov     cx,0001H ;Track 0, sec 01
    mov     dx,0000H ;side A, (DL bit 7 = 0) drive 0,

    int     13H     ;AH=2, CX=1, read 1 (the boot), sector

    JNC     F_BOOT_OK ;If NC, then no errors
    MOV     BX,BOOT_FAIL_MSG
    CALL    PRINT_STRING
    JMP     IBM_BIOS ;Will return back up to IBM_BIOS location

F_BOOT_OK:

```

```

    XOR     AX,AX
    MOV     DS,AX
    CMP     word [DOS_BOOT_SIGNATURE],0AA55H           ;Check we have a valid MBL signature
    JZ      F_BOOT_OK1
;
    MOV     BX,NO_MBL_MSG                             ;No Floppy Boot Loader Signature detected
    CALL    PRINT_STRING
    JMP     IBM_BIOS                                   ;Will return back up to IBM_BIOS location

F_BOOT_OK1:
    MOV     BX,BOOT_OK_MSG
    CALL    PRINT_STRING
;
; Call CI                                           ;Wait for CRT input for boot debugging (info at 7C00H)
;
    MOV     DX,0                                       ;Required see above
    JMP     word 0000H:DOS_BOOT_LOC                   ;Far Jump, execute the boot code @0:7C00H

; <<<< BOOT HDISK . IDE Board MUST be active (ZFDC board may be offline)
BOOT_HDISK:
    STI                                           ;Boot MSDOS (or FreeDOS) from IDE/CF Card
                                           ;Bootstrap Handler (Interrupt 19H)

    CALL    SET_DRIVE_B                             ;Select the second Drive/CF card
    CALL    IDEinit                                 ;Initialize drive 1. If there is no drive abort
    JZ      BOOT_RESET_OK

    MOV     BX,INIT_2_ERROR                         ;Warn second IDE drive did not initialize
    CALL    PRINT_STRING
    JMP     IBM_BIOS                                   ;Will return back up to start of Monitor

BOOT_RESET_OK:
    PUSH    DS
    XOR     AX,AX                                     ;Set DS to data area for ROM usage in low RAM @ 400H....)
    MOV     DS,AX
;
    MOV     AL,0H                                    ;Flag to indicate ZFDC board is NOT Initilized
    MOV     [ZFDC_INIT_FLAG],AL
;
    CALL    INIT_ZFDC                                ;Initilize the ZFDC board hardware (360K & 1.44M disks)
    POP     DS                                       ;Balance up stack

BOOT_ZFDC_OK:
    sub     ax,ax
    mov     ds,ax                                    ;DS -> 0
    mov     dx,0080H                                 ;DL = 80H will always boot from HDisk #2

    mov     ah,0
    int     13H                                       ;AH=0, reset Hard Disk system

    JNC     HBOOT_RESET_OK
    MOV     BX,RESET_FAIL_MSG
    CALL    PRINT_STRING
    JMP     IBM_BIOS                                   ;Will return back up to IBM_BIOS location

HBOOT_RESET_OK:
    XOR     AX,AX
    mov     DS,AX
    mov     ES,AX                                    ;DS = ES = 0000H
    mov     ax,201h                                  ;read one sector
    mov     bx,DOS_BOOT_LOC                          ;set ES:BX to data destination 7C00H (BB,00,7c)

```

```

    mov     cx,0001H                ;Track 0, sec 01 for MBL >>> Boot on Sector 12H <<<
    mov     dx,0080H                ;head 0, HDisk 0, (DL bit 7 = 1)
    int     13H                    ;AH=2, CX=1, read 1 (the boot), sector
    JNC     HDOS_BOOT_OK           ;If NC, then no errors
    MOV     BX,BOOT_FAIL_MSG
    CALL    PRINT_STRING
    JMP     IBM_BIOS                ;Will return back up to IBM_BIOS location

HDOS_BOOT_OK:
    MOV     BX,BOOT_OK_MSG
    CALL    PRINT_STRING

;     Call     CI                    ;Wait for CRT input for boot debugging
;                                     ;(Can reset and look at BOOT sector)

    MOV     DX,0080H                ;Required see above
    JMP     word 0000H:DOS_BOOT_LOC ;Far Jump, execute the boot code @0:7C00H

;*****
;
;     Disk I/O Handler      (Software Interrupt 13H & 40H)
;
;Input: AH = 00h          DISK - RESET DISK SYSTEM
;     DL = drive (if bit 7 is set, both hard disks and floppy disks are reset)
;Return:AH = status (see below)
;     CF clear if successful (returned AH=00h)
;     CF set on error
;
;
;Input: AH = 01h          DISK - GET STATUS OF LAST OPERATION
;     DL = drive (bit 7 set for hard disk)
;Return:CF clear if successful (returned status 00h)
;     CF set on error
;     AH = status of previous operation (see below)
;
;
;Input: AH = 02h          READ 03H,WRITE SECTOR DATA
;     AL = number of sectors to read (must be nonzero)
;     CH = low eight bits of cylinder number
;     CL = sector number 1-63 (bits 0-5, high two bits of cylinder (bits 6-7, hard disk
;           only)
;     DH = head number
;     DL = drive number (bit 7 set, for hard disk)
;     ES:BX -> data buffer
;
;Return:CF set on error
;     if AH = 11h (corrected ECC error), AL = burst length
;     CF clear if successful
;     AH = status (see below)
;     AL = number of sectors transferred (only valid if CF set for some BIOSes)
;
;
;Input: AH = 04h          DISK - VERIFY DISK SECTOR(S)
;     AL = number of sectors to verify (must be nonzero)
;     CH = low eight bits of cylinder number
;     CL = sector number 1-63 (bits 0-5) high two bits of cylinder (bits 6-7, hard disk
;           only)
;     DH = head number
;     DL = drive number (bit 7 set, for hard disk)
;     ES:BX -> data buffer (PC,XT,AT with BIOS prior to 1985/11/15)
;

```

```
;Return:CF set on error
;      CF clear if successful
;      AH = status (see below)
;      AL = number of sectors verified
;
;
;Input: AH = 05h          FLOPPY - FORMAT TRACK
;      AL = number of sectors to format
;      CH = track number
;      DH = head number
;      DL = drive number
;      ES:BX -> address field buffer:-
;              00h  BYTE  track number
;              01h  BYTE  head number (0-based)
;              02h  BYTE  sector number
;              03h  BYTE  sector size (00h=128 bytes, 01h=256 bytes, 02h=512,
;              03h=1024)
;Return:CF set on error
;      CF clear if successful
;      AH = status (see below)
;      Note: On AT or higher, call AH=17h first. The number of sectors per
;      track is read from the diskette
;      parameter table pointed at by INT 1E
;
;Input: AH = 08h          RETURN DRIVE PARAMATERS
;      DL = drive number (bit 7 set, for hard disk)
;      ES:DI = 0000H:0000H
;      Note: For systems predating the IBM AT, this call is only valid for
;      hard disks, as it is implemented
;      by the hard disk BIOS rather than the ROM BIOS. The IBM ROM-BIOS
;      returns the total number of hard disks
;      attached to the system regardless of whether DL >= 80h on entry

;Return:CF set on error
;      CF clear if successful
;      AH = status (see below)
;      AL = 00h on at least some BIOSes
;      BL = drive type (AT/PS2 floppies only)
;      Values for diskette drive type:
;              01h  360K
;              02h  1.2M
;              03h  720K
;              04h  1.44M
;      CH = low eight bits of maximum cylinder number
;      CL = maximum sector number (bits 5-0)
;              high two bits of maximum cylinder number (bits 7-6)
;      DH = maximum head number
;      DL = number of drives
;      ES:DI -> drive parameter table (floppies only)

;Input: AH = 15h          GET DISK TYPE
;      DL = drive number (bit 7 set, for hard disk)

;Return:CF set on error
;      CF clear if successful
;      AH = type code (see below)
;              00h no such drive
;              01h floppy without change-line support
;              02h floppy (or other removable drive) with change-line support
;              03h hard disk
;      CX:DX = number of 512-byte sectors

;RETURNED ERROR CODES IN AH:-
;      00h  successful completion
;      01h  invalid function in AH or invalid parameter
;      02h  address mark not found
```

```

; 03h   disk write-protected
; 04h   sector not found/read error
; 05h   reset failed (hard disk)
; 05h   data did not verify correctly (TI Professional PC)
; 06h   disk changed (floppy)
; 07h   drive parameter activity failed (hard disk)
; 08h   DMA overrun
; 09h   data boundary error (attempted DMA across 64K boundary or >80h sectors)
; 0Ah   bad sector detected (hard disk)
; 0Bh   bad track detected (hard disk)
; 0Ch   unsupported track or invalid media
; 0Dh   invalid number of sectors on format (PS/2 hard disk)
; 0Eh   control data address mark detected (hard disk)
; 0Fh   DMA arbitration level out of range (hard disk)
; 10h   uncorrectable CRC or ECC error on read
; 11h   data ECC corrected (hard disk)
; 20h   controller failure
; 31h   no media in drive (IBM/MS INT 13 extensions)
; 32h   incorrect drive type stored in CMOS (Compaq)
; 40h   seek failed
; 80h   timeout (not ready)
; AAh   drive not ready (hard disk)
; B0h   volume not locked in drive (INT 13 extensions)
; B1h   volume locked in drive (INT 13 extensions)
; B2h   volume not removable (INT 13 extensions)
; B3h   volume in use (INT 13 extensions)
; B4h   lock count exceeded (INT 13 extensions)
; B5h   valid eject request failed (INT 13 extensions)
; B6h   volume present but read protected (INT 13 extensions)
; BBh   undefined error (hard disk)
; CCh   write fault (hard disk)
; E0h   status register error (hard disk)
; FFh   sense operation failed (hard disk)

```

```

;*****
*****

```

```

OLD_DISKIO:                                     ;Come here via INT 40H, (rearily) for the
old Floppy Disk relocated INTs
STI                                             ;Normal INT 13H Entry point
PUSH     DS                                     ;For all commands use variables in low RAM
if needed
PUSH     AX
XOR      AX,AX                                 ;Set DS to data area for ROM usage in low
RAM @ 400H....)
MOV      DS,AX
POP      AX

CMP      byte [DEBUG_FLAG],0                   ;Is Floppy Debug mode on
JZ       COMMON_DISK_COMMANDS                 ;If not skip to "normal" FDisk routines

PUSH     AX
PUSH     BX
PUSH     CX
MOV      BX,INT_40F_MSG                       ;"Int 40H (<--Floppy) AX="
CALL     SERIAL_PRINT_STRING
POP      CX
POP      BX
POP      AX
CALL     SERIAL_DISPLAY_REGISTERS              ;Display Registers on serial port display
(All registers retained)
JMP      COMMON_DISK_COMMANDS                 ;Go to "normal" Disk routines

DISKIO:                                         ;Normal INT 13H Entry point
STI
PUSH     DS                                     ;For all commands use variables in low RAM

```

```

    if needed
    PUSH    AX
    XOR     AX,AX                               ;Set DS to data area for ROM usage in low
    RAM @ 400H....)
    MOV     DS,AX
    POP     AX

    CMP     byte [DEBUG_FLAG],0                ;Is Debug mode on
    JZ      COMMON_DISK_COMMANDS              ;If not skip

    PUSH    AX
    PUSH    BX
    PUSH    CX
    TEST    DL,80H                             ;Floppy or HDisk
    JNZ    DISKIO1
    MOV     BX,INT_13F_MSG                       ;"Int 13H (Floppy) AX="
    JMP     DISKIO2
DISKIO1:MOV     BX,INT_13H_MSG                   ;"Int 13H (** HDisk **) AX="
DISKIO2:CALL    SERIAL_PRINT_STRING
    POP     CX
    POP     BX
    POP     AX
    CALL    SERIAL_DISPLAY_REGISTERS            ;Display Registers on serial port display
    (All registers retained)

;Fall through to COMMON_DISK_COMMANDS

COMMON_DISK_COMMANDS:
    TEST    DL,80H                             ;HDisk or Floppy CMD
    JZ      FD_COMMANDS                        ;For Floppy disk commands
    JMP     HD_COMMANDS                       ;For HDISK Commands

;----- Floppy Disk Commands -----

FD_COMMANDS:
    TEST    AH,AH                             ;Is it a FDisk reset
    JNZ    N_FDISK_RESET
    JMP     FDISK_RESET
N_FDISK_RESET:
    CMP     AH,1                               ;Is it a FDisk status request
    JNZ    N_FDISK_STATUS
    JMP     FDISK_STATUS
N_FDISK_STATUS:
    CMP     AH,2                               ;Is it a FDisk read request
    JNZ    N_FDISK_READ
    MOV     byte [VERIFY_FLAG],0H             ;Turn off verify flag
    JMP     FDISK_READ
N_FDISK_READ:
    CMP     AH,3                               ;Is it a FDisk write request
    JNZ    N_FDISK_WRITE
    JMP     FDISK_WRITE
N_FDISK_WRITE:
    CMP     AH,4                               ;Is it a FDisk Verify request
    JNZ    N_FDISK_VERIFY
    MOV     byte [VERIFY_FLAG],0ffH          ;Turn on verify flag
    JMP     FDISK_READ                         ;Modified read
N_FDISK_VERIFY:
    CMP     AH,5                               ;Is it a FDisk format request
    JNZ    N_FDISK_FORMAT
    JMP     FDISK_FORMAT
N_FDISK_FORMAT:
    CMP     AH,8                               ;Is it a FDisk paramaters request
    JNZ    N_FDISK_PARAMS
    JMP     FDISK_PARAMS
N_FDISK_PARAMS:
    CMP     AH,15H                             ;GET DISK TYPE (XT 1986/1/10 or later,XT286
    ,AT,PS)

```



```

        JNZ     N_FDISK_DASB
        JMP     FDISK_DASB
N_FDISK_DASB:
        CMP     AH,16H                ;FDisk media change check request
        JNZ     NOT_VALID_DISK
        JMP     FDISK_MEDIA_CHANGE

NOT_VALID_DISK:                        ;Thats all for now
        PUSH    AX
        MOV     BX,INVALID_AH_FMSG
        CALL    PRINT_STRING
        POP     AX
        MOV     AL,AH
        CALL    AL_HEXOUT
        MOV     BX,H_MSG_CRLF
        CALL    PRINT_STRING
        mov     byte [IBM_DISK_STATUS],cmderr ;Show bad command
                                                ;Fall through to DONE_DISK

DONE_DISK:                              ;Most (but not all), floppy commands come
        back here before returning to DOS
        mov     ah,[IBM_DISK_STATUS]
        OR     AH,AH                ;Was there an error
        JZ     ALL_OK
        STC                               ;Set carry to indicate an error
ALL_OK:
        POP     ds                    ;Get back the original saved DS at start
        RETF     2                    ;Remove the original status flags on
        return (remember we got here via an INT)

;----- Floppy Disk Routines -----

FDISK_RESET:                            ;Home the disk head etc.
        PUSH    BX                    ;Save ALL
        PUSH    CX
        PUSH    DX
        MOV     [CURRENT_DRIVE],DL

        MOV     CL,CMD_SET_DRIVE      ;Set Drive Drive, ZFDC will just return if
current drive
        CALL    S100OUT
        MOV     CL,[CURRENT_DRIVE]
        OR     CL,CL                ;DL = 0 --> ZFDC Drive #3. DL = 1 -->ZFDC
Drive #2
        MOV     CL,3                ;Default to Drive #3
        JZ     R_FLOPPY
        MOV     CL,2                ;Drive #2
R_FLOPPY:
        CALL    S100OUT
        CALL    WAIT_FOR_ACK          ;Return Z (or NZ with error # in [AH])
        JNZ     FDISK_RESET_ERROR

        MOV     CL,CMD_SET_HOME       ;Home the heads of the current drive
        CALL    S100OUT
        CALL    WAIT_FOR_ACK          ;Return Z (or NZ with error # in [AH])
        JNZ     FDISK_RESET_ERROR
        mov     byte [SEEK_STATUS],0 ;show good seek status
        mov     byte [IBM_DISK_STATUS],0 ;and good disk status
        POP     DX
        POP     CX
        POP     BX
        JMP     DONE_DISK            ;and return

FDISK_RESET_ERROR:
        MOV     BX,HOME_ERR_MSG

```

```

CALL    PRINT_STRING
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
mov     byte [VERIFY_FLAG],0          ;Initially sector reads (rather than sctor ✓
verifys)
POP     DX
POP     CX
POP     BX
JMP     DONE_DISK                      ;and return (with error)

FDISK_STATUS:                          ;AH = 0
mov     al,[IBM_DISK_STATUS]           ;Return past floppy status
mov     byte [IBM_DISK_STATUS],0      ;reset status in low RAM for next time
JMP     DONE_DISK                      ;and return

FDISK_PARAMS:                          ;AH = 8
CMP     DL,00H                         ;DL=1 from INT call if drive B: (ZFDC ✓
controllor drive #2, 5" disk)
JZ      IS_144M_DISK
MOV     DI,FDISK_5PARAM_TBL           ;Return with drive paramater table in ES:DI
MOV     AX,CS
MOV     ES,AX                          ;And segment int ES:
XOR     AX,AX                          ;Disk paramaters for 360K 5" Drive
MOV     BH,0                            ;Always
MOV     BL,01H                         ;0=Unknown, 1=360K, 2=1.2M, 3=720K, 4=1.44M
MOV     CH,27H                         ;Max Track 39
MOV     CL,9                            ;Max sector
MOV     DH,1                            ;Max value of head
MOV     DL,2                            ;Number of floppy disks
mov     byte [IBM_DISK_STATUS],0      ;Show OK
JMP     DONE_DISK                      ;and return

IS_144M_DISK:
MOV     DI,FDISK_3PARAM_TBL           ;Return with drive paramater table in ES:DI
MOV     AX,CS
MOV     ES,AX                          ;And segment int ES:
XOR     AX,AX                          ;Disk paramaters for 1.44M 3" Drive
MOV     BH,0                            ;Always
MOV     BL,04H                         ;0=Unknown, 1=360K, 2=1.2M, 3=720K, 4=1.44M
MOV     CH,4FH                         ;Max Track 79
MOV     CL,18                          ;Max sector
MOV     DH,1                            ;Max value of head
MOV     DL,2                            ;Number of floppy disks!
mov     byte [IBM_DISK_STATUS],0      ;Show OK
JMP     DONE_DISK                      ;and return

FDISK_DASB:                            ;AH = 15H, GET DISK TYPE (XT 1986/1/10 or ✓
later,XT286,AT,PS)
XOR     AX,AX
MOV     AH,01                          ;For now return flag "no disk change line ✓
support implemmented"
mov     byte [IBM_DISK_STATUS],0      ;Show OK
CLC                                         ;Clear CF
JMP     ALL_OK                          ;Do not check status, just return

FDISK_MEDIA_CHANGE:                   ;AH = 16H
XOR     AX,AX
MOV     AX,06                          ;change line not support implemmented"
mov     byte [IBM_DISK_STATUS],0      ;Show OK
CLC                                         ;Clear CF

```

```

        JMP     ALL_OK                ;Do not check status, just return

;----- READ FLOPPY DISK SECTORS -----

FDISK_READ:                ;AH=2, Read disk sector(s)
        PUSH   BX                    ;Save everything, DS already on stack
        PUSH   CX
        PUSH   DX
        PUSH   ES
        PUSH   DI                    ;Used in LES below and DMA_ADJUST

        MOV    [SECTORS_TO_DO],AL    ;save everything first
        MOV    byte [SECTORS_DONE],0
        MOV    [CURRENT_TRACK],CH
        MOV    [CURRENT_SECTOR],CL
        MOV    [CURRENT_HEAD],DH
        MOV    [CURRENT_DRIVE],DL
        MOV    [DMA_SEGMENT],ES     ;Save for below
        MOV    [DMA_OFFSET],BX

        CALL   DMA_ADJUST           ;Some DMA controllers cannot cross seg  ✓
        boundries, adjust

READ_COMMON:
        MOV    CL,CMD_SET_DRIVE     ;Set Drive Drive, ZFDC will just return if  ✓
        current drive
        CALL   S100OUT
        MOV    CL,[CURRENT_DRIVE]   ;DL from INT call
        OR     CL,CL                ;DL = 0 --> ZFDC Drive #3.  DL = 1 -->ZFDC  ✓
        Drive #2
        MOV    CL,3                 ;Default to Drive #3
        JZ     RDD_FLOPPY
        MOV    CL,2                 ;Drive #2

RDD_FLOPPY:
        CALL   S100OUT
        CALL   WAIT_FOR_ACK         ;Return Z (or NZ with error # in [AH])
        JZ     READ_1
        mov    byte [IBM_DISK_STATUS],seekerr ;show seek error
        JMP    ZFDC_READ_ERROR

READ_1:
        MOV    CL,CMD_SET_TRACK     ;Set Track
        CALL   S100OUT
        MOV    CL,[CURRENT_TRACK]
        CALL   S100OUT              ;Send Selected track number
        CALL   WAIT_FOR_ACK         ;Return Z (or NZ with error # in [AH])
        JZ     READ_2
        mov    byte [IBM_DISK_STATUS],seekerr ;show seek error
        JMP    ZFDC_READ_ERROR

READ_2:
        MOV    CL,CMD_SET_SIDE     ;Set Drive Side/Head
        CALL   S100OUT
        MOV    CL,[CURRENT_HEAD]    ;Set side (Head 0,1)
        CALL   S100OUT
        CALL   WAIT_FOR_ACK         ;Return Z (or NZ with error # in [AH])
        JZ     READ_3
        mov    byte [IBM_DISK_STATUS],seekerr ;show seek error
        JMP    ZFDC_READ_ERROR

READ_3:
        MOV    CL,CMD_DOS_SET_SECTOR ;Set MS_DOS Sector (Note not CMD_SET_SECTOR) ✓
        for CPM)
        CALL   S100OUT
        MOV    CL,[CURRENT_SECTOR]
        CALL   S100OUT              ;Send Selected track number

```



```

        JNZ      RD_LOOP

        CALL    WAIT_FOR_ACK          ;Return Z (or NZ with error # in [AH])
        JNZ      RD_SEC_ERR

        mov     byte [IBM_DISK_STATUS],0      ;Show good operation
        POP     DI                      ;Get back all original registers
        POP     ES
        POP     DX
        POP     CX
        POP     BX
        mov     AL, [SECTORS_DONE]          ;Return # of sectors done
        JMP     DONE_DISK                  ;and return

RD_SEC_ERR:
        mov     byte [IBM_DISK_STATUS],crcerr ;Show CRC error
                                                ;Fall through to ZFDC_READ_ERROR
ZFDC_READ_ERROR:
        routine                          ;General read sector error reporting
        PUSH    AX
        MOV     BX,READ_ERR_MSG
        CALL    PRINT_STRING
        POP     AX
        MOV     AL,AH
        CALL    AL_HEXOUT
        MOV     BX,H_MSG_CRLF
        CALL    PRINT_STRING
        POP     DI                      ;Get back all original registers
        POP     ES
        POP     DX
        POP     CX
        POP     BX
        mov     AL, [SECTORS_DONE]          ;Return # of sectors done
        JMP     DONE_DISK                  ;and return

VERIFY_SECTOR:
                                                ;Special case where we just check sector
        for CRC errors/verify
        MOV     BX,SECTOR_TIMEOUT          ;Put in a timeout count (Loop for status
        reads at most 256X4 times)
VRDSEC1:DEC     BX                        ;Dec BC
        JNZ    VRDSEC2                    ;Will wait 400H times before timing out
        MOV    AH,TIMEOUT_ERROR            ;Send Timeout error
        mov    byte [IBM_DISK_STATUS],timerr ;show as timeout error
        JMP    ZFDC_READ_ERROR

VRDSEC2:IN     AL,S100STATUSB              ;Send data to ZFDC output
        TEST   AL,80H                      ;Is ZFDC in INPUT mode, if not wait
        JZ    VRDSEC1
        TEST   AL,01H                      ;Has previous (if any) character been read.
        JZ    VRDSEC1                      ;Z if not yet ready

        IN     AL,S100DATAB                ;Get data
        LOOP   VERIFY_SECTOR
        JMP    RDSEC5                      ;Are there more sectors to verify

;----- WRITE FLOPPY DISK SECTORS -----

FDISK_WRITE:
                                                ;AH=3, Write disk
        PUSH   BX                          ;Save everything, DS already on stack
        PUSH   CX
        PUSH   DX
        PUSH   ES
        PUSH   DI                          ;Used in DMA ADJUST
        PUSH   SI                          ;Need for LDS below

```

```

MOV     [SECTORS_TO_DO],AL           ;save everything first
MOV     byte [SECTORS_DONE],0
MOV     [CURRENT_TRACK],CH
MOV     [CURRENT_SECTOR],CL
MOV     [CURRENT_HEAD],DH
MOV     [CURRENT_DRIVE],DL
MOV     [DMA_SEGMENT],ES           ;Save for below
MOV     [DMA_OFFSET],BX

CALL    DMA_ADJUST                 ;Some DMA controllers cannot cross seg  ✓
boundries, adjust

WRITE_COMMON:
MOV     CL,CMD_SET_DRIVE           ;Set Drive Drive, ZFDC will just return if  ✓
current drive
CALL    S100OUT
MOV     CL,[CURRENT_DRIVE]        ;DL from INT call
OR      CL,CL                      ;DL = 0 --> ZFDC Drive #3. DL = 1 -->ZFDC  ✓
Drive #2
MOV     CL,3                       ;Default to Drive #3
JZ      WDD_FLOPPY
MOV     CL,2                       ;Drive #2
WDD_FLOPPY:
CALL    S100OUT
CALL    WAIT_FOR_ACK              ;Return Z (or NZ with error # in [AH])
JZ      WRITE_1
mov     byte [IBM_DISK_STATUS],seekerr ;Show seek error
JMP     ZFDC_WRITE_ERROR

WRITE_1:
MOV     CL,CMD_SET_TRACK           ;<<< Set Track
CALL    S100OUT
MOV     CL,[CURRENT_TRACK]
CALL    S100OUT                   ;Send Selected track number
CALL    WAIT_FOR_ACK              ;Return Z (or NZ with error # in [AH])
JZ      WRITE_2
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP     ZFDC_WRITE_ERROR

WRITE_2:
MOV     CL,CMD_SET_SIDE           ;<<< Set Drive Side/Head
CALL    S100OUT
MOV     CL,[CURRENT_HEAD]        ;Set side (Head 0,1)
CALL    S100OUT
CALL    WAIT_FOR_ACK              ;Return Z (or NZ with error # in [AH])
JZ      WRITE_3
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP     ZFDC_WRITE_ERROR

WRITE_3:
MOV     CL,CMD_DOS_SET_SECTOR     ;Set MS_DOS Sector (Note not CMD_SET_SECTOR) ✓
for CPM)
CALL    S100OUT
MOV     CL,[CURRENT_SECTOR]
CALL    S100OUT                   ;Send Selected track number
CALL    WAIT_FOR_ACK              ;Return Z (or NZ with error # in [AH])
JZ      WRITE_4
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP     ZFDC_WRITE_ERROR

WRITE_4:
MOV     CL,CMD_SEEK_TRACK         ;<<< Seek to that track (if not  ✓
already there)
CALL    S100OUT
CALL    WAIT_FOR_ACK              ;Return Z (or NZ with error # in [AH])
JZ      WRITE_5
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error

```



```

        JMP     DONE_DISK                ;and return

WR_SEC_ERR:
        mov     byte [IBM_DISK_STATUS],crcerr ;Show CRC error
                                                ;Fall through to ZFDC_WRITE_ERROR
ZFDC_WRITE_ERROR:                        ;General write sector error reporting
        routine
        CMP     AH,DISK_WP_ERR           ;Special case for Write Protected Disk
        error
        JZ      F_DISK_WP_ERROR
        PUSH    AX
        MOV     BX,WRITE_ERR_MSG
        CALL    PRINT_STRING
        POP     AX
        MOV     AL,AH
        CALL    AL_HEXOUT
        MOV     BX,H_MSG_CRLF
        CALL    PRINT_STRING
WP_DONE: POP     SI
        POP     DI                        ;Get back all original registers
        POP     ES
        POP     DX
        POP     CX
        POP     BX
        mov     AL, [SECTORS_DONE]        ;Return # of sectors done
        JMP     DONE_DISK                ;and return

F_DISK_WP_ERROR:
        mov     byte [IBM_DISK_STATUS],wpterr ;Write protected disk
        JMP     WP_DONE

;----- FORMAT FLOPPY DISK -----
;-----
;Code not tested/complete yet!
FDISK_FORMAT:                            ;Format the current disk using teh ZFDC
        format track command
        PUSH    BX
        PUSH    CX
        PUSH    DX

        MOV     [CURRENT_DRIVE],DL
        MOV     [CURRENT_TRACK],CH

        CMP     DL,0                    ;If first track home heads
        JNZ     FORMAT_F1
        MOV     CL,CMD_SET_HOME         ;Note this is a restore with NO verify.
        (disk my not be formatted)
        CALL    S100OUT
        CALL    WAIT_FOR_ACK            ;Return Z (or NZ with error # in [AH])
        JZ      FORMAT_F1
        mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
        JMP     ZFDC_FORMAT_ERROR

FORMAT_F1:
        MOV     CL,CMD_FORMAT_TRACK     ;Format a complete track on ZFDC controller
        CALL    S100OUT

        MOV     CL,[CURRENT_TRACK]      ;Send the track number
        CALL    S100OUT

        MOV     CL,CONFIRM_FORMAT       ;Now send SPECIAL OK to FORMAT Disk flag
        CALL    S100OUT

        ;<<< Now wait until track is formatted >>>
WAIT_F:  CALL    S100STAT                ;Wait until ZFDC Board is ready

```



```

    JNZ     TRACK_DONE                ;NZ, something there!
    MOV     AH,1
    int    16H                        ;KEYBOARD - CHECK FOR KEYSTROKE
    JZ      WAIT_F                    ;Nothing, then wait some more
    MOV     AH,0                      ;Get character
    int    16H
    CMP     AL,ESC                    ;Was an ESC character entered
    JZ      ZFDC_FORMAT_ERROR
    JMP     WAIT_F

TRACK_DONE:
    CALL    S100IN                    ;Get returned Error # (Note this releases
the SEND_DATA routine on the ZFDC board)
    CMP     AL,NO_ERRORS_FLAG        ;Was SEND_OK/NO_ERRORS_FLAG sent back from
ZFDC Board
    JNZ     ZFDC_FORMAT_ERROR
    mov     byte [IBM_DISK_STATUS],0 ;and good disk status
    POP     DX
    POP     CX
    POP     BX
    JMP     DONE_DISK                ;and return

ZFDC_FORMAT_ERROR:
    mov     byte [IBM_DISK_STATUS],cmderr ;Show as CMD error
    PUSH    AX
    MOV     BX,FORMAT_ERR_MSG
    CALL    PRINT_STRING
    POP     AX
    MOV     AL,AH
    CALL    AL_HEXOUT
    MOV     BX,H_MSG_CRLF
    CALL    PRINT_STRING
    POP     DX
    POP     CX
    POP     BX
    mov     AL, [SECTORS_DONE]        ;Return # of sectors done
    JMP     DONE_DISK                ;and return

;----- HARD DISK Routines -----
;-----

;We will use for MS-DOS Drive C: the second IDE Drive.
;Leaving the first for CPM86 (or, later the second MS-DOS hard disk)

HD_COMMANDS:
    TEST    AH,AH                    ;Is it a FDisk reset
    JNZ     N_HDISK_RESET
    JMP     HDISK_RESET

N_HDISK_RESET:
    CMP     AH,1                    ;Is it a HDISK status request
    JNZ     N_HDISK_STATUS
    JMP     HDISK_STATUS

N_HDISK_STATUS:
    CMP     AH,2                    ;Is it a HDISK read request
    JNZ     N_HDISK_READ
    MOV     byte [VERIFY_FLAG],0H    ;Turn off verify flag
    JMP     HDISK_READ

N_HDISK_READ:
    CMP     AH,3                    ;Is it a HDISK write request
    JNZ     N_HDISK_WRITE
    JMP     HDISK_WRITE

```

```

N_HDISK_WRITE:
    CMP     AH,4                      ;Is it a HDISK Verify request
    JNZ     N_HDISK_VERIFY
    MOV     byte [VERIFY_FLAG],0FFH  ;Turn on verify flag
    JMP     HDISK_READ                ;Modified read

N_HDISK_VERIFY:
    CMP     AH,5                      ;Is it a HDisk format request
    JNZ     N_HDISK_FORMAT
    JMP     HDISK_FORMAT

N_HDISK_FORMAT:
    CMP     AH,8                      ;Is it a HDisk paramaters request
    JNZ     N_HDISK_PARAMS
    JMP     HDISK_PARAMS

N_HDISK_PARAMS:
    CMP     AH,9                      ;Is it a HDisk Controller Initilize request
    JNZ     N_HDISK_INIT_REQ
    JMP     HDISK_INIT_REQ

N_HDISK_INIT_REQ:
    CMP     AH,0DH                    ;Is it a HDisk Reset request (Alternative)
    JNZ     N_HDISK_RESET2
    JMP     HDISK_RESET

N_HDISK_RESET2:
    CMP     AH,10H                   ;Is it a HDisk Ready check request
    JNZ     N_HDISK_READY_CHK
    JMP     HDISK_READY_CHK

N_HDISK_READY_CHK:
    CMP     AH,15H                   ;Is it a HDISK read DASB request
    JNZ     N_NOT_VALID_DISK
    JMP     HDISK_DASB

N_NOT_VALID_DISK:
    JMP     NOT_VALID_DISK           ;Go to common/floppy error return

HDISK_RESET:                          ;AH = 0, Home the disk head etc.
    CALL    SET_DRIVE_B              ;Select the second Drive/CF card as MS-DOS ✓
    Drive C:
    CALL    IDEinit                  ;Initialize drive 2. If there is no drive ✓
    abort
    JNZ     HDISK_RESET_ERROR
    mov     byte [SEEK_STATUS],0     ;show good seek status
    mov     byte [IBM_DISK_STATUS],0 ;and good disk status
    JMP     DONE_DISK                ;and return

HDISK_RESET_ERROR:
    MOV     BX,HOME_ERR_MSG
    CALL    PRINT_STRING
    mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
    JMP     DONE_DISK                ;and return (with error)

HDISK_STATUS:                          ;AH = 1
    mov     al,[IBM_DISK_STATUS]     ;Return past disk status
    mov     byte [IBM_DISK_STATUS],0 ;reset status in low RAM for next time
    JMP     DONE_DISK                ;and return

HDISK_PARAMS:                          ;AH = 8H Get Hard Drive Parmas (We will ✓
    assume one hard disk only, Custom type)
    MOV     AH,0
    MOV     AL,DOS_MAXSEC            ;Do NOT change ES or BX
    MOV     CH,DOS_MAXCYL_L-1       ;0FEH, low eight bits of maximum cylinder ✓
    number
    MOV     CL,DOS_MAXSEC_CYL       ;3FH, maximum sector number (bits 5-0)+ two ✓
    Cyl High Bits (Sectors numbered 1....x)
    ;high two bits of maximum cylinder number ✓
    (bits 7-6)

```

```

MOV     DH,DOS_MAXHEADS-1           ;0FH, (0...15) 16 Heads
MOV     DL,1                         ;Number of Hard Disks
mov     byte [IBM_DISK_STATUS],0    ;Show OK
JMP     DONE_DISK                    ;and return. This will put AH=0 & Clear CF

HDISK_INIT_REQ:                      ;AH = 9H,   INITIALIZE CONTROLLER WITH
    DRIVE PARAMETERS (AT,PS)         ;
HDISK_READY_CHK:                     ;AH = 10H,  HARD DISK - CHECK IF DRIVE
    READY                            ;
    mov     byte [IBM_DISK_STATUS],0 ;Since we have only one HDisk just return
    for now
    JMP     DONE_DISK

HDISK_DASB:                           ;AH = 15H,  GET DISK TYPE (XT 1986/1/10 or
    later,XT286,AT,PS)              ;
    MOV     AX,0310H                 ;AH, Indicates a Hard Disk
    MOV     CX,000FH
    MOV     DX,0BC10H                ;This is what the AMI Bios returns for our
    cystem drive (CX:DX = Total sectors)
    mov     byte [IBM_DISK_STATUS],0 ;Show OK
    CLC                                     ;Clear CF
    JMP     ALL_OK                    ;Do not check status, just return

HDISK_FORMAT:                          ;AH = 05H,  Format disk - Return
    immediately with status ok
    mov     byte [IBM_DISK_STATUS],0 ;show good operation no matter what
    JMP     DONE_DISK                ;and return

;----- READ HARD DISK DISK SECTORS -----

HDISK_READ:
    PUSH    BX                       ;Save everything, DS already on stack
    PUSH    CX
    PUSH    DX
    PUSH    ES
    PUSH    DI                       ;Used in LES below and DMA_ADJUST

    MOV     [SECTORS_TO_DO],AL        ;save everything first
    MOV     byte [SECTORS_DONE],0
    MOV     AL,CL                     ;Store Sector
    AND     CL,00111111B              ;Strip High 2 track bits
    MOV     [CURRENT_SECTOR],CL
    MOV     AH,0                       ;Shift the top 2 bits of AL into AH
    SHL     AX,1
    SHL     AX,1
    MOV     [CURRENT_TRACK_HIGH],AH
    MOV     [CURRENT_TRACK],CH        ;Store low track#
    MOV     [CURRENT_HEAD],DH        ;Store Head#
    MOV     [CURRENT_DRIVE],DL       ;Actully for now always drive #2 on IDE
    Board
    MOV     [DMA_SEGMENT],ES          ;Save for below
    MOV     [DMA_OFFSET],BX

    CALL    DMA_ADJUST                ;Some DMA controllers cannot cross seg
    boundaries, adjust

    CMP     byte [DEBUG_FLAG],2      ;Is Detailed Hdisk/Floppy Debug mode on
    JL     HREAD_COMMON              ;If not skip
    CALL    DUMP_TRACK_PARAMS        ;Dump the Track,Head,Cylinder data to
    serial debug terminal

HREAD_COMMON:

```

```

        CALL    DOS_WR_LBA                ;Setup Drive, Track, Sector for MS-DOS      ✓
        formatted disk.
        CALL    IDEwaitnotbusy           ;Make sure drive is ready
        JNB    HL_19                     ;Carry flag set if problem
        CALL    SHOWerrors               ;Show error data on CRT
        mov    byte [IBM_DISK_STATUS],seekerr ;show seek error
        JMP    H_READ_ERROR              ;General read HDisk sector error reporting ✓
        routine
                                           ;and return (with error)

HL_19:  MOV     DH,COMMANDread
        MOV     DL,REGcommand
        CALL    IDEwr8D                  ;Send Sec read command to drive.
        CALL    IDEwaitdrq              ;Wait until it's got the data
        JNB    HL_20                     ;Carry flag set if problem
        CALL    SHOWerrors               ;Show error data on CRT
        mov    byte [IBM_DISK_STATUS],crcerr ;Show as CRC error
        JMP    H_READ_ERROR              ;General read HDisk sector error reporting ✓
        routine
                                           ;and return (with error)

HL_20:  LES     DI,[DMA_OFFSET]          ;Point to initial DMA address (ES & DI      ✓
        already saved above)
HRD_LOOP:
        MOV     CX,256                   ;ALWAYS read 512 bytes to [CX] (256X2      ✓
        bytes)
HRD_LOOP_BYTES:
        MOV     AL,REGdata                ;REG regsiter address
        OUT    IDEportC,AL
        OR     AL,IDERdline              ;08H+40H, Pulse RD line
        OUT    IDEportC,AL
        IN     AL,IDEportA                ;Read the LOWER byte first
        STOSB                             ;READ 1 BYTE BYTE, AL->ES:[DI++]
        IN     AL,IDEportB                ;THEN read the UPPER byte
        STOSB                             ;READ 1 BYTE BYTE, AL->ES:[DI++]
        MOV     AL,REGdata                ;Deassert RD line
        OUT    IDEportC,AL
        LOOP   HRD_LOOP_BYTES             ;256 words, for 512 bytes
        CMP    byte [DEBUG_FLAG],2       ;Is Detailed HDISK/Floppy Debug mode on
        JL    HRDSEC4                    ;If not skip
        CALL   SERIAL_DUMP_RD_SECTOR_DATA ;Dump first 16 bytes of data
HRDSEC4:
        MOV     CX,0FFFFH                ;Need to wait until the IDE drive is ready
HRDSEC5:
        MOV     DL,REGstatus              ;with status data after potentially a long
        CALL    IDErd8D                  ;series of sector reads.
        AND    DH,80H                    ;Returned data in DH
        AND    DH,80H                    ;Is IDE Drive still busy (bit 7 low)
        JZ     HRDSEC6                    ;No, then check returned status
        LOOP   HRDSEC5                    ;wait until ready
HRDSEC6:
        MOV     AL,DH                     ;Was previous command completed without ✓
        errors
        AND    AL,1H                      ;Ret AL=0 for all OK
        JZ     HNEXT_SECTOR_RD
        CALL    SHOWerrors                ;Show error data on CRT
        mov    byte [IBM_DISK_STATUS],crcerr ;Show as CRC error
        JMP    H_READ_ERROR              ;General write HDisk sector error reporting ✓
        routine

```

```

;and return (with error)

;We have done one sector, are there more
;On hard disks (with XT and AT BIOSes), a
multi-sector read
;continues on the next higher head of the
same cylinder and if
HNEXT_SECTOR_RD:
;necessary, advances to the next higher
cylinder on the first head.
mov     al,[SECTORS_DONE]
INC     al
mov     [SECTORS_DONE],al
CMP     [SECTORS_TO_DO],al
JNE     HRD_LOOP
;Store it
;Have we done all yet

mov     byte [IBM_DISK_STATUS],0
;Show good operation
HRD_DONE:
POP     DI
POP     ES
POP     DX
POP     CX
POP     BX
mov     AL, [SECTORS_DONE]
JMP     DONE_DISK
;Return # of sectors done
;and return

H_READ_ERROR:
PUSH    AX
MOV     BX,HREAD_ERR_MSG
CALL    PRINT_STRING
CALL    H_PRINT_CHS
;Print current Cyl, Head, Sector (DS:
points to low RAM data stores)
POP     AX
JMP     HRD_DONE

HDISK_WRITE:
;Arrive here with DS: pointing to low RAM
data area
PUSH    BX
PUSH    CX
PUSH    DX
PUSH    ES
PUSH    DI
PUSH    SI
;Save everything, DS already on stack
;Used in LES below and DMA_ADJUST
;Need for LDS below

MOV     [SECTORS_TO_DO],AL
MOV     byte [SECTORS_DONE],0
MOV     AL,CL
AND     CL,00111111B
MOV     [CURRENT_SECTOR],CL
MOV     AH,0
SHL     AX,1
SHL     AX,1
;save everything first
;Store Sector
;Strip High 2 track bits
MOV     [CURRENT_TRACK_HIGH],AH
MOV     [CURRENT_TRACK],CH
MOV     [CURRENT_HEAD],DH
MOV     [CURRENT_DRIVE],DL
;Shift the top 2 bits of AL into AH
Board
MOV     [DMA_SEGMENT],ES
MOV     [DMA_OFFSET],BX
;Save for below

CALL    DMA_ADJUST
;Some DMA controllers cannot cross seg
boundries, adjust

CMP     byte [DEBUG_FLAG],2
;Is Detailed Hdisk/Floppy Debug mode on

```

```

        JL      HWRITE_COMMON          ;If not skip
        CALL   DUMP_TRACK_PARAMS      ;Dump the Track,Head,Cylinder data to
        serial debug terminal
HWRITE_COMMON:
        CALL   DOS_WR_LBA             ;Setup Drive, Track, Sector for MS-DOS
        formatted disk.
        CALL   IDEwaitnotbusy        ;Make sure drive is ready
        JNB    HW_19                  ;Carry flag set if problem
        CALL   SHOWerrors            ;Show error data on CRT
        mov    byte [IBM_DISK_STATUS],seekerr ;show seek error
        JMP    H_WRITE_ERROR         ;General write HDisk sector error reporting
        routine
                                           ;and return (with error)

HW_19:  MOV     DH,COMMANDwrite
        MOV     DL,REGcommand
        CALL   IDEwr8D               ;Send Sec write command to drive.
        CALL   IDEwaitdrq           ;Wait until it's got the data
        JNB    HW_20                  ;Carry flag set if problem
        CALL   SHOWerrors            ;Show error data on CRT
        mov    byte [IBM_DISK_STATUS],crcerr ;Show as CRC error
        JMP    H_WRITE_ERROR         ;General write HDisk sector error reporting
        routine
                                           ;and return (with error)

HW_20:  PUSH    DS                    ;Remember from now on, low RAM DS pointer
        is no longer valid
        MOV     AX,DS
        XOR     AX,AX
        MOV     ES,AX                ;ES will now temporly have the low RAM
        pointer
        LDS     SI,[DMA_OFFSET]

HWR_LOOP:
        MOV     AL,WRITEcfg8255      ;8255 to write mode
        OUT    IDECtrlPort,AL
        MOV     CX,256               ;ALWAYS read 512 bytes to [CH] (256X2
        bytes)

HWR_LOOP_BYTES:
        LODSB                          ;WRITE 1 BYTE, DS:[SI++] -> AL
        OUT    IDEportA,AL            ;Write the LOWER byte first
        LODSB                          ;WRITE 1 BYTE, DS:[SI++] -> AL
        OUT    IDEportB,AL            ;THEN UPPER byte on B

        MOV     AL,REGdata
        PUSH   AX
        OUT    IDEportC,AL            ;Send write command
        OR     AL,IDEwrline           ;Send WR pulse
        OUT    IDEportC,AL
        POP    AX
        OUT    IDEportC,AL            ;Send write command
        LOOP   HWR_LOOP_BYTES         ;One sector done

        MOV     AL,READcfg8255        ;Set 8255 back to read mode
        OUT    IDECtrlPort,AL

HW_21:  MOV     CX,0FFFFH             ;Need to wait until the IDE drive is ready
        ;with status data after potentially a long
        MOV     DL,REGstatus          ;Series of sector writes
        CALL   IDErd8D               ;Returned data in DH
        AND    DH,80H                ;Is IDE Drive still busy
        JZ     HW_22                  ;No, then check returned staus
        LOOP   HW_21

```

```

HW_22:
    MOV     AL,DH                ;Was previous command completed without
errors                                ;
    AND     AL,1H                ;Ret AL=0 for all OK
    JZ      HNEXT_SECTOR_WR

    POP     DS                    ;Get back DS for above
    CALL    SHOWerrors           ;Show error data on CRT
    mov     byte [IBM_DISK_STATUS],crcerr ;Show as CRC error
    JMP     H_WRITE_ERROR        ;General write HDisk sector error reporting
    routine

                                ;We have done one sector, are there more
                                ;On hard disks (with XT and AT BIOSes), a
multi-sector read                    ;
                                ;continues on the next higher head of the
    same cylinder and if            ;
HNEXT_SECTOR_WR:                    ;necessary, advances to the next higher
    cylinder on the first head.
    mov     al,[ES:SECTORS_DONE]
    INC     al
    mov     [ES:SECTORS_DONE],al    ;Store it
    CMP     [ES:SECTORS_TO_DO],al   ;Have we done all yet
    JNZ     HWR_LOOP

    POP     DS                    ;Get back DS for above.
    mov     byte [IBM_DISK_STATUS],0 ;Show good operation
HWR_DONE:
    POP     SI
    POP     DI                    ;Get back all original registers
    POP     ES
    POP     DX
    POP     CX
    POP     BX
    mov     AL, [SECTORS_DONE]      ;Return # of sectors done
    JMP     DONE_DISK              ;and return

H_WRITE_ERROR:
    MOV     AL,READcfg8255         ;Set 8255 back to read mode
    OUT     IDECtrlPort,AL
    PUSH    AX
    MOV     BX,HWRITE_ERR_MSG     ;"HDisk Sector Write Error"
    CALL    PRINT_STRING
    CALL    H_PRINT_CHS           ;Print current Cyl, Head, Sector (DS:
points to low RAM data stores)
    POP     AX
    JMP     HWR_DONE

H_PRINT_CHS:                        ;DS: points to low RAM data stores
    MOV     BX,HD_MSG             ;" Head = "
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_HEAD]
    CALL    AL_HEXOUT

    MOV     BX,CYL_MSG            ;"H Cyl = "
    CALL    PRINT_STRING
    MOV     AH,[CURRENT_TRACK_HIGH]
    MOV     AL,[CURRENT_TRACK]
    CALL    AX_HEXOUT

    MOV     BX,SEC_MSG            ;"H Sec = "
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_SECTOR]
    CALL    AL_HEXOUT

    MOV     BX,BRAC1_MSG         ;"H ("

```

```

CALL    PRINT_STRING
MOV     AL,[SECTORS_DONE]
CALL    AL_HEXOUT

MOV     BX,OF_MSG                      ;"H of "
CALL    PRINT_STRING
MOV     AL,[SECTORS_TO_DO]
CALL    AL_HEXOUT

MOV     BX,BRAC2_MSG                    ;H") "
CALL    PRINT_STRING
RET

```

```

;----- SUPPORT ROUTINES FOR ZFDC BOARD FOR MSDOS/FREEDOS -----
;-----

```

```

INIT_ZFDC:                                ;Return 0FFH in [ZFDC_INIT_FLAG] and Z flag set if
all OK                                     ;Do a hardware reset. Does not matter what is in
OUT    RESETZFDCPORT,AL                   ;[AL]
[AL]

MOV     AX,5                               ;~0.5 second at 10 MHz
MOV     CX,0                               ;Delay to allow board to setup hardware
WAITD: LOOP WAITD                          ;Delay for ~0.5 seconds
DEC     AX
JNZ    WAITD

IN     AL,S100DATAB                        ;Check the board is there
CMP     AL,CMD_HANDSHAKE                  ;Make sure we get HANDSHAKE byte back
MOV     AH,ZFDC_ABSENT                    ;If not then no ZFDC board present
JNZ    BADZFDC                            ;If not there, just abort

MOV     AL,CMD_HANDSHAKE                  ;Send another byte just to be sure.
OUT     S100DATAB,AL                      ;This clears up ints on ZFDC board
CALL    WAIT_FOR_ACK                      ;Return Z (or NZ with error # in [AH])

OR     AL,AL
MOV     AH,ZFDC_INIT_ERROR                ;If not then no ZFDC board present
JNZ    BADZFDC                            ;just abort

;Leave drives 0,1 UNFORMATTED/UNINITIALIZED for now

MOV     CL,CMD_SET_FORMAT                  ;Send Set Disk Format to Drive CMD for drive #3 (1.
44M 3" disk)
CALL    S100OUT
MOV     CL,3                               ;Floppy Drive 3, (ZFDC Board expects a 0H, 1H, 2H
or 3H)
CALL    S100OUT
MOV     CL,IBM144                          ;1.4M (For MSDOS) DDDS, 18 X 512 Byte Sectors, 80
Tracks. (See ZFDC Board Code for more info)
CALL    S100OUT
CALL    WAIT_FOR_ACK                      ;Return Z (or NZ with error # in [AH])
JNZ    BADZFDC

MOV     CL,CMD_SET_FORMAT                  ;Send Set Disk Format to Drive CMD for drive #2
(360K 5" disk)
CALL    S100OUT
MOV     CL,2                               ;Floppy Drive 2, (ZFDC Board expects a 0H, 1H, 2H
or 3H)
CALL    S100OUT
MOV     CL,MSDOS2                          ;5", IBM PC, MSDOS 2.x, 512 byte, DDDS, 9 sector
format (See ZFDC Board Code for more info)
CALL    S100OUT
CALL    WAIT_FOR_ACK                      ;Return Z (or NZ with error # in [AH])
JNZ    BADZFDC

```



```

MOV     CL,CMD_SET_DRIVE      ;<<< Set Drive Drive DOS A: ZFDC will just return  ✓
if current drive
CALL    S100OUT
MOV     CL,3                  ;Set drive #3 as the current drive
CALL    S100OUT
CALL    WAIT_FOR_ACK         ;Return Z (or NZ with error # in [AH])
JNZ     BADZFDC              ;just abort

PUSH    BX                    ;Return BX unaltered
MOV     AL,0FFH               ;Flag to indicate ZFDC board is setup OK
MOV     [ZFDC_INIT_FLAG],AL   ;Note DS is already set for ROM usage in low RAM  ✓
(400H)
MOV     BX,ZFDC_OK_MSG       ;Announce success
CALL    PRINT_STRING
POP     BX
XOR     AL,AL
RET                                     ;Return Z for all OK

BADZFDC:
PUSH    BX                    ;Return BX unaltered
MOV     AL,0H                 ;Flag to indicate ZFDC board is NOT OK
MOV     [ZFDC_INIT_FLAG],AL   ;Note DS is already set for ROM usage in low RAM  ✓
(400H)
MOV     BX,ZFDC_FAIL_MSG     ;Announce failure
CALL    PRINT_STRING
POP     BX
XOR     AL,AL
DEC     AL
RET                                     ;Return NZ WITH ERROR IN AH

DUMP_TRACK_PARAMS:          ;Dump the Track,Head,Cylinder data to serial debug  ✓
terminal
MOV     CL,CR
CALL    SERIAL_OUT
MOV     CL,LF
CALL    SERIAL_OUT

MOV     CL,'h'
CALL    SERIAL_OUT
MOV     AL,[CURRENT_HEAD]
CALL    SERIAL_AL_HEXOUT

MOV     CL, '.'
CALL    SERIAL_OUT
MOV     CL,'t'
CALL    SERIAL_OUT
MOV     AL,[CURRENT_TRACK]    ;Note DS is already set for ROM usage in low RAM  ✓
(400H)
CALL    SERIAL_AL_HEXOUT

MOV     CL, '.'
CALL    SERIAL_OUT
MOV     CL,'s'
CALL    SERIAL_OUT
MOV     AL,[CURRENT_SECTOR]
CALL    SERIAL_AL_HEXOUT

MOV     CL, ' '
CALL    SERIAL_OUT
MOV     CL,'#'
CALL    SERIAL_OUT
MOV     AL,[SECTORS_TO_DO]
CALL    SERIAL_AL_HEXOUT

```

```

MOV     CL,','
CALL    SERIAL_OUT
MOV     AL,[SECTORS_DONE]
CALL    SERIAL_AL_HEXOUT
MOV     CL,' '
CALL    SERIAL_OUT
MOV     CL,' '
CALL    SERIAL_OUT
RET

```

```

SERIAL_DUMP_RD_SECTOR_DATA:           ;Note this is only for sector reads. ES: is invalid
    for Writes
    PUSH    AX                        ;Show first 8 bytes of sector data on serial output
    (for debugging)
    PUSH    BX
    PUSH    CX
    PUSH    DI
DUMPS1: MOV     CX,16                  ;Show first 16 characters
    MOV     AL,[ES:DI]                ;DI will have the current address
    CALL    SERIAL_AL_HEXOUT
    INC     DI
    LOOP   DUMPS1
    MOV     BX,CR_TAB_MSG              ;CR to next line then tab in 18 spaces (for
multisector reads)
    CALL    SERIAL_PRINT_STRING
    POP     DI
    POP     CX
    POP     BX
    POP     AX
    RET

```

```

SIMPLE_SECTOR_DUMP:                  ;Dump first CX bytes of sector data at ES:BX on CRT
    PUSH    DS

    PUSH    BX
    PUSH    CX

    PUSH    BX
    PUSH    CX

    XOR     AX,AX                      ;Set DS to data area for ROM usage in low RAM @
    400H....)
    MOV     DS,AX

    MOV     BX,SEQAT500                ;"First [CX] bytes of loaded Sector (@ES:BX) Head =
"
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_HEAD]
    CALL    AL_HEXOUT

    MOV     BX,TRACK_MSG                ;"H Track ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_TRACK]
    CALL    AL_HEXOUT

    MOV     BX,SEC_MSG                  ;"H Sector ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_SECTOR]
    CALL    AL_HEXOUT
    MOV     BX,START_DATA_MSG          ;"H Start of Data = CR,LF"
    CALL    PRINT_STRING

    POP     CX                          ;From above
    POP     BX

```

```

ONE_LINE_SECTOR1:
    MOV     AX, [ES:BX]           ;High byte/low byte order
    PUSH   AX
    CALL   AL_HEXOUT
    POP    AX
    MOV    AL, AH
    CALL   AL_HEXOUT
    INC    BX
    INC    BX
    LOOP   ONE_LINE_SECTOR1

    CALL   CRLF
    POP    CX                     ;Again from above
    POP    BX

SECTOR_DUMP1:
    PUSH   CX
    MOV    CL, [ES:BX]           ;High byte/low byte order
    and    cl, 7fh
    cmp    cl, ' '                ;filter out control characters
    jnc    xloop3
xloop4:  mov    cl, '.'
xloop3:  cmp    cl, '~'
    jnc    xloop4
    CALL   CO
    INC    BX                     ;Next character
    POP    CX
    LOOP   SECTOR_DUMP1
    CALL   CRLF
    POP    DS                     ;Balance up stack
    RET

S100STAT:                          ;Check if ZFDC has any data for S-100 system
    IN     AL, S100STATUSB
    TEST   AL, 01H                ;Anything there ?
    JZ     S100ST1                ;Return 0 if nothing
    XOR    AL, AL
    DEC    AL                     ;Return NZ, & 0FFH in AL if something there
S100ST1:RET

S100IN:  IN     AL, S100STATUSB    ;Check if ZFDC has any data for S-100 system
    TEST   AL, 80H                ;Is ZFDC in input mode, if not, wait
    JZ     S100IN                ;If low then ZFDC board is still in input mode,
    wait
    TEST   AL, 01H
    JZ     S100IN
    IN     AL, S100DATAA          ;return with character in AL
    RET

S100OUT:IN     AL, S100STATUSB    ;Send data to ZFDC output (arrive with character to
    be sent in C)
    TEST   AL, 80H                ;Is ZFDC in output mode, if not wait
    JNZ    S100OUT
    TEST   AL, 02H                ;Has previous (if any) character been read.
    JZ     S100OUT                ;Z if not yet ready
    MOV    AL, CL
    OUT    S100DATAB, AL
    RET

WAIT_FOR_ACK:                       ;Delay to wait for ZFDC to return data. There is a
    timeout of about 2 sec.

```

```

        PUSH    BX                ;This can be increased if you are displaying
        debugging info on the ZFDC
        PUSH    DX                ;HEX LED display.
        MOV     BX,0
        MOV     DL,STATUSDELAY    ;Timeout, (about 2 seconds)
XWAIT1: IN     AL,S100STATUSB     ;Check if ZFDC has any data for S-100 system
        TEST   AL,80H            ;Is ZFDC in input mode
        JZ     XWAIT2            ;if low then ZFDC is still in input mode
        CALL   S100STAT          ;Wait until ZFDC Board sends something
        JZ     XWAIT2
        CALL   S100IN            ;Get returned Error # (Note this releases the
        SENDDATA routine on the ZFDC board)
        MOV    AH,AL             ;<<< Store Error Code (if any) in AH
        CMP    AL,NO_ERRORS_FLAG ;Was SENDOK/NOERRORSFLAG sent back from ZFDC Board
        POP    DX                ;Balance up stack
        POP    BX
        RET                     ;Return NZ if problem, Z if no problem

XWAIT2: DEC    BH
        JNZ    XWAIT1            ;Try for ~2 seconds
        DEC    BH
        DEC    BL
        JNZ    XWAIT1
        DEC    BH
        DEC    BL
        DEC    DL
        JNZ    XWAIT1
        XOR    AL,AL
        DEC    AL
        MOV    AH,3FH            ;Flag as local Time out error
        POP    DX                ;Balance up stack
        POP    BX
        RET                     ;Return NZ flag set if timeout & 0FFH in [AL]
                                ;Error code in AH

; Adjust DMASEG:DMAOFF via [ES:DI] so that the in DI is the
; smallest possible. This process is called normalization.
; Registers: Only ES and DI altered

DMA_ADJUST:
        MOV    ES,[DMA_SEGMENT]
        MOV    DI,[DMA_OFFSET]

        PUSH   AX
        PUSH   DI
        SHR    DI,1              ; Get paragraph to low 12 bits
        SHR    DI,1              ; Shift 0's in at hi 4 bits
        SHR    DI,1
        SHR    DI,1
        MOV    AX,ES              ; Get segment to Bx
        ADD    AX,DI              ; Add in segment skew
        MOV    ES,AX              ; Restore dma segment
        POP    DI                 ; Get back original offset
        AND    DI,0FH            ; Only need within paragraph

        MOV    [DMA_SEGMENT],ES
        MOV    [DMA_OFFSET],DI   ;<<< Later use LES (or for Sec Write LDS)
        POP    AX
        RET

;*****
;

```

```

;      Non Maskable Interrupt Handler (for IBM-PC is int #2, or 08H in RAM)
;
;*****
NMI_hnd:                                ;Non Maskable Interrupt Handler (Note uses current
stack!)                                ;Should not get here. If so send warning and
PUSHF                                  ;*****
continue
PUSH  AX
PUSH  BX
MOV   BX,NMI_MSG                       ;Announce we got an NMI Interrupt
CALL  PRINT_STRING                     ;Note PRINT_STRING always uses the CS: override for
the BX pointer
POP   BX
POP   AX
POPF                                     ;Note NMI does not push the flags on to the stack
IRET

;*****
;
;      Print Screen Software Interrupt Handler (14H in RAM)
;
;*****
PrintScrTest:                          ;Test interrupt from Monitor Menu
MOV   BX,PSCR_TEST_MSG                 ;Announce we are goint to print the screen
CALL  PRINT_STRING                     ;Note PRINT_STRING always uses the CS: override for
the BX pointer

MOV   AX,0001H                         ;AH = 01h Initilize Printer
MOV   DX,0                             ;DX = printer number (00h-02h)
INT   17H                              ;Printer Int

PUSH  ES                               ;Used for INT 10H Write String
PUSH  BP
PUSH  DS                               ;Need DS=0
XOR   AX,AX                            ;Set DS to data area for ROM usage in low RAM @
400H....)
MOV   DS,AX
MOV   AX,word [CONSOL_FLAG]            ;Save current Console Output device flag
PUSH  AX
MOV   word[CONSOL_FLAG],1              ;Set (temporly) Console Output device flag to CGA/
VGA

MOV   AX,CS
MOV   ES,AX
MOV   BP,PSCR_TEST_MSG                 ;ES:BP = string pointer for INT 10H
MOV   CX,PSCR_TEST_LEN                 ;CX = string length
MOV   AH,13H                           ;AH = 0EH, String Output mode
MOV   AL,1                             ;Update cursor, no attribute
MOV   BH,0                             ;Page 0
MOV   BL,02                            ;Attribute B/W
MOV   DX,0                             ;0,0
INT   10H

INT   5H                               ;Call the Print Screen Interrupt routine below

MOV   AX,000CH                         ;AH = 00h PRINTER - WRITE CHARACTER, AL=0CH, Flush
printer buffer
MOV   DX,0                             ;DX = printer number (00h-02h)
INT   17H                              ;Printer Int

POP   AX                               ;Get back saved current Console Output device flag
MOV   [CONSOL_FLAG],AX                 ;DS still = 0
POP   DS
POP   BP

```

```

        POP     ES
        RET

PrintScreenRoutine:                ;In PC BIOS is at 0FF54H
        STI                     ;Can allow further interrupts
        push   ds
        push   ax
        push   bx
        push   cx
        push   dx
        xor    ax,ax
        mov    ds,ax
        cmp    byte[STATUS_BYTE],1    ;are we already here
        jz     pexit
        CMP    word [CONSOL_FLAG],0    ;Skip if current Console is Propeller board (0)
        JZ     pexit

        mov    Byte [STATUS_BYTE],byte 1
        MOV    AH,15                ;request current screen mode
        INT    10H                  ;AL=mode, AH=columns,BH=page

        mov    cl,ah
        mov    ch,25                ;CX= row & columns count
        call   pcrLf

        push   cx
        mov    ah,3                ;Get current cursor position

        int    10H

        pop    cx
        push   dx                    ;Save cursor position to DX
        xor    dx,dx                ;to position 0,0

pri10:  mov    ah,2                ;Directly from IBM ROM BIOS
        int    10h                ;set cursor
        mov    ah,8
        int    10h                ;read character
        or     al,al                ;valid character?
        jnz   pri15
        mov    al,' '

pri15:  push   dx
        xor    dx,dx
        xor    ah,ah
        int    17H                ;print character
        pop    dx
        test   ah,25h              ;check for error
        jnz   err10
        inc   dl
        cmp    cl,dl
        jnz   pri10                ;next character
        xor    dl,dl                ;to col 0
        mov    ah,dl
        push   dx
        call   pcrLf
        pop    dx
        inc   dh
        cmp    ch,dh                ;all lines done?
        jnz   pri10

pri20:  pop    dx                    ;Done, recall cursor position
        mov    ah,2
        int    10h
        mov    byte[STATUS_BYTE],0
        jmp    pexit

```

```

err10:  pop    dx
        mov    ah,2
        int    10H                ;Restore cursor position

err20:  mov    byte[STATUS_BYTE],0FFH ;Flag error
pexit:  pop    dx
        pop    cx
        pop    bx
        pop    ax
        pop    ds
        IRET                ;Note IRET

pcrlf:  xor    dx,dx
        xor    ah,ah
        mov    al,LF
        int    17H
        XOR    ah,ah
        mov    al,CR
        int    17H
        ret

;*****
;
;   Keypressed Handler           (for IBM-PC is int #9 via 8259A to 24H in RAM)
;
;   IRQ1 - KEYBOARD DATA READY
;   This interrupt is generated when data is received from the keyboard. This
is normally
;   a scan code (from either a keypress OR a key release), but may also be an
ACK or NAK
;   of a command on AT-class keyboards. (Note My Propeller Board translates the
scan codes ASCII chars)
;
;   Note: This IRQ may be masked by setting bit 1 on the 8259A I/O port 21h.
;
;   If the BIOS supports an enhanced (101/102-key)keyboard, it calls INT 15/AH=
4Fh after reading the
;   scan code from the keyboard and before further processing all further
processing uses the scan code
;   returned from INT 15/AH=4Fh. (This is not done here)
;
;   The default interrupt handler is at F000h:E987h in 100%-compatible BIOSes.
The interrupt handler performs
;   the following actions for certain special keystrokes:-
;
;   Ctrl-Break clear keyboard buffer, place word 0000h in buffer, invokes INT
1B, and sets flag at 0040h:0071h
;   SysReq invokes INT 15/AH=85h (SysReq is often labeled SysRq)
;   Ctrl-Numlock place system in a tight wait loop until next INT 09
;   <<<<<< None of the above "extra" items are yet implemented >>>>>>
;
;   Shift-PrtSc invokes INT 05 (This is now implemented here).
;   Ctrl-Alt-Del jump to BIOS startup code (either F000h:FFF0h or the
destination of the jump at that address)
;   Pause & Ctrl-Num_Lock will halt Console Output until the next keyboard
input
;
;
;*****

keyhnd: push    ax                ;This interrupt can strike any time, so save all

```

```

    push    ds
    push    bx
    XOR     AX,AX                ;Set DS to data area for ROM usage in low RAM @
    400H....)
    MOV     DS,AX

    in      al,KEYIN            ;Get KEYBOARD DATA
    CMP     AL,1CH              ;Propeller Board will return 1CH for a "Print
    Screen" key press
    JNZ     NO_PRN_SCR
    mov     al,NS_EOI           ;End the current interrupt
    OUT     MASTER_PIC_PORT,al

    INT     5H                  ;Activate software Print Screen Interrupt

    MOV     AX,000CH            ;AH = 00h PRINTER - WRITE CHARACTER, AL=0Ch, Flush
    printer buffer
    MOV     DX,0                ;DX = printer number (00h-02h)
    INT     17H                 ;Printer Int
    POP     BX
    JMP     K27                  ;Finish up

NO_PRN_SCR:
    CMP     AL,1DH              ;Propeller Board will return 1DH for "Ctrl+Alt+Del"
    key press
    JNZ     NO_CAD_SCR
    mov     al,NS_EOI           ;End the current interrupt
    OUT     MASTER_PIC_PORT,al
    JMP     word 0F000H:0FFF0H   ;Far Jump to F000H:FFF0H ;To Reset the CPU address

NO_CAD_SCR:
    CMP     AL,1EH              ;Propeller Board will return 1EH for "Pause
    " key press
    JNZ     NO_PAUSE_SCR
    OR      byte[KB_FLAG_1],HOLD_STATE ;Set flag to indicate a Pause is required
    mov     al,NS_EOI           ;End the current interrupt
    OUT     MASTER_PIC_PORT,al
    POP     BX
    pop     ds
    pop     ax
    IRET

NO_PAUSE_SCR:
    AND     byte[KB_FLAG_1],NO_HOLD_STATE ;Set flag to indicate a NO PAUSE is
    required
    and     al,7fh              ;strip parity bit (if any)
    mov     bl,[chrcnt]         ;get current character count
    cmp     bl,chrmax           ;is the buffer full?
    jge     keyxt               ;ignore if buffer full
    inc     bl
    mov     [chrcnt],bl         ;store new character count
    mov     bx,[buft1]          ;get destination address
    mov     [bx],al             ;store the character
    inc     bx                  ;bump buffer address
    cmp     bx,keybuff+32       ;at end of buffer?
    jl     keyhnl               ;skip if not
    mov     bx,keybuff          ;reset to start of buffer
keyhnl:  mov     [buft1],bx      ;store adr for next character
keyxt:   pop     bx
    mov     al,NS_EOI
    OUT     MASTER_PIC_PORT,al

K27:    pop     ds
    pop     ax
    iret

```



```

;*****
;
;   Timer Handler           (for IBM-PC is int #8 via 8259A to 20H in RAM)
;   IRQ0 - SYSTEM TIMER
;   On a PC this is generated 18.2 times per second by channel 0 of the 8254
;   system timer.
;   This interrupt is used to keep the time-of-day clock updated. It can strike
;   any time in a program!
;
;*****
;Note: The IBM PC clock interrupts at
;1193180/65536 counts/sec (Approx 18.2 per second).
;Our clock interrupts at ~60 hz so adjust to
approximate
must be
kept by PC-DOS.
;the IBM clock, the time constants in this routine
;adjusted accordingly if accurate time is to be
timer:  push  ax                ;This interrupt can strike any time, so save all
        (flags are already saved)
        push  ds
        XOR   AX,AX           ;Set DS to data area for ROM usage in low RAM @
        MOV   DS,AX          400H....)
        inc   word [timlow]   ;Bump count
        jnz   timer1
        inc   word [timhi]   ;Bump high part of count
timer1: cmp   word [timhi],18h ;End of a day?
        jnz   timer2        ;24 hours at 3600 sec/hr
        cmp   word [timlow],0b0h ;and 1193180/65536 tics/sec
        jnz   timer2        ;= 1573040 tics (1800B0 hex)
        sub   ax,ax          ;0 to AX
        mov   [timlow],ax
        mov   [timhi],ax
        mov   byte[timofl],1
timer2: INT    1CH           ;Go to user timer int at 1CH, IRET when done <<<<
        (Currently just a return)
        sti
        mov   al,NS_EOI      ;End with Send_EOI
        OUT  MASTER_PIC_PORT,al
        pop  ds
        pop  ax
        iret                ;IRET will return flags
Send_EOI:
        PUSH AX
        mov  al,NS_EOI
        OUT  MASTER_PIC_PORT,al
        POP  AX
dummy_return:
        iret                ;Remember IRET will pop the flags
;*****
;
;   Time of Day Handler     (For IBM-PC Software Interrupt 1AH)
;

```

```

;Input  AH = 00h          TIME - GET SYSTEM TIME
;Return: CX:DX = number of clock ticks since midnight
;        AL = midnight flag, nonzero if midnight passed since time last read
;
;
;Input  AH = 01h          TIME - SET SYSTEM TIME
;        CX:DX = number of clock ticks since midnight
;Return: Nothing
;
;
;Input:  AH = 02h          TIME - GET REAL-TIME CLOCK TIME (AT, XT286, PS)
;        CF clear to avoid a bug
;Return: CF clear if successful
;        CH = hour (BCD)
;        CL = minutes (BCD)
;        DH = seconds (BCD)
;        DL = daylight savings flag (00h standard time, 01h daylight time)
;        CF set on error (i.e. clock not running or in middle of update)
;
;
;Input:  AH = 03h          TIME - SET REAL-TIME CLOCK TIME (AT, XT286, PS)
;        CH = hour (BCD)
;        CL = minutes (BCD)
;        DH = seconds (BCD)
;        DL = daylight savings flag (00h standard time, 01h daylight time)
;Return: Nothing
;
;
;Input:  AH = 04h          TIME - GET RTC DATE (AT, XT286, PS)
;        CH = century (BCD)
;        CL = year (BCD)
;        DH = month (BCD)
;        DL = day (BCD)
;        CF clear if OK
;
;
;Return: CF clear if successful
;        CH = century (BCD)
;        CL = year (BCD)
;        DH = month (BCD)
;        DL = day (BCD)
;        CF set on error
;
;
;Input:  AH = 05h          TIME - SET REAL-TIME CLOCK DATE (AT, XT286, PS)
;        CH = century (BCD)
;        CL = year (BCD)
;        DH = month (BCD)
;        DL = day (BCD)
;Return: Nothing
;
;*****
;        ***
time_of_day:
    sti
    push    ds
    PUSH   AX
    XOR    AX,AX                ;Set DS to data area for ROM usage in low RAM @
    MOV    DS,AX
    POP    AX

    CMP    byte [DEBUG_FLAG],0    ;Is Debug mode on
    JZ     Xtime_of_day
    CMP    AH,00H                ;Skip simple Get System Time

```

```

    JZ     Xtime_of_day
    PUSH  AX
    PUSH  BX
    PUSH  CX
    MOV   BX,INT_1AH_MSG           ;"Int 1AH (Time) AX="
    CALL  SERIAL_PRINT_STRING
    POP   CX
    POP   BX
    POP   AX
    CALL  SERIAL_DISPLAY_REGISTERS ;Display Registers on serial port display ✓
    (All registers retained)

Xtime_of_day:
    TEST  AH,AH                   ;AH=0 read system tick time?
    JZ    READ_TICKS              ;go do it if so
    CMP   AH,1                    ;AH = 1 set tick time?
    JZ    SET_TICKS
    CMP   AH,2                    ;AH = 2 Get RTC Time?
    JZ    READ_RTC_TIME
    CMP   AH,4                    ;AH = 4 Get RTC Date?
    JZ    READ_RTC_DATE
    JMP   TIME_DONE

READ_TICKS:                       ;Read the system tick time
    cli
    mov   al,[timofl]
    mov   byte [timofl],0
    mov   cx,[timhi]
    mov   dx,[timlow]
    sti
    pop   ds
    iret

SET_TICKS:                         ;Set the system tick time
    cli                             ;no interrupts while we set it
    mov   [timlow],dx
    mov   [timhi],cx
    mov   byte [timofl],0
    sti                             ;interrupts ok now

TIME_DONE:
    pop   ds
    iret

                                ;AH = 2H, Read CMOS RTC Time
                                ;CH = hour (BCD, CL = minutes (BCD), DH = seconds ✓
                                (BCD), DL = daylight savings flag (00h standard time, 01h daylight time)
READ_RTC_TIME:                   ;CF set on error (i.e. clock not running or in ✓
    middle of update)
    CALL  LOAD_TIME
    POP   ds                       ;Get back the original saved DS at start
    retf  2                         ;Remove the original status flags on return ✓
    (remember we got here via an INT)

                                ;AH = 4H, Read CMOS RTC
                                ;CH = century (BCD), CL = year (BCD), DH = month ✓
                                (BCD), DL = day (BCD)
READ_RTC_DATE:                   ;CF set on error
    CALL  LOAD_DATE
    POP   ds                       ;Get back the original saved DS at start
    retf  2                         ;Remove the original status flags on return ✓
    (remember we got here via an INT)

;----- Routines to set flag for Consol Output to Propeller or Lava Video board

```

```

SET_CO_FLAG:
  MOV     BX,VIDIO_OUTPUT_MSG      ;Video Board XY positioning etc tests. Enter AX  ✓
  Value
  CALL    PRINT_STRING
  CALL    CICO                      ;1st Console input digit to AL
  PUSH    DS
  PUSH    BX
  PUSH    AX
  CALL    CRLF
  POP     AX
  XOR     BX,BX                      ;Set DS to data area for ROM usage in low RAM @  ✓
  400H....)
  MOV     DS,BX
  CMP     AL,'0'
  JZ      CRT_TO_PROPELLER
  CMP     AL,'2'
  JZ      CRT_TO_LAVA
  CMP     AL,'1'
  JZ      CRT_TO_VGA
  MOV     BX,INT10_ERR_MSG          ;Invalid Selection
  CMP     AL,ESC
  JNZ     SET_CRT_DONE
  POP     BX
  POP     DS
  RET

CRT_TO_PROPELLER:
  MOV     word[CONSOL_FLAG],0        ;Console output Propeller Video Board
  MOV     BX,VIDIO_PROP_MSG
  CALL    SPEAK_STRING              ;Speak out the message
  MOV     BX,VIDIO_PROP_SMSG         ;Video to PROPELLER
  JMP     SET_CRT_DONE

CRT_TO_LAVA:
  MOV     word[CONSOL_FLAG],2        ;Console output to LAVA Video Board
  CALL    INITILIZE_LAVA            ;Clear Screen, Green/Black Cursor 0,0
  MOV     BX,VIDIO_LAVA_SMSG
  CALL    SPEAK_STRING              ;Speak out the message
  MOV     BX,VIDIO_LAVA_MSG         ;Video to LAVA
  JMP     SET_CRT_DONE

CRT_TO_VGA:
  MOV     word[CONSOL_FLAG],1        ;Console output to CGA/VGA Video Board
  MOV     BX,VIDIO_VGA_SMSG
  CALL    SPEAK_STRING              ;Speak out the message
  MOV     BX,VIDIO_VGA_MSG         ;Video to VGA
  JMP     SET_CRT_DONE

SET_CRT_DONE:
  CALL    PRINT_STRING
  POP     BX
  POP     DS
  RET

;----- Routines to test Video Board Int 10H Functions out using this IBM PC BIOS  ✓
; section
; The value of AH, CX, etc are used to control the positioning of characters on ✓
; then CRT see below

XY_VIDEO:
  MOV     BX,VIDIO_TEST_MSG          ;Video Board XY positioning etc tests. Enter AX  ✓
  Value
  CALL    PRINT_STRING
  CALL    GET4DIGITS
  PUSH    DI                          ;AX value in DI
  MOV     BX,ENTER_BX_MSG           ;Enter BX Value

```



```

        JZ      READ_WORD_TEST      ;must be 0-3
        cmp    al,'2'              ;Find meuu option from table
        JZ      WRITE_BYTE_TEST    ;must be 0-3
        cmp    al,'3'              ;Find meuu option from table
        JZ      WRITE_WORD_TEST    ;must be 0-3
        JMP    RAM_RD_WR_TESTS

;Loop to analyze hardware RAM Read signals
READ_BYTE_TEST:
        MOV    BX, BYTE_RTEST_MSG  ;Get RAM location Enter AX Value
        CALL  PRINT_STRING
        CALL  GET5DIGITS           ;Will return ES=000xH, DI = xxxxH
        PUSH  ES
        PUSH  DI
        MOV    BX, TEST_RUNNING_MSG ;"Test Running, hit reset to stop"
        CALL  PRINT_STRING
        POP   DI
        POP   ES
BRTEST: MOV    AL, [ES:DI]
        JMP   BRTEST

READ_WORD_TEST:
        MOV    BX, WORD_RTEST_MSG  ;Get RAM location Enter AX Value
        CALL  PRINT_STRING
        CALL  GET5DIGITS           ;Will return ES=000xH, DI = xxxxH
        PUSH  ES
        PUSH  DI
        MOV    BX, TEST_RUNNING_MSG ;"Test Running, hit reset to stop"
        CALL  PRINT_STRING
        POP   DI
        POP   ES
WRTEST: MOV    AX, [ES:DI]
        JMP   WRTEST              ;Note CPU will not return from this loop. Reset
        required                  ↙

;Loop to analyze hardware RAM Write signals
WRITE_BYTE_TEST:
        MOV    BX, BYTE_WTEST_MSG  ;Get RAM location Enter AX Value
        CALL  PRINT_STRING
        CALL  GET5DIGITS           ;Will return ES=000xH, DI = xxxxH
        PUSH  ES
        PUSH  DI
        MOV    BX, TEST_RUNNING_MSG ;"Test Running, hit reset to stop"
        CALL  PRINT_STRING
        POP   DI
        POP   ES
BWTEST: MOV    [ES:DI], AL
        JMP   BWTEST

WRITE_WORD_TEST:
        MOV    BX, WORD_WTEST_MSG  ;Get RAM location Enter AX Value
        CALL  PRINT_STRING
        CALL  GET5DIGITS           ;Will return ES=000xH, DI = xxxxH
        PUSH  ES
        PUSH  DI
        MOV    BX, TEST_RUNNING_MSG ;"Test Running, hit reset to stop"
        CALL  PRINT_STRING
        POP   DI
        POP   ES
        MOV    AX, 5555H
WWTEST: MOV    [ES:DI], AX
        JMP   WWTEST              ;Note CPU will not return from this loop. Reset
        required                  ↙

```

```
*****
;XXXXX:
;   Video Output Handler      (Software Int# 10H)
;   Will recognize the following settings:-
;
;Input: AH = 00h          VIDEO - SET VIDEO PARAMATERS
;       AL = Display Mode
;
;Input: AH = 01h          VIDEO - SET TEXT-MODE CURSOR SHAPE
;       CH = cursor start and options (see below)
;       CL = bottom scan line containing cursor (bits 0-4)
;           Bitfields for cursor start and options:
;           7          should be zero
;           6,5       cursor blink.
;                   (00=normal, 01=invisible, 10=erratic, 11=slow).
;                   (00=normal, other=invisible on EGA/VGA)
;           4-0       topmost scan line containing cursor
;Return:Nothing
;
;Input: AH = 02h          VIDEO - SET CURSOR POSITION
;       BH = page number (0-3 in modes 2&3. 0-7 in modes 0&1. 0 in graphics modes)
;       DH = row (00h is top)
;       DL = column (00h is left)
;Return:Nothing
;
;Input: AH = 03h          VIDEO - GET CURSOR POSITION AND SIZE
;       BH = page number (0-3 in modes 2&3. 0-7 in modes 0&1. 0 in graphics modes)
;Return:AX = 0000h        (Phoenix BIOS - only)
;       CH = start scan line of cursor
;       CL = end scan line of cursor
;       DH = row (00h is top)
;       DL = column (00h is left)
;
;Input: AH = 05h          VIDEO - SET PAGE
;       BH = page number (0-3 in modes 2&3. 0-7 in modes 0&1. 0 in graphics modes)
;
;Input: AH = 06h          VIDEO - SCROLL UP WINDOW
;       AL = number of lines by which to scroll up (00h = clear entire window)
;       BH = attribute used to write blank lines at bottom of window
;       CH,CL = row,column of window's upper left corner
;       DH,DL = row,column of window's lower right corner
;Return:Nothing
;
;Input: AH = 07h          VIDEO - SCROLL DOWN WINDOW
;       AL = number of lines by which to scroll down (00h=clear entire window)
;       BH = attribute used to write blank lines at top of window
;       CH,CL = row,column of window's upper left corner
;       DH,DL = row,column of window's lower right corner
;Return:Nothing
;
;Input:AH = 08h VIDEO - READ CHARACTER AND ATTRIBUTE AT CURSOR POSITION
;       BH = page number (00h to number of pages - 1) (see #00010)
;Return:   AH = character's attribute (text mode only)
;       AL = character
;
;Input: AH = 09h          VIDEO - WRITE CHARACTER AND ATTRIBUTE AT CURSOR POSITION
;       AL = character to display
;       BH = page number (00h to number of pages - 1)
;       BL = attribute (text mode) or color (graphics mode)
;           if bit 7 set in <256-color graphics mode, character is XOR'ed onto screen
;       CX = number of times to write character
;Return:Nothing
```

```

;Input: AH = 0Ah          VIDEO - WRITE CHARACTER ONLY AT CURSOR POSITION
;      AL = character to display
;      BH = page number (00h to number of pages - 1)
;      BL = attribute color (graphics mode)
;          if bit 7 set in <256-color graphics mode, character is XOR'ed onto screen
;      CX = number of times to write character
;Return:Nothing
;
;
;
;Input: AH = 0Eh          VIDEO - TELETYPE OUTPUT
;      AL = character to write
;      BH = page number
;      BL = foreground color (graphics modes only)
;Return:Nothing
;
;
;Input: AH = 0Fh          VIDEO - GET VIDEO PARAMATERS
;Return:
;      AH = Number of CRT Columns
;      AL = Display Mode
;      BH = Current page
;
;*****

```

VIDEO_TABLE:

DW	SET_MODE	;<--0	Set Mode	
DW	VIDEO_TBD	;1	Set Cursor Type	
DW	SET_CURSOR_POS	;<--2	Set Cursor Positriion	
DW	GET_CURSOR_POS	;<--3	Get Cursor Position	
DW	VIDEO_TBD	;4	Read Light Pen	
DW	SET_PAGE	;<--5	Set page	
DW	SCROLL_UP	;<--6	Scroll up [AL] lines	
DW	SCROLL_DOWN	;<--7	Scroll down [AL] lines	
DW	READ_CHAR_ATT	;<--8	Read Char & Attribute at cursor position	
DW	WRITE_AT_CURSOR_ATT	;<--9	Write character & attribute at current	↙
	cursor position			
DW	WRITE_AT_CURSOR	;<--0AH	Write character at current cursor position	
DW	VIDEO_TBD	;0BH	Set Color	
DW	VIDEO_TBD	;0cH	Write Dot	
DW	VIDEO_TBD	;0dH	Read Dot	
DW	VIDEO_TTY	;<--0EH	***** Simple TTY mode *****	
DW	GET_VIDEO_PARMS	;<--0FH	Get Video state	
DW	VIDEO_TBD	;10H	reserved	
DW	VIDEO_TBD	;11H	reserved	
DW	VIDEO_VGA	;12H	VIDEO - ALTERNATE FUNCTION SELECT (VGA,	↙
MCGA) - VIDEO ADDRESSING				
DW	WRITE_STRING	;13H	Write String	

M1L equ \$-VIDEO_TABLE

```

CONOUT: STI ;For now just dump character on Propeller Console ↙
         IO board
         CLD ;This section of code will very carefully reproduce↙
           everything
         PUSH ES ;that is in the IBM-PC BIOS ROM
         PUSH DS
         PUSH DX
         PUSH CX
         PUSH BX
         PUSH SI
         PUSH DI
         PUSH BP ;New for AT BIOS
         PUSH AX ;<<< Save character (in AH) on stack >>>
         PUSH AX ;Note extra AX on stack for VIDEO_NOT_FINISHED etc ↙

```



```

routines below

PUSH    AX                ;Need for Debugging output below
XOR     AX,AX            ;Set DS to data area for ROM usage in low RAM @
400H....)
MOV     DS,AX
POP     AX

MOV     [ES_STORE],ES    ;Save for AH=13H String write (Normally ES is used
for the Video RAM pointer)

CMP     AH,0EH           ;Skip simple TTYOut debugging (too much data)
JZ     SKIP_VIDEO_DEBUG

CMP     byte [DEBUG_FLAG],0 ;Is Debug mode on
JNZ    SHOW_DEBUG_DATA  ;If NZ, then debug mode

PUSH    AX
IN      AL,IOBYTE       ;If bit 3 of Port EFH is 0, Then force Debug
Display
AND     AL,08H
POP     AX
JNZ    SKIP_VIDEO_DEBUG

SHOW_DEBUG_DATA:
PUSH    AX
PUSH    BX
MOV     BX,INT_10H_MSG   ;"Int 1AH (VIDEO) AX="
CALL    SERIAL_PRINT_STRING
POP     BX
POP     AX
CALL    SERIAL_DISPLAY_REGISTERS ;Display Registers on serial port display (All
registers retained)

SKIP_VIDEO_DEBUG:
;Use a lookup table to locate the correct AH option
MOV     AL,AH
XOR     AH,AH            ;0 to AH
SAL     AX,1            ;X2 for table lookup
MOV     SI,AX
CMP     AX,M1L          ;Check we are within range
JB     VIDEO_AH_OK

PUSH    BX                ;Out of range request
MOV     BX,INT_10H_MSG   ;"Int 1AH (VIDEO) AX="
CALL    SERIAL_PRINT_STRING
POP     BX
CALL    SERIAL_DISPLAY_REGISTERS ;Display Registers on serial port display (All
registers retained)
POP     AX                ;Currently there are 2 AX's on stack
JMP     VIDEO_RETURN

VIDEO_AH_OK:
MOV     AX,0B800H        ;Segment of CGA Board RAM
mov     di,[EQFLAG]
and     di,30h          ;isolate crt switches
cmp     di,30h
jne     MX3
mov     ax,0B000h        ;segment for B/W card
MX3:   mov     es,ax      ;Set ES: to point to video area
POP     AX                ;<--- Get requested AH & AL values
MOV     AH,[CRT_MODE]    ;Current mode now in AH (used by CGA/VGA video
board)

JMP     [CS:SI+VIDEO_TABLE] ;go to appropriate routine with card type in DI
;mode in AH, video ram in ES and value in AL.

```

```

;-----
SET_MODE:                                ;AH = 0h, AL= Mode      VIDEO - GET VIDEO PRAMATERS
CMP    word [CONSOL_FLAG],0             ;Send output to Propeller board (0), VGA Video  ✓
board (1), or LAVA Board (2)
JZ     PROPELLER_SET_MODE
CMP    word [CONSOL_FLAG],2
JZ     LAVA_SET_MODE
JMP    VGA_SET_MODE                      ;Set the display mode of the CGA/VGA Board

PROPELLER_SET_MODE:
MOV    AX,0003H
JMP    VIDEO_RETURN

LAVA_SET_MODE:                           ;LAVA has one mode only
CALL   INITILIZE_LAVA                   ;Clear Screen, Green/Black, Cursor 0,0
MOV    AX,0003H
JMP    VIDEO_RETURN

;-----
SET_CURSOR_POS:                          ;AH = 02h      VIDEO - SET CURSOR POSITION
CMP    word [CONSOL_FLAG],0             ;DH = row (00h is top), DL = column (00h is left)
(1), or LAVA Board (2)                 ;Send output to Propeller board (0),VGA Video board ✓
JZ     PROPELLER_SET_CURSOR_POS
CMP    word [CONSOL_FLAG],2
JZ     LAVA_SET_CURSOR_POS
JMP    VGA_SET_CURSOR_POS

PROPELLER_SET_CURSOR_POS:
CALL   PROPELLER_SET_CURSOR             ;Set Cursor at [DX] on Propeller Board
JMP    VIDEO_RETURN

LAVA_SET_CURSOR_POS:                     ;Set Cursor at [DX] on LAVA Board
CALL   L_HIDE_CURSOR                   ;DX is unchanged
CALL   L_SET_CURSOR
JMP    VIDEO_RETURN

;-----
SIZE                                     ;AH = 03h      VIDEO - GET CURSOR POSITION AND  ✓
GET_CURSOR_POS:                          ;DH = row (00h is top), DL = column (00h is left)
CMP    word [CONSOL_FLAG],0             ;Send output to Propeller board (0), or Video board ✓
(1), or LAVA Board (2)
JZ     PROPELLER_GET_CURSOR_POS
CMP    word [CONSOL_FLAG],2
JZ     LAVA_GET_CURSOR_POS
JMP    VGA_GET_CURSOR_POS

PROPELLER_GET_CURSOR_POS:
JMP    VIDEO_NOT_FINISHED              ;<<<< Ignore for now

LAVA_GET_CURSOR_POS:
CALL   L_GET_CURSOR
JMP    VIDEO_RETURN

;-----
SET_PAGE:                                 ;AH = 05h      VIDEO - SET PAGE
&1. 0 in graphics modes)              ;BH = page number (0-3 in modes 2&3. 0-7 in modes 0 ✓
CMP    word [CONSOL_FLAG],0             ;Send output to Propeller board (0), or Video board ✓
(1), or LAVA Board (2)
JZ     PROPELLER_SET_PAGE
CMP    word [CONSOL_FLAG],2
JZ     LAVA_SET_PAGE
JMP    VGA_SET_PAGE

PROPELLER_SET_PAGE:
MOV    BH,0                             ;Always
JMP    VIDEO_RETURN

LAVA_SET_PAGE:

```

```

MOV     BH,0                ;<<<<< Ignore for now (Add 0 & 1 later)
JMP     VIDEO_RETURN

;-----
SCROOL_UP:
clear entire window)
CMP     word [CONSOL_FLAG],0 ;Send output to Propeller board (0), or Video board
(1), or LAVA Board (2)
JZ     PROPELLER_SCROLL_UP
CMP     word [CONSOL_FLAG],2
JZ     LAVA_SCROLL_UP
JMP     VGA_SCROLL_UP
PROPELLER_SCROLL_UP:
OR     CX,CX                ;Start 0,0?, (CH,CL = row,column start, DH,DL = row
,column end)
JZ     SCROLL_UP_0
PUSH   AX
PUSH   DX
MOV     DX,CX              ;At least we will reposition cursor to 0,0
CALL   PROPELLER_SET_CURSOR ;Set Cursor at [DX]
POP     DX
POP     AX
JMP     VIDEO_NOT_FINISHED ;Will ignore DX for now
SCROLL_UP_0:
OR     AL,AL                ;AL has number of lines to scroll
JNZ   SCROLL_UP_1
MOV     AL,40                ;0 for current 40 line CRT
SCROLL_UP_1:
PUSH   AX
MOV     AH,ESC
CALL   FAST_CONOUT
MOV     AH,'D'
CALL   FAST_CONOUT
POP     AX
DEC     AL
JNZ   SCROLL_UP_1
JMP     VIDEO_RETURN
LAVA_SCROLL_UP:
OR     CX,CX                ;Start 0,0?, (CH,CL = row,column start, DH,DL = row
,column end)
JZ     LAVA_SCROLL_UP_L0
PUSH   AX
PUSH   DX
MOV     DX,CX              ;At least we will reposition cursor to 0,0
CALL   L_SET_CURSOR        ;Set Cursor at [DX]
POP     DX
POP     AX
JMP     VIDEO_NOT_FINISHED ;Will ignore DX for now
LAVA_SCROLL_UP_L0:
OR     AL,AL                ;AL has number of lines to scroll
JNZ   LAVA_SCROLL_UP_L1
CALL   L_CLEAR_SCREEN      ;AL=0 then clear whole screen
JMP     VIDEO_RETURN
LAVA_SCROLL_UP_L1:
PUSH   AX
CALL   L_SCROLL_UP_1
POP     AX
DEC     AL
JNZ   LAVA_SCROLL_UP_L1
JMP     VIDEO_RETURN
;-----
;AH = 07h                VIDEO - SCROLL DOWN WINDOW

```



```

    CMP     word [CONSOL_FLAG],0      ;Send output to Propeller board (0), Video board
    (1), or LAVA Board (2)
    JZ      PROPELLER_READ_CHAR_ATT
    CMP     word [CONSOL_FLAG],2
    JZ      LAVA_READ_CHAR_ATT
    JMP     VGA_READ_AC_CURRENT
PROPELLER_READ_CHAR_ATT:             ;AL = character to display
    OR      BH,BH                     ;BH = page number (00h to number of pages - 1)
    JNZ     VIDEO_NOT_FINISHED       ;BL = attribute (text mode) or color (graphics
mode)
    MOV     AH,07                     ;Return: AH = character's attribute (text mode
only)
    MOV     AL,0                       ;      AL = character (Not implemented)
    JMP     VIDEO_RETURN
LAVA_READ_CHAR_ATT:                 ;AL = character to display
    OR      BH,BH                     ;BH = page number (00h to number of pages - 1)
    JNZ     VIDEO_NOT_FINISHED       ;BL = attribute (text mode) or color (graphics
mode)
    MOV     AH,07                     ;Return: AH = character's attribute (text mode
only)
    MOV     AL,0                       ;      AL = character (Not implemented)
    JMP     VIDEO_RETURN

;-----
                                ;AH = 09h      VIDEO - WRITE CHARACTER AND
                                ;AL = character to display
WRITE_AT_CURSOR_ATT:              ;AL = character to display
    CMP     word [CONSOL_FLAG],0      ;Send output to Propeller board (0), Video board
    (1), or LAVA Board (2)
    JZ      PROPELLER_WRITE_AT_CURSOR_ATT
    CMP     word [CONSOL_FLAG],2
    JZ      LAVA_WRITE_AT_CURSOR_ATT
    JMP     VGA_WRITE_AC_CURRENT       ;Send to display on CGA/VGA Board
PROPELLER_WRITE_AT_CURSOR_ATT:     ;BH = page number (00h to number of pages - 1)
    OR      BH,BH                     ;BL = attribute (text mode) or color (graphics
mode)
    MOV     AH,AL                     ;CX = number of times to write character
AT_CURSOR1:
    CALL    FAST_CONOUT               ;Fast direct output to Propeller boardr
    LOOP   AT_CURSOR1                 ;Repeat CX times
    JMP     VIDEO_RETURN
LAVA_WRITE_AT_CURSOR_ATT:         ;BH = page number (00h to number of pages - 1)
    OR      BH,BH                     ;BL = attribute (text mode) or color (graphics
mode)
    MOV     AH,AL                     ;CX = number of times to write character
L_AT_CURSOR:
    CALL    L_TTY_OUT                 ;Fast direct output to LAVA board (Character in
AH)
    LOOP   L_AT_CURSOR                 ;Repeat CX times
    JMP     VIDEO_RETURN

;-----
                                ;AH = 0Ah      VIDEO - WRITE CHARACTER ONLY AT
                                ;AL = character to display
WRITE_AT_CURSOR:                  ;AL = character to display
    CMP     word [CONSOL_FLAG],0      ;Send output to Propeller board (0), Video board
    (1), or LAVA Board (2)
    JZ      PROPELLER_WRITE_AT_CURSOR
    CMP     word [CONSOL_FLAG],2
    JZ      PROPELLER_WRITE_AT_CURSOR
    JMP     VGA_WRITE_C_CURRENT       ;Send to display on CGA/VGA Board

```

```

PROPELLER_WRITE_AT_CURSOR:
    OR     BH,BH                ;BH = page number (00h to number of pages - 1)
    JNZ   VIDEO_NOT_FINISHED  ;BL = attribute (text mode) or color (graphics)
    mode)
    MOV   AH,AL                ;CX = number of times to write character
AT_CURSOR2:
    CALL  FAST_CONOUT         ;Fast direct output to Propeller board
    LOOP  AT_CURSOR2         ;Repeat CX times
    JMP   VIDEO_RETURN

LAVA_WRITE_AT_CURSOR:
    OR     BH,BH                ;BH = page number (00h to number of pages - 1)
    JNZ   VIDEO_NOT_FINISHED  ;BL = attribute (text mode) or color (graphics)
    mode)
    MOV   AH,AL                ;CX = number of times to write character
AT_CURSOR2L:
    CALL  L_TTY_OUT           ;Fast direct output to LAVA board (Character in
    AH)
    LOOP  AT_CURSOR2L        ;Repeat CX times
    JMP   VIDEO_RETURN

;-----
VIDEO_TTY:
    page
    TEST  byte[KB_FLAG_1],HOLD_STATE ;Is Pause flag set
    JNZ   VIDEO_TTY

    CMP   word [CONSOL_FLAG],0      ;Send output to Propeller board (0), Video board
    (1), or LAVA Board (2)

    JZ    PROPELLER_VIDEO_TTY
    CMP   word [CONSOL_FLAG],2
    JZ    LAVA_VIDEO_TTY
    JMP   VGA_WRITE_TTY
PROPELLER_VIDEO_TTY:
    IN    AL,KEYSTAT              ;Default Propeller or SD SYSTEMS VIDIO BOARD PORT
    AND   AL,4H                  ;Is board ready for character
    JZ    VIDEO_TTY
    POP   AX                      ;<-- Get character from AX on stack above
    OUT   KEYOUT,AL
    JMP   VIDEO_RETURN1          ;Note the normal extra AX was removed from stack
    above
LAVA_VIDEO_TTY:
    MOV   AH,AL
    CALL  L_TTY_OUT              ;Fast direct output to LAVA board (Character in
    AH)
    JMP   VIDEO_RETURN

;-----
GET_VIDEO_PARMS:
    CMP   word [CONSOL_FLAG],0      ;Send output to Propeller board (0) or Video board
    (1), or LAVA Board (2)
    JZ    PROPELLER_GET_VIDEO_STATE
    CMP   word [CONSOL_FLAG],2
    JZ    LAVA_GET_VIDEO_STATE
    JMP   VGA_GET_VIDEO_STATE
PROPELLER_GET_VIDEO_STATE:
    MOV   AX,5003H
    MOV   BX,0
    JMP   VIDEO_RETURN
    ;BH = Current page

```

```

LAVA_GET_VIDEO_STATE:
    MOV     AX,6303H           ;99 Characters/line
    MOV     BX,0              ;BH = Current page
    JMP     VIDEO_RETURN

;-----
                                ;AH = 12H    VIDEO - ALTERNATE FUNCTION SELECT (VGA)
                                ;BL = 32, return AL = new state. 0 = enabled, 1 =
VIDEO_VGA:
    disable
    CMP     BL,32H            ;Use for Cirrus VGA Board initialization (only)
    JNZ     VIDEO_TBD
    MOV     AL,12H           ;Return AL = 12h if function is supported
    JMP     VIDEO_RETURN

;-----
                                ;AH = 13H    VIDEO - WRITE CHARACTER AND
                                ;ES:BP = string pointer
                                ;Saved at the start
WRITE_STRING:
    MOV     ES,[ES_STORE]    ;Send output to Propeller board (0), Video board
    CMP     word [CONSOL_FLAG],0
    (1), or LAVA Board (2)
    JZ     PROPELLER_WRITE_STRING ;CX = string length
    CMP     word [CONSOL_FLAG],2
    JZ     LAVA_WRITE_STRING   ;CX = string length
    JMP     VGA_WRITE_STRING   ;DX = cursor position

PROPELLER_WRITE_STRING:
    OR     BH,BH              ;Can do only page 0
    JNZ     VIDEO_NOT_FINISHED ;BH = page number (00h to number of pages - 1)
    OR     CX,CX              ;For zero length string, just return (as IBM does)
    JZ     PrW2
    OR     AL,AL              ;AL = 0, do not move cursor, AL = 1, update cursor
    . AL=3 or 4 add attriute also
    JZ     PrW1
    CALL   PROPELLER_SET_CURSOR ;Currently only AL=0 & 1 mode implemented
    PrW1: MOV     AH,[ES:BP]    ;Set Cursor at [DX]
    CALL   FAST_CONOUT         ;Send string to console
    INC    BP                  ;No need to save BP
    LOOP   PrW1
    PrW2:  JMP     VIDEO_RETURN

LAVA_WRITE_STRING:
    OR     BH,BH              ;Can do only page 0
    JNZ     VIDEO_NOT_FINISHED ;BH = page number (00h to number of pages - 1)
    OR     CX,CX              ;For zero length string, just return (as IBM does)
    JZ     LPrW2
    PUSH   AX                 ;Save Cursor update info
    OR     AL,AL              ;AL = 0, do not move cursor, AL = 1, update cursor
    . AL=3 or 4 add attriute also
    JZ     LPrW1
    CALL   L_HIDE_CURSOR
    LPrW1: MOV     AH,[ES:BP]    ;Send string to console
    CALL   L_TTY_OUT_NO_UPDATE
    INC    BP                  ;No need to save BP
    LOOP   LPrW1

    POP    AX
    OR     AL,AL              ;AL = 0, do not move cursor, AL = 1, update cursor
    . AL=3 or 4 add attriute also
    JZ     LPrW2
    CALL   L_NEXT_POSITION    ;Advance the cursor one position, next line if at
    EOL, Scroll up if at bottom of screen
    CALL   L_SHOW_CURSOR     ;Show new cursor position
    LPrW2: JMP     VIDEO_RETURN

```

```

;----- CGA/VGA Video board routines -----
;
;   Note all INT 10H generated Console outputs will come here if [CONSOLE_FLAG] = 1
;
VGA_SET_MODE:
    CALL    VGA_INIT                ;Want this callable because it is used at
    Initilization
    JMP     VIDEO_RETURN

                                ;Arrive here with ES: set to Video RAM area, DS:=0,
                                ;
                                ;Initilize the S-100 Lomas CGA video board (or
                                ;
                                ;compatible board)
VGA_INIT:
    mov     dx,c6845port+4          ;address of colour card
    mov     bl,0                    ;mode set for colour
    cmp     di,30h
    jne     m8
    mov     al,7
    mov     dx,bw6845port+4        ;address of b/w card
    inc     bl                       ;mode set for bw card

m8:
    mov     ah,al                    ;save mode in ah
    mov     [CRT_MODE],al           ;store it
    mov     [ADDR_6845],dx          ;also chip ports

    PUSH    DS                       ;Stuff in capitals below are mods in the AT-BIOS
    ROM
    push    ax
    push    dx                        ;save 6845 base reg

    add     dx,4                      ;point to control reg = 3d8h
    mov     al,bl                     ;get mode
    out     dx,al                     ;setup chip for new mode

    pop     dx                         ;back to base 6845 reg
    sub     ax,ax
    mov     ds,ax                       ;DS: to 0

    LDS     bx,[VID_PARM_PTR]          ;DS=0, BX=VID_PARM_PTR, will set DS=CS (here), BX
    to VID_PARM_TABLES
    pop     ax                          ;get back parameters

    mov     cx,Index_Reg_Count        ;length of row table
    cmp     ah,2                       ;Need to figure out which patamater table to use
    jc     m9                           ;mode 0 or 1 (40X25)
    add     bx,cx                       ;go to next row of int table, ie 16 bytes higher
    cmp     ah,4
    jc     m9                           ;mode 2 or 3 (80X25)
    add     bx,cx
    cmp     ah,7
    jc     m9                           ;mode is 4,5 or 6 (graphics mode)
    add     bx,cx                       ;else BW Card paramaters

m9:
    push    ax                          ;BX points to correct row of init Table
    PUSH    ES
    XOR     AX,AX                       ;Not clear why AT BIOS has this stuff
    MOV     ES,AX                       ;ES:-> 0
    MOV     AX,[BX+10]                  ;Uses DS:=0
    XCHG    AH,AL
    MOV     [ES:CURSOR_MODE],AX
    POP     ES

    xor     ah,ah

```



```

m10:   mov     al,ah           ;Block output iniation parms to chip.
       out     dx,al

       inc     dx           ;next port
       inc     ah           ;next value
       mov     al,[bx]      ;Note this will use [DS:BX] from the above LDS
       out     dx,al

       inc     bx
       dec     dx           ;back to pointer reg
       loop   m10

       pop     ax
       POP     DS

       xor     di,di        ;fill video with blanks
       mov     [CRT_START],di ;start address
       mov     byte[ACTIVE_PAGE],0
       mov     cx,8192      ;number of words in colour card
       cmp     ah,4         ;Test for colour card
       jc     m12
       cmp     ah,7
       je     m11
       xor     ax,ax        ;fill for graphics mode
       jmp     short m13
m11:   mov     CH,08H        ;buffer size for b/w card
m12:   mov     ax,' '+ (02H*256) ;<<<<NOTE IBM USES WHITE ON BLACK (07), we use 02, ✎
       Green
m13:   rep     stosw         ;AX -> [ES:DI] (Normally B800:0 upwards)

       mov     al,[CRT_MODE] ;;;get the mode ->AL
       xor     ah,ah        ;AH to 0
       mov     si,ax
       mov     dx,[ADDR_6845]
       add     dx,4

       mov     al,[CS:si+m7] ;Make sure we use the CS: override (DS:=0)

       out     dx,al
       mov     [CRT_MODE_SET],al ;save that value

       mov     al,[CS:si+m6]
       xor     ah,ah
       mov     [CRT_COLS],ax

       and     si,0eh        ;word offset into clear length table
       mov     cx,[CS:si+m5] ;Make sure we use teh CS: override (DS:=0)
       mov     [CRT_LEN],cx ;save length of crt
       mov     cx,2         ;clear all cursor positions (we have space for only✎
       2)
       mov     di,[CURSOR_POSN]
       push   ds            ;DS=0
       pop    es            ;ES=0
       xor     ax,ax        ;AX=0 -> [ES:DI]
       rep    stosw         ;Repeat 2 times

       inc     dx           ;Set overscan port to a default
       mov     al,30h
       cmp     byte[CRT_MODE],6
       jnz    m14
       mov     al,3fh        ;640 x 200 is special case
m14:   out     dx,al
       mov     [CRT_PALLETTE],al ;store value
       ret

```

```

;      SET CURRENT CURSOR VALUE
;      CX = CURSOR VALUE, CH (BITS 4-0) START LINE, CL (BITS (4-0) STOP LINE

VGA_SET_CURSOR_TYPE:                                ;AH = 1
    mov     ah,10                                    ;set cursor value
    mov     [CURSOR_MODE],cx
    call    m16
    jmp     VIDEO_RETURN

m16:    mov     dx,[ADDR_6845]                        ;this routine outputs cx to 6845 reg in ah
    mov     al,ah
    out     dx,al
    inc     dx
    jmp     short+$+2                                ;IO delay (AT-BIOS)
    mov     al,ch
    out     dx,al
    dec     dx
    jmp     short+$+2                                ;IO delay (AT-BIOS)
    mov     al,ah
    inc     al                                        ;point to other data reg
    out     dx,al
    inc     dx
    jmp     short+$+2                                ;IO delay (AT-BIOS)
    mov     al,cl
    out     dx,al
    ret

;      SET CURRENT CURSOR POSITION TO NEW X-Y VALUE
;      DX = ROW,COLUMN OF NEW CURSOR
;      BH = DISPLAY PAGE OF NEW CURSOR (MUST BE 0 FOR GRAPHICS MODE)

VGA_SET_CURSOR_POS:                                ;AH = 2
    mov     cl,bh                                    ;get display page
    xor     ch,ch
    sal     cx,1
    mov     si,cx
    mov     [si+CURSOR_POSN],dx                      ;DS=0
    cmp     [ACTIVE_PAGE],BH
    jnz     m17                                       ;if not current page abort
    mov     ax,dx
    call    m18
m17:    jmp     VIDEO_RETURN

m18:    call    POSITION                                ;Set Cursor pas. AX has Row/Col info
    mov     cx,ax
    add     cx,[CRT_START]
    sar     cx,1
    mov     ah,14                                    ;reg no of cursor
    call    m16
    ret

;      READ CURSOR POSITION
;      BH = PAGE OF CURSOR
;output:-
;      DX = ROW,COLUMN OF THE CURSOR POSITION
;      CX = CURRENT CURSOR MODE

VGA_GET_CURSOR_POS:                                ;AH = 03h      VIDEO - GET CURSOR POSITION AND
    SIZE
    mov     bl,bh
    xor     bh,bh
    sal     bx,1

```

```

    mov     dx, [bx+CURSOR_POSN]
    mov     cx, [CURSOR_MODE]
    POP     AX                      ;Remove the "extra AX"
    POP     BP                      ;New for AT-BIOS
    POP     DI
    POP     SI
    POP     BX
    POP     AX                      ;Discard old CX & DX
    POP     AX
    POP     DS
    POP     ES
    IRET

;     SET THE ACTIVE DISPLAY PAGE
;     AL = NEW DISPLAY PAGE

VGA_SET_PAGE:                      ;AH = 5
    mov     [ACTIVE_PAGE], al
    mov     cx, [CRT_LEN]
    cbw
    push   ax
    mul    cx
    mov     [CRT_START], ax

    mov     cx, ax
    sar    cx, 1
    mov     ah, 12
    call   m16
    pop    bx
    sal    bx, 1
    mov     ax, [bx+CURSOR_POSN]
    call   m18
    JMP    VIDEO_RETURN

;     SET BACKGROUND COLOUR, OVERSCAN COLOUR, AND FORGROUND COLOUR FOR MEDIUM RESOLUTION
;     GRAPHICS
;     BH = 0 THEN BACKGROUND SET FROM LOW BITS OF BL (0-31)
;     BH = 1 THE PALLET SELECTION IS MADE BASED ON LOW BITS OF BL:-
;           0 = GREEN, RED, YELLOW FOR COLOURS 1,2,3
;           1 = BLUE, CYAN, MAGENTA FOR COLOURS 1,2,3
;     BL = COLOUR VALUE TO BE USED

VGA_SET_COLOR:                    ;AH = 0BH
    mov     dx, [ADDR_6845]
    add     dx, 5
    mov     al, [CRT_PALLETTE]
    or     bh, bh
    jnz    m20

    and     al, 0e0h                ;handle for colour 0
    and     bl, 1fh
    or     al, bl

m19:   out     dx, al
    mov     [CRT_PALLETTE], al
    JMP    VIDEO_RETURN

m20:   and     al, 0dfh            ;handel colour 1
    shr    bl, 1
    jnc    m19
    or     al, 20h
    jmp    m19

```



```

n6:    JMP     VIDEO_RETURN

n7:    mov     bl,dh
       jmp     n3

scrool_position:
                                ;the lomas board does not need video off here
                                ;also no need to wait for retrace
       cmp     byte [CRT_MODE],2
       jb     n9
       cmp     byte [CRT_MODE],3
       ja     n9

       push   dx                    ;must be 80x25 colour scroll
       mov     dx,3dah
       push   ax

n8:    in     al,dx
       test    al,8                    ;wait for vertical retrace
       jz     n8
       mov     al,25h
       mov     dx,3d8h
       out    dx,al                    ;turn off vidio
       pop     ax                      ;during retrace
       pop     dx

n9:    call   POSITION
       add     ax,[CRT_START]
       mov     di,ax
       mov     si,ax
       sub     dx,cx
       inc     dh
       inc     dl
       xor     ch,ch
       mov     bp,[CRT_COLS]
       add     bp,bp
       mov     al,bl
       mul    byte [CRT_COLS]
       add     ax,ax
       push   es
       pop     ds
       cmp     bl,0
       ret

n10:   mov     cl,dl                    ;no of columns to move
       push   si
       push   di
       rep   movsw
       pop    di
       pop    si
       ret

n11:   mov     cl,dl                    ;no of columns to clear
       push   di
       rep   stosw
       pop    di
       ret

;     Scroll down text on screen
;     Ah     =     CURRENT CRT MODE
;     AL     =     NUMBER OF ROOLS TO SCROOL
;     CX     =     ROW/COL UPPER LEFT
;     DX     =     ROW/COL LOWER RIGHT
;     BH     =     ATTRIBUTE

```



```
        jc      p1
        cmp     ah,7
        je     p1
        jmp    graphics_read

p1:     call    find_position
        mov     si,bx

        mov     dx,[ADDR_6845]           ;wait for retreace
        add     dx,6
        push    es
        pop     ds

p2:     in      al,dx
        test   al,1
        jnz    p2
        cli                    ;no more ints

p3:     in      al,dx
        test   al,1
        jz     p3
        lodsw
        JMP     VIDEO_RETURN

find_position:
        mov     cl,bh
        xor     ch,ch
        mov     si,cx
        sal     si,1
        mov     ax,[si+CORSOR_POSN]
        xor     bx,bx
        jcxz   p5

p4:     add     bx,[CRT_LEN]
        loop   p4

p5:     call    POSITION
        add     bx,ax
        ret

;       WRITE CHAR AND ATTRIBUATE AT CURRENT CURSOR POSITION
;       AH = CURRENT CRT MODE
;       BH = DISPLAY PAGE
;       CX = COUNT OF CHARACTERS TO WRITE
;       AL = CHAR TO WRITE
;       BL = ATTRIBUATE OF CHAR TO WRITE
;       DS = DATA SEGMENT
;       ES = REGEN SEGMENT

VGA_WRITE_AC_CURRENT:           ;AH = 9
        cmp     ah,4
        jc     p6
        cmp     ah,7
        je     p6
        jmp    graphics_write

p6:     mov     ah,bl
        push   ax
        push   cx
        call   find_position
        mov     di,bx
        pop    cx
        pop    bx
```

```
p7:    mov    dx, [ADDR_6845]
      add    dx, 6
```

```
p8:    in     al, dx
      test   al, 1
      jnz   p8
      cli
```

```
p9:    in     al, dx
      test   al, 1
      jz    p9
      mov   ax, bx
      stosw
      sti
      loop  p7
      JMP   VIDEO_RETURN
```

```
;    WRITE CHAR AT CURSOR POSITION DO NOT CHANGE ATTRIBUATE
;    BH = DISPLAY PAGE
;    CX = COUNT OF CHARACTERS TO WRITE
;    AL = CHAR TO WRITE
;    DS = DATA SEGMENT
;    ES = REGEN SEGMENT
```

```
VGA_WRITE_C_CURRENT:                ;AH = 0AH
```

```
      cmp    ah, 4
      jc    p10
      cmp    ah, 7
      je    p10
      jmp   graphics_write
```

```
p10:   push   ax
      push  cx
      call  find_position
      mov   di, bx
      pop   cx
      pop   bx
```

```
p11:   mov    dx, [ADDR_6845]
      add    dx, 6
```

```
p12:   in     al, dx
      test   al, 1
      jnz   p12
      cli
```

```
p13:   in     al, dx
      test   al, 1
      jz    p13
      mov   al, bl
      stosb
      sti
      inc   di                ;go past attribute
      loop  p11
      JMP   VIDEO_RETURN
```

```
;AH = 13H        VIDEO - WRITE CHARACTER AND
```

```
      ATTRIBUTE AT CURSOR POSITION
```

```
VGA_WRITE_STRING:
```

```
      CMP    AL, 04
```

```
;ES:BP = string pointer (Note: New in AT-BIOS)
;Test for invalid request
```



```

        JB      W0
        JMP     DONE
W0:     OR      CX,CX          ;Return if zero length
        JNZ    W1
        JMP     DONE
W1:     PUSH   BX
        MOV    BL,BH          ;get current cursor position for that page
        XOR    BH,BH
        SAL    BX,1          ;X2
        MOV    SI,[BX+CORSOR_POSN] ;0,1,2,..UP TO 8 PAGES
        POP    BX
        PUSH   SI          ;save current cursor position

        PUSH   AX          ;save write string option
        MOV    AX,0200H
        INT    10H        ;set new cursor position
        POP    AX

WRITE_CHAR:
        PUSH   CX
        PUSH   BX
        PUSH   AX
        PUSH   ES

        XCHG  AH,AL
        MOV    AL,[ES:BP]
        INC    BP

        CMP    AL,08H      ;special cases, BS
        JE     DD_TTY
        CMP    AL,0DH
        JE     DD_TTY
        CMP    AL,0AH
        JE     DD_TTY
        CMP    AL,07H
        JNE    GET_ATTRIBUTE

DD_TTY: MOV    AH,0EH      ;write to tty
        INT    10H
        MOV    BL,BH
        SAL    BH,1        ;X2
        MOV    DX,[BX+CORSOR_POSN]
        POP    ES
        POP    AX
        POP    BX
        POP    CX
        JMP    ROWS_SET

GET_ATTRIBUTE:
        MOV    CX,1
        CMP    AH,2        ;If AL is 1 or 2 them AL has ASCII character, BL
        has the Attribute
        JB     GOT_IT      ;If 3 or 4 then attrib, char, attrtrib, char.....
        MOV    BL,[ES:BP]
        INC    BP

GOT_IT: MOV    BH,0
        MOV    CX,1
        MOV    AH,09H      ;write char & attribute on crt
        INT    10H
        POP    ES
        POP    AX
        POP    BX
        POP    CX

        INC    DL          ;inc column count

```

```

        CMP     DL, [CRT_COLS]

        JB     COLUMNS_SET
        INC     DH
        SUB     DL, DL
        CMP     DH, 25                ;bottom of page
        JB     ROWS_SET

        PUSH   ES
        PUSH   AX
        MOV     AX, 0E0AH            ;scroll down one line
        INT     10H
        DEC     DH
        POP     AX
        POP     ES

ROWS_SET:
COLUMNS_SET:
        PUSH   AX
        MOV     AX, 0200H            ;set cursor position
        INT     10H
        POP     AX
        LOOP   WRITE_CHAR

        POP     DX
        CMP     AL, 1
        JE     DONE
        CMP     AL, 3
        JE     DONE
        MOV     AX, 0200H            ;set cursor position
DONE:   JMP     VIDEO_RETURN

;      READ OR WRITE A DOT AT INDICATED POSITION
;      DX = ROW (0-199)
;      CX = COLUMN (0-639)
;      AL = DOT VALUE (see text)
;      DS = DATA SEGMENT
;      ES = REGEN SEGMENT
;output:-
;      AL = DOT VALUE READ, RIGHT JUSTIFIED

VGA_READ_DOT:                ;AH = 0DH
        call   RX3
        mov    al, [es:si]
        and   al, ah
        shl   al, cl
        mov   cl, dh
        rol   al, cl
        jmp   VIDEO_RETURN

VGA_WRITE_DOT:                ;AH = 0CH
        push  ax
        push  ax
        call  RX3
        shr  al, cl
        and  al, ah
        mov  cl, [es:si]
        pop  bx
        test bl, 80h
        jnz  rx2
        not  ah
        and  cl, ah
        or   al, cl

```

```
rx1:   mov     [es:si],al
       pop     ax
       JMP    VIDEO_RETURN

rx2:   xor     al,cl
       jmp    rx1

;
;       THIS ROUTINE DETERMINES THE RAM LOCATION OF COL/ROW
;input:-
;       DX = ROW (0-199)
;       CX = COLUMN (0-639)
;output:-
;       SI = OFFSET INTO RAM
;       AH = MASK TO STRIP OF BITS OF INTREST
;       CL = BITS TO SHIFT TO RIGHT JUSTIFY MASK IN AH
;       DH = NO OF BITS IN RESULT
;
RX3:   push    bx
       push    ax

       mov     al,40h
       push    dx
       and     dl,0FEH
       mul     dl

       pop     dx
       test    dl,1
       jz     rx4
       add     ax,2000H

rx4:   mov     si,ax
       pop     ax
       mov     dx,cx

       mov     bx,2C0H           ;determine graphics mode currently in effect
       mov     cx,302h
       cmp     byte [CRT_MODE],6
       jc     rx5
       mov     bx,180h
       mov     cx,703h

rx5:   and     ch,dl

       shr     dx,cl
       add     si,dx
       mov     dh,bh

       sub     cl,cl
rx6:   ror     al,1

       add     cl,ch
       dec     bh
       jnz    rx6

       mov     ah,b1
       shr     ah,cl
       pop     bx
       ret

;
;       GRAPHICS SCROOL UP
;       CH,CL = UPPER LEFT HAcD CORNER OF SCREEN
```

```

;      DH,DL = LOWER RIGHT HAND CORNER OF SCREEN
;      BH = FILL CHAR FOR BLANK LINES
;      DS = DATA SEGMENT
;      ES = REGEN SEGMENT

graphics_up:
    mov     bl,al                ;save line count
    mov     ax,cx

    call    graph_posn
    mov     di,ax

    sub     dx,cx
    add     dx,101h
    sal     dh,1

    sal     dh,1

    cmp     byte [CRT_MODE],6
    jnc     rx7

    sal     dl,1
    sal     dl,1

rx7:    push    es
        pop     ds
        sub     ch,ch
        sal     bl,1
        sal     bl,1
        jz      rx11
        mov     al,bl
        mov     ah,80
        mul     ah
        mov     si,di
        add     si,ax
        mov     ah,dh
        sub     ah,bl

rx8:    call    rx17
        sub     si,2000h-80        ;next row
        sub     di,2000h-80
        dec     ah
        jnz     rx8

rx9:    mov     al,bh                ;fill in vacent lines
rx10:   call    RX18
        sub     di,2000h-80
        dec     bl
        jnz     rx10
        JMP     VIDEO_RETURN

rx11:   mov     bl,dh
        jmp     rx9

;      GRAPHICS SCROOL DOWN
;      CH,CL = UPPER LEFT HAND CORNER OF SCREEN
;      DH,DL = LOWER RIGHT HAND CORNER OF SCREEN
;      BH = FILL CHAR FOR BLANK LINES
;      DS = DATA SEGMENT
;      ES = REGEN SEGMENT

graphics_down:
    std
    mov     bl,al

```

```
    mov     ax, dx

    call   graph_posn
    mov    di, ax

    sub    dx, cx
    add    dx, 101h
    sal    dh, 1
    sal    dh, 1

    cmp    byte [CRT_MODE], 6
    jnc    rx12

    sal    dl, 1
    sal    di, 1
    inc    di

rx12:  push   es
       pop   ds
       sub   ch, ch
       add   di, 240
       sal   bl, 1
       sal   bl, 1
       jz    rx16
       mov   al, bl
       mov   ah, 80
       mul   ah
       mov   si, di
       sub   si, ax
       mov   ah, dh
       sub   ah, bl

rx13:  call   rx17
       sub   si, 2000h+80
       sub   di, 2000h+80
       dec   ah
       jnz   rx13

rx14:  mov    al, bh

rx15:  call   RX18
       sub   di, 2000h+80
       dec   bl
       jnz   rx15
       cld
       JMP   VIDEO_RETURN

rx16:  mov    bl, dh
       jmp   rx14

rx17:  mov    cl, dl
       push  si
       push  di
       rep  movsb

       pop   di
       pop   si
       add   si, 2000h
       add   di, 2000h
       push  si
       push  di
       mov   cl, dl
       rep  movsb
       pop   di
       pop   si
       ret
```



```
        lodsb

s5:     mov     [es:di+1ffffh],al
        add     di,79
        dec     dh
        jnz     s4
        pop     si
        pop     di
        inc     di
        loop    s3
        JMP     VIDEO_RETURN

s6:     xor     al,[es:di]
        stosb
        lodsb
        xor     al,[es:di+1ffffh]
        jmp     s5

s7:     mov     dl,bl                ;high res write
        sal     dl,1
        call    s19

s8:     push    di
        push    si
        mov     dh,4

s9:     lodsb
        call    s21
        and     ax,bx

        test    dl,80h
        jz     s10
        xor     ah,[es:di]
        xor     al,[es:di+1]

s10:    mov     [es:di],ah
        mov     [es:di+1],al
        lodsb
        call    s21
        and     ax,bx
        test    dl,80h
        jz     s11
        xor     ah,[es:di+2000h]
        xor     al,[es:di+2001h]

s11:    mov     [es:di+2000h],ah
        mov     [es:di+2001h],al
        add     di,80
        dec     dh
        jnz     s9
        pop     si
        pop     di
        inc     di
        inc     di
        loop    s8
        JMP     VIDEO_RETURN

;       GRAPHICS READ
;       NONE (0 IS ASSUMED FOR BACKGROUND COLOUR)
;output:-
;       AL = CHAR (0 IF NONE THERE)

graphics_read:
```

```

        call    s26
        mov     si,ax
        sub    sp,8
        mov    bp,sp

        cmp    byte [CRT_MODE],6
        push  es
        pop    ds
        jc    s13

        mov    dh,4

s12:    mov     al,[si]
        mov    [bp],al
        inc   bp
        mov    al,[si+2000h]
        mov    [bp],al
        inc   bp
        add   si,80
        dec   dh
        jnz   s12
        jmp   s15

s13:    sal     si,1
        mov    dh,4

s14:    call    s23
        add   si,2000h
        call  s23
        sub   si,2000h-80
        dec   dh
        jnz   s14

s15:    mov     di,CRT_CHAR_GEN           ;char gen in IBM Rom
        push  cs                         ;<<<< NOTE FOR 27128K EPROM OR 8088 BOARD I HAVE ✓
        REMOVED THIS CHARACTER TABLE
        pop   es                         ;THERE IS NOT ENOUGH ROOM IN ROM. SELDOM USED ✓
        ANYWAY>>>>
        sub   bp,8
        mov   si,bp
        cld
        mov  al,0

s16:    push  ss
        pop  ds
        mov  dx,128

s17:    push  si
        push di
        mov  cx,8
        repe cmpsb

        pop  di
        pop  si
        jz   s18
        inc  al
        add  di,8
        dec  dx
        jnz  s17

        cmp  al,0
        je   s18
        sub  ax,ax
        mov  ds,ax                       ;set ds to 0

        les  di,[EXT_CHAR_PTR]

```



```
    mov     ax,es
    or      ax,di
    jz      s18
    mov     al,128
    jmp     s16

s18:   add     sp,8                ;<<<<<<<<< Check!
       JMP    VIDEO_RETURN

s19:   and     b1,3
       mov     al,b1
       push   cx
       mov     cx,3

s20:   sal     al,1
       sal     al,1
       or      b1,al
       loop   s20
       mov     bh,b1
       pop    cx
       ret

s21:   push   dx
       push   cx
       push   bx
       sub    DX,DX
       mov    cx,1

s22:   mov     bx,ax
       and    bx,cx
       or     dx,bx
       shl   ax,1
       shl   cx,1
       mov   bx,ax
       and   bx,cx
       or    dx,bx
       shl   cx,1

       jnc   s22
       mov   ax,dx
       pop   bx
       pop   cx
       pop   dx
       ret

s23:   mov     ah,[si]
       mov     al,[si+1]
       mov     cx,0c000h
       mov     dl,0

s24:   test    ax,cx
       clc
       jz     s25
       stc

s25:   rcl     dl,1
       shr    cx,1
       shr    cx,1
       jnc   s24
       mov    [bp],dl
       inc   bp
       ret

s26:   mov     ax,[CURSOR_POSN]

graph_posn:
```

```

push    bx
mov     bx,ax
mov     al,ah
mul     byte [CRT_COLS]
shl     ax,1
shl     ax,1
sub     bh,bh
add     ax,bx
pop     bx
ret

```

```

;     WRITE_TTY             <<<< MAIN VIDEO BOARD CHARACTER OUTPUT ROUTINE >>>>>
;     AL = CHARACTER
;     BL = BACKGROUND CHAR IF IN GRAPHICS MODE

```

```

VGA_WRITE_TTY:                ;AH = 0EH
    push    ax
    push    ax
    mov     ah,3
    MOV     BH,[ACTIVE_PAGE]
    int     10h                ;DX now has current Cursor position
    pop     ax                ;Get character

    cmp     al,8              ;is it BS
    je     u8
    cmp     al,0dh            ;Is it CR
    je     u9
    cmp     al,0ah            ;Is it LF
    je     u10
    cmp     al,07             ;Is it BELL
    je     u11

    mov     ah,10             ;Write char on screen
    mov     cx,1              ;1X
    int     10h

    inc     dl
    cmp     dl,byte [CRT_COLS]
    jnz    u7
    mov     dl,0
    cmp     dh,24
    jnz    u6

u1:    mov     ah,2            ;Set Cursor
    int     10h                ;;Difference on AT-BIOS (PC has BH=0)

    mov     al,[CRT_MODE]
    cmp     al,4
    jc     u2
    cmp     al,7
    mov     bh,0
    jne    u3

u2:    mov     ah,8            ;Read cursor
    int     10h
    mov     bh,ah

u3:    mov     ax,601h         ;Scroll up one line
    sub     cx,cx
    mov     dh,24
    mov     dl,byte [CRT_COLS]
    dec     dl
u4:    int     10h

```

```

u5:    pop     ax
       jmp     VIDEO_RETURN

u6:    inc     dh

u7:    mov     ah,2
       jmp     u4

u8:    cmp     dl,0
       je      u7
       dec     dl
       jmp     u7

u9:    mov     dl,0
       jmp     u7

u10:   cmp     dh,24
       jne     u6
       jmp     u1

u11:   mov     bl,2
       call    BELL1           ;send hardware bell
       jmp     u5

;----- VIDEO SUPPORT ROUTINES -----

VIDEO_RETURN:           ;Most (but not all) routines finish up here
    POP     DI           ;Remove the "extra AX on stack"
VIDEO_RETURN1:
    POP     BP
    POP     DI
    POP     SI
    POP     BX
M15:   POP     CX
    POP     DX
    POP     DS
    POP     ES
    IRET                ;Note IRET

FAST_CONOUT:           ;Fast send Character (in AH) to Propeller board
    IN      AL,KEYSTAT   ;Propeller or SD SYSTEMS VIDIO BOARD PORT
    AND     AL,4H        ;Is board ready for character
    JZ      FAST_CONOUT
    MOV     AL,AH
    OUT     KEYOUT,AL
    RET

PROPELLER_SET_CURSOR: ;Set cursor location to DH & DL
    MOV     AH,ESC
    CALL    FAST_CONOUT  ;Send is VT100 Format "ESC [ row ; column H"
    MOV     AH,'['
    CALL    FAST_CONOUT

    MOV     AL,DH        ;DH = row (00h is top)
    CALL    HEX_TO_BCD   ;(DX unaltered for below)
    PUSH    AX
    MOV     AH,AL
    ROR     AH,1
    ROR     AH,1
    ROR     AH,1
    ROR     AH,1
    AND     AH,0FH
    ADD     AH,30H       ;Convert to ASCII

```

```

CALL    FAST_CONOUT        ;Send ROW 10's digit
POP     AX
MOV     AH,AL
AND     AH,0FH             ;Low nibble
ADD     AH,30H            ;Convert to ASCII
CALL    FAST_CONOUT        ;Send ROW 1's digit

MOV     AH,','
CALL    FAST_CONOUT

MOV     AL,DL              ;DL = Column (00h is left)
CALL    HEX_TO_BCD

PUSH    AX
MOV     AH,AL
ROR     AH,1
ROR     AH,1
ROR     AH,1
ROR     AH,1
AND     AH,0FH
ADD     AH,30H            ;Convert to ASCII
CALL    FAST_CONOUT        ;Send ROW 10's digit
POP     AX
MOV     AH,AL
AND     AH,0FH             ;Low nibble
ADD     AH,30H            ;Convert to ASCII
CALL    FAST_CONOUT        ;Send ROW 1's digit
MOV     AL,AH

MOV     AH,'H'
CALL    FAST_CONOUT
RET

POSITION:
;Calculate th Video RAM address from row/column
;ax = row,column
;calculates ram address
push    bx
mov     bx,ax
mov     al,ah
mul     byte [CRT_COLS]
xor     bh,bh
add     ax,bx
sal     ax,1
pop     bx
ret

VIDEO_NOT_FINISHED:
PUSH    BX
MOV     BX,VID_PARM_TBD1_MSG ;"Int 10H Video paramater routine not fully
implemented"
JMP     VIDEO_TBD1

VIDEO_TBD:
PUSH    BX
MOV     BX,VID_PARM_TBD_MSG  ;"Int 10H Video paramater not yet implemented"

VIDEO_TBD1:
CALL    SERIAL_PRINT_STRING
POP     BX
POP     AX                  ;Recover that extra AX on stack
CALL    SERIAL_DISPLAY_REGISTERS ;Display Registers on serial port display (All
registers retained)
JMP     VIDEO_RETURN1       ;Remember we have removed that one extra AX on
stack

```

```

; Input: AL = input number   Output: AL = BCD
HEX_TO_BCD:
    pushf                ; Save flags register
    push cx              ; Save general-purpose regs
    push dx
    push ax

    sub ah, ah           ; We don't want a high-order byte so we don't have
a divide overflow
    mov dl, 0Ah          ; Divide by 10
    div dl               ; Unsigned divide. Quotient in al, remainder in ah.
    mov dl, ah           ; Save remainder
    mov ah, al           ; Move quotient (multiple of 10)
    mov cl, 4            ; and shift into high nibble of al
    shr ax, cl           ; (8086 imposes stupid restrictions on shr
operands)
    or al, dl            ; Set low nibble of al to remainder
    pop dx               ; Recover ah (pulling its value into dx first)
    mov ah, dh           ; restore cx, dx and flags
    pop dx
    pop cx
    popf
    ret                  ; All done.

;----- BASIC LAVA-10 CRT TREMINAL COMMANDS -----
;
;           Only AL register changed unless stated otherwise

INITILIZE_LAVA:                ;Clear Screen, Green/Black Cursor 0,0
    MOV     AL,00000000B        ;Set to WRITE mode, no strobes etc
    OUT     LavaStatus,AL      ;Send to lava status port (91H)
    CALL    L_CLEAR_BUFFER     ;Clear a buffer LAVA RAM area for Clear line etc
    CALL    L_CLEAR_SCREEN
    CALL    L_HOME              ;Set cursor X,Y to 0,0
    MOV     BX,L_GREEN_COLOR
    CALL    L_SET_COLOR
    CALL    L_SHOW_CURSOR
    RET

L_TTY_OUT:                      ;<< CORE FUNCTION >>Write 1 character (in [AH]) to
current cursor X,Y position. Update cursor
    CMP     AH,SPACE           ;Special treatment for control characters.
    JGE     L_NOT_SEPCIAL

    CMP     AH,CR              ;First treat the special case situations
    JNZ     L_NOT_CR
    CALL    L_DO_CR
    RET

L_NOT_CR:
    CMP     AH,LF
    JNZ     L_NOT_LF
    CALL    L_DO_LF
    RET

L_NOT_LF:
    CMP     AH,BS
    JNZ     L_NOT_BS
    CALL    L_BACK_SPACE
    RET

L_NOT_BS:
    CMP     AH,SCROLL          ;Scroll up one line with 01H
    JNZ     L_NOT_SCROLL
    CALL    L_SCROLL_UP_1
    RET

L_NOT_SCROLL:
    CMP     AH,CLEAR

```

```

        JNZ     L_NOT_CLEAR
        CALL    L_CLEAR_SCREEN
        RET
L_NOT_CLEAR:
        CMP     AH,BELL
        JNZ     L_NOT_BELL
        CALL    BELL1                ;Send Bell to Propeller Board
        RET

L_NOT_BELL:
L_NOT_SEPCIAL:                ;We need to also take care of DEL (7FH)
        CMP     AH,DELETE
        JNZ     L_NOT_DEL
        CALL    L_DEL_SPACE
        RET

L_NOT_DEL:                    ;Else do "regular" ASCII characters
        CALL    L_HIDE_CURSOR

        MOV     AL,DRAW$TEXT        ;Send Draw Text Command
        CALL    L_PULSE$WR
        MOV     AL,1                ;Send 1 character only
        CALL    L_PULSE$WR
        MOV     AL,AH
        CALL    L_PULSE$WR        ;Send Ascii
        MOV     AL,0
        CALL    L_PULSE$WR        ;send Ascii X2 (So we have an even number of bytes
sent)
L_TTY_DONE:
        CALL    L_NEXT_POSITION    ;Advance the cursor one position, next line if at
EOL, Scroll up if at bottom of screen
        CALL    L_SHOW_CURSOR      ;Show new cursor position
        RET

L_TTY_OUT_NO_UPDATE:        ;<< CORE FUNCTION >>Write 1 character (in [AH]) to
current cursor X,Y position. NO Update cursor
        MOV     AL,DRAW$TEXT        ;Send Draw Text Command
        CALL    L_PULSE$WR
        MOV     AL,1                ;Send 1 character only
        CALL    L_PULSE$WR
        MOV     AL,AH
        CALL    L_PULSE$WR        ;Send Ascii
        MOV     AL,0
        CALL    L_PULSE$WR        ;send Ascii X2 (So we have an even number of bytes
sent)
        RET

L_HOME:                    ;Cursor to Top left of screen
        PUSH    BX
        CALL    L_HIDE_CURSOR
        XOR     BX,BX
        CALL    L_SET_X
        CALL    L_SET_Y
        CALL    L_SHOW_CURSOR
        POP     BX
        RET

L_SET_CURSOR:                ;AH = 02h        VIDEO - SET CURSOR POSITION
        PUSH    BX                ;DH = row (00h is top), DL = column (00h is left)
        XOR     BX,BX
        MOV     BL,DL

```

```

    SHL     BX,1           ;X2
    SHL     BX,1           ;X4
    SHL     BX,1           ;X8      (8 Pixels/character)
    CALL    L_SET_X
    XOR     BX,BX
    MOV     BL,DH
    SHL     BX,1           ;X2
    SHL     BX,1           ;X4
    SHL     BX,1           ;X8
    SHL     BX,1           ;X16     (16 Pixels/character)
    CALL    L_SET_Y
    POP     BX
    RET

;AH = 03h      VIDEO - GET CURSOR POSITION AND
L_GET_CURSOR: ;DH = row (00h is top), DL = column (00h is left)
    PUSH    BX
    CALL    L_GET_X
    SHR     BX,1           ;/2
    SHR     BX,1           ;/4
    SHR     BX,1           ;/8      (8 Pixels/character)
    MOV     DL,BL
    CALL    L_GET_Y
    SHR     BX,1           ;/2
    SHR     BX,1           ;/4
    SHR     BX,1           ;/8
    SHR     BX,1           ;/16     (16 Pixels/character)
    MOV     DH,BL
    POP     BX
    RET

L_SHOW_CURSOR: ;Show cursor at current position
    MOV     AL,DRAW$TEXT   ;Send Draw Text Command
    CALL    L_PULSE$WR
    MOV     AL,1           ;Send 1 character only
    CALL    L_PULSE$WR
    MOV     AL,'_'
    CALL    L_PULSE$WR     ;Send Ascii
    MOV     AL,0
    CALL    L_PULSE$WR     ;Send Ascii X2 (So we have an even number of bytes
sent)
    RET

L_HIDE_CURSOR: ;Hide cursor at current position
    PUSH    BX
    CALL    L_GET_COLOR    ;Normally white on black
    PUSH    BX             ;Save For below
    MOV     BX,L_BLACK_COLOR
    CALL    L_SET_COLOR
    MOV     AL,DRAW$TEXT   ;Send Draw Text Command
    CALL    L_PULSE$WR
    MOV     AL,1           ;Send 1 character only
    CALL    L_PULSE$WR
    MOV     AL,'_'
    CALL    L_PULSE$WR     ;Send Ascii
    MOV     AL,0
    CALL    L_PULSE$WR     ;Send Ascii X2 (So we have an even number of bytes
sent)
    POP     BX             ;Get Back original color
    CALL    L_SET_COLOR

```

```

        POP     BX
        RET

L_DO_CR:
        PUSH    BX                ;Move cursor to start of line
        CALL    L_HIDE_CURSOR
        XOR     BX,BX
        CALL    L_SET_X
        CALL    L_SHOW_CURSOR
        POP     BX
        RET

L_DO_LF:
        PUSH    BX                ;Move cursor down vertically one line
        CALL    L_HIDE_CURSOR
        CALL    L_GET_Y
        CMP     BX,(L_SCREEN_LINES * L_CHAR_HEIGHT) - L_CHAR_HEIGHT
        JL     L_DO_LF1
        CALL    L_SCROLL_UP_1      ;Scroll up 1 line
        JMP     L_DO_LF2

L_DO_LF1:
        ADD     BX,L_CHAR_HEIGHT
        CALL    L_SET_Y

L_DO_LF2:
        CALL    L_SHOW_CURSOR
        POP     BX
        RET

L_GET_COLOR:
                                ;READ Register command, Get Text Color. Data in BX
        MOV     AL,READ$CSR
        CALL    L_PULSE$WR        ;Send
        MOV     AL,0
        CALL    L_PULSE$WR
        MOV     AL,0
        CALL    L_PULSE$WR
        MOV     AL,0H            ;Point to CSR_COLOR
        CALL    L_PULSE$WR
        CALL    L_PULSE$2RD       ;<<< Read 2 byte into [BX]
        RET

L_SET_COLOR:
                                ;WRITE Register command, Set Text Color. Data in BX
        MOV     AL,WRITE$CSR
        CALL    L_PULSE$WR        ;Send
        MOV     AL,0
        CALL    L_PULSE$WR
        MOV     AL,0
        CALL    L_PULSE$WR
        MOV     AL,0H            ;Point to CSR_COLOR
        CALL    L_PULSE$WR
        MOV     AL,BH
        CALL    L_PULSE$WR
        MOV     AL,BL
        CALL    L_PULSE$WR
        RET

L_NEXT_POSITION:
                                ;Advance LAVA cursor to next position
        (Cursor is not displayed here)
        PUSH    BX
        CALL    L_GET_X           ;Get X position in BX
        CMP     BX,(L_CHARS_PER_LINE * L_CHAR_WIDTH) - L_CHAR_WIDTH

```



```

        JL      L_SAME_LINE          ;On Same line just update
        CALL   L_DO_LF
        CALL   L_HIDE_CURSOR
        XOR    BX,BX                  ;X=0 always to start of next line
        CALL   L_SET_X
        POP    BX
        RET
L_SAME_LINE:                          ;This is the normal situation
        ADD    BX,8
        CALL   L_SET_X
        POP    BX
        RET

L_CLEAR_CURRENT_LINE:                ;Clear a whole line at current cursor Y position  ✓
        (Any X position on that line)
        PUSH   BX
        PUSH   CX                    ;No need to hide cursor
        PUSH   SI
        CALL   L_GET_X
        PUSH   BX                    ;Store it for when we return below

        CALL   L_GET_Y
        MOV    SI,BX
        CALL   L_CLEAR_LINE

        POP    BX                    ;Get Back original Cursor position
        CALL   L_SET_X
        POP    SI
        POP    CX
        POP    BX
        RET

L_CLEAR_SCREEN:                      ;Clear the whole screen. Cursor to 0,0
        PUSH   BX
        PUSH   CX
        PUSH   SI
        MOV    SI,0
        MOV    CX,L_SCREEN_LINES+1 ;Count of total lines on screen
L_CLEAR1:
        PUSH   CX
        PUSH   SI
        CALL   L_CLEAR_LINE
        POP    SI
        POP    CX
        ADD    SI,L_CHAR_HEIGHT
        LOOP   L_CLEAR1
        XOR    BX,BX                  ;Set cursor position 0,0
        CALL   L_SET_X
        CALL   L_SET_Y
        POP    SI
        POP    CX
        POP    BX
        RET

L_CLEAR_LINE:                        ;Clear line at [SI]. Note BX & DX changed
        MOV    CX,0                    ;Count for lines below
L_CLEAR_LINE1:
        MOV    BX,L_BELOW_SCREEN      ;SOURCE: Below bottom of screen (will  ✓
        display as background, see L_CLEAR_BUFFER)
        ADD    BX,CX
        MOV    DX,0                    ;X position is 0
        CALL   L_MAKE_24_ADDRESS      ;Generate LAVA 24 bit address DX+BX -> DX+  ✓
        BH

```

```

MOV     AL,COPY$MEMORY           ;Sent COPY MEMORY command
CALL    L_PULSE$WR
MOV     AL,BH
CALL    L_PULSE$WR               ;Source Address 23:16
MOV     AL,DH
CALL    L_PULSE$WR               ;Source Address 15:8
MOV     AL,DL
CALL    L_PULSE$WR               ;Source Address 7:0

MOV     AL,03H
CALL    L_PULSE$WR               ;Next two size bytes
MOV     AL,0FFH
CALL    L_PULSE$WR

MOV     AX,0
CALL    L_PULSE$WR               ;Filler byte

MOV     BX,SI                     ;DESTINATION:  Get Y position
ADD     BX,CX
MOV     DX,0                       ;X position is 0
CALL    L_MAKE_24_ADDRESS         ;Generate LAVA 24 bit address DX+BX -> DX+
BH
MOV     AL,BH
CALL    L_PULSE$WR               ;Send Address 23:16
MOV     AL,DH
CALL    L_PULSE$WR               ;Send Address 15:8
MOV     AL,DL
CALL    L_PULSE$WR               ;Send Address 7:0
INC     CX
CMP     CX,L_CHAR_HEIGHT
JNZ     L_CLEAR_LINE1
RET

L_CLEAR_EOL:                       ;Clear to EOL (Any X position to end of that line)
PUSH    BX
PUSH    CX
PUSH    DX
PUSH    SI
PUSH    DI
CALL    L_HIDE_CURSOR
CALL    L_GET_X                   ;GET X POSITION OF CURSOR IN BX (Number of
character positions)
PUSH    BX                       ;Save Cursor for when done

MOV     SI,BX                     ;>>> X Position in SI <<<
MOV     DX,L_CRT_WIDTH
SUB     DX,BX                     ;>>> Length in DX <<<< of line in delete area left
to EOL

CALL    L_GET_Y                   ;GET Y POSITION OF CURSOR IN BX (Number of
character positions)
MOV     DI,BX                     ;>>> Y Position in DI <<<

MOV     CX,0                       ;Count for lines for below
EOL_LINE1:                       ;Will move a clear memory block into the area
PUSH    DX                       ;Save data
MOV     BX,L_BELOW_SCREEN         ;SOURCE: Below bottom of screen (will
display as background, see L_CLEAR_BUFFER)
ADD     BX,CX
MOV     DX,SI
CALL    L_MAKE_24_ADDRESS         ;Generate LAVA 24 bit address DX+BX -> DX+
BH

MOV     AL,COPY$MEMORY           ;Sent COPY MEMORY command

```

```

CALL    L_PULSE$WR
MOV     AL,BH
CALL    L_PULSE$WR           ;Source Address 23:16
MOV     AL,DH
CALL    L_PULSE$WR           ;Source Address 15:8
MOV     AL,DL
CALL    L_PULSE$WR           ;Source Address 7:0

POP     DX                   ;Get back saved length
MOV     AL,DH
CALL    L_PULSE$WR           ;Next two size bytes
MOV     AL,DL
CALL    L_PULSE$WR
PUSH    DX                   ;Save length again

MOV     AX,0
CALL    L_PULSE$WR           ;Filler byte

MOV     BX,DI                ;DESTINATION:  Get Y position
ADD     BX,CX
MOV     DX,SI                ;X position is 0
CALL    L_MAKE_24_ADDRESS    ;Generate LAVA 24 bit address DX+BX -> DX+
BH
MOV     AL,BH
CALL    L_PULSE$WR           ;Send Address 23:16
MOV     AL,DH
CALL    L_PULSE$WR           ;Send Address 15:8
MOV     AL,DL
CALL    L_PULSE$WR           ;Send Address 7:0

POP     DX                   ;balance up stack
INC     CX
CMP     CX,L_CHAR_HEIGHT
JNZ    EOL_LINE1

POP     BX                   ;Get Back original Cursor position
CALL    L_SET_X
CALL    L_SHOW_CURSOR
POP     DI
POP     SI
POP     DX
POP     CX
POP     BX
RET

L_SCROLL_UP_1:                ;Move the whole screen up one line (quickly)
PUSH    BX
PUSH    CX
PUSH    SI
PUSH    DI
CALL    L_GET_Y
PUSH    BX                   ;Store it for when we return below
CALL    L_HIDE_CURSOR

MOV     CX,(L_CHAR_HEIGHT * L_SCREEN_LINES) - L_CHAR_HEIGHT    ;(Count for screen
scan lines below)
MOV     SI,L_CHAR_HEIGHT    ;Source, one line
down
MOV     DI,0                ;Destination, top
of screen

UP1:   MOV     BX,SI                ;SOURCE
MOV     DX,0                ;X position is 0
CALL    L_MAKE_24_ADDRESS    ;Generate LAVA 24 bit address DX+BX -> DX+BH

```

```

MOV     AL,COPY$MEMORY           ;Sent COPY MEMORY command
CALL   L_PULSE$WR
MOV     AL,BH
CALL   L_PULSE$WR               ;Source Address 23:16
MOV     AL,DH
CALL   L_PULSE$WR               ;Source Address 15:8
MOV     AL,DL
CALL   L_PULSE$WR               ;Source Address 7:0

MOV     AL,03H
CALL   L_PULSE$WR               ;Next two size bytes
MOV     AL,0FFH
CALL   L_PULSE$WR

MOV     AX,0
CALL   L_PULSE$WR               ;Filler byte

MOV     BX,DI                    ;DESTINATION
MOV     DX,0                     ;X position is 0
CALL   L_MAKE_24_ADDRESS         ;Generate LAVA 24 bit address DX+BX -> DX+BH
MOV     AL,BH
CALL   L_PULSE$WR               ;Send Address 23:16
MOV     AL,DH
CALL   L_PULSE$WR               ;Send Address 15:8
MOV     AL,DL
CALL   L_PULSE$WR               ;Send Address 7:0

INC     SI                       ;Next scan line
INC     DI
LOOP   UP1

MOV     SI,(L_CHAR_HEIGHT * L_SCREEN_LINES)
CALL   L_CLEAR_CURRENT_LINE

POP     BX                       ;Get Back original Y Cursor position
CALL   L_SHOW_CURSOR
POP     DI
POP     SI
POP     CX
POP     BX
RET

L_DEL_SPACE:                     ;DEL requires special treatment because LAVA does ✓
    not
    PUSH    BX                   ;Overwrite characters. ie a space will not delete a ✓
    character if overwritten
    PUSH    CX
    PUSH    DX
    CALL   L_HIDE_CURSOR
    CALL   L_GET_X
    JMP    L_PUT_SPACE

L_BACK_SPACE:                    ;Back space requires special treatment because LAVA ✓
    does not
    PUSH    BX                   ;Overwrite characters. ie a space will not delete a ✓
    character if overwritten
    PUSH    CX
    PUSH    DX
    CALL   L_HIDE_CURSOR
    CALL   L_GET_X
    CMP    BX,8
    JL    L_PUT_SPACE
    SUB    BX,8
    CALL   L_SET_X               ;Back space one character

```

```

L_PUT_SPACE:                                ;Print a space on Screen at current X,Y position
CALL    L_GET_COLOR
PUSH    BX                                  ;Save for below
MOV     BX,L_BLACK_COLOR                    ;The trick is to overlay with two ASCII
characters that fill the complete
CALL    L_SET_COLOR                          ;8X16 pixel area in black (If a different
background color, then change)

MOV     AL,DRAW$TEXT                          ;Send Draw Text Command
CALL    L_PULSE$WR
MOV     AL,1                                  ;Send 1 character only
CALL    L_PULSE$WR
MOV     AL,03H
CALL    L_PULSE$WR                          ;Send Ascii 'Heart figure"
MOV     AL,0
CALL    L_PULSE$WR                          ;send Ascii X2 (So we have an even number of bytes
sent)

MOV     AL,DRAW$TEXT                          ;Send Draw Text Command
CALL    L_PULSE$WR
MOV     AL,1                                  ;Send 1 character only
CALL    L_PULSE$WR
MOV     AL,08H
CALL    L_PULSE$WR                          ;Overlay with ASCII "Circle figure"
MOV     AL,0
CALL    L_PULSE$WR                          ;send Ascii X2 (So we have an even number of bytes
sent)

POP     BX                                    ;Get back color
CALL    L_SET_COLOR
CALL    L_SHOW_CURSOR
POP     DX
POP     CX
POP     BX
MOV     AL,BS                                ;Return with space in AL
RET

L_MAKE_24_ADDRESS:                          ;Generate LAVA 24 bit memory address from X in DX,
and Y in BX
MOV     AX,DX                                ;Get X address, isolate bits 8 & 9
AND     AH,03H
SHL     BX,1                                  ;Shift over Y by 2 bits
SHL     BX,1
OR      AH,BL                                ;Combine in lower 6 bits of Y coordinate
MOV     DH,AH
RET                                           ;Return Address 7:0 in DL, 15:8 in DH, and 23:16 in
BH

L_GET_X:
MOV     AL,READ$CSR                          ;READ Register command for X Position into BX
CALL    L_PULSE$WR                          ;Send
MOV     AL,0
CALL    L_PULSE$WR
MOV     AL,0
CALL    L_PULSE$WR
MOV     AL,01H                                ;Point to CSR_FONT_X
CALL    L_PULSE$WR
CALL    L_PULSE$2RD                          ;<<< Read 2 byte into [BX]
RET

L_GET_Y:
MOV     AL,READ$CSR                          ;READ Register command for Y Position into BX
CALL    L_PULSE$WR                          ;Send

```

```

MOV     AL,0
CALL   L_PULSE$WR
MOV     AL,0
CALL   L_PULSE$WR
MOV     AL,02H                ;Point to CSR_FONT_Y
CALL   L_PULSE$WR
CALL   L_PULSE$2RD           ;<<< Read 2 byte into [BX]
RET

```

```

L_SET_X:
MOV     AL,WRITE$CSR         ;WRITE Register command, X Position, data in BX
CALL   L_PULSE$WR           ;Send
MOV     AL,0
CALL   L_PULSE$WR
MOV     AL,0
CALL   L_PULSE$WR
MOV     AL,01H              ;Point to CSR_FONT_X
CALL   L_PULSE$WR
MOV     AL,BH
CALL   L_PULSE$WR
MOV     AL,BL
CALL   L_PULSE$WR
RET

```

```

L_SET_Y:
MOV     AL,WRITE$CSR         ;WRITE Register command, Y Position, data in BX
CALL   L_PULSE$WR           ;Send
MOV     AL,0
CALL   L_PULSE$WR
MOV     AL,0
CALL   L_PULSE$WR
MOV     AL,02H              ;Point to CSR_FONT_Y
CALL   L_PULSE$WR
MOV     AL,BH
CALL   L_PULSE$WR
MOV     AL,BL
CALL   L_PULSE$WR
RET

```

```

;Clear an area of the LAVA screen RAM for use with
Clear Line, EOL etc.
L_CLEAR_BUFFER:             ;We will us this for fast LAVA block moves etc.
MOV     BX,L_BELOW_SCREEN   ;Y position of RAM below bottom of visible screen
CLEARB2:MOV                 ;X position is 0
DX,0
CLEARB1:PUSH                BX
PUSH    DX
CALL    L_MAKE_24_ADDRESS   ;Generate LAVA 24 bit address DX+BX -> DX+
BH
MOV     AL,WRITE$MEMORY     ;Sent COPY MEMORY command
CALL   L_PULSE$WR
MOV     AL,BH               ;Address 23:16
CALL   L_PULSE$WR
MOV     AL,DH               ;Address 15:8
CALL   L_PULSE$WR
MOV     AL,DL               ;Address 7:0
CALL   L_PULSE$WR
MOV     AL,L_BLACK_COLOR    ;BLACK (0FH = Blue for testing)
CALL   L_PULSE$WR
MOV     AL,L_BLACK_COLOR    ;BLACK
CALL   L_PULSE$WR
POP     DX
POP     BX

```

```

INC     DX                      ;Are we at end of line
CMP     DX,L_CRT_WIDTH+10
JLE     CLEARB1
INC     BX                      ;Go to next scan line
CMP     BX,L_BELOW_SCREEN+L_CHAR_HEIGHT ;16 scan lines total
JLE     CLEARB2
RET

```

```

;----- LAVA CORE WRITE ROUTINE -----

```

```

;Note only [AL] altered
L_PULSE$WR: ;>>>> WRITE ONE BYTE OF DATA TO LAVA CHIP, Data in
    [AL] <<<<<
    OUT     LavaData,AL          ;Send [AL] to Lava data port (91H)
    MOV     AL,00000001B        ;Output enable U10 to LAVA data bus, and set LAVA
    to WRITE mode
    OUT     LavaStatus,AL       ;Send to lava status port (90H)
    MOV     AL,10000001B        ;Then pulse status port strobe bit LOW (Bit 7 high,
    pulsed strobe low)
    OUT     LavaStatus,AL       ;Send to lava status port (90H)
L_WR$NOT$RDY:
    IN      AL,LavaStatus       ;Wait until LAVA "Done" signal clears U12A. Then we
    are done
    AND     AL,80H              ;This will set strobe bit back HIGH. Note still in
    WRITE LAVA mode
    JZ     L_WR$NOT$RDY
    RET

```

```

;----- LAVA CORE READ ROUTINE -----

```

```

;Note only [AL] & [BX] altered
L_PULSE$2RD: ;>>>> READ TWO BYTES OF DATA FROM LAVA CHIP, Data
    in [BX] <<<<<
    MOV     AL,00001000B        ;Set to LAVA READ MODE, Disable U10 to LAVA data
    bus
    OUT     LavaStatus,AL       ;Send to lava status port (91H)
    MOV     AL,10001000B        ;Then pulse strobe bit LOW
    OUT     LavaStatus,AL       ;Send to lava status port (91H)
L_RD$NOT$RDY:
    IN      AL,LavaStatus       ;Wait until JAVA "Done" signal clears U12A. Then we
    are done
    AND     AL,80H              ;This will set strobe bit back HIGH. Note still in
    READ LAVA mode
    JZ     L_RD$NOT$RDY

    IN      AL,LavaData         ;Data [15:8] from port (90H)
    MOV     BH,AL               ;Save in BH

    MOV     AL,10001000B        ;Pulse strobe bit LOW
    OUT     LavaStatus,AL       ;Send to lava status port (91H)
L_RD$NOT$RDY1:
    IN      AL,LavaStatus       ;Wait until JAVA "Done" signal clears U12A. Then we
    are done
    AND     AL,80H              ;This will set strobe bit back HIGH. Note still in
    READ LAVA mode
    JZ     L_RD$NOT$RDY1

    IN      AL,LavaData         ;Now Second Byte
    MOV     BL,AL               ;Data [7:0] from port (90H)
    RET                         ;Return with data in [BX]

```

```

;*****
;
;   Console Input Handler   (Software Interrupt 16H)
;   Return with keyboard buffer character in AL
;
;Input: AH = 00h           KEYBOARD - GET KEYSTROKE
;
;Return:AH = BIOS scan code
;       AL = ASCII character
;
;       Note:   On extended keyboards, this function discards any extended
;               keystrokes,
;               returning only when a non-extended keystroke is available.
;               The BIOS
;               scan code is usually, but not always, the same as the
;               hardware scan
;               code processed by INT 09. It is the same for ASCII
;               keystrokes and most
;               unshifted special keys (F-keys, arrow keys, etc.), but
;               differs for shifted
;               special keys. Some (older) clone BIOSes do not discard
;               extended keystrokes
;               and manage function AH=00h and AH=10h the same.
;
;Input: AH = 01h           KEYBOARD - CHECK FOR KEYSTROKE
;
;Return:ZF set if no keystroke available
;       ZF clear if keystroke available
;       AH = BIOS scan code
;       AL = ASCII character
;
;       Note:   If a keystroke is present, it is not removed from the
;               keyboard buffer;
;               however, any extended keystrokes which are not compatible
;               with 83/84- key keyboards
;               are removed by IBM and most fully-compatible BIOSes in the
;               process of checking
;               whether a non-extended keystroke is available. Some (older)
;               clone BIOSes do not
;               discard extended keystrokes and manage function AH=00h and
;               AH=10h the same.
;
;Input: AH = 02h           KEYBOARD - GET SHIFT FLAGS
;
;Return:AL = shift flags (see below)
;       AH destroyed by many BIOSes
;
;       Bitfields for keyboard shift flags:-
;       7       Insert active
;       6       CapsLock active
;       5       NumLock active
;       4       ScrollLock active
;       3       Alt key pressed (either Alt on 101/102-key keyboards)
;       2       Ctrl key pressed (either Ctrl on 101/102-key keyboards)
;       1       left shift key pressed
;       0       right shift key pressed
;
;*****

CONIN:  sti
        push    ds
        push    bx
        XOR     BX,BX                ;Set DS to data area for ROM usage in low RAM @
        MOV     DS,BX                400H....)
;
Xconi0: or     ah,ah                ;read keyboard?
        jnz    con1                 ;skip if not

```



```

coni0:  TEST    byte[KB_FLAG_1],HOLD_STATE      ;Is Pause flag set
        JNZ    coni0
        mov    al,[chrCnt]                   ;any data in buffer?
        test   al,al
        je     coni0                         ;wait for a key
        mov    bx,[bufhd]                    ;get buffer address
        mov    al,[bx]                       ;character to al
        mov    ah,0                          ;scan code always zero
        inc    bx
        cmp    bx,keybuff+32                 ;at end of buffer?
        jl     coni0
        mov    bx,keybuff                   ;reset buffer address if so
coni00: mov    [bufhd],bx                    ;Store pointer to next character
        cli    ;turn off interrupts
        dec    byte [chrCnt]                ;while we adjust count
        sti
        pop    bx
        pop    ds
        iret    ;return char in AL, AH=0

coni1:  cmp    ah,1                          ;read status?
        jne    coni2                         ;skip if not
        mov    al,[chrCnt]                  ;get character count
        test   al,al                        ;Z-flag = availability
        mov    bx,[bufhd]
        mov    al,[bx]                      ;character to al
        mov    ah,0                          ;scan code = 0
coniirt: pop    bx
        pop    ds
        retf    2                            ;throw away flags

coni2:  cmp    ah,3                          ;read shift status
        jne    coni3
        mov    al,0                          ;set status to zero
coni3:  pop    bx
        pop    ds
        iret

```

```

;*****
;
;      Printer Output Handler      (Software Interrupt 17H)
;
;Input: AH = 00h      PRINTER - WRITE CHARACTER
;      AL = character to write
;      DX = printer number (00h-02h)
;
;Return:AH = printer status
;      Bitfields set for printer status:
;      7      not busy
;      6      acknowledge
;      5      out of paper
;      4      selected
;      3      I/O error
;      2-1    unused
;      0      timeout
;
;Input: AH = 01h      PRINTER - INITIALIZE PORT
;      DX = printer number (00h-02h)
;
;Return:AH = printer status (same as above)
;
;Input: AH = 02h      PRINTER - GET STATUS
;      DX = printer number (00h-02h)

```

```

;
;Return:AH = printer status (see above)
;
;*****
LST_OUT: PUSH    AX                ;Note we will assume only one printer
          PUSH    BX
          PUSH    CX
          CMP     AH,0              ;AH=0 Print Character
          JZ     PRN_CHAR
          CMP     AH,1
          JZ     INIT_PRN           ;AH=1 Initilize Printer (Set Font etc)
          JMP     STATUS_PRN        ;AH=2 Get status

PRN_CHAR:
          CALL    LIST_OUT1         ;AH = 0; Print a character (in AL) on printer
LDONE:   POP     CX
          POP     BX
          POP     AX
          XOR     AH,AH             ;Retur Z set (and AH = 0 ) if all OK
          IRET    ;<- Note IRET

STATUS_PRN:
          CALL    LIST_STATUS       ;Get List Status
          JZ     LDONE              ;Must be initilize or a status check. Same ending
          PSTAT: TEST    AL,00001000B ;If it matches xxxx0110B we are OK
          JNZ    PAPER_OUT         ;Test for paper out
          POP     CX                ;Else just return busy signal
          POP     BX
          POP     AX                ;Just in case return with character in AL
          MOV     AH,00000001B      ;return with timeout bit set
          IRET

PAPER_OUT:
          POP     CX
          POP     BX
          POP     AX                ;Just in case return with character in AL
          MOV     AH,00100000B      ;Flag for paper out
          IRET

INIT_PRN:
          MOV     BX,PRN_INIT_STR   ;Set Font etc.
INIT_PRN1:
          MOV     CL,[CS:BX]
          INC     BX
          OR     CL,CL
          JZ     LDONE
          CALL    LIST_OUT
          JMP     INIT_PRN1

LIST_OUT1:
          monitor section           ;Remember can be called by IBM BIOS section or the
          MOV     CL,AL              ;For BIOS interrupt printing character is in AL
LIST_OUT:
          MOV     CH,0FFH           ;Within this monitor character is in CL
          CALL    LIST_STATUS       ;Check status up to 255 times
          JZ     LIST_OK            ;XXXX0110 if ready
          DEC     CH
          JNZ    LO2
LIST_OK: MOV     AL,0FFH           ;Setup strobe high to low then high
          OUT     PRINTER_STROBE,AL
          MOV     AL,CL
          OUT     PRINTER_OUT,AL   ;Now Data
          MOV     AL,0FEH           ;Bit 0, STROBE FOR CENTRONICS
          OUT     PRINTER_STROBE,AL
          MOV     AL,0FFH           ;Raise strobe again
          OUT     PRINTER_STROBE,AL

```

```

    RET

LIST_STATUS:                                ;Remember can be called by IBM BIOS section or the ✓
    monitor section
    IN     AL,PRINTER_STATUS
CENSTAT:AND    AL,00001111B                ;XXXX0110 IS READY (BIT 3=PAPER BIT 2=FAULT
    CMP    AL,00000110B                    ;BIT 1=SELECT BIT 0=BUSY
    RET

;*****
;
;     BASIC Handler      (Software Interrupt 18h)
;
;*****

basic:  PUSH    AX
        PUSH    BX
        PUSH    CX
        MOV     BX,NO_BASIC_MSG            ;Announce we got an BASIC Interrupt
NO_INT_SUPPORT:
        CALL    PRINT_STRING              ;Common for warning about un-implemented int
        POP     CX                          ;Send msg pointed to by CS:BX
        section
        POP     BX
        POP     AX
        iret                                ;Remember IRET collects the saved Flags

;*****
;
;     Equipment Check Handler      (Software Interrupt 11H)
;
;*****

equip:  push    ds                            ;save data segment
        XOR     AX,AX                        ;Set DS to data area for ROM usage in low RAM @ ✓
        (400H....)
        MOV     DS,AX
        mov     ax,[EQFLAG]
        pop     ds
        iret

;*****
;
;     Memory Size Handler      (Software Interrupt 12H)
;     BIOS - GET MEMORY SIZE
;     Return:AX = kilobytes of contiguous memory starting at absolute address 00000h
;     Note: This call returns the contents of the word at 0040h: ✓
;     0013h;
;
;     in PC and XT, this value is set from the switches on ✓
;     the motherboard
;*****

memsiz: push    ds
        XOR     AX,AX                        ;Set DS to data area for ROM usage in low RAM @ ✓
        (400H....)
        MOV     DS,AX
        mov     ax,[memrsz]
        pop     ds
        iret

```

```

;*****
;
;       Interrupt 1Bh Keyboard Break
;
;*****

kbd_break:
    PUSH    AX
    PUSH    BX
    PUSH    CX
    MOV     BX,NO_BREAK_MSG           ;Announce we got an BREAK Interrupt
    jmp     NO_INT_SUPPORT

;*****
;
;       Interrupt 1Ch (28 Decimal)  User Timer Tic
;
;*****

user_timer:
    IRET                                ;Just return

;*****
;
;       Comm I/O Handler                (Software Interrupt 14H)
;
;       Note: We will leave it at 19,200 Baud (faster than on original PC)
;
;Input: AH = 00h          SERIAL - INITIALIZE PORT
;       AL = port parameters
;           Paramater Bit Description
;           7-5    data rate (110,150,300,600,1200,2400,4800,9600 bps)
;           4-3    parity (00 or 10 = none, 01 = odd, 11 = even)
;           2      stop bits (set = 2, clear = 1)
;           1-0    data bits (00 = 5, 01 = 6, 10 = 7, 11 = 8)
;       DX = port number (00h-03h)
;Return:AH = line status
;           Bit(s)  Description
;           7      carrier detect
;           6      ring indicator
;           5      data set ready
;           4      clear to send
;           3      delta carrier detect
;           2      trailing edge of ring indicator
;           1      delta data set ready
;           0      delta clear to send
;
;Input: AH = 01h          SERIAL - WRITE CHARACTER TO PORT
;       AL = character to write
;       DX = port number (00h-03h)
;Return:AH bit 7 clear if successful
;       AH bit 7 set on error
;       AH bits 6-0 = port status
;
;Input: AH = 02h          SERIAL - READ CHARACTER FROM PORT
;       AL = 00h (ArtiCom)
;       DX = port number (00h-03h)
;Return:AH = line status
;       AL = received character if AH bit 7 clear

```



```

        OUT        ACTL,AL
SIO_DONE:
        POP        CX                ;We will assume no problem, always!
        POP        BX
        POP        AX
        XOR        AH,AH
        IRET       ;Note IRET not RET

WR_SIO:                ;Write a character to SSC Channel A
        MOV        AH,AL            ;Store char in AH
        MOV        CX,256          ;Will try 256 times, then timeout
WR_SIO1:IN            AL,ACTL      ;(A0), Is SCC TX Buffer empty
        AND        AL,04H
        JNZ        SENDSER        ;NZ if ready to recieve character
        LOOP       WR_SIO1
BAD_SER:POP           CX
        POP        BX
        POP        AX
        XOR        AH,AH
        OR         AH,80H          ;Flag we have a problem
        IRET       ;Note IRET not RET

SENDSER:MOV          AL,AH
        OUT        ADTA,AL        ;(A2), Send it
        JMP        SIO_DONE

RD_SIO:                ;Read a character from SSC Channel A
        MOV        CX,256          ;Will try 256 times, then timeout
RD_SIO1:IN            AL,ACTL      ;(A0), Is SCC TX Buffer empty
        AND        AL,01H
        JNZ        GETSER        ;NZ if something there
        LOOP       RD_SIO1
        JMP        BAD_SER
GETSER:POP           CX            ;Get back everything
        POP        BX
        POP        AX
        XOR        AH,AH
        IN         AL,ADTA        ;(A2), return with data
        IRET       ;Note IRET not RET

SERIAL_OUT:            ;Simple write a character to SSC Channel#1 on
        S100Computers Serial IO Board
        MOV        AH,CL            ;Store char in AH
        PUSH       CX
        MOV        CX,256          ;Will try 256 times, then timeout
SERIAL_OUT1:IN        AL,ACTL      ;(A0), Is SCC TX Buffer empty
        AND        AL,04H
        JNZ        SERIAL_OUT2    ;NZ if ready to recieve character
        LOOP       SERIAL_OUT1
        POP        CX
        XOR        AH,AH
        OR         AH,80H          ;Flag we have a problem
        RET        ;Note RET not IRET
SERIAL_OUT2:
        MOV        AL,AH            ;(A2), Send it
        OUT        ADTA,AL        ;We will assume no problem, always!
        POP        CX
        XOR        AH,AH          ;Z for no problem
        RET        ;Note RET not IRET

```

```
;*****
```

```

;
;   Old Cassette Handler           (Software Interrupt 15H)
;   We will use this as a staging point for a far Jump if an extra
;   ROM is discovered during the BIOS initialization sequence
;   Things like SCSI adaptors etc.
;
;*****
CASSETTE:
    push    DS

    PUSH    AX

    XOR     AX,AX                ;Set DS to data area for ROM usage in low RAM @
    400H....)
    MOV     DS,AX
    CMP     byte [DEBUG_FLAG],0 ;Is Debug mode on
    JNZ    CASSETTE_DEBUG      ;If not 0 then send debug data

    PUSH    AX
    IN      AL,IOWRITE          ;If bit 3 of Port EFH is 0, Then force Debug
    Display
    AND     AL,08H
    POP     AX
    JNZ    Cassette1          ;If not 0, skip

CASSETTE_DEBUG:
    PUSH    AX
    PUSH    BX
    MOV     BX,INT_15H_MSG      ;"Int 15H (Cassette) AX="
    CALL    SERIAL_PRINT_STRING
    POP     BX
    POP     AX
    CALL    SERIAL_DISPLAY_REGISTERS ;Display Registers on serial port display (All
    registers retained)

Cassette1:
    POP     AX
    POP     DS

    CMP     AH,44H              ;Cirrus Logic VGA board used this to check BIOS is
    capable
    JNZ    Cassette2
    MOV     BX,VGA_OK_MSG
    CALL    PRINT_STRING       ;Send msg pointed to by CS:BX
    XOR     AX,AX
    CLC
    retf    2                  ;Remove the original status flags on return

Cassette2:
    CMP     AH,41H              ;Extenal Wait event (Unused)
    JZ     EXT_WAIT

    CMP     AH,0C0H
    JZ     GET_DESCRIPTION_TABLE

    CMP     AH,0C1H            ;RETURN EXTENDED-BIOS DATA-AREA SEGMENT ADDRESS
    (PS)
    JZ     EXT_BIOS_DATA

    CMP     AH,88H
    JZ     HIGH_RAM_CHECK

    PUSH    AX
    PUSH    BX

```



```

MOV     BX,INT_CX_MSG           ;"H CX="
CALL    SERIAL_PRINT_STRING
POP     AX                       ;Get CX
CALL    SERIAL_AX_HEXOUT

MOV     BX,INT_DX_MSG           ;"H DX="
CALL    SERIAL_PRINT_STRING
POP     AX                       ;Get DX
CALL    SERIAL_AX_HEXOUT

MOV     BX,H_MSG                 ;"H"
CALL    SERIAL_PRINT_STRING

POP     DX                       ;Restore everything
POP     CX
POP     BX
POP     AX
RET

```

```

;=====CORE SUPPORT ROUTINES =====

```

```

; Calculate length difference between DS:SI(end) and ES:DI(start)

```

```

CLENGTH:

```

```

MOV     AX,DS                     ;DS has segment of final value
MOV     CX,ES                     ;ES has segment of start value
SUB     AX,CX                     ;Check if finish is the next segment up
JZ     SAME_SEGMENT
CMP     AX,1000H                 ;Max length must be < 64K
JG     BAD_RANGE
MOV     AX,0FFFFH
SUB     AX,DI                     ;Calculate start up to end of segment
ADD     AX,SI                     ;Add in the part from the next segment up.
INC     AX                       ;Count = difference +1
MOV     CX,AX                     ;Return value in CX
RET

```

```

SAME_SEGMENT:

```

```

MOV     CX,SI
sub     CX,DI
CMP     CX,0FFFEH
JZ     BAD_RANGE
inc     cx                       ;count = difference +1
ret

```

```

BAD_RANGE:

```

```

PUSH    BX
PUSH    CX
MOV     BX,RangeErrMsg           ;Range error
CALL    PRINT_STRING
jmp     ToMonitor                 ;Note this will clean up the stack

```

```

; Send to console the address ES+DI ;CX Unchanged

```

```

SHOW_ADDRESS_ES:

```

```

push    cx
mov     ax,es
mov     cl,12
shr     ax,cl                     ;Get high nibble down to AL

```

```

    call    hexdigout
    MOV     BX,DI
    call    BX_HEXOUT           ;Then next 4 digits in BX
    call    BLANK
    pop     cx
    ret

SHOW_ADDRESS_ES_NOSPACE:      ;Same but no trailing blank
    push    cx
    mov     ax,es
    mov     cl,12
    shr     ax,cl              ;Get high nibble down to AL
    call    hexdigout
    MOV     BX,DI
    call    BX_HEXOUT         ;Then next 4 digits in BX
    pop     cx
    ret

;      BINARY OUTPUT           ;Send what is in [al] in bits
AL_BINOUT:                    ;No registers altered (except AL)
    push    cx
    mov     cx,8
binout1: push    cx
    shl     al,1
    jb     bout1
    mov     cl,'0'
    push    ax
    call    CO
    pop     ax
    jmp     binend
bout1:  mov     cl,'1'
    push    ax
    call    CO
    pop     ax
binend: pop     cx
    loop   binout1
    pop     cx
    ret

;      HEXCHK                 ;check for a valid HEX DIGIT
HEX_check:
    sub     al,'0'            ;convert to binary if ok set carry if problem
    jb     hret
    cmp     al,0ah
    cmc
    jnb    hret
    sub     al,7
    cmp     al,10
    jb     hret
    cmp     al,16
    cmc
hret:   ret

;  Send to console the address DS+SI      ;CX Unchanged

SHOW_ADDRESS_DS:
    push    cx                ;Same but send upper nibble of ds reg
    mov     ax,ds
    mov     cl,12
    shr     ax,cl            ;Get high nibble down to AL
    call    hexdigout

```

```

MOV     BX,SI
call    BX_HEXOUT           ;Then next 4 digits in BX
call    BLANK
pop     cx
ret

```

```

; Send to console the address SS+SI           ;Used (Only) by sector display routine. CX
Unchanged

```

SHOW_ADDRESS_SS:

```

push    cx                 ;Same but send upper nibble of ds reg
mov     ax,ss
mov     cl,12
shr     ax,cl              ;Get high nibble down to AL
call    hexdigout
MOV     BX,SI
call    BX_HEXOUT         ;Then next 4 digits in BX
call    BLANK
pop     cx
ret

```

```

; Get 4 bit value (1 digits) to AL. (BX, CX & DX Unchanged), terminator in AH -
normally 0

```

GET1DIGIT:

```

PUSH    BX
PUSH    CX
mov     bx,0               ;Default to 0H
call    CICO               ;1st Console input digit to AL
cmp     al,'0'            ;alphanumeric?
jb     bexit2
call    HEX_check         ;convert to binary and check it
jb     err2
POP     CX
POP     BX
RET                       ;Digit in AL

```

```

; Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged), terminator in AH -
normally 0

```

GET2DIGITS:

```

PUSH    BX
PUSH    CX
mov     bx,0               ;Default to 0H

call    CICO               ;1st Console input digit to AL
cmp     al,'0'            ;alphanumeric?
jb     bexit2
call    HEX_check         ;convert to binary and check it
jb     err2
add     bl,al              ;Move into BX
mov     cl,4
shl     bx,cl              ;shift in last addition to high nibble on BL

push    BX                 ;Just in case
call    CICO               ;2nd Console input digit to AL
pop     BX

cmp     al,'0'            ;alphanumeric?
jb     bexit2
call    HEX_check         ;convert to binary and check it
jb     err2
add     bl,al              ;Move into BX
MOV     AL,BL
MOV     AH,0               ;Ret 0 in AH if all OK

```

```

        POP     CX
        POP     BX
        ret

err2:   POP     CX                ;Cleanup stack
        POP     BX
        JMP     ERR                ;Then normal error exit

bexit2: cmp     al,' '                ;save terminator, if SP,CR accept only 1 digit
        je     bgood2
        cmp     al,', '
        je     bgood2
        cmp     al,CR
        je     bgood2
        cmp     al,ESC
        je     bgood2
        POP     CX                ;Cleanup stack
        POP     BX
        JMP     ERR                ;Then normal error exit

bgood2: mov     ah,al                ;Save SP,', ' or CR in AH
        MOV     BH,0
        mov     cl,4
        shr     bx,cl                ;shift down last addition to low nibble on BL
        MOV     AL,BL
        POP     CX
        POP     BX
        ret

```

; Get (up to) 16 bit value (4 digits) to DI. Termination byte in AH

```

GET4DIGITS:
        PUSH    BX
        PUSH    CX
        MOV     CX,5                ;4 characters maximum + CR
        mov     bx,0
loop4b: call    CICO                ;Console input to AL
        cmp     al,'0'                ;alphanumeric?
        jb     bexit
        push    cx
        mov     cl,4
        shl     bx,cl                ;shift in last addition
        pop     cx
        call    HEX_check            ;convert [AL] to binary and check it
        jb     AddressError
        add     bl,al
        loop   loop4b
        MOV     DI,BX
        POP     CX
        POP     BX
        ret                        ;Will return BX = xxxxH

```

; Get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
; If 5 digits, first digit entered to ES (BX,CX, DX unaltered)

```

GET5DIGITS:                                ;Will return ES=000xH, DI = xxxxH
        PUSH    BX
        PUSH    CX
        mov     cx,6                ;Max count of 5 characters + CR
loopb:   mov     bx,0                ;So initially ES=0, see below
        call    CICO                ;Console input to AL
        cmp     al,'0'                ;alphanumeric?
        jb     bexit

```

```

        push    cx                ;Save character count
        push    bx                ;force the highest nibble to ds:
        and     bx,0f000h
        mov     es,bx
        pop     bx
        mov     cl,4
        shl    bx,cl              ;shift in last addition
        pop     cx
        call   HEX_check          ;convert to binary and check it
        jb     AddressError
        add     bl,al
        loop   loopb              ;Do up to 5 characters

bexit:  MOV     DI,BX              ;Move data to DI
        cmp    al,' '             ;Terminate with a SP, ",", or CR only
        je     bgood
        cmp    al,', '
        je     bgood
        cmp    al,CR
        je     bgood
        jmp    ERR

bgood:  mov     ah,al              ;Save terminator
        POP    CX                 ;Balance up stack
        POP    BX
        ret

AddressError:
        MOV    BX,AddressErrMsg   ;Range error
        CALL  PRINT_STRING
        jmp    ToMonitor           ;Note this will clean up the stack

;      For debugging display

DEBUG_AX:
        PUSH   AX
        PUSH   BX
        PUSH   CX
        CALL  AX_HEXOUT
        POP    CX
        POP    BX
        POP    AX
        RET

;      CHECK FOR ^S or ESC AT CONSOL
CTRL_CHECK:
        call   CSTS
        cmp    al,0
        jz    ctlexit
        call   CICO
        cmp    al,'S'-40h         ;^S will pause
        jnz   ctlcchek           ;possibly ^C
xwait:  call   CSTS
        cmp    al,0
        jz    xwait
        ret

ctlcchek:
        cmp    al,ESC             ;ESC will abort
        jz    ERR
ctlexit:ret

```



```

AX_HEXOUT:                                     ;No registers altered
    PUSH    AX
    MOV     AL,AH
    CALL   AL_HEXOUT
    POP     AX
    CALL   AL_HEXOUT
    RET

;       AL_HEXOUT                               ;output the 2 hex digits in [AL]
AL_HEXOUT:                                     ;No registers altered
    push    ax
    push    cx
    push    ax
    mov     cl,4                               ;first isolate low nibble
    shr    al,cl
    call   hexdigout
    pop     ax
    call   hexdigout                           ;get upper nibble
    pop     cx
    pop     ax
    ret

hexdigout:
    and    al,0fh                               ;convert nibble to ascii
    add    al,90h
    daa
    adc    al,40h
    daa
    mov    cl,al
    call   CO
    ret

;   ROUTINE TO PRINT A STRING   CS:BX = START OF STRING   $ or 0 = FINISH

PRINT_STRING:
    push    cx
print1:  mov    al,[CS:bx]                       ;Note this routine does NOT assume DS = CS here.
    inc    bx                                   ;By using the CS over-ride we will always have
    cmp    al,'$'                               ;a valid pointer to messages at the end of this
    monitor
    jz     print2
    cmp    AL,0                                 ;Also terminate with 0's
    JZ     print2
    mov    cl,al
    call   CO
    jmp    print1
print2:  pop    cx
    ret

;   ROUTINE TO PRINT A STRING   TO S100Computers Serial Port #1   BX = START OF STRING   $ or 0 = FINISH
;   This routine is used mainly for Debugging the IBM BIOS section. No registers altered

SERIAL_PRINT_STRING:
    push    AX
    push    cx
sprint1:mov    al,[CS:bx]                       ;Note this routine does NOT assume DS = CS here.
    inc    bx                                   ;By using the CS over-ride we will always have
    cmp    al,'$'                               ;a valid pointer to messages at the end of this
    monitor
    jz     sprint2
    cmp    AL,0
    JZ     sprint2

```



```

        JB      C1C1
        CMP     AL, 'a'
        JB      BAD_CHAR
        CMP     AL, '{'
        JB      UPPER_CASE
        JMP     BAD_CHAR
UPPER_CASE:
        AND     AL, 5FH                ;THIS CONVERTS ALL LC->UC
C1C1:   PUSH    AX
        PUSH    CX
        MOV     CL, AL
        CALL   CO                    ;DISPLAY ON CONSOLE
        POP     CX
        POP     AX
        RET

;
BAD_CHAR:
        MOV     AL, BELL                ;SEND BELL TO INDICATE BAD DATA
        CALL   C1C1
        MOV     AL, '?'                ;SEND ? TO INDICATE BAD DATA
        JMP     C1C1

SPEAKOUT:                                ;Character in CL
        MOV     AL, 0H                ;Will try 256 times, then timeout
SOUT1:  PUSH    AX
        IN      AL, BCTL                ;Are we ready for a character
        AND     AL, 04H
        JNZ    SENDS
        POP     AX
        DEC     AL
        JNZ    SOUT1
        RET
SENDS:  POP     AX
        MOV     AL, CL
        OUT    BDTA, AL                ;Send it
        RET

;SPEAKTOMM THIS IS A ROUTINE TO SEND A STRING TO TALKER [BX] AT STRING
SPEAK_STRING:
        PUSH    CX
STOMM2: MOV     AL, [CS:BX]
        CMP     AL, '$'                ;Terminate with "$", CR or 0
        JZ     STOMM1
        OR     AL, AL
        JZ     STOMM1
        CMP     AL, CR
        JZ     STOMM1
        MOV     CL, AL
        CALL   SPEAKOUT
        INC     BX
        JMP     STOMM2
STOMM1: MOV     CL, CR                ;MUST END WITH A CR
        CALL   SPEAKOUT
        POP     CX
        RET

POO:    RET                            ;NO PUNCH OUTPUT AT THE MOMENT
RI:     MOV     AL, 1AH                ;NO READER AT THE MOMENT
        RET

```

```

NOT_DONE_WARNING:
    mov     bx,TO_BE_DONE           ;Signon notice
    call    PRINT_STRING           ;Note up until now stack was not used
    RET

;-----
;
;          <<<<<< MAIN PROTECTED MODE 32 BIT DIAGNOSTIC MENU >>>>>>
;-----

GO_TO_PMODE:
    xor     ah,ah                   ;Setup Protected mode descriptors.
    push   ax                       ;First check we have a 80386/80486 present
    popf                                ;push AX onto the stack
    pushf                               ;pop this value into the flag register
    pop     ax                       ;push flags onto the stack
    and    ah,0f0h                  ;...and get flags into AX
    cmp    ah,0f0h                  ;try to set the high nibble
    je     no386                    ;the high nibble is never 0f0h on a
    mov    ah,70h                   ;80386/80486!
    push   ax                       ;now try to set NT and IOPL
    popf
    pushf
    pop     ax
    and    ah,70h                   ;if they couldn't be modified, there
    jz     no386                    ;is no 80386/80486 installed
    jmp    PMODE2

no386:
    mov    bx,NOT386CPU_MSG         ;if there isn't a 80386/80486, put a msg
    call   PRINT_STRING            ;and exit
    RET

PMODE2:
    CLD                               ;Clear direction flag
    CLI                               ;Just in case
    MOV    AX,GDT_SEG               ;Will move the GDT tables to D000:0H in RAM ✓
    (up to max 0FFh, currently)
    MOV    ES,AX
    MOV    DI,GDT_OFFSET           ;<----- Will place GDT at 0D0000H in RAM
    MOV    AX,CS                   ;Actully not needed here (CS=DS), but want ✓
    general case
    MOV    DS,AX
    MOV    SI,Gdt
    MOV    CX,GDT_SIZE
    INC    CX
    REP    MOVSB                   ;Move tables to 0E000:0H RAM location
    ;[DS:SI] -> [ES:DI]

    ;Next setup the IDT table
    mov    bx,IDT_SEG              ;IDT_SEG starts at D000:100 to D000:900H in ✓
    RAM
    mov    es,bx
    mov    bx,IDT_OFFSET           ;Offset to start of IDT table
    mov    cx,100H                 ;Fill all (256 or 100H) 80386/80486 ✓
    interrupts initially with a default error trapping pointer
    mov    di,0

p_fill_ints:
    ;First fill up all 256 Int entries with the ✓

```

```

        default unassigned Int warning
mov     ax,PM_INT_JUMP_TABLE           ;Start of interrupt routines list (6 per
int)
add     ax,di
mov     word [es:bx],ax                ;Offset of unassigned int error routine in
IDT
mov     word [es:bx+2],PM_IDT_386     ;Protect mode 386 code segment for IDT jump
table
mov     byte [es:bx+4],0
mov     byte [es:bx+5],10001110B     ;P=1 (enable), DPL=0, 01110 = 80386/80486
Interrupt Gate (8EH)
mov     word [es:bx+6],0              ;Offset 31...16 (0, because PM_IDT_386 is
at start of IDT)

add     bx,8                           ;Point to next int entry
add     di,6                             ;Point to next int error routine (note RM
is only 5)
loop   p_fill_ints                      ;Fill in all 256 ebtries

CPU 386                                ;Allow 80386/80486 Opcodes

o32    LGDT   [dword CS:GdtDesc]         ;Initilize GDTR (for GdtDesc, see below)
o32    LIDT   [dword CS:IdtDesc]        ;Initilize IDTR (for IdtDesc, see below)

MOV     EAX,CR0                         ;Set to protected mode
OR      EAX,1
MOV     CR0,EAX                         ;<---- GOTO P MODE

                                           ;The CPU is now executing in 16-bit protected mode.
                                           ;Make a far jump in order to load CS with a
selector                                ;to our 32-bit executable code descriptor (GDT[1]
below).

o32    JMP     dword PM_CS_386:(PM_ROM_BASE+Start32) ;Long JMP to absolute Start32:
(PM_CS_386 in GDT)

;     DB     66H                         ;Alternatively we can write it like this!
;     DB     0EAH
;     DD     (PM_ROM_BASE+Start32)       ;Code starts at absolute 0E0000H
;     DW     PM_CS_386                   ;Note 08 = CS, is the GDT[1] addresss

[BITS 32]                               ;<<<<<<< We now need 32-bit instructions from now
on >>>

Start32:
MOV     AX,PM_DS_386                    ;GDT[2]: Writable (0-4GB)
MOV     DS,AX
MOV     ES,AX
MOV     FS,AX
MOV     GS,AX

MOV     SS,AX
MOV     ESP,STACK_SEG                   ;Get real mode current SP to ESP
SHL     ESP,4
MOV     EBX,STACK_POINTER
ADD     ESP,EBX                          ;Force to 000DFFFCH

MOV     EBX,MSG_PROTECTED
call   P_SPEAK_STRING                   ;Speak out the message "Protected Mode" (32 Bit
Code)

P_MODE_LOOP1:

```



```
CALL    P_PRINT_STRING
POP     EAX
CALL    P_EAX_HEXOUT

MOV     EBX,INT_EBX_MSG           ;"H EBX="
CALL    P_PRINT_STRING
POP     EAX
CALL    P_EAX_HEXOUT

MOV     EBX,INT_ECX_MSG           ;"H ECX="
CALL    P_PRINT_STRING
POP     EAX
CALL    P_EAX_HEXOUT

MOV     EBX,INT_EDX_MSG           ;"H EDX="
CALL    P_PRINT_STRING
POP     EAX
CALL    P_EAX_HEXOUT

MOV     EBX,INT_ESI_MSG           ;"ESI="
CALL    P_PRINT_STRING
POP     EAX
CALL    P_EAX_HEXOUT

MOV     EBX,INT_EDI_MSG           ;"EDI="
CALL    P_PRINT_STRING
POP     EAX
CALL    P_EAX_HEXOUT

MOV     EBX,INT_EBP_MSG           ;"EBP="
CALL    P_PRINT_STRING
POP     EAX
CALL    P_EAX_HEXOUT

MOV     EBX,INT_ESP_MSG           ;[ESP]=
CALL    P_PRINT_STRING
POP     EAX
ADD     EAX,20H                   ; Adjust because we first saved stuff above
(PUSHAD)
CALL    P_EAX_HEXOUT

MOV     EBX,INT_DR0_MSG           ;[DR0]=
CALL    P_PRINT_STRING
MOV     EAX,DR0
CALL    P_EAX_HEXOUT

MOV     EBX,INT_DR1_MSG           ;[DR1]=
CALL    P_PRINT_STRING
MOV     EAX,DR1
CALL    P_EAX_HEXOUT

MOV     EBX,INT_DR2_MSG           ;[DR2]=
CALL    P_PRINT_STRING
MOV     EAX,DR2
CALL    P_EAX_HEXOUT

MOV     EBX,INT_DR3_MSG           ;[DR3]=
CALL    P_PRINT_STRING
MOV     EAX,DR3
CALL    P_EAX_HEXOUT

MOV     EBX,INT_DR6_MSG           ;[DR6]=
CALL    P_PRINT_STRING
MOV     EAX,DR6
CALL    P_EAX_HEXOUT
```

```

MOV     EBX,INT_DR7_MSG           ;[DR7]=
CALL    P_PRINT_STRING
MOV     EAX,DR7
CALL    P_EAX_HEXOUT

MOV     EBX,INT_FLAGS_MSG        ;[Flags]=
CALL    P_PRINT_STRING
PUSHFD
PUSHFD
POP     EAX                       ;Flags to EAX
MOV     AL,AH
CALL    P_AL_BINOUT              ;Output lower 16 bits
POP     EAX
CALL    P_AL_BINOUT
CALL    P_BLANK
CALL    P_BLANK
POPAD
RET

```

;----- 32 BIT SWITCH CONTROL BACK TO Z80 (Master) -----

```

P_Z80:  in      al,SW86            ;This switches control back over to Z80
NOP
NOP
MOV     AL,00                    ;Utilize the more specific circuit on the V2-SMB
OUT     SW_TMAX,AL              ;Make sure its bit 0 this raises TMA0*
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP
JMP     P_MODE_LOOP            ;Currently this will never happed because slave
mode always starts from a reset of CPU

```

;-----32 BIT MAP the 0-4GB MG Addresss space -----

```

P_MAP:  call    P_CRLF            ;Display complete memory map with R=ram, P=PROM and
      "." empty space
mov     eax,0
mov     dl,64                    ;character count
mov     ESI,eax                 ;need to reset ESI
call    P_SHOW_ADDRESS_ESI      ;Start with address, Send to console the address
ESI

p_map1: mov     eax,[ESI]         ;Get data
mov     ebx,eax                 ;save it here
mov     ecx,[ESI+4]             ;save this also, see below
not     eax                     ;change data
mov     [ESI],eax              ;Write it back
nop
nop
mov     [ESI+4],ebx            ;Clear floating data lines if no RAM present (else
old data can remain briefly)
nop
nop
cmp     eax,[ESI]              ;did above RAM change
jnz     p_not_ram              ;did not, then not RAM
mov     [ESI],ebx              ;put back original data
mov     [ESI+4],ecx
mov     cl,'R'

```



```

        jmp     p_nextbk             ;get next block

p_not_ram:
    mov     eax,0ffffffffh
    cmp     eax,[ESI]               ;is data FFFFFFFFh, probably ROM if not so
    jne     p_prom
    mov     cl, '.'                 ;no need to correct data for here
    jmp     p_nextbk               ;get next block
p_prom:  mov     cl, 'p'

p_nextbk:
    call    P_CO                    ;send the R,P or "."

    ADD     ESI,2000H                ;check every 2000h at a time
    dec     dl                       ;64X1000H across
    jnz     p_map1                  ;one line of 64K done

    mov     dl,64                    ;reset counter for next line
p_mapdone1:
    CALL    P_CRLF_CHECK             ;Send CR/LF then check for ESC
    call    P_SHOW_ADDRESS_ESI      ;Print current address at start of each line
p_mapdone:
    CMP     ESI,1000000H             ;Is first 16 MB done
    jb     p_map1                   ;No, more of same (Was jl. Correction)
    jg     over_S100_range

    PUSHAD                           ;At 100000H print warning
    MOV     EBX,ABOVE_16MB_MSG       ;"Above S-100 Bus 16M Range"
    CALL    P_PRINT_STRING
    call    P_SHOW_ADDRESS_ESI      ;Print current address at start of each line
    POPAD

over_S100_range:
    CMP     ESI,2000H                ;No wrap around from 4GB done!
    jle     P_MODE_LOOP             ;<< We are done
    jmp     p_map1                   ;No, more of same

;----- 32 BIT Display memory contents (bytes) -----
;
P_DISPLAY_RAM_BYTES:
    CALL    P_GET8DIGITS_ESI         ;Get (up to) 32 bit parameter. (8 digits) to ESI.
    PUSH    ESI                       ;Save start address in ESI.

    CALL    P_GET8DIGITS_ESI
    MOV     EDI,ESI                   ;Put end address in EDI

    POP     ESI                       ;Start=ESI End=EDI
    CMP     EDI,0                     ;If 0, then just start Address = 100H
    JNZ     NOT_DEFAULT
    MOV     EDI,ESI
    ADD     EDI,100H

NOT_DEFAULT:
;    AND     ESI,0FFF0h               ;even up printout
;    OR      EDI,000Fh                ;also nice ending for Ray G.

    mov     ebx,edi
    sub     ebx,esi
    inc     ebx                       ;Length ebx = (edi-esi)+1

p_dloop6:
    CALL    P_CRLF_CHECK             ;Note EBX,ECX is saved, ESC at keyboard will abort
    call    P_SHOW_ADDRESS_ESI      ;Send start address (in ESI)

```

```

MOV     DL,16                ;First print a line of 16 Hex byte values
PUSH   EBX                  ;Save current length
PUSH   EDI                  ;Save end address
PUSH   ESI                  ;save current (start) address

p_dloop1:
mov     al,[esi]             ;Will increment ESI
call   P_AL_HEXOUT
call   P_BLANK
inc     esi                  ;Next byte
DEC     DL                  ;Have we done 16 bytes yet
jnz    p_dloop1

                                ;Now print ascii for those 16 bytes
mov     cx,4
call   P_TABS

MOV     DL,16                ;16 across again
POP     ESI
POP     EDI
POP     EBX

p_dloop2:
mov     al,[ESI]
and     al,7fh
cmp     al,' '               ;filter out control characters
jnc    p_dloop3

p_dloop4:
mov     al,','
p_dloop3:
cmp     al,'~'
jnc    p_dloop4
mov     cl,al
call   P_CO

DEC     EBX
jnz    p_dloop5             ;--ECX has total byte count
JMP    P_MODE_LOOP         ;<<< we are done

p_dloop5:
INC     ESI                 ;Next Byte
DEC     DL                  ;Have we done 16 bytes yet
jnz    p_dloop2
JMP    p_dloop6

;-----32 Bit FILL Memory -----
--

P_FILL:
CALL   P_GET8DIGITS_ESI     ;Get (up to) 32 bit parameter. (8 digits) to ESI.
PUSH   ESI                 ;Save start address in ESI.

CALL   P_GET8DIGITS_ESI
MOV    EDI,ESI             ;Put end address in ESI

CALL   P_GET8DIGITS_ESI
MOV    DX,SI               ;Put value address in DL

POP    ESI                 ;Start=ESI End=EDI

mov    ecx,edi
sub    ecx,esi
inc    ecx                 ;Length ecx = (edi-esi)+1

PUSH   ECX                 ;Save for check Below
PUSH   ESI

```

```

P_FILL1:
    mov     [esi],dl
    inc     esi
    loop   P_FILL1                ;count down ecx

    POP     ESI                    ;Check fill went OK
    POP     ESI
    MOV     EDX,10                ;Show at most 10 errors

    JMP     P_MODE_LOOP           ;<<< we are done

;-----32 Bit MOVE Memory -----
--

P_MOVE: CALL     P_GET8DIGITS_ESI    ;Get (up to) 32 bit parameter. Up to 8 digits to
    ESI.
    PUSH    ESI                    ;Save START address for now.

    CALL    P_GET8DIGITS_ESI
    MOV     EDX,ESI                ;Temporly put END address in EDX

    CALL    P_GET8DIGITS_ESI
    MOV     EDI,ESI                ;Put NEW location start address in EDI

    POP     ESI                    ;Get back start address

    mov     ecx,edx                ;END ADDRESS -> ECX
    sub     ecx,esi                ;Length ecx = (edx-esi)+1
    inc     ecx

    PUSH    ECX                    ;Save them for check when done (see below)
    PUSH    ESI
    PUSH    EDI

P_MOVE1:
    MOV     AL,[ESI]                ;Now move them.
    MOV     [EDI],AL                ;Could get fancy but lets keep it simple
    INC     ESI
    INC     EDI
    loop   P_MOVE1

    POP     EDI                    ;Check they are the same
    POP     ESI
    POP     ECX
    MOV     EDX,10                ;Show at most 10 errors

P_MOVE_CHK:
    MOV     AL,[ESI]
    CMP     AL,[EDI]
    JNZ    P_BAD_MOVE              ;Flag first error

P_MOVE_CHK1:
    INC     ESI
    INC     EDI
    LOOP   P_MOVE_CHK
    JMP     P_MODE_LOOP           ;<< we are done

P_BAD_MOVE:
    PUSHAD                            ;temp everything
    MOV     EBX,BAD_MOVE_MSG        ;"Error(s) with move"
    CALL    P_PRINT_STRING
    MOV     EAX,ESI
    CALL    P_EAX_HEXOUT

```

```

    MOV     EBX,H_MSG_CRLF           ;H,CRLF.
    CALL    P_PRINT_STRING
    POPAD
    DEC     EDX
    JZ      P_BAD_MOVE_DONE
    JMP     P_MOVE_CHK1             ;See if more

P_BAD_MOVE_DONE:
    MOV     EBX,MORE_BAD_MOVE_MSG   ;"If over 10 just abort"
    CALL    P_PRINT_STRING
    JMP     P_MODE_LOOP            ;<< we are done

;-----SUBSTITUTE Memory -----
-

P_SUBSTITUTE:
    CALL    P_GET8DIGITS_ESI        ;Get (up to) 32 bit parameter. 16 bit value (8
    digits) to ESI.

p_nusloop:
    CALL    P_CRLF
    call    P_SHOW_ADDRESS_ESI     ;Send start address
    mov     cx,8                   ;Display 8 bytes per line

p_sloop:
    call    P_BLANK
    mov     al,[ESI]
    push   ecx
    push   eax
    call    P_AL_HEXOUT
    mov     cl,'-'
    call    P_CO
    pop     eax
    pop     ecx
    call    P_GET2DIGITS            ;Get 8 bit value (2 digits) to AL. (BX, CX & DX
    Unchanged), terminator in AH
    cmp     ah,CR                  ;CR signals we are done
    je     p_qtest
    cmp     ah,ESC                 ;Also ESC
    je     p_qtest
    cmp     ah,' '                 ;is a SP so skip to next byte
    je     p_snext1
    mov     [ESI],al

p_snext1:
    inc     ESI
    loop   p_sloop
    jmp    p_nusloop
p_qtest:JMP P_MODE_LOOP            ;<< we are done

;-----32 Bit Verify Memory Contents -----
---

P_VERIFY:CALL P_GET8DIGITS_ESI     ;Get (up to) 32 bit parameter. Up to 8 digits) to
    ESI.
    PUSH   ESI                    ;Save start address (in ESI) for now .

    CALL    P_GET8DIGITS_ESI     ;Put end address in ESI
    POP     EDI                   ;Start in EDI

    call    P_CLENGTH             ;Length ecx = (esi-edi)+1
    PUSH   ECX                   ;Save length, just in case

    CALL    P_GET8DIGITS_ESI     ;Put new location start address in ESI

```

```

        MOV     EBP,0                ;Count of mis-matches flag in EBP

        MOV     EBX,LISTMATCHES      ;Describe range
        CALL    P_PRINT_STRING
        MOV     EAX,EDI
        CALL    P_EAX_HEXOUT         ;First Location =

        MOV     EBX,LISTMATCHES2     ;Second Location =
        CALL    P_PRINT_STRING
        MOV     EAX,ESI
        CALL    P_EAX_HEXOUT

        MOV     EBX,LISTMATCHES3     ;Range =
        CALL    P_PRINT_STRING
        POP     ECX                   ;Get back length
        MOV     EAX,ECX
        CALL    P_EAX_HEXOUT

        MOV     EBX,H_MSG_CRLF
        CALL    P_PRINT_STRING

        ECX
P_VERIFY1:
        MOV     AL,[EDI]              ;Could use fancy things line cmps but lets keep it ✓
        simple
        CMP     AL,[ESI]
        JZ      P_MATCH_OK
        call    p_verr                ;If mismatch error show actual data

P_MATCH_OK:
        INC     EDI
        INC     ESI
        DEC     ECX
        JNZ    P_VERIFY1             ;Not done yet.

        CMP     EBP,0                ;Was there any errors during whole test
        JNZ    P_TOTAL_MISMATCHES    ;Non Zero if at least one
        MOV     EBX,MATCHES_OK        ;Say none were found if so
        CALL    P_PRINT_STRING

P_TOTAL_MISMATCHES:
        JMP     P_MODE_LOOP          ;<< we are done

p_verr:  CMP     EBP,0                ;Save count, print error
        JNZ    P_SKIP_DIFF_MSG

        MOV     EBX,DIFF_Header_Msg  ;If first error, print heading
        CALL    P_PRINT_STRING

P_SKIP_DIFF_MSG:
        CALL    P_CRLF                ;There is a mis-match show values
        PUSH   ECX                    ;Save total count
        PUSH   ESI                    ;Save for below

        MOV     ESI,EDI
        call    P_SHOW_ADDRESS_ESI

        MOV     ECX,3
        call    P_TABS
        mov     al,[EDI]              ;First RAM value
        call    P_AL_HEXOUT
        call    P_BLANK
        call    P_AL_BINOUT

        MOV     ECX,5
        call    P_TABS

```

```

    POP     ESI                ;Get second location value
    call    P_SHOW_ADDRESS_ESI ;Show second address

    MOV     ECX,3
    call    P_TABS
    mov     al,[ESI]
    call    P_AL_HEXOUT        ;Second RAM Value
    call    P_BLANK
    call    P_AL_BINOUT

    POP     ECX                ;Get back range
    call    P_CTRL_CHECK
    INC     EBP                ;This prevents the header being show each time
    ret

;-----32 Bit DISPLAY Double Words Memory -----
;
; This routine forces the CPU to do RAM Double Word reads rather than byte reads.
; It is used to test the hardware's ability to do 32 bit reads on odd and even
; addresses.
; This is very important. "Normal" byte reads will not show such a hardware problem.
; A block or RAM/ROM read with the "D" & "T" commands must be identical

P_DISPLAY_RAM_DWORDS:
    CALL    P_GET8DIGITS_ESI   ;Get (up to) 32 bit parameter. (8 digits) to ESI.
    PUSH    ESI                ;Save start address for now.

    CALL    P_GET8DIGITS_ESI
    MOV     EDI,ESI            ;Put end address in EDI

    POP     ESI                ;Start=ESI End=EDI
    CMP     EDI,0              ;If 0, then just start Address = 100H
    JNZ     NOT_TDEFAULT
    MOV     EDI,ESI
    ADD     EDI,100H

NOT_TDEFAULT:
;    POP     ESI                ;Start=ESI End=EDI (Error remove extra POP ESI)
;
;    AND     ESI,0FFF0h         ;even up printout
;    OR      EDI,000Fh         ;also nice ending for Ray G.

    mov     ebx,edi
    sub     ebx,esi
    inc     ebx                ;Length ebx = (edi-esi)+1

p_ddloop6:
    CALL    P_CRLF_CHECK       ;Note EBX,ECX is saved, ESC at keyboard will abort
    call    P_SHOW_ADDRESS_ESI ;Send start address

    MOV     DL,4                ;First print a line of 16 Hex byte values (2 DW's)
    PUSH    EBX                ;Save current length for below
    PUSH    EDI                ;Save end address
    PUSH    ESI                ;save current (start) address

p_ddloop1:
    mov     eax,[esi]          ;Will increment ESI
    call    P_AL_HEXOUT
    call    P_BLANK
    shr     eax,8
    call    P_AL_HEXOUT
    call    P_BLANK

```

```

    shr     eax,8
    call    P_AL_HEXOUT
    call    P_BLANK
    shr     eax,8
    call    P_AL_HEXOUT
    call    P_BLANK
    inc     esi                ;Next byte
    inc     esi
    inc     esi
    inc     esi
    DEC     DL                ;Have we done 16 bytes yet
    jnz     p_ddloop1
                                ;Now print ascii for those 16 bytes
    mov     cx,4              ;first send 4 spaces
    call    P_TABS

    POP     ESI
    POP     EDI
    POP     EBX
    MOV     DL,4              ;4X4 across again

p_ddloop2:
    MOV     DH,4              ;1,2,3,4 bytes in eax
    mov     eax,[ESI]
p_ddloop2x:
    and     al,7fh
    cmp     al,' '           ;filter out control characters
    jnc     p_ddloop3
p_ddloop4:
    mov     al,'.'
p_ddloop3:
    cmp     al,'~'
    jnc     p_ddloop4
    mov     cl,al
    call    P_CO
    shr     eax,8
    dec     dh                ;4 bytes per DW
    jnz     p_ddloop2x

    SUB     EBX,4
    CMP     EBX,3            ;In case we have an odd boundary
    jge     p_ddloop5       ;EBX has total byte count
    JMP     P_MODE_LOOP     ;<<< we are done

p_ddloop5:
    inc     esi                ;Next byte
    inc     esi
    inc     esi
    inc     esi
    DEC     DL                ;Have we done 4X4 bytes yet
    jnz     p_ddloop2
    JMP     p_ddloop6

;----- 32 BIT QUERY PORTS -----

P_QUERY:
    call    P_CICO           ;is it input or output
    cmp     al,'I'
    jz     p_input
    cmp     al,'O'
    jz     p_output
    jmp     P_ERR           ;if not QI or QO then error

p_input:call    P_GET4DIGITS_ESI    ;Get 8 or 16 bit value (2 or 4 digits) to ESI

```

```

    call    P_CRLF
    mov     dx,si
    in     al,dx                ;Note will assume here we have just an 8 bit port
    push   ax
    call   P_AL_HEXOUT         ;Show value in HEX
    call   P_BLANK
    pop    ax
    call   P_AL_BINOUT        ;Show value in binary
    JMP    P_MODE_LOOP       ;<<< we are done

```

p_output:

```

    call   P_GET4DIGITS_ESI   ;Get 8 or 16 bit value (2 or 4 digits) to ESI
    mov    dx,si
    CALL   P_GET2DIGITS_ESI  ;Port output value to AL (BX unaltered)
    mov    ax,si
    PUSH  AX
    CALL   P_CRLF
    CALL   P_CRLF
    POP   AX
    out   dx,al              ;Send 8 bit value in AL to port at [DX]
    CALL   P_CRLF
    JMP    P_MODE_LOOP       ;<<< we are done

```

```

;----- (32 BIT) GO TO AN ABSOLUTE LOCATION IN RAM -----
; Remember code has to be in 32 bit mode at that location

```

```

P_GOTO: mov     ebx,GET_ABS_LOC      ;"RAM Location (32 Bit address, <<< NOTE MUST BE PM
        CODE >>>> ) ="
    call   P_PRINT_STRING
    call   P_GET8DIGITS_ESI        ;Get (up to) 32 bit value (8 digits) to ESI.
    mov    ebx,WILL_JUMP_TO
    call   P_PRINT_STRING
    MOV    EAX,ESI
    CALL   P_EAX_HEXOUT
    mov    EBX,H_MSG_CRLF         ;H,CRLF.
    CALL   P_PRINT_STRING
    JMP    ESI

```

```

;-----Execute Code in PM at an address > 16MB RAM -----

```

```

P_EXE_IN_PM_RAM:
    mov    ebx,EX_CODE_MSG        ;Will test PM execution in extended memory forever
    call   P_PRINT_STRING

    CALL   P_GET8DIGITS_ESI        ;Get (up to) 32 bit parameter. 32 bit value (up to
    8 digits) to ESI.
    MOV    EDX,ESI                ;Save it for far jump below
    PUSH  ESI                    ;Save ESI will point to where we want to place the
    test code.

    mov    EBX,EX_CODE1_MSG        ;Show location
    call   P_PRINT_STRING
    MOV    EAX,ESI
    CALL   P_EAX_HEXOUT            ;Show count so far
    mov    ebx,EX_CODE2_MSG        ;Say ESC to abort
    call   P_PRINT_STRING

    MOV    ESI,TEST_EXE_CODE       ;For 32 bit address need to add in "offset" to RM
    Monitor location
    MOV    EAX,PM_ROM_BASE        ; (Normaly E0000H or F0000H)
    ADD    ESI,EAX                ;We now have the correct location of the code below
    .

```



```

MOV     ECX, CODE_LENGTH+4      ;Extra to be on the safe side!
POP     EDI                     ;ESI->EDI will now point to where we want to place
the test code (from above).

;This code will be relocated to extended RAM before
being executed
MORE_CODE:
MOV     AL, [ESI]               ;Do it in a simple format/nothing fancy to be safe
MOV     [EDI], AL
INC     ESI
INC     EDI
DEC     ECX
JNZ     MORE_CODE
JMP     EDX                     ;Jump directly to that location now containing the
PM code in high RAM

TEST_EXE_CODE:
IN      AL, IOBYTE              ;Continuously display the IOBYTE port value on the
screen
AND     AL, 7FH
MOV     CL, AL
P_COX:  IN      AL, KEYSTAT      ;PROPELLER CONSOLE (or SD SYSTEMS) VIDIO BOARD PORT
AND     AL, 4H
JZ      P_COX
MOV     AL, CL
OUT     KEYOUT, AL
MOV     ECX, 0FFFFFFH          ;Next do a local PM RAM RD/WR Loop many times
P_COX2: MOV     AL, [EDX]        ;Direct PM RAM byte read and writes
MOV     [EDX], AL
MOV     AX, [EDX]              ;Direct PM RAM word read and writes
MOV     [EDX], AX
MOV     EAX, [EDX]             ;Direct PM RAM DWord read and writes
MOV     [EDX], EAX
DEC     ECX
JNZ     P_COX2
IN      AL, KEYSTAT
TEST    AL, 02H                ;Check if something is there
JZ      TEST_EXE_CODE
IN      AL, KEYIN
AND     AL, 7FH
CMP     AL, ESC
JNZ     TEST_EXE_CODE
JMP     dword PM_CS_386:(PM_ROM_BASE+Start32) ;Long JMP to absolute Start32:
(PM_CS_386 in GDT)

CODE_LENGTH EQU ($ - TEST_EXE_CODE) ;Size of code to move, in bytes

;----- 32 BIT HEX MATH -----
P_HEXMATH:
mov     ebx, MATH_MSG           ;HEX MATH
call    P_PRINT_STRING

call    P_GET8DIGITS_ESI
push   ESI                     ;save data for the moment

call    P_GET8DIGITS_ESI
MOV     EDI, ESI

mov     ebx, MATH_HEADER1
call    P_PRINT_STRING
pop     ESI                     ;Get back data1
MOV     EAX, ESI                ;First show sum
add     EAX, EDI

```



```

        CALL    P_CRLF
        JMP     P_SOFT_INTS
P_BAD_SOFT_40_CHECK:
        CALL    P_CRLF
        INT     40H
        CALL    P_CRLF
        JMP     P_SOFT_INTS
P_BAD_SOFT_F0_CHECK:
        CALL    P_CRLF
        INT     0F0H
        CALL    P_CRLF
        JMP     P_SOFT_INTS

P_NOT_FAULTS:
        CALL    P_CRLF
        MOV     BX,INT_RANGE_MSG
        CALL    P_PRINT_STRING
        JMP     P_SOFT_INTS
P_INTS_DONE:
        JMP     P_MODE_LOOP

```

```

;----- Run diagnostic tests on the 8259A PIC in protected mode. -----
;Configured below for the S100Computers PIC/RTC S-100 and MSDOS Support Boards

```

```

P_TEST_8259:                                ;"L" Test 8259A hardware
        mov     ebx,PIC_SIGNON              ;Send a signon message
        call    P_PRINT_STRING

        ;First swap out the "PM_Core_INT_Routine"
        routine in the 256
        ;default interrupts collection (starting at
        P_INT_JUMP_TABLE)
        ;with a specilized keypress one for this
        test. The rest of the IDT
        ;table is already setup (at p_fill_ints:)

        mov     [PM_BUFFER_START],dword keybuff ;Pointer for start of keyboard
        buffer
        mov     [PM_BUFFER_END],dword keybuff ;Pointer for end of keyboard buffer
        (start=end)
        mov     byte [chrcnt],0              ;No characters so far

        mov     al,11111111b                 ;Block all INTs initially
        out     MASTER_PIC_PORT+1,al

        mov     al,MasterICW1                ;Initilize the 8259A PIC Controller
        out     MASTER_PIC_PORT,al
        mov     al,PM_MasterICW2             ;Relocate PM Ints to start at Int# 108H in
        IDT
        out     MASTER_PIC_PORT+1,al
        mov     al,MasterICW4                ;No slaves above, so 8259 does not expect
        ICW3
        out     MASTER_PIC_PORT+1,al

        mov     al,11111101b                 ;Allow V1 on 8259A now (Will trigger INT#
        41H)
        out     MASTER_PIC_PORT+1,al
        sti
        ;Enable hardware interrupts

        MOV     EBX,IN_CHAR_MSG              ;'Type character characters'
        CALL    P_PRINT_STRING

PT5_8259:
        NOP
        ;<<< MAIN LOOP
        ;Allow CPU time to pickup the INT

```

```

NOP
NOP
NOP

    cmp     byte[chrCnt],0           ;Any data in buffer?
    JZ     PT5_8259
    cli                    ;turn off interrupts while doing what is
    below
    mov     dword ebx,[PM_BUFFER_START] ;Get current buffer start pointer address.
    mov     al,[ebx]                ;character to al
    mov     ah,0                    ;scan code always zero
    inc     ebx                       ;Step pointer along
    mov     dword [PM_BUFFER_START],ebx ;Store destination address
    cmp     ebx,dword keybuff+32     ;at end of buffer?
    jl     p_coni00
    mov     [PM_BUFFER_START],dword keybuff ;Reset pointer to start of keyboard buffer
p_coni00:
    dec     byte [chrCnt]            ;Adjust count

    CMP     AL,ESC
    JZ     PT6_8259                 ;We are done if an ESC character
    MOV     CL,AL
    CALL    P_CO                     ;Display character recieved
    sti                    ;Ints back on
    JMP     PT5_8259                 ;<< BACK TO START OF LOOP

PT6_8259:
    mov     al,11111111b            ;Do not Allow V1 on 8259A again
    out     MASTER_PIC_PORT+1,al
    cli                    ;Turn hardware int's back off
    JMP     P_MODE_LOOP

;----- 32 BIT SET/CLEAR  HARDWARE BREAKPOINT REGISTERS -----
P_SET_BREAKPOINTS:                ;Set 80386/80486 Hardware Breakpoints
    MOV     EBX,BREAKPOINT_MENU    ;Show Menu
    CALL    P_PRINT_STRING
    CALL    P_CICO
    CMP     AL,ESC
    JZ     P_BREAK_ABORT
    CMP     AL,'S'
    JZ     P_BREAK_ON
    CMP     AL,'C'
    JZ     P_BREAK_OFF
    MOV     EBX,BREAK_BAD           ;Bad command, retry, ESC to abort
    CALL    P_PRINT_STRING
    JMP     P_SET_BREAKPOINTS

P_BREAK_ON:                        ;SET a breakpoint Register
    MOV     EBX,SET_N_REGISTER     ;Which register
    CALL    P_PRINT_STRING
    CALL    P_CICO
    CMP     AL,ESC
    JZ     P_BREAK_ABORT
    PUSH    AX
    CMP     AL,'0'
    JZ     P_SET_REG0
    CMP     AL,'1'
    JZ     P_SET_REG1
    CMP     AL,'2'
    JZ     P_SET_REG2
    CMP     AL,'3'
    JZ     P_SET_REG3
    MOV     EBX,BREAK_BAD           ;Bad command
    CALL    P_PRINT_STRING

```

```

        JMP     P_BREAK_ON

P_SET_REG0:
    MOV     EBX,ENTER_BREAKPOINT           ;Enter breakpoint location
    CALL    P_PRINT_STRING
    CALL    P_GET8DIGITS_ESI               ;Get (up to) 32 bit parameter. (8 digits) ✓
    to ESI.

    MOV     DR0,ESI                        ;Save in DR0
    MOV     EAX,DR7                        ;Get debug control bits
    AND     EAX,0FFF0FFFFH                 ;Clear LEN0 & RW0
    OR      EAX,000000002H                 ;Set Global enable bit 0, all tasks
    MOV     DR7,EAX
    JMP     P_BRAKE_DONE

P_SET_REG1:
    MOV     EBX,ENTER_BREAKPOINT           ;Enter breakpoint location
    CALL    P_PRINT_STRING
    CALL    P_GET8DIGITS_ESI               ;Get (up to) 32 bit parameter. (8 digits) ✓
    to ESI.

    MOV     DR1,ESI                        ;Save in DR1
    MOV     EAX,DR7                        ;Get debug control bits
    AND     EAX,0FF0FFFFFH                 ;Clear LEN1 & RW1
    OR      EAX,000000008H                 ;Set Global enable bit 1, all tasks
    MOV     DR7,EAX
    JMP     P_BRAKE_DONE

P_SET_REG2:
    MOV     EBX,ENTER_BREAKPOINT           ;Enter breakpoint location
    CALL    P_PRINT_STRING
    CALL    P_GET8DIGITS_ESI               ;Get (up to) 32 bit parameter. (8 digits) ✓
    to ESI.

    MOV     DR2,ESI                        ;Save in DR0
    MOV     EAX,DR7                        ;Get debug control bits
    AND     EAX,0F0FFFFFFFH                 ;Clear LEN2 & RW2
    OR      EAX,000000020H                 ;Set Global enable bit 2, all tasks
    MOV     DR7,EAX
    JMP     P_BRAKE_DONE

P_SET_REG3:
    MOV     EBX,ENTER_BREAKPOINT           ;Enter breakpoint location
    CALL    P_PRINT_STRING
    CALL    P_GET8DIGITS_ESI               ;Get (up to) 32 bit parameter. (8 digits) ✓
    to ESI.

    MOV     DR3,ESI                        ;Save in DR0
    MOV     EAX,DR7                        ;Get debug control bits
    AND     EAX,00FFFFFFFH                 ;Clear LEN3 & RW3
    OR      EAX,000000080H                 ;Set Global enable bit 3, all tasks
    MOV     DR7,EAX
    JMP     P_BRAKE_DONE

P_BRAKE_DONE:
    CALL    P_DISPLAY_80386_REGISTERS       ;Display Protect Mode Registers
    MOV     EBX,BREAKPOINT_ACTIVE           ;Enter breakpoint location
    CALL    P_PRINT_STRING

P_BREAK_ABORT:
    JMP     P_MODE_LOOP

P_BREAK_OFF:
    ;CLEAR aBreakpoint Register
    MOV     EBX,CLEAR_N_REGISTER           ;Which register to clear
    CALL    P_PRINT_STRING
    CALL    P_CICO
    CMP     AL,ESC
    JZ      P_BREAK_ABORT
    PUSH   AX
    CMP     AL,'0'

```

```

    JZ     P_CLEAR_REG0
    CMP    AL,'1'
    JZ     P_CLEAR_REG1
    CMP    AL,'2'
    JZ     P_CLEAR_REG2
    CMP    AL,'3'
    JZ     P_CLEAR_REG3
    MOV    EBX,BREAK_BAD                ;Bad command
    CALL   P_PRINT_STRING
    JMP    P_BREAK_OFF

P_CLEAR_REG0:
    XOR    EAX,EAX                    ;Zero register just in case
    MOV    DR0,EAX
    MOV    EAX,DR7
    AND    EAX,0FFFFFFFCH            ;Zero global (& Local) bits
    JMP    P_OFF_DONE

P_CLEAR_REG1:
    XOR    EAX,EAX
    MOV    DR1,EAX
    MOV    EAX,DR7
    AND    EAX,0FFFFFFF3H            ;Zero global (& Local) bits
    JMP    P_OFF_DONE

P_CLEAR_REG2:
    XOR    EAX,EAX
    MOV    DR2,EAX
    MOV    EAX,DR7
    AND    EAX,0FFFFFFCFH            ;Zero global (& Local) bits
    JMP    P_OFF_DONE

P_CLEAR_REG3:
    XOR    EAX,EAX
    MOV    DR3,EAX
    MOV    EAX,DR7
    AND    EAX,0FFFFFFF3FH            ;Zero global (& Local) bits
    JMP    P_OFF_DONE

P_OFF_DONE:
    CALL   P_DISPLAY_80386_REGISTERS    ;Display Protect Mode Registers
    MOV    EBX,BREAKPOINT_OFF          ;Enter breakpoint location
    CALL   P_PRINT_STRING
    JMP    P_MODE_LOOP

;----- Protect Mode XMODEM File Recieve Routine -----↵
;-----

P_XMODEM_LOAD:
    mov    ebx,MODEM_SIGNON            ;Send Modem signon message
    call   P_PRINT_STRING
    CLD                                ;Default to direction up
    CLI                                ;No hardware Ints

    MOV    AX,PM_DS_386                ;Just in case, GDT[2]: Writable (0-4GB)
    MOV    DS,AX

    PUSH  EBP
    MOV    EBP,ESP                    ;Will store certain variables well below ↵
    stack
    MOV    byte [EBP-RECVD_SECT_NO],0
    MOV    byte [EBP-SECTNO],0
    MOV    byte [EBP-ERRCT],0

```

```

CALL    P_INIT_SCC                ;MASTER RESET THE ZILOG SCC
                                           ;GOBBLE UP GARBAGE CHARS FROM THE LINE
MOV     CH,1                       ;TIMEOUT DELAY
CALL    P_RECV

MOV     EBX,P_RAM_DESTINATION      ;Ask for destination (up to 8 digits)
call    P_PRINT_STRING
CALL    P_GET8DIGITS_ESI           ;Get (up to) 32 bit parameter. 32 bit value
    (8 digits) to DI.

CMP     AL,ESC
JZ      P_MODEM_DONE

CALL    P_CRLF
MOV     CH,MODEM_RTS_DELAY         ;TIMEOUT DELAY
CALL    P_RECV

MOV     EBX,START_POINTER          ;"Will load data starting at RAM location "
CALL    P_PRINT_STRING
call    P_SHOW_ADDRESS_ESI_NOSPACE ;Show address
MOV     EBX,H_MSG_CRLF
CALL    P_PRINT_STRING
CALL    P_CRLF
CALL    P_CRLF

MOV     EBX,DOWNLOAD_MSG           ;Speak "Downloading file"
CALL    P_SPEAK_STRING

P_RECV_LOOP:                        ;<<< MAIN RECIEVE LOOP >>>
XOR     AX,AX                       ;GET 0
MOV     [EBP-ERRCT],AL             ;Start error count with 0
P_RECV_HDR:
PUSH    BX
MOV     EBX,RMSG                   ;Reading sector message
CALL    P_PRINT_STRING
MOV     AL,[EBP-SECTNO]
INC     AL
CALL    P_AL_HEXOUT
MOV     EBX,RAM_MSG                ;"H.  If OK, will write to RAM location"
CALL    P_PRINT_STRING
call    P_SHOW_ADDRESS_ESI_NOSPACE ;Show address
MOV     EBX,H_MSG
CALL    P_PRINT_STRING
POP     BX

MOV     CH,(20*MODEM_RTS_DELAY)    ;~10 SEC TIMEOUT
CALL    P_RECV
JNB     P_RHNTO                    ;WE ARE OK, NO TIMEOUT

P_RECV_HDR_TIMEOUT:
MOV     EBX,TOUTM                   ;PRINT TIMEOUT MESSAGE
CALL    P_PRINT_STRING
MOV     AL,[EBP-ERRCT]
CALL    P_AL_HEXOUT                 ;FALL INTO CR/LF
CALL    P_CRLF

P_RECV_SECT_ERR:                    ;PURGE THE LINE OF INPUT CHARS
MOV     CH,MODEM_RTS_DELAY         ;~1 SEC W/NO CHARS
CALL    P_RECV
JNB     P_RECV_SECT_ERR            ;LOOP UNTIL SENDER DONE
MOV     AL,NAK
CALL    P_SEND                       ;SEND NAK
MOV     AL,[EBP-ERRCT]             ;Inc Error Count (ERRCT)
INC     AL
MOV     [EBP-ERRCT],AL
CMP     AL,MODEM_ERR_LIMIT         ;Currently set for 8 trys

```

```

        JB      P_RECV_HDR          ;Go try again
        CALL   P_CHECK_FOR_QUIT
        JZ     P_RECV_HDR          ;Try again
        MOV    EBX,BAD_HEADER      ;'Unable to get a valid file header!'
        CALL   P_PRINT_STRING
        JMP    P_MODEM_DONE        ;Abort back to Monitor start

P_RHNT0: CMP    AL,SOH              ;GOT CHAR - MUST BE SOH
        JZ     P_GOT_SOH
        OR     AL,AL                ;00 FROM SPEED CHECK?
        JNZ   PL_2
        JMP    P_RECV_HDR
PL_2:   CMP    AL,EOT
        JNZ   PL_3
        JMP    P_GOT_EOT
PL_3:   CALL   P_AL_HEXOUT
        MOV    EBX,ERRSOH         ;'H Received',CR,LF,'Did not get Correct'
        CALL   P_PRINT_STRING
        JMP    P_RECV_SECT_ERR

P_GOT_SOH:                ;We got correct SOH so now get data
        MOV    CH,1
        CALL   P_RECV
        JB     P_RECV_HDR_TIMEOUT
        MOV    DH,AL              ;D=BLK #
        MOV    CH,1
        CALL   P_RECV              ;GET CMA'D SECT #
        JB     P_RECV_HDR_TIMEOUT
        NOT    AL
        CMP    AL,DH              ;GOOD SECTOR #?
        JZ     P_RECV_SECTOR
                                ;GOT BAD SECTOR #
        MOV    EBX,MODEM_ERR2     ;'++BAD SECTOR # IN HDR'
        CALL   P_PRINT_STRING
        JMP    P_RECV_SECT_ERR

P_RECV_SECTOR:            ;Now get 128 Bytes
        MOV    AL,DH              ;GET SECTOR #
        MOV    [EBP-RECVD_SECT_NO],AL ;Save it
        MOV    CL,0               ;INIT CKSUM
        MOV    BL,80H             ;128 Byte sectors always

P_RECV_CHAR:
        MOV    CH,MODEM_RTS_DELAY ;~1 SEC TIMEOUT
        CALL   P_RECV              ;GET CHAR
        JNB   P_MODL_4
        JMP    P_RECV_HDR_TIMEOUT
P_MODL_4:
        MOV    [ESI],AL           ;<<< STORE CHAR >>>
        INC    ESI
        DEC    BL                  ;128 Bytes done yet?
        JNZ   P_RECV_CHAR
                                ;NEXT VERIFY CHECKSUM
        MOV    DH,CL              ;SAVE CHECKSUM IN DH FOR BELOW
        MOV    CH,MODEM_RTS_DELAY ;~1 Sec TIMEOUT
        CALL   P_RECV              ;GET CHECKSUM
        JNB   P_MODL_5
        JMP    P_RECV_HDR_TIMEOUT
P_MODL_5:
        CMP    AL,DH              ;CHECK
        JNZ   P_RECV_CKSUM_ERR
        MOV    AL,[EBP-RECVD_SECT_NO] ;GOT A SECTOR, WRITE IF = 1+PREV SECTOR
        MOV    CH,AL              ;SAVE IT
        MOV    AL,[EBP-SECTNO]    ;GET PREV
        INC    AL                  ;CALC NEXT SECTOR #

```



```

        CMP     AL,CH                ;MATCH?
        JNZ     P_DO_ACK

        MOV     AL,[EBP-RECVD_SECT_NO] ;Indicate we transferred a sector
        MOV     [EBP-SECTNO],AL      ;UPDATE SECTOR #
P_DO_ACK:
        MOV     AL,ACK
        CALL    P_SEND
        JMP     P_RECV_LOOP          ;TO NEXT SECTOR

P_RECV_CKSUM_ERR:
        MOV     EBX,MODEM_ERR3
        CALL    P_PRINT_STRING
        JMP     P_RECV_SECT_ERR

P_GOT_EOT:
        MOV     AL,ACK                ;DONE - CLOSE UP SHOP
        CALL    P_SEND                ;ACK THE EOT
        CALL    P_CRLF
        MOV     EBX,FINISH_MSG        ;Speak downloading finished
        CALL    P_SPEAK_STRING
        MOV     EBX,TRANS_DONE

P_EXIT2:
        CALL    P_PRINT_STRING

P_MODEM_DONE:
        XOR     AL,AL
        POP     EBP                    ;RESTORE IT
        JMP     P_MODE_LOOP

P_EXIT1:
        MOV     EBX,ABORT_MSG
        JMP     P_EXIT2

P_INIT_SCC:
        MOV     EBX,SSC_MSG_INIT      ;INITIALIZE THE ZILOG SCC SERIAL PORT
        CALL    P_PRINT_STRING        ;Say Initalizing ACIA/SCC
        MOV     CH,14                 ;Byte count (14), for below
        MOV     EBX,SCCINIT + PM_ROM_BASE ;Table of Zilog SCC Initalization values
        ;Need to convert offsets to absolute
        address
P_SCC_1:
        MOV     AL,[EBX]
        OUT     MODEM_CTL_PORT,AL     ;Program the SCC Channel B (A1,A3 or 10,
        12H) for 19K Baud
        INC     EBX
        DEC     CH
        JNZ     P_SCC_1
        MOV     EBX,SPEED_MSG         ;Speek, baud rate set
        CALL    P_SPEAK_STRING
        RET

        ;---- SERIAL PORT GET CHARACTER ROUTINE ----
-
P_RECV: PUSH     DX                    ;SAVE
        MOV     AL,5H                 ;Lower RTS line
        OUT     MODEM_CTL_PORT,AL     ;Sel Reg 5
        MOV     AL,11101010B         ;EAH
        OUT     MODEM_CTL_PORT,AL
        NOP
        NOP
P_MSEC: MOV     DX,8000H              ;~0.1 SEC DCR COUNT
P_MWTI: IN      AL,MODEM_CTL_PORT
        AND     AL,MODEM_RECV_MASK
        CMP     AL,RCV_READY

```

```

        JZ      P_MCHAR          ;GOT CHAR
        DEC     DX              ;COUNT DOWN
        JNZ     P_MWTI          ;FOR TIMEOUT
        DEC     CH              ;DCR # OF SECONDS
        JNZ     P_MSEC          ;MODEM TIMED OUT RECEIVING
        POP     DX              ;RESTORE DX
        STC     ;CARRY SHOWS TIMEOUT
        RET

P_MCHAR: IN     AL,MODEM_DATA_PORT
        POP     DX              ;RESTORE DE
        LAHF                    ;CALC CHECKSUM
        XCHG   AL,AH
        PUSH   AX
        XCHG   AL,AH
        ADD    AL,CL
        MOV    CL,AL
        POP    AX
        XCHG   AL,AH
        OR     AL,AL          ;TURN OFF CARRY TO SHOW NO TIMEOUT
        RET

--
;---- SERIAL PORT SEND CHARACTER ROUTINE --
P_SEND: LAHF                    ;CHECK IF MONITORING OUTPUT
        XCHG   AL,AH
        PUSH   AX
        XCHG   AL,AH
        ADD    AL,CL          ;CALC CKSUM
        MOV    CL,AL

P_SENDW:
        IN     AL,MODEM_CTL_PORT ;Don't worry PC is always fast enough
        AND    AL,MODEM_SEND_MASK
        CMP    AL,SEND_READY
        JNZ    P_SENDW
        POP    AX              ;GET CHAR
        XCHG   AL,AH
        SAHF
        OUT    MODEM_DATA_PORT,AL ;Raise RTS line to prevent the next
        character arriving
        MOV    AL,5H          ;while the Z80 is busy processing info
        OUT    MODEM_CTL_PORT,AL ;Sel Reg 5
        MOV    AL,11101000B    ;E8H
        OUT    MODEM_CTL_PORT,AL
        RET

P_CHECK_FOR_QUIT:
        XOR    AL,AL          ;MULTIPLE ERRORS, ASK IF TIME TO QUIT
        MOV    [EBP-ERRCT],AL ;GET 0
        MOV    EBX,QUITM      ;RESET ERROR COUNT
        CALL   P_PRINT_STRING
        CALL   P_CICO
        PUSH   AX
        CALL   P_CRLF
        POP    AX
        CMP    AL,'R'
        JZ     P_DONE_CHECK
        CMP    AL,'Q'
        JZ     P_NOT_DONE_CHECK
        CMP    AL,ESC
        JZ     P_NOT_DONE_CHECK
        JMP    P_CHECK_FOR_QUIT

P_NOT_DONE_CHECK:
        OR     AL,AL          ;TURN OFF ZERO FLAG

P_DONE_CHECK:
        RET

```

```

;----- PM TESTS FOR RAM HARDWARE -----
;XXXXX:

P_PM_MEM_TEST:
    MOV     EBX,PM_RAM_TEST           ;Inform test is starting
    CALL    P_PRINT_STRING
    CLI                                           ;No hardware Ints
    MOV     AX,PM_DS_386              ;Just in case, GDT[2]: Writable (0-4GB)
    MOV     DS,AX

    CALL    P_CICO                     ;Get menu option
    PUSH    AX
    CALL    P_CRLF
    POP     AX

    CMP     AL,'0'
    JZ      P_READ_RAM_SIGNAL         ;Generate RAM RD signal on CPU board
    CMP     AL,'1'
    JZ      P_WRITE_RAM_SIGNAL       ;Generate RAM WR signal on CPU board
    CMP     AL,'2'
    JZ      P_MOVE_RAM_TEST          ;Move Bytes, Words, DWords from/to a      ✓
    specified location
    CMP     AL,'3'
    JZ      P_FAST_8_TEST_RAM        ;FASTER RAM test 100000H - 7FFFFFFH (8MB      ✓
    S100 RAM)
    CMP     AL,'4'
    JZ      P_FAST_16_TEST_RAM       ;FASTER RAM test 1000000H - 3FFFFFFFH (16MB ✓
    S100 RAM)
    CMP     AL,'5'
    JZ      P_FAST_E16_TEST_RAM      ;FASTER RAM test 2000000H - 2FFFFFFFH (16MB ✓
    80386/80486 RAM Board)
    CMP     AL,'6'
    JZ      P_FAST_E32_TEST_RAM      ;FASTER RAM test 2000000H - 3FFFFFFFH (32MB ✓
    80386/80486 RAM Board)
    CMP     AL,'7'
    JZ      P_TEST_RAM               ;Extensive PM RAM RD/WR test
    CMP     AL,'8'
    JZ      P_MEZZANINE_CHECK        ;Identify bad RAM mezzanine boards on 32MB ✓
    Overhead connected RAM board.'
    JMP     P_ERR

P_READ_RAM_SIGNAL:
    MOV     EBX,PM_RAM_TEST_LOC      ;Generate RAM RD signal on CPU board
    CALL    P_PRINT_STRING           ;Get RAM test location

    CALL    P_GET8DIGITS_ESI         ;Get up to 8 digits
    MOV     EBX,PM_RAM_WILL_DO      ;Inform will start test
    CALL    P_PRINT_STRING
    MOV     EAX,ESI

    CALL    P_EAX_HEXOUT
    MOV     EBX,H_MSG_CRLF          ;H,CRLF.
    CALL    P_PRINT_STRING
    MOV     EBX,ESI                 ;Put address in EBX

P_PM_RAM1:
    MOV     EAX,[EBX]               ;<<< Continue until reset >>>
    JMP     P_PM_RAM1

P_WRITE_RAM_SIGNAL:
    MOV     EBX,P_WR_JMSG           ;Generate RAM WR signal on CPU board
    call    P_PRINT_STRING          ;Get RAM test location

    CALL    P_GET8DIGITS_ESI        ;Get (up to) 32 bit parameter. 32 bit value ✓

```

```

        (up to 8 digits) to ESI.
MOV     EBX,ESI                                ;Save in EBX

CALL    P_CRLF_CHECK                          ;Note EBX,ECX is saved, ESC at keyboard ✓
will abort

MOV     ECX,20H                               ;WRITE 20H bytes at a time
MOV     EAX,12345678H                         ;Test patern

P_MEM_BYT:
MOV     [EBX],AL
INC     EBX
LOOP    P_MEM_BYT

MOV     ECX,10H                               ;10H words

P_MEM_WORD:
MOV     [EBX],AX
INC     EBX
INC     EBX
LOOP    P_MEM_WORD

MOV     ECX,0FH                               ;5H Dwords

P_MEM_DWORD:
MOV     [EBX],EAX
INC     EBX
INC     EBX
INC     EBX
INC     EBX
LOOP    P_MEM_DWORD
JMP     P_PM_MEM_TEST                        ;Done, next menu item

P_MOVE_RAM_TEST :                            ;Move Bytes, Words, DWords from/to a ✓
specified location
MOV     EBX,P_MOV_JMSG                        ;Move 800H Bytes, 400H Words, 100H DWords ✓
from/to a specified location
call    P_PRINT_STRING

CALL    P_GET8DIGITS_ESI                     ;Get (up to) 32 bit parameter. 32 bit value ✓
(up to 8 digits) to ESI.
PUSH    ESI

CALL    P_GET8DIGITS_ESI                     ;Get (up to) 32 bit parameter. 32 bit value ✓
(up to 8 digits) to EDI.
MOV     EDI,ESI
POP     ESI

CALL    P_CRLF_CHECK                          ;Note EBX,ECX is saved, ESC at keyboard ✓
will abort

MOV     ECX,800H                             ;MOVE 800H bytes at a time

P_MOV_BYT:
MOV     AL,[ESI]
MOV     [EDI],AL
INC     ESI
INC     EDI
LOOP    P_MOV_BYT

MOV     ECX,400H                             ;MOVE 400H words at a time

P_MOV_WORD:
MOV     word AX,[ESI]
MOV     word [EDI],AX
INC     ESI
INC     ESI
INC     EDI
INC     EDI

```

```

        LOOP    P_MOV_WORD

P_MOV_DWORD:
        MOV     ECX,100H                ;Move 100H dwords
        MOV     dword EAX,[ESI]
        MOV     dword [EDI],EAX
        ADD     ESI,4
        ADD     EDI,4
        LOOP   P_MOV_DWORD
        JMP     P_PM_MEM_TEST          ;Done, next menu item

;----- HARDWARE RAM ADDRESS LINES TESTING ROUTINE -----
;-----

P_TEST_RAM:                                ;Extensive PM RAM RD/WR test
        MOV     EBX,P_JMSG
        call    P_PRINT_STRING

        CALL    P_GET8DIGITS_ESI        ;Get (up to) 32 bit parameter. 32 bit value
        (up to 8 digits) to ESI.
        AND     ESI,0FFFFFF0H          ;Start on an even boundry
        PUSH   ESI

        CALL    P_GET8DIGITS_ESI        ;Get (up to) 32 bit parameter. 32 bit value
        (up to 8 digits) to EDI.
        MOV     EDI,ESI
        POP    ESI
        JMP     TEST_RAM_RAM

P_FAST_8_TEST_RAM:                          ;Fast PM RAM RD/WR test for all 16MB RAM
        MOV     ESI,START_16_RAM_TEST  ;Start location,100000H
        MOV     EDI,END_8_RAM_TEST     ;End location,7FFFFFFH
        JMP     TEST_RAM_RAM

P_FAST_16_TEST_RAM:                          ;Fast PM RAM RD/WR test for all 16MB RAM
        MOV     ESI,START_16_RAM_TEST  ;Start location,100000H
        MOV     EDI,END_16_RAM_TEST    ;End location,FFFFFFH
        JMP     TEST_RAM_RAM

P_FAST_E16_TEST_RAM:                          ;Fast PM RAM RD/WR test for 16MB of PM RAM
        MOV     ESI,START_P32_RAM_TEST ;Start location,2000000H
        MOV     EDI,END_P16_RAM_TEST   ;End location,2FFFFFFH
        JMP     TEST_RAM_RAM

P_FAST_E32_TEST_RAM:                          ;Fast PM RAM RD/WR test for all 32MB RAM
        MOV     ESI,START_P32_RAM_TEST ;Start location,2000000H
        MOV     EDI,END_P32_RAM_TEST   ;End location,3FFFFFFH
        JMP     TEST_RAM_RAM

TEST_RAM_RAM:
        mov     ecx,edi
        sub     ecx,esi
        inc     ecx                      ;Length ecx = (edi-esi)+1

        CALL    P_CRLF_CHECK            ;Note ECX (& EBX) are not changed, ESC at
keyboard will abort
        mov     ebx,START_AT_MSG        ;Start=
        call    P_PRINT_STRING
        call    P_SHOW_ADDRESS_ESI      ;Show start address (in ESI)

        PUSH   ESI
        mov     esi,edi
        mov     ebx,END_AT_MSG          ;End=
        call    P_PRINT_STRING
        call    P_SHOW_ADDRESS_ESI      ;Show start address (in ESI)

```



```

    CMP     AX,5555H                ;Should be 5555H from
    mov     ebx,BAD_55_AT_MSG       ;Message "55H fill error at:" - IF NEEDED
    CALL    P_STATUS_DISPLAY        ;Special display if first time error, ✓
    repeat error, or last error
    CALL    P_DISPLAY_UPDATE        ;Display current location if not in middle ✓
    of errors display
    MOV     AX,1234H                ;5555->1234
    STOSW                                     ;WORD, AX->[EDI++]
    LOOP   P_CHK_5555_RAM           ;End of Loop

    mov     ebx,LAST_LOC_MSG        ;CR,'Last tested location ='
    call    P_PRINT_STRING
    CALL    P_CURRENT_LOC           ;Print Current Location - No space (EDI)
    mov     ebx,H_MSG_CRLF          ;'H, CR,LF$'
    call    P_PRINT_STRING          ;Finish out that line. Start on a new one

    ;-----✓
    -----
    mov     ebx,CHK_DWORD_JMSG      ;"Checking RAM was filled with WORD 1234H, ✓
    replacing with DWORD 12345678H."
    call    P_PRINT_STRING
    MOV     EDI,ESI                 ;Pointer back to start
    MOV     ECX,EBP                 ;get total count
    SHR     ECX,2                   ;Because this time we are using DWords
    XOR     EDX,EDX                 ;set EDX to 00H as flag for error count
    P_CHK_1234_RAM:                ;Start of DWORD write test Loop
    MOV     EAX,dword[EDI]          ;Put RAM word in AX
    CMP     EAX,12341234H           ;Should be 12341234 from above
    mov     ebx,BAD_1234_AT_MSG     ;Message "1234H fill error at:" - IF NEEDED
    CALL    P_STATUS_DISPLAY        ;Special display if first time error, ✓
    repeat error, or last error
    CALL    P_DISPLAY_UPDATE        ;Display current location if not in middle ✓
    of errors display
    MOV     EAX,12345678H           ;1234 -> 12345678
    STOSD                                     ;DWORD, EAX->[EDI++]
    LOOP   P_CHK_1234_RAM           ;End of Loop

    mov     ebx,LAST_LOC_MSG        ;CR,'Last tested location ='
    call    P_PRINT_STRING
    CALL    P_CURRENT_LOC           ;Print Current Location - No space (EDI)
    mov     ebx,H_MSG_CRLF          ;'H, CR,LF$'
    call    P_PRINT_STRING          ;Finish out that line. Start on a new one

    ;-----✓
    -----
    mov     ebx,FILLED_DWORD_JMSG   ;"Checking RAM was filled with DWord ✓
    12345678H"
    call    P_PRINT_STRING
    MOV     EDI,ESI                 ;Pointer back to start
    MOV     ECX,EBP                 ;get total count
    SHR     ECX,2                   ;Because this time we are using DWords
    XOR     EDX,EDX                 ;set EDX to 00H as flag for error count
    P_CHK_12345678_RAM:            ;Start of DWORD write test Loop
    MOV     EAX,dword[EDI]          ;Put RAM dword in EAX
    CMP     EAX,12345678H           ;Should be 12345678 from above
    mov     ebx,BAD_12345678_AT_MSG ;Message "12345678H fill error at:" - IF ✓
    NEEDED
    CALL    P_STATUS_DISPLAY        ;Special display if first time error, ✓
    repeat error, or last error
    CALL    P_DISPLAY_UPDATE        ;Display current location if not in middle ✓
    of errors display
    INC     EDI                     ;X2 because word
    INC     EDI
    INC     EDI

```



```

        LODSB                ;[ESI++] -> AL
        OR                   AL,AL                ;is it Zero
        JNZ                  BAD_BYTE_1
        LODSB                ;[ESI++] -> AL
        OR                   AL,AL                ;is it Zero
        JNZ                  BAD_BYTE_2
        LODSB                ;[ESI++] -> AL
        OR                   AL,AL                ;is it Zero
        JNZ                  BAD_BYTE_3

        POP                  EDI                  ;Back to start again

        PUSH                 EDI                  ;Save for below
        MOV                  ESI,EDI              ;Save for below
        MOV                  AL,0FFH
        STOSB                ;BYTE, 0FF->[EDI++]
        STOSB                ;BYTE, 0FF->[EDI++]
        STOSB                ;BYTE, 0FF->[EDI++]
        STOSB                ;BYTE, 0FF->[EDI++]

        LODSB                ;[ESI++] -> AL
        CMP                  AL,0FFH              ;is it 0FFH
        JNZ                  BAD_BYTE_0
        LODSB                ;[ESI++] -> AL
        CMP                  AL,0FFH              ;is it 0FFH
        JNZ                  BAD_BYTE_1
        LODSB                ;[ESI++] -> AL
        CMP                  AL,0FFH              ;is it 0FFH
        JNZ                  BAD_BYTE_2
        LODSB                ;[ESI++] -> AL
        CMP                  AL,0FFH              ;is it 0FFH
        JNZ                  BAD_BYTE_3

        CALL                 P_DISPLAY_UPDATE     ;Display current location, check for abort ✓
        as well
        LOOP                 P_MEZ_CHECK_LOOP     ;Count down ECX, <<<<<<<< End of Zero ✓
        RAM Loop
        mov                  ebx,MEZ_TEST_DONE    ;Mezzanine boards test done"
        call                 P_PRINT_STRING
        JMP                  P_MODE_LOOP          ;We are done here

BAD_BYTE_0:
        mov                  ebx,BAD_MEZ          ;"R/W Byte error found on Mezzanine board ✓
        in "
        call                 P_PRINT_STRING
        mov                  ebx,BAD_MEZ_0        ;"P103 socket"
        call                 P_PRINT_STRING
        JMP                  P_MODE_LOOP          ;We are done here

BAD_BYTE_1:
        mov                  ebx,BAD_MEZ          ;"R/W Byte error found on Mezzanine board ✓
        in "
        call                 P_PRINT_STRING
        mov                  ebx,BAD_MEZ_1        ;"P104 socket"
        call                 P_PRINT_STRING
        JMP                  P_MODE_LOOP          ;We are done here

BAD_BYTE_2:
        mov                  ebx,BAD_MEZ          ;"R/W Byte error found on Mezzanine board ✓
        in "
        call                 P_PRINT_STRING
        mov                  ebx,BAD_MEZ_2        ;"P105 socket"
        call                 P_PRINT_STRING
        JMP                  P_MODE_LOOP          ;We are done here

BAD_BYTE_3:

```

```

    mov     ebx,BAD_MEZ                ;"R/W Byte error found on Mezzanine board  ✓
    in     "
    call    P_PRINT_STRING
    mov     ebx,BAD_MEZ_3              ;"P106 socket"
    call    P_PRINT_STRING
    JMP     P_MODE_LOOP                ;We are done here

;----- Support Routines for RAM testing ----- ✓
;-----

P_DISPLAY_UPDATE:
    OR     EDX,EDX                    ;Are we in the middle of an error output  ✓
    string
    JNZ    P_NO_DISPLAY_UPDATE        ;If so skip
P_DISPLAY_UPDATE1:
    MOV    EAX,EDI                    ;Check it display update is required
    AND    EAX,2FFFFH
    CMP    EAX,2000H
    JNZ    P_NO_DISPLAY_UPDATE        ;After every 64K give a status update
    mov     ebx,STATUS_UPDATE_MSG     ;CR,'Current location = '
    call    P_PRINT_STRING
    CALL    P_CURRENT_LOC              ;See if we need to update location display ✓
    (every ~2K)
    mov     ebx,H_MSG                  ;'H$'
    CALL    P_PRINT_STRING
P_NO_DISPLAY_UPDATE:
    call    P_CTRL_CHECK                ;See if an abort was requested
    RET

P_STATUS_DISPLAY:                    ;Special routine to display for RAM ✓
    errors (if any)
    PUSH   EAX
    PUSHF                                  ;Save error flag
    OR     EDX,EDX                      ;Are we in the middle of an error output  ✓
    string
    JNZ    P_OLD_ERRORS_PRESENT        ;Is ther a current error
    POPF
    JNZ    P_NEW_ERROR                 ;Balance up stack
    POP    EAX
    RET                                  ;Else no errors, just return

P_NEW_ERROR:
    call    P_PRINT_STRING              ;Message is already in EBX
    CALL    P_CURRENT_LOC               ;Print Current Location - No space (EDI)
    mov     ebx,AL_EQUAL_MSG           ;BELL,'H EAX='
    CALL    P_PRINT_STRING
    POP    EAX                          ;find out what the RAM value was
    CALL    P_EAX_HEXOUT
    mov     ebx,UNTIL_MSG              ;'H Until '
    CALL    P_PRINT_STRING
    CALL    P_CURRENT_LOC               ;Print Current Location - No space (EDI)
    mov     ebx,H_MSG                  ;'H$'
    call    P_PRINT_STRING
    INC    EDX                          ;Flag first error detected
    RET

P_OLD_ERRORS_PRESENT:
    POPF                                  ;Are there still errors
    POP    EAX                          ;Balance up stack
    JZ     P_LAST_ERROR                 ;No new error, but need to finish  ✓
    updatingprevious one(s)
    MOV    EAX,EDI
    AND    EAX,2FFFFH                  ;Check it display update is required (every ✓
    2K)

```

```

    CMP     EAX,2000H
    JNZ     P_NO_DISPLAY_UPDATE2           ;After every 64K give a status update
    mov     ebx,BACKSPACE_9_MSG           ;Still errors, Backspace 9 positions
    call    P_PRINT_STRING
    CALL    P_CURRENT_LOC                 ;Print Current Location - No space (EDI)
    mov     ebx,H_MSG                     ;'H$'
    call    P_PRINT_STRING
P_NO_DISPLAY_UPDATE2:
    INC     EDX                           ;flag still errors detected
    RET

P_LAST_ERROR:
    mov     ebx,BACKSPACE_9_MSG           ;No more new errors
    call    P_PRINT_STRING                ;Backspace 9 positions
    CALL    P_CURRENT_LOC                 ;Print Current Location - No space (EDI)
    mov     ebx,H_MSG_CRLF                ;'H, CR,LF$'
    call    P_PRINT_STRING                ;Finish out that line. Start on a new one
    XOR     EDX,EDX                       ;clear errors
    RET

P_CURRENT_LOC:
    PUSH    ESI                           ;Print Current Location - No space (EDI)
    mov     esi,edi                       ;Update Current location, temporarily save ESI
    call    P_SHOW_ADDRESS_ESI_NOSPACE    ;Show start address (in ESI)
    POP     ESI                           ;Get back start address
    RET

;----- 32 BIT GENERAL ERROR WARNING MESSAGE ROUTINE -----

P_ERR:  CMP     AL,ESC                     ;If ESC key is here skip error message, (Was an abort request)
        JZ      P_ERR1
        MOV     EBX,ERR_MSG               ;Invalid Menu Command (32 BIT) (or code not yet done)
        CALL    P_PRINT_STRING
P_ERR1: CALL    P_CRLF
        jmp     Start32                   ;Reload everything Stack may be bad

;----- 32 BIT Support Routines -----
;
; Send to console the address in ESI      ;EAX, ECX Unchanged

P_SHOW_ADDRESS_ESI:
    push    eax                           ;32 Bit Routine
    MOV     EAX,ESI                       ;Save
    CALL    P_EAX_HEXOUT
    call    P_BLANK
    pop     eax
    ret

P_SHOW_ADDRESS_ESI_NOSPACE:
    push    eax                           ;32 Bit Routine
    MOV     EAX,ESI                       ;Save
    CALL    P_EAX_HEXOUT
    pop     eax
    ret

; P_EAX_HEXOUT
P_EAX_HEXOUT:
    ;Output the 8 hex digits in [EAX]
    ;No registers altered

```

```

        PUSH     EAX                ;32 Bit Routine
        PUSH     EAX
        ROR     EAX,16              ;Shift down upper 16 bits
        CALL    P_AX_HEXOUT
        POP     EAX
        CALL    P_AX_HEXOUT
        POP     EAX
        RET

;      P_AX_HEXOUT                ;output the 4 hex digits in [AX]
P_AX_HEXOUT:                          ;No registers altered
        PUSH     AX                ;32 Bit Routine
        MOV     AL,AH
        CALL    P_AL_HEXOUT
        POP     AX
        CALL    P_AL_HEXOUT
        RET

;      P_AL_HEXOUT                ;output the 2 hex digits in [AL]
P_AL_HEXOUT:                          ;No registers altered
        push    eax
        push    eax                ;32 Bit Routine
        shr    al,4
        call   p_hexdigout
        pop    eax
        call   p_hexdigout        ;get upper nibble
        pop    eax
        ret

p_hexdigout:
        push   ecx
        and    al,0fh              ;convert nibble to ascii
        add    al,90h
        daa
        adc    al,40h
        daa
        mov    cl,al
        call   P_CO
        pop    ecx
        ret

;      32 Bit BINARY OUTPUT        ;Send what is in [al] in bits
P_AL_BINOUT:                          ;No registers altered
        push   eax
        push   ecx                ;32 Bit Routine
        mov    ecx,8
p_binout1:
        push   ecx
        shl   al,1
        jb    p_bout1
        mov   cl,'0'
        push  eax
        call  P_CO
        pop   eax
        jmp   p_binend
p_bout1:
        mov   cl,'1'
        push  eax
        call  P_CO
        pop   eax
p_binend:
        pop   ecx
        loop  p_binout1
        pop   ecx

```

```

    pop    eax
    ret

;----- 32 BIT GET 8,4, or 2 DIGITS INTO ESI -----

P_GET4DIGITS_ESI:                ;Get up to 4 digits (16 bit address/value) to ESI
    PUSH  EBX
    PUSH  ECX
    mov   ecx,5
    JMP   P_GETNDIGITS_ESI

P_GET2DIGITS_ESI:                ;Get up to 4 digits (16 bit address/value) to ESI
    PUSH  EBX
    PUSH  ECX
    mov   ecx,3
    JMP   P_GETNDIGITS_ESI

P_GET8DIGITS_ESI:                ;Get up to 8 digits (32 bit address/value) to ESI
    PUSH  EBX
    PUSH  ECX
    mov   ecx,9

P_GETNDIGITS_ESI:                ;Common section from here on
    mov   esi,0                    ;So initially ESI=0
p_loopb:
    call  P_CICO                    ;Console input to AL and ECHO
    AND  EAX,0FFH                  ;Byte only

    cmp   al,'0'                    ;alphanumeric?
    jb   p_bexit
    call  P_HEX_check                ;convert to binary and check it
    jb   P_AddressError

    and  eax,0FH
    shl  esi,4                      ;shift in last addition
    or   esi,eax
    loop p_loopb                    ;Do up to 8 characters

p_bexit:
    cmp   al,' '                    ;Terminate with a SP, ", " or CR only
    je   p_bgood
    cmp   al','
    je   p_bgood
    cmp   al,CR
    je   p_bgood
    jmp  P_ERR

p_bgood:
    mov  ah,al                      ;Save terminator
    POP  ECX                        ;Balance up stack
    POP  EBX
    ret

P_AddressError:
    MOV  EBX,AddressErrMsg          ;Range error
    CALL P_PRINT_STRING
    POP  ECX                        ;Balance up stack
    POP  EBX
    POP  EAX                        ;Cleanup stack from original CALL to this routine
    JMP  P_ERR

P_CLENGTH:
    MOV  ECX,ESI                    ;Length ecx = (esi-edi)+1
    SUB  ECX,EDI                    ;DSI has segment of final value
    INC  ECX                        ;Subtract initial value

```

```

    RET

;      HEXCHK                ;check for a valid HEX DIGIT
P_HEX_check:
    sub    al,'0'            ;convert to binary if ok set carry if problem
    jb     p_hret
    cmp    al,0ah
    cmc
    jnb    hret
    sub    al,7
    cmp    al,10
    jb     hret
    cmp    al,16
    cmc
p_hret: ret

                                ;Get 8 bit value (2 digits) to AL. (EBX, ECX & EDX
    Unchanged), terminator in AH - normally 0
P_GET2DIGITS:
    PUSH   EBX
    PUSH   ECX
    mov    bx,0                ;Default to 0H

    call   P_CICO              ;1st Console input digit to AL
    cmp    al,'0'             ;alphanumeric?
    jb     p_bexit2
    call   P_HEX_check        ;convert to binary and check it
    jb     p_err2
    add    bl,al               ;Move into BX
    mov    cl,4
    shl   bx,cl                ;shift in last addition to high nibble on BL

    push  EBX                  ;Just in case
    call  P_CICO              ;2nd Console input digit to AL
    pop   EBX

    cmp    al,'0'             ;alphanumeric?
    jb     p_bexit2
    call   P_HEX_check        ;convert to binary and check it
    jb     p_err2
    add    bl,al               ;Move into BX
    MOV   AL,BL
    MOV   AH,0                 ;Ret 0 in AH if all OK
    POP   ECX
    POP   EBX
    ret

p_err2: POP   ECX              ;Cleanup stack
        POP   EBX
        JMP   P_ERR           ;Then normal error exit

p_bexit2:
    cmp    al,' '             ;save terminator, if SP,CR accept only 1 digit
    je     p_bgood2
    cmp    al','             ;
    je     p_bgood2
    cmp    al,CR
    je     p_bgood2
    cmp    al,ESC
    je     p_bgood2
    POP   ECX                  ;Cleanup stack
    POP   EBX
    JMP   P_ERR               ;Then normal error exit

```

```

p_bgood2:
    mov     ah,al                ;Save SP,', ' or CR in AH
    MOV     BH,0
    mov     cl,4
    shr     bx,cl                ;shift down last addition to low nibble on BL
    MOV     AL,BL
    POP     ECX
    POP     EBX
    ret

P_PRINT_STRING:                ;32 Bit version of PRINT_STRING
    push   ecx
    ADD     EBX,PM_ROM_BASE     ;Need to convert offsets to absolute address
p_print1:
    mov     cl,[ebx]
    inc     ebx
    cmp     cl,'$'              ;a valid pointer to messages at the end of this
    monitor
    jz      p_print2
    cmp     cl,0                ;Also terminate with 0's
    JZ      p_print2
    call   P_CO
    jmp     p_print1
p_print2:
    pop     ecx
    RET

;SPEAKTOMM THIS IS A ROUTINE (32 BIT) TO SEND A STRING TO TALKER [EBX] AT STRING
P_SPEAK_STRING:
    PUSH   ECX
    ADD     EBX,PM_ROM_BASE     ;Need to convert offsets to absolute address
P_STOMM2:
    MOV     CL,[EBX]
    INC     EBX
    CMP     CL,'$'              ;Terminate with "$",CR or 0
    JZ      P_STOMM1
    CMP     CL,CR
    JZ      P_STOMM1
    CMP     CL,0
    JZ      P_STOMM1
    CALL   P_SPEAKOUT
    JMP     P_STOMM2
P_STOMM1:
    MOV     CL,CR                ;MUST END WITH A CR
    CALL   P_SPEAKOUT
    POP     ECX
    RET

P_SPEAKOUT:
    MOV     AL,0H                ;Will try 256 times, then timeout
P_SOUT1:
    PUSH   EAX
    IN     AL,BCTL               ;Are we ready for a character
    AND     AL,04H
    JNZ    P_SENDS
    POP     EAX
    DEC     AL
    JNZ    P_SOUT1              ;After 256 times abort
    RET
P_SENDS:
    POP     EAX
    MOV     AL,CL

```

```

        OUT     BDTA,AL           ;Send it
        RET

;32 Bit Get keyboard with echo
P_CICO: IN     AL,KEYSTAT
        TEST   AL,02H           ;Wait until something is there
        JZ     P_CICO
        IN     AL,KEYIN        ;Not clear why but a direct call here to P_CI:
        hangs system!

        AND    AL,7FH
        JZ     P_BAD_CHAR      ;No Nulls
        CMP    AL,', '        ;Allow ", " character
        JZ     P_CIC1
        CMP    AL,CR          ;ACCEPT ONLY CR,LF,SP
        JZ     P_CIC1
        CMP    AL,LF
        JZ     P_CIC1
        CMP    AL,SPACE
        JZ     P_CIC1
        CMP    AL,ESC         ;Also ESC
        JZ     P_CIC1

        CMP    AL,'0'
        JB     P_BAD_CHAR
        CMP    AL,':'        ;Allow 0-9
        JB     P_CIC1
        CMP    AL,'A'
        JB     P_BAD_CHAR    ;do not allow : to @
        CMP    AL,'['        ;Is upper case A to Z
        JB     P_CIC1
        CMP    AL,'a'
        JB     P_BAD_CHAR
        CMP    AL,'{'
        JB     P_UPPER_CASE
        JMP    P_BAD_CHAR

P_UPPER_CASE:
        AND    AL,5FH         ;THIS CONVERTS ALL LC->UC
P_CIC1: PUSH    EAX
        PUSH   ECX
        MOV    CL,AL
        CALL   P_CO           ;DISPLAY ON CONSOLE
        POP    ECX
        POP    EAX
        RET

P_BAD_CHAR:
        MOV    CL,BELL        ;SEND BELL TO INDICATE BAD DATA
        CALL   P_CO
        MOV    CL,'?'        ;SEND ? TO INDICATE BAD DATA
        CALL   P_CO
        RET

; SIMPLE SEND CRLF (32 BIT MODE) NO REGISTERS ALTERED
P_CRLF: pushad
        mov    cl,CR
        call   P_CO           ;32 Bit Console out
        mov    cl,LF
        call   P_CO
        popad
        ret

; CHECK FOR ^S or ESC AT CONSOL
P_CTRL_CHECK:

```



```
DB      6AH,3H
jmp     word PM_CC_INT_Routine      ;3 <<<< Software CC Interrupt >>>>
DB      6AH,4H
jmp     word PM_Overflow_INT_Routine ;4 Overflow INT
DB      6AH,5H
jmp     word PM_Bounds_INT_Routine  ;5 Bounds Check, FAULT
DB      6AH,6H
jmp     word PM_Opcode_INT_Routine  ;6 Invalid Opcode, FAULT
DB      6AH,7H
jmp     word PM_Device_INT_Routine  ;7 Device not available, FAULT
DB      6AH,8H
jmp     word PM_DFault_INT_Routine  ;8 Double fault Fault
DB      6AH,9H
jmp     word PM_MathSeg_INT_Routine  ;9 Math Coprocessor Segment error
DB      6AH,0AH
jmp     word PM_TSS_INT_Routine     ;10 Invalid TSS (+ Error Number)
DB      6AH,0BH
jmp     word PM_Segment_INT_Routine  ;11 Segment Error (+ Error Number)
DB      6AH,0CH
jmp     word PM_Stack_INT_Routine    ;12 Stack Exception (+ Error Number)
DB      6AH,0DH
jmp     word PM_General_INT_Routine  ;13 General Protection (+ Error Number)
DB      6AH,0EH
jmp     word PM_Page_INT_Routine     ;14 Page error, FAULT
DB      6AH,0FH
jmp     word PM_Intel_INT_Routine    ;15 Intel reserved TRAP

DB      6AH,10H
jmp     word PM_Coprocessor_INT_Routine ;16 Co-processor error, FAULT
DB      6AH,11H
jmp     word PM_Default_INT_Routine
DB      6AH,12H
jmp     word PM_Default_INT_Routine
DB      6AH,13H
jmp     word PM_Default_INT_Routine
DB      6AH,14H
jmp     word PM_Default_INT_Routine
DB      6AH,15H
jmp     word PM_Default_INT_Routine
DB      6AH,16H
jmp     word PM_Default_INT_Routine
DB      6AH,17H
jmp     word PM_Default_INT_Routine
DB      6AH,18H
jmp     word PM_Default_INT_Routine
DB      6AH,19H
jmp     word PM_Default_INT_Routine
DB      6AH,1AH
jmp     word PM_Default_INT_Routine
DB      6AH,1BH
jmp     word PM_Default_INT_Routine
DB      6AH,1CH
jmp     word PM_Default_INT_Routine
DB      6AH,1DH
jmp     word PM_Default_INT_Routine
DB      6AH,1EH
jmp     word PM_Default_INT_Routine
DB      6AH,1FH
jmp     word PM_Default_INT_Routine

DB      6AH,20H
jmp     word PM_Default_INT_Routine
DB      6AH,21H
jmp     word PM_Default_INT_Routine
DB      6AH,22H
jmp     word PM_Default_INT_Routine
```

```
DB      6AH,23H
jmp     word PM_Default_INT_Routine
DB      6AH,24H
jmp     word PM_Default_INT_Routine
DB      6AH,25H
jmp     word PM_Default_INT_Routine
DB      6AH,26H
jmp     word PM_Default_INT_Routine
DB      6AH,27H
jmp     word PM_Default_INT_Routine
DB      6AH,28H
jmp     word PM_Default_INT_Routine
DB      6AH,29H
jmp     word PM_Default_INT_Routine
DB      6AH,2AH
jmp     word PM_Default_INT_Routine
DB      6AH,2BH
jmp     word PM_Default_INT_Routine
DB      6AH,2CH
jmp     word PM_Default_INT_Routine
DB      6AH,2DH
jmp     word PM_Default_INT_Routine
DB      6AH,2EH
jmp     word PM_Default_INT_Routine
DB      6AH,2FH
jmp     word PM_Default_INT_Routine

DB      6AH,30H
jmp     word PM_Default_INT_Routine
DB      6AH,31H
jmp     word PM_Default_INT_Routine
DB      6AH,32H
jmp     word PM_Default_INT_Routine
DB      6AH,33H
jmp     word PM_Default_INT_Routine
DB      6AH,34H
jmp     word PM_Default_INT_Routine
DB      6AH,35H
jmp     word PM_Default_INT_Routine
DB      6AH,36H
jmp     word PM_Default_INT_Routine
DB      6AH,37H
jmp     word PM_Default_INT_Routine
DB      6AH,38H
jmp     word PM_Default_INT_Routine
DB      6AH,39H
jmp     word PM_Default_INT_Routine
DB      6AH,3AH
jmp     word PM_Default_INT_Routine
DB      6AH,3BH
jmp     word PM_Default_INT_Routine
DB      6AH,3CH
jmp     word PM_Default_INT_Routine
DB      6AH,3DH
jmp     word PM_Default_INT_Routine
DB      6AH,3EH
jmp     word PM_Default_INT_Routine
DB      6AH,3FH
jmp     word PM_Default_INT_Routine

DB      6AH,00H                               ;<--- note here we will pass the  ↙
hardware INT #
jmp     word PM_Default_8259A_INT_0_Routine   ;Will relocate the 8259A Ints to  ↙
here in PM
DB      6AH,01H
jmp     word P_MS_DOS_KEYPRESS               ;8259A Keypress Int
```

```
DB      6AH,02H
jmp     word PM_Default_8259A_INT_2_Routine
DB      6AH,03H
jmp     word PM_Default_8259A_INT_3_Routine
DB      6AH,04H
jmp     word PM_Default_8259A_INT_4_Routine
DB      6AH,05H
jmp     word PM_Default_8259A_INT_5_Routine
DB      6AH,06H
jmp     word PM_Default_8259A_INT_6_Routine
DB      6AH,07H
jmp     word PM_Default_8259A_INT_7_Routine
DB      6AH,48H                                ;Back to software INT#
jmp     word PM_Default_INT_Routine
DB      6AH,49H
jmp     word PM_Default_INT_Routine
DB      6AH,4AH
jmp     word PM_Default_INT_Routine
DB      6AH,4BH
jmp     word PM_Default_INT_Routine
DB      6AH,4CH
jmp     word PM_Default_INT_Routine
DB      6AH,4DH
jmp     word PM_Default_INT_Routine
DB      6AH,4EH
jmp     word PM_Default_INT_Routine
DB      6AH,4FH
jmp     word PM_Default_INT_Routine

DB      6AH,50H
jmp     word PM_Default_INT_Routine
DB      6AH,51H
jmp     word PM_Default_INT_Routine
DB      6AH,52H
jmp     word PM_Default_INT_Routine
DB      6AH,53H
jmp     word PM_Default_INT_Routine
DB      6AH,54H
jmp     word PM_Default_INT_Routine
DB      6AH,55H
jmp     word PM_Default_INT_Routine
DB      6AH,56H
jmp     word PM_Default_INT_Routine
DB      6AH,57H
jmp     word PM_Default_INT_Routine
DB      6AH,58H
jmp     word PM_Default_INT_Routine
DB      6AH,59H
jmp     word PM_Default_INT_Routine
DB      6AH,5AH
jmp     word PM_Default_INT_Routine
DB      6AH,5BH
jmp     word PM_Default_INT_Routine
DB      6AH,5CH
jmp     word PM_Default_INT_Routine
DB      6AH,5DH
jmp     word PM_Default_INT_Routine
DB      6AH,5EH
jmp     word PM_Default_INT_Routine
DB      6AH,5FH
jmp     word PM_Default_INT_Routine

DB      6AH,60H
jmp     word PM_Default_INT_Routine
DB      6AH,61H
jmp     word PM_Default_INT_Routine
```

```
DB      6AH,62H
jmp     word PM_Default_INT_Routine
DB      6AH,63H
jmp     word PM_Default_INT_Routine
DB      6AH,64H
jmp     word PM_Default_INT_Routine
DB      6AH,65H
jmp     word PM_Default_INT_Routine
DB      6AH,66H
jmp     word PM_Default_INT_Routine
DB      6AH,67H
jmp     word PM_Default_INT_Routine
DB      6AH,68H
jmp     word PM_Default_INT_Routine
DB      6AH,69H
jmp     word PM_Default_INT_Routine
DB      6AH,6AH
jmp     word PM_Default_INT_Routine
DB      6AH,6BH
jmp     word PM_Default_INT_Routine
DB      6AH,6CH
jmp     word PM_Default_INT_Routine
DB      6AH,6DH
jmp     word PM_Default_INT_Routine
DB      6AH,6EH
jmp     word PM_Default_INT_Routine
DB      6AH,6FH
jmp     word PM_Default_INT_Routine

DB      6AH,70H
jmp     word PM_Default_INT_Routine
DB      6AH,71H
jmp     word PM_Default_INT_Routine
DB      6AH,72H
jmp     word PM_Default_INT_Routine
DB      6AH,73H
jmp     word PM_Default_INT_Routine
DB      6AH,74H
jmp     word PM_Default_INT_Routine
DB      6AH,75H
jmp     word PM_Default_INT_Routine
DB      6AH,76H
jmp     word PM_Default_INT_Routine
DB      6AH,77H
jmp     word PM_Default_INT_Routine
DB      6AH,78H
jmp     word PM_Default_INT_Routine
DB      6AH,79H
jmp     word PM_Default_INT_Routine
DB      6AH,7AH
jmp     word PM_Default_INT_Routine
DB      6AH,7BH
jmp     word PM_Default_INT_Routine
DB      6AH,7CH
jmp     word PM_Default_INT_Routine
DB      6AH,7DH
jmp     word PM_Default_INT_Routine
DB      6AH,7EH
jmp     word PM_Default_INT_Routine
DB      6AH,7FH
jmp     word PM_Default_INT_Routine

DB      6AH,80H                ;Quirk with NASM forces 80H and above to a ↵
word!
jmp     word PM_Default_INT_Routine ;So use DB's
DB      6AH,81H
```

```
    jmp     word PM_Default_INT_Routine
    DB     6AH,82H
    jmp     word PM_Default_INT_Routine
    DB     6AH,83H
    jmp     word PM_Default_INT_Routine
    DB     6AH,84H
    jmp     word PM_Default_INT_Routine
    DB     6AH,85H
    jmp     word PM_Default_INT_Routine
    DB     6AH,86H
    jmp     word PM_Default_INT_Routine
    DB     6AH,87H
    jmp     word PM_Default_INT_Routine
    DB     6AH,88H
    jmp     word PM_Default_INT_Routine
    DB     6AH,89H
    jmp     word PM_Default_INT_Routine
    DB     6AH,8AH
    jmp     word PM_Default_INT_Routine
    DB     6AH,8BH
    jmp     word PM_Default_INT_Routine
    DB     6AH,8CH
    jmp     word PM_Default_INT_Routine
    DB     6AH,8DH
    jmp     word PM_Default_INT_Routine
    DB     6AH,8EH
    jmp     word PM_Default_INT_Routine
    DB     6AH,8FH
    jmp     word PM_Default_INT_Routine

    DB     6AH,90H
    jmp     word PM_Default_INT_Routine
    DB     6AH,91H
    jmp     word PM_Default_INT_Routine
    DB     6AH,92H
    jmp     word PM_Default_INT_Routine
    DB     6AH,93H
    jmp     word PM_Default_INT_Routine
    DB     6AH,94H
    jmp     word PM_Default_INT_Routine
    DB     6AH,95H
    jmp     word PM_Default_INT_Routine
    DB     6AH,96H
    jmp     word PM_Default_INT_Routine
    DB     6AH,97H
    jmp     word PM_Default_INT_Routine
    DB     6AH,98H
    jmp     word PM_Default_INT_Routine
    DB     6AH,99H
    jmp     word PM_Default_INT_Routine
    DB     6AH,9AH
    jmp     word PM_Default_INT_Routine
    DB     6AH,9BH
    jmp     word PM_Default_INT_Routine
    DB     6AH,9CH
    jmp     word PM_Default_INT_Routine
    DB     6AH,9DH
    jmp     word PM_Default_INT_Routine
    DB     6AH,9EH
    jmp     word PM_Default_INT_Routine
    DB     6AH,9FH
    jmp     word PM_Default_INT_Routine

    DB     6AH,0A0H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0A1H
```

```
    jmp     word PM_Default_INT_Routine
    DB     6AH,0A2H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0A3H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0A4H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0A5H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0A6H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0A7H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0A8H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0A9H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0AAH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0ABH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0ACH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0ADH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0AEH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0AFH
    jmp     word PM_Default_INT_Routine

    DB     6AH,0B0H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0B1H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0B2H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0B3H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0B4H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0B5H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0B6H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0B7H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0B8H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0B9H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0BAH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0BBH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0BCH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0BDH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0BEH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0BFH
    jmp     word PM_Default_INT_Routine

    DB     6AH,0C0H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0C1H
```



```
    jmp     word PM_Default_INT_Routine
    DB     6AH,0C2H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0C3H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0C4H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0C5H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0C6H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0C7H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0C8H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0C9H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0CAH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0CBH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0CCH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0CDH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0CEH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0CFH
    jmp     word PM_Default_INT_Routine

    DB     6AH,0D0H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0D1H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0D2H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0D3H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0D4H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0D5H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0D6H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0D7H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0D8H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0D9H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0DAH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0DBH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0DCH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0DDH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0DEH
    jmp     word PM_Default_INT_Routine
    DB     6AH,0DFH
    jmp     word PM_Default_INT_Routine

    DB     6AH,0E0H
    jmp     word PM_Default_INT_Routine
    DB     6AH,0E1H
```

```

jmp     word PM_Default_INT_Routine
DB     6AH,0E2H
jmp     word PM_Default_INT_Routine
DB     6AH,0E3H
jmp     word PM_Default_INT_Routine
DB     6AH,0E4H
jmp     word PM_Default_INT_Routine
DB     6AH,0E5H
jmp     word PM_Default_INT_Routine
DB     6AH,0E6H
jmp     word PM_Default_INT_Routine
DB     6AH,0E7H
jmp     word PM_Default_INT_Routine
DB     6AH,0E8H
jmp     word PM_Default_INT_Routine
DB     6AH,0E9H
jmp     word PM_Default_INT_Routine
DB     6AH,0EAH
jmp     word PM_Default_INT_Routine
DB     6AH,0EBH
jmp     word PM_Default_INT_Routine
DB     6AH,0ECH
jmp     word PM_Default_INT_Routine
DB     6AH,0EDH
jmp     word PM_Default_INT_Routine
DB     6AH,0EEH
jmp     word PM_Default_INT_Routine
DB     6AH,0EFH
jmp     word PM_Default_INT_Routine

DB     6AH,0F0H
jmp     word PM_Default_INT_Routine
DB     6AH,0F1H
jmp     word PM_Default_INT_Routine
DB     6AH,0F2H
jmp     word PM_Default_INT_Routine
DB     6AH,0F3H
jmp     word PM_Default_INT_Routine
DB     6AH,0F4H
jmp     word PM_Default_INT_Routine
DB     6AH,0F5H
jmp     word PM_Default_INT_Routine
DB     6AH,0F6H
jmp     word PM_Default_INT_Routine
DB     6AH,0F7H
jmp     word PM_Default_INT_Routine
DB     6AH,0F8H
jmp     word PM_Default_INT_Routine
DB     6AH,0F9H
jmp     word PM_Default_INT_Routine
DB     6AH,0FAH
jmp     word PM_Default_INT_Routine
DB     6AH,0FBH
jmp     word PM_Default_INT_Routine
DB     6AH,0FCH
jmp     word PM_Default_INT_Routine
DB     6AH,0FDH
jmp     word PM_Default_INT_Routine
DB     6AH,0FEH
jmp     word PM_Default_INT_Routine
IRET
/80486 Board?
;For INT 0FFH, Just return. (Noise on 80386

```

PM_Default_INT_Routine:

;Unless told otherwise all the above Ints ↵

```

will come here
PUSH    EAX                                ;Save what will be changed. Note IRET saves
  flags
PUSH    EBX
PUSH    EBP
MOV     EBP,ESP
mov     EBX,UNASSIGNED_1_INT_MSG           ;"Un-assigned Int #"
CALL    P_PRINT_STRING                     ;Note PRINT_STRING always uses the CS:
override for the BX pointer
MOV     EAX,[EBP+12]                       ;Interrupt number was passed on stack
CALL    P_AL_HEXOUT
MOV     EBX,H_MSG_CRLF
POP     EBP
P_INT_INFO_DONE:
CALL    P_PRINT_STRING                     ;Display message
POP     EBX
POP     EAX
ADD     ESP,4                              ;Balance up stack,return
IRET

PM_Zero_INT_Routine:                       ;Int #0, Divide by Zero, (Return address to
  error, so ABORT)
PUSH    EAX
PUSH    EBX
MOV     EBX,DIVIDE_MSG                     ;"Divide by 0 INT #0"
P_INT_HALT:
CALL    P_PRINT_STRING
MOV     EBX,CPU_HALTED_MSG                 ;"The CPU is Halted" +CRLF
CALL    P_PRINT_STRING
POP     EBX
POP     EAX
ADD     ESP,4                              ;Balance up stack,return in case other INT
's
HLT                                         ;Halt for all FAULTS

PM_NMI_INT_Routine:                       ;Int #2, NMI TRAP,
PUSH    EAX
PUSH    EBX
MOV     EBX,NMI_FAULT_MSG
JMP     P_INT_INFO_DONE

PM_Overflow_INT_Routine:                   ;Int #4, Overflow TRAP
PUSH    EAX
PUSH    EBX
MOV     EBX,OVERFLOW_ERR_MSG
JMP     P_INT_INFO_DONE

PM_Bounds_INT_Routine:
PUSH    EAX
PUSH    EBX
MOV     EBX,BOUNDS_ERR_MSG                 ;Int #5, Bounds Check, (Return address to
error, so ABORT)
JMP     P_INT_HALT                         ;Display text and halt

PM_Opcode_INT_Routine:
PUSH    EAX
PUSH    EBX
MOV     EBX,INVALID_ERR_MSG               ;Int #6, Invalid Opcode, (Return address to
error, so ABORT)
JMP     P_INT_HALT                         ;Display text and halt

PM_Device_INT_Routine:
PUSH    EAX
PUSH    EBX

```

```

MOV     EBX,DEVICE_ERR_MSG           ;Int #7, Math Coprocessor not available,  ✓
(Return address to error, so ABORT)
JMP     P_INT_HALT                   ;Display text and halt  ✓

PM_DFault_INT_Routine:
PUSH    EAX
PUSH    EBX
MOV     EBX,DOUBLE_ERR_MSG         ;Int #8, Double, (Return address to error,  ✓
so ABORT)
JMP     P_INT_HALT                   ;Display text and halt  ✓

PM_MathSeg_INT_Routine:
PUSH    EAX
PUSH    EBX
MOV     EBX,COPROCESSOR_ERR_MSG    ;Int #9, No Coprocessor, (ABORT anyway)  ✓
JMP     P_INT_HALT                   ;Display text and halt  ✓

PM_TSS_INT_Routine:
;Int #10, Invalid TSS, (+ ERROR #)
PUSH    EAX
PUSH    EBX
PUSH    EBP
MOV     EBX,INVALID_TSS_ERR_MSG

P_INT2_INFO_DONE:
CALL    P_PRINT_STRING
MOV     EBX,INT_ERR_NUM_MSG         ;Show the associated error number
CALL    P_PRINT_STRING
MOV     EBP,ESP
MOV     EAX,[EBP+14]                ;Get INT specific error number send by the  ✓
above relevent routine
CALL    P_AX_HEXOUT                 ;Need to check, +14, may not be correct
MOV     EBX,H_MSG_CRLF
POP     EBP                          ;Balance up for P_INT_HALT
JMP     P_INT_HALT                   ;Display text and halt  ✓

PM_Segment_INT_Routine:
;Int #11, Segment not present (+ ERROR #)
PUSH    EAX
PUSH    EBX
PUSH    EBP
MOV     EBX,SEGMENT_ERR_MSG
JMP     P_INT2_INFO_DONE

PM_Stack_INT_Routine:
;Int #12, Stack Exception (+ ERROR #)
PUSH    EAX
PUSH    EBX
PUSH    EBP
MOV     EBX,STACK_ERR_MSG
JMP     P_INT2_INFO_DONE

PM_General_INT_Routine:
;Int #13, General protection error (+ ERROR) ✓
#)
PUSH    EAX
PUSH    EBX
PUSH    EBP
MOV     EBX,GENERAL_ERR_MSG
JMP     P_INT2_INFO_DONE

PM_Page_INT_Routine:
;Int #14, Page fault
PUSH    EAX
PUSH    EBX
MOV     EBX,PAGE_ERR_MSG
JMP     P_INT_INFO_DONE             ;No CPU error number attached, so simple  ✓
return

```

```

PM_Intel_INT_Routine:                                ;Int #15, Intel reserved Int
    PUSH    EAX                                       ;To balance up stack for return
    PUSH    EBX
    MOV     EBX,RESERVED_ERR_MSG
    JMP     P_INT_INFO_DONE                           ;No CPU error number attached, so simple ✓
    return

PM_Coprocessor_INT_Routine:                          ;Int #16 Cprocessor Error
    PUSH    EAX                                       ;To balance up stack for return
    PUSH    EBX
    MOV     EBX,COPROCESSOR_ERR_MSG
    JMP     P_INT_HALT                               ;No CPU error number attached, so simple ✓
    return

PM_CC_INT_Routine:                                   ;INT #3, Software CC Interrupt
    CALL    P_DISPLAY_80386_REGISTERS                ;Display Protected Mode Registers
    PUSH    EAX
    PUSH    EBX
    PUSH    ECX
    PUSH    EBP
    MOV     EBP,ESP
    MOV     EBX,IP_ADDRESS_MSG                       ;IP=
    CALL    P_PRINT_STRING
    MOV     EAX,[EBP+20]                             ;Get return IP address on stack
    CALL    P_EAX_HEXOUT
    MOV     EBX,H_MSG_CRLF
    CALL    P_PRINT_STRING
    POP     EBP
    POP     ECX
    POP     EBX
    POP     EAX
    ADD     ESP,4                                     ;Balance up stack,return
    IRET                                           ;Remember the byte saved on the stack is ✓
    extended to a word by the CPU

PM_TRACE_INT_Routine:                               ;>>>>> INT#1, trace mode <<<<<<<
    CALL    P_DISPLAY_80386_REGISTERS                ;Display Protect Mode Registers
    PUSH    EAX
    PUSH    EBX
    PUSH    ECX
    PUSH    EBP
    MOV     EBP,ESP
    MOV     EBX,IP_ADDRESS_MSG                       ;IP=
    CALL    P_PRINT_STRING
    MOV     EAX,[EBP+20]                             ;Get return IP address on stack
    CALL    P_EAX_HEXOUT

    MOV     EAX,DR6                                  ;Find out if a DR0-3 register triggered the ✓
    INT
    AND     EAX,1                                     ;Was it DR0
    JNZ    NOT_DR0
    AND     EAX,0FFFFFFFEH                           ;Clear the bit 0
    MOV     DR7,EAX
    XOR     EAX,EAX
    MOV     DR0,EAX                                  ;Clear DR0 Just in case
    JMP     P_DR_RESET

NOT_DR0:
    AND     EAX,2                                     ;Was it DR1
    JNZ    NOT_DR1
    AND     EAX,0FFFFFFFDH                           ;Clear the bit 1
    MOV     DR7,EAX
    XOR     EAX,EAX

```

```

        MOV     DR1,EAX
        JMP     P_DR_RESET
NOT_DR1:
        AND     EAX,4                ;Was it DR2
        JNZ     NOT_DR2
        AND     EAX,0FFFFFFFBH      ;Clear the bit 2
        MOV     DR7,EAX
        XOR     EAX,EAX
        MOV     DR2,EAX
        JMP     P_DR_RESET
NOT_DR2:
        AND     EAX,8                ;Was it DR3
        JNZ     P_DR_RESET
        AND     EAX,0FFFFFFF7H      ;Clear the bit 3
        MOV     DR7,EAX
        XOR     EAX,EAX
        MOV     DR3,EAX
        JMP     P_DR_RESET

P_DR_RESET:
        MOV     EBX,TRACE_CONTINUE_MSG ;"H,CR,LF,Continue to trace ?"
        CALL   P_PRINT_STRING
        CALL   P_CICO
        CMP     AL,'Y'
        JZ      P_MORE_TRACE
        CMP     AL,SPACE              ;For speed, allow space bar as well
        JZ      P_MORE_TRACE
        CMP     AL,ESC
        JZ      Start32              ;Reload everything Stack may be bad
        AND     word [EBP+28],0FEFFH ;Clear Trace Flag
        CALL   P_CRLF
        JMP     P_FINISH_TRACE

P_MORE_TRACE:
        OR      word [EBP+28],0100H ;Turn ON trace Bit
P_FINISH_TRACE:
        POP     EBP
        POP     ECX
        POP     EBX
        POP     EAX
        ADD     ESP,4                ;Balance up stack,return
        IRET

P_TRACE_MODE_ON:
        ;Turn on CPU trace mode (can be used in code development)
        PUSH   AX
        PUSHF ;EFLAGS to stack
        POP    AX
        OR     AX,0100H ;Turn ON trace Bit
        PUSH   AX
        POPF   ;Move back into EFLAGS
        POP    AX
        RET

P_TRACE_MODE_OFF:
        ;Turn off CPU trace mode
        PUSH   AX
        PUSHF ;EFLAGS to stack
        POP    AX
        AND   AX,0FEFFH ;Turn OFF trace Bit
        PUSH   AX
        POPF   ;Move back into EFLAGS
        POP    AX
        RET

PM_Default_8259A_INT_0_Routine:
        ;Take care of PM 8259A Ints

```

```

PM_Default_8259A_INT_2_Routine:
PM_Default_8259A_INT_3_Routine:
PM_Default_8259A_INT_4_Routine:
PM_Default_8259A_INT_5_Routine:
PM_Default_8259A_INT_6_Routine:
PM_Default_8259A_INT_7_Routine:
    PUSH    EAX
    PUSH    EBX
    PUSH    ECX
    PUSH    EBP
    MOV     EBP,ESP
    MOV     EBX,DEFAULT_8259_INT1           ;"Default 8259 PM Interrupt INT#"
    CALL    P_PRINT_STRING
    MOV     EAX,[EBP+16]                   ;Get Hardware INT# passed on stack
    CALL    P_AL_HEXOUT
    MOV     EBX,DEFAULT_8259_INT2           ;"H. IP="
    CALL    P_PRINT_STRING
    MOV     EAX,[EBP+20]                   ;Get return IP address on stack
    CALL    P_EAX_HEXOUT
    MOV     EBX,H_MSG_CRLF                  ;"H. CRLF"
    CALL    P_PRINT_STRING
    POP     EBP
    POP     ECX
    POP     EBX
    POP     EAX
    ADD     ESP,4                           ;Balance up stack,return
    IRET

P_MS_DOS_KEYPRESS:                       ;PM 8259A Vector #1 keyboard Input Routine
    PUSH    EAX
    PUSH    EBX
    PUSH    ECX
    PUSH    EBP
    MOV     EBP,ESP
    in     al,KEYIN                         ;Get KEYBOARD DATA
    and    al,7fh                           ;strip parity bit (if any)
    mov    bl,[chrCnt]                      ;get current character count (chrCnt=419H)
    cmp    bl,byte chrmax                   ;is the buffer full? (chrmax=32)
    jge    P_keyxt                          ;ignore if buffer full
    inc    bl
    mov    [chrCnt],bl                      ;store new character count
    mov    dword ebx,[PM_BUFFER_END]        ;get destination address
    mov    [ebx],al                          ;store the character

    inc    ebx                               ;bump buffer address
    mov    dword [PM_BUFFER_END],ebx        ;get destination address
    cmp    dword ebx,keybuff+32             ;at end of buffer?
    jl     P_keyxt                          ;skip if not
    mov    [PM_BUFFER_END],dword keybuff    ;Pointer for end of keyboard buffer back to
    start

P_keyxt:mov    al,NS_EOI
    OUT    MASTER_PIC_PORT,al
    POP    EBP
    POP    ECX
    POP    EBX
    POP    EAX
    ADD    SP,4                             ;Balance up stack,return
    IRET

CPU 8086                                 ;Allow 8086 Opcodes only
[BITS 16]                               ;<<<<<<<<< Back to default 16 bit code

```

```

;End of the bios code

;+++++
;
;   Data contained in BIOS (Does not get modified, rommable)
;
;
;***** DATA SECTION *****
;*****

;   RM Interrupt vector table for 8259A

vec_tbl_8259A:                                ;Pointer to 8259A Hardware
interrupts used here
dw   timer                ;Interrupt Base + 0   ;Will use timer
dw   keyhnd               ;Interrupt Base + 1   ;Will use for keyboard press
dw   Send_EOI             ;Interrupt Base + 2
dw   Send_EOI             ;Interrupt Base + 3
dw   Send_EOI             ;Interrupt Base + 4
dw   Send_EOI             ;Interrupt Base + 5
dw   Send_EOI             ;Interrupt Base + 6
dw   Send_EOI             ;Interrupt Base + 7

vec_tbl_soft_ints:                          ;Pointer to software interrupts
used here
dw   CONOUT               ;interrupt 10
dw   equip                ;interrupt 11
dw   memsiz               ;interrupt 12
dw   DISKIO               ;interrupt 13
dw   commio               ;interrupt 14
dw   CASSETTE             ;interrupt 15
dw   CONIN                ;interrupt 16
dw   LST_OUT              ;interrupt 17
dw   basic                ;interrupt 18
dw   BOOT_DOS_INT        ;interrupt 19
dw   time_of_day          ;interrupt 1A
dw   kbd_break            ;interrupt 1B
dw   user_timer           ;interrupt 1C
dw   VID_PARM_TABLES     ;interrupt 1D
dw   FDISK_3PARAM_TBL    ;interrupt 1E           ;Default to 1.44M Disk
dw   0                    ;interrupt 1F

;
;
INITIAL_VGA_VALUES:                          ;to initilize properly with
MS-DOS. (Starting at 0:449H...)
    DB   03H                ;CRT_MODE
    DW   0050H              ;CRT_COLS
    DW   1000H              ;CRT_LEN
    DW   0000H              ;CRT_START
    DW   0000H,0000H,0000H,0000H ;CURSOR_POSN (8 Total)
(Must be 0000 for first one at initialization!)
    DW   0000H,0000H,0000H,0000H
    DW   0607H              ;CURSOR_MODE
    DB   0H                  ;ACTIVE_PAGE
    DW   3D4H                ;ADDR_6845
    DB   29H                  ;CRT_MODE_SET
    DB   30H                  ;CRT_PALLETTE
IVGA_VAL_LEN EQU $-INITIAL_VGA_VALUES

;   Miscellaneous Data Area
;
VID_PARM_TABLES db   38h,28h,2dh,0ah,1fh,6,19h ;for 40 x 25
                 db   1ch,2,7,6,7

```



```

                db      0,0,0,0

                db      71h,50h,5ah,0ah,1fh,6,19h          ;for 80 x 25
                db      1ch,2,7,6,7
                db      0,0,0,0

                db      38h,28h,2dh,0ah,7fh,6,64h          ;for graphics
                db      70h,2,1,6,7
                db      0,0,0,0

                db      61h,50h,52h,0fh,19h,6,19h          ;for 80 x 25 on b/w card
                db      19h,2,0dh,0bh,0ch
                db      0,0,0,0

m5              dw      2048                                ;40 x 25 length
                dw      4096                                ;80 x 25
                dw      16384                               ;graphics
                dw      16384

m6              db      40,40,80,80,40,40,80,80            ;columns

m7              db      2ch,28h,2dh,29h,2ah,2eh,1eh,29h    ;table of Video board mode ↵
sets

                                                         ;Paramaters that MUST be in ↵

                low RAM for the Lomas CGA board
                DB      '<-JMP to VIDIO PARMS TABLE '

;              Default Floppy Disk Parameters Tables
;              Most are unique to the NEC 765 controller used in the IBM-PC.
;              I do not use them in this BIOS

FDISK_5PARAM_TBL db      0DFH                                ;For 5" 360K Disks
                db      2
                db      25                                ;Time delay for motor
                db      2                                ;512 byte sectors
                db      09H                                ;sectors per track!
                db      02ah                               ;GAP length
                db      0ffh                               ;DTL
                db      050h                               ;GAP length for format
                db      0f6h                               ;Fill byte for format
                db      25                                ;Head settle time
                db      4                                 ;Motor stat time
                db      11                                ;length of Table

FDISK_3PARAM_TBL db      0AFH                                ;For 3" 1.44M Disks
                db      2
                db      25                                ;Time delay for motor
                db      2                                ;512 byte sectors
                db      12H                                ;18 sectors per track
                db      1BH                                ;GAP length
                db      0FFH                               ;DTL
                db      6CH                                ;GAP length for format
                db      0F6H                               ;Fill byte for format
                db      0FH                                ;Head settle time
                db      8                                 ;Motor stat time
                db      11                                ;length of Table

;              Default Hard Disk Parameters Table:-
;              Custom HDISK: 1024 Cylinders, 15 heads, 63 sectors, 512MB Total

HDISK_PARM_TBL  DW      DOS_MAXCYL                        ;0, Max Cylinders

```

```

        DB      DOS_MAXHEADS      ;2, Max heads (15)
        DW      0000H              ;3, Not used on AT
        DW      0FFFFH            ;5, Start Write Precomp (not used)
        DB      0H                 ;7, ECC burst length (not used)
        DB      08H                ;8, "Control Byte" (Bit 7 = disable retrys)
        DB      0H,0H,0H          ;9, Timeouts no used on AT
        DW      0400H              ;A, Landing zone
        DB      DOS_MAXSEC        ;B, Sec/track
        DB      0H,0H,0H,0H       ;C, Reserved

SYS_TABLE    DW      8H            ;Called by INT 15H, AH=C0H called by MSDOS V3+
             DB      0FCH          ;Machine ID Byte
             DB      0             ;Sub model
             DB      0             ;BIOS version
             DB      10H           ;Keyboard Int
             DB      0,0,0

;MAIN MENU COMMAND BRANCH TABLE

ctable      dw      MAP            ;A                ;Display Memory Map
             dw      SET_CO_FLAG   ;B                ;Set Console output to Propeller, ✓
LAVA-10 or  CGA/VGA Video board
             dw      MMENU_FBOOT_DOS ;C                ;LOAD MS-DOS from 5" Floppy ((No ✓
debugging))
             dw      DISPLAY_RAM_BYTES ;D                ;Display Memory contents (Read RAM ✓
in Bytes)
             dw      SET_TIME_DATE  ;E                ;Display/Set Time & Date
             dw      FILL           ;F                ;Fill memory contents
             dw      GOTO           ;G                ;Jump to a SEG:ADDRESS location
             dw      RAM_RD_WR_TESTS ;H                ;For S100 Bus RAM RD/WR hardware ✓
signal testing
             dw      SOFT_INTS      ;I                ;Test Software interrupts
             dw      TEST_RAM       ;J                ;Test RAM
             dw      KCMD           ;K                ;Display this menu
             dw      TEST_8259      ;L                ;Test 8259A hardware
             dw      MOVE           ;M                ;Move memory
             dw      MYIDE          ;N                ;Sub-menu to test/diagnose IDE ✓
Board
             dw      GO_TO_PMODE    ;O                ;<<<< Go to protect mode
             dw      MMENU_HBOOT_DOS ;P                ;LOAD MS-DOS from HDISK (No ✓
debugging)
             dw      QUERY          ;Q                ;Query In or Out to a port
             dw      REGISTERS      ;R                ;Display the 8086 registers in RM
             dw      SUBSTITUTE     ;S                ;Substitute byte values in RAM
             dw      DISPLAY_RAM_WORDS ;T                ;Display Memory contents (Read RAM ✓
in Words)
             dw      INPORTS        ;U                ;Display all active 8086 INPUT ✓
ports
             dw      VERIFY         ;V                ;Verify two memory regions are the ✓
same
             dw      XMODEM_LOAD    ;W                ;Load code to RAM from Modem/Serial ✓
port
             dw      IBM_BIOS       ;X                ;IBM-PC Sub menu
             DW      PATCH          ;Y                ;Quick patch to move RAM 4000H- ✓
9000H to f4000h & JUMP to it
             dw      Z80            ;Z                ;Return back to Z80 master

;PROTECT MODE MENU COMMAND BRANCH TABLE

PMODE_table dw      P_MAP           ;A                ;Display Memory Map
             dw      P_ERR          ;B
             dw      P_ERR          ;C
             dw      P_DISPLAY_RAM_BYTES ;D                ;Display Memory contents (Read RAM ✓
in Bytes)
             dw      P_ERR          ;E

```

```

        dw      P_FILL          ;F          ;Fill memory contents
        dw      P_GOTO         ;G          ;Jump to an absolute 32 bit
location
        dw      P_HEXMATH      ;H          ;Add & Subtract two Hex numbers
        dw      P_SOFT_INTS    ;I          ;PM Interrupt tests
        dw      P_PM_MEM_TEST  ;J          ;PM hardware test of RAM (500H to
4GB)
        dw      P_MODE_MENU    ;K          ;Display this menu
        dw      P_TEST_8259    ;L          ;PM Test 8259A hardware
        dw      P_MOVE         ;M          ;Move memory
        dw      P_ERR          ;N
        dw      P_GOTO_REAL_MODE ;O          ;<<< Back to 8086/Real mode
        dw      P_ERR          ;P
        dw      P_QUERY        ;Q          ;Query In or Out to a port
        dw      P_DISPLAY_REG  ;R          ;Display 80386/80486 Registers
        dw      P_SUBSTITUTE    ;S          ;Substitute byte values in RAM
        dw      P_DISPLAY_RAM_DWORDS ;T          ;Display Memory contents (Read RAM
in Words)
        dw      P_ERR          ;U
        dw      P_VERIFY       ;V          ;Verify two memory regions are the
same
        dw      P_XMODEM_LOAD  ;W          ;Load code to RAM from Modem/Serial
port
        dw      P_SET_BREAKPOINTS ;X          ;Set 80386/80486 Hardware
Breakpoints
        DW      P_EXE_IN_PM_RAM ;Y          ;Execute test code in RAM > 16 MB
        dw      P_Z80          ;Z          ;Return back to Z80 master

```

;IDE COMMAND BRANCH TABLE

```

IDE_TABLE  DW  SET_DRIVE_A      ; "A"  Select Drive A
           DW  SET_DRIVE_B      ; "B"  Select Drive B
           DW  ERR               ; "C"  LOAD CPM (If present)
           DW  DISPLAY          ; "D"  Sector contents display:- ON/OFF
           DW  RAMCLEAR         ; "E"  Clear RAM buffer
           DW  FORMAT           ; "F"  Format current disk
           DW  ERR               ; "G"  Restore backup
           DW  HEXMATH          ; "H"  Add & Subtract two Hex numbers
           DW  NEXT_SECT        ; "I"  Next Sector
           DW  PREV_SECT        ; "J"  Previous sector
           DW  IDE_LOOP         ; "K"
           DW  SET_LBA          ; "L"  Set LBA value (Set Track,sector)
           DW  ERR               ; "M"
           DW  SPINDOWN         ; "N"  Power down hard disk command
           DW  DRIVE_ID         ; "O"  Show current Drive ID
           DW  ERR               ; "P"
           DW  LBA_DISPLAY_TEST ; "Q"  Check the LBA mode HEX display on the IDE
board is working correctly
           DW  READ_SEC         ; "R"  Read sector to data buffer
           DW  SEQ_SEC_RD       ; "S"  Sequential sec read and display contents
           DW  ERR               ; "T"
           DW  SPINUP           ; "U"  Power up hard disk command
           DW  N_RD_SEC         ; "V"  Read N sectors
           DW  WRITE_SEC        ; "W"  Write data buffer to current sector
           DW  N_WR_SEC         ; "X"  Write N sectors
           DW  COPY_AB          ; "Y"  Copy Drive A to Drive B
           DW  VERIFY_AB        ; "Z"  Verify Drive A:= Drive B:

```

;IBM_BIOS COMMAND BRANCH TABLE

```

IBM_TABLE  dw      MENU_TIMER_TEST ;A
           dw      SET_CO_FLAG      ;B          Set Console output to Propeller or CGA/VGA
Video board
           dw      MENU_FBOOT_DOS   ;C          Boot MS-DOS from 5" floppy (Allow
Debugging)
           dw      DEBUG_ON_OFF     ;D

```



```

CLEANUP          DB      CR,LF,BELL,'>$'
SMSG_REAL3      DB      '3 8 6 4 8 6 MONITOR VERSION 1.74 IS NOW IN REAL MODE! $$'
SHOWSTACK      DB      'Stack pointer = $'
TO_BE_DONE      DB      CR,LF,'Code not done yet!',CR,LF,'$'
AXMSG           DB      'AX=$'
BXMSG           DB      'H BX=$'
CXMSG           DB      'H CX=$'
DXMSG           DB      'H DX=$'
DIMSG           DB      'H DI=$'
SIMSG           DB      'H SI=$'
CSMSG           DB      'CS=$'
SPMSG           DB      'H SP=$'
SSMSG           DB      'H SS=$'
DSMSG           DB      'H DS=$'
ESMSG           DB      'H ES=$'
BPMSG           DB      'H BP=$'
FSMSG           DB      'H FS=$'
GSMSG           DB      'H GS=$'
H_MSG           DB      'H$'
AddressErrMsg   DB      CR,LF,'Address paramater error.$'
RangeErrMsg     DB      CR,LF,'Paramater range error.$'

MAIN_MENU       DB      CR,LF
                DB      'A=Memmap      B=Video      C=DOS(F)      D=Disp RAM      E=Time & Date',CR
,LF
                DB      'F=Fill RAM      G=Goto      H=Rd/Wr Test  I=Interrupts  J=Test RAM',CR,LF
                DB      'K=Menu      L=8259A      M=Move RAM      N=IDE Menu      O=Enter Protect
Mode',CR,LF
                DB      'P=DOS(H)      Q=Ports      R=Registers      S=Subs      T=Disp RAM
(Words)',CR,LF
                DB      'U=All Ports  V=Verify      W=XModem      X=PC-BIOS      Y=PATCH      Z=Z80'
                DB      CR,LF,'$'

DIFF_Header_Msg DB      CR,LF,'First RAM      HEX Binary      Second RAM      HEX Binary$'
MATCHES_OK      DB      CR,LF,'Both RAM locations match$'
PORTS_IN_MSG    DB      CR,LF,'Input Ports, 0-0FFFFH Ports. (16 Bit Port DX->AX and DX->
AL)',CR,LF,LF,'$'
MORE_MSG        DB      CR,LF,'Continue ? (Y/N) $'
MSG30           DB      CR,LF,'Adj :- $'
MSG12T          DB      ' $'
MSG16T          DB      '/20$'

EX_CODE_MSG     DB      CR,LF,LF,'Continous test PM code execution in extended RAM.',CR,LF,
'Please enter RAM location (+CR). $'
EX_CODE1_MSG    DB      CR,LF,LF,'Will now run test PM code at location $'
EX_CODE2_MSG    DB      'H. Hit ESC any time to abort',CR,LF,LF,LF,'$'

TMMSG           DB      CR,LF,'Time:- $'
GET_SEG_MSG     DB      CR,LF,'Enter Segment (xxxxH)->$'
GET_OFFS_MSG    DB      CR,LF,'Enter Offset (xxxxH)->$'
MATH_MSG        DB      CR,LF,LF,'Hex Math. Enter xxxxH,xxxxH:- $'
MATH_HEADER1    DB      CR,LF,'Sum = $'
MATH_HEADER2    DB      'H. Difference = $'
PIC_SIGNON      DB      CR,LF,LF,'Test of Interrupts on the MSDOS Support Board',CR,LF
                DB      'Any keyboard key should flash the "D1" LED.',CR,LF
                DB      'Indicating the 8279A picked up an Int (V1).',CR,LF
                DB      'The CPU returned sINTA signal should flash the MSDOS Support Board
"D2" LED.',CR,LF,LF,'$'
CRLFMSG         DB      CR,LF,'$'

DIVIDE_MSG      DB      CR,LF,'Int #0 (Invalid Divide), FAULT',CR,LF,'$'
PM_DIVIDE_MSG   DB      'PM Int 0 Divide, FAULT',CR,LF,'$'
DEBUG_MSG       DB      'Int 1 Debug Exception, TRAP',CR,LF,LF,'$'
BREAKPOINT_MSG DB      'Int 3 Breakpoint, TRAP',CR,LF,LF,'$'
NMI_FAULT_MSG   DB      CR,LF,'Int #2 (NMI Interrupt), TRAP',CR,LF,'$'

```

```

OVERFLOW_ERR_MSG      DB      CR,LF,'Int #4 (Overflow), TRAP',CR,LF,'$'
BOUNDS_ERR_MSG        DB      CR,LF,'Int #5 (Bounds Check), FAULT',CR,LF,'$'
INVALID_ERR_MSG       DB      CR,LF,'Int #6 (Invalid Opcode), FAULT',CR,LF,'$'
DEVICE_ERR_MSG        DB      CR,LF,'Int #7 (No Coprocessor), FAULT',CR,LF,'$'
DOUBLE_ERR_MSG        DB      CR,LF,'Int #8 (Double Fault), ABORT',CR,LF,'$'
COPROCESSOR_SEG_ERR_MSG DB    CR,LF,'Int #9 Co-processor Segment Overrun, ABORT',CR,LF,'$'

INVALID_TSS_ERR_MSG   DB      CR,LF,'Int #10 Invalid TSS, FAULT, $'
INT_ERR_NUM_MSG       DB      'Error Number = $'
SEGMENT_ERR_MSG       DB      CR,LF,'Int #11 Segment not present, FAULT, $'
STACK_ERR_MSG         DB      CR,LF,'Int #12, Stack exception, FAULT $'
GENERAL_ERR_MSG       DB      CR,LF,'Int #13 General protection error, FAULT $'
PAGE_ERR_MSG          DB      CR,LF,'Int #14 Page Fault, FAULT',CR,LF,'$'
RESERVED_ERR_MSG      DB      CR,LF,'INT #15 Intel Reserved Int, TRAP',CR,LF,'$'
COPROCESSOR_ERR_MSG   DB      CR,LF,'Int #16 Co-processor error, FAULT',CR,LF,'$'
CPU_HALTED_MSG        DB      'The CPU is Halted. Press Reset to restart.',CR,LF,'$'

INT_SIGNON            DB      CR,LF,LF,'Test of CPU FAULT & TRAP Interrupts.'
                      DB      CR,LF,'Note. The CPU will HALT upon accepting FAULTS!'
                      DB      CR,LF,LF,'CPU Interrupt Testing Menu',CR,LF
                      DB      '00 = Divide by Zero FAULT test',CR,LF
                      DB      '04 = Overflow TRAP test',CR,LF
                      DB      '06 = Invalid Opcode FAULT test',CR,LF
                      DB      '0D = General Protection Fault, FAULT test',CR,LF
                      DB      '40 = Software Int 40H test',CR,LF
                      DB      'F0 = Software Int F0H test',CR,LF,LF
IDE_MENU              DB      'Enter a Command:- $'

INT_RANGE_MSG         DB      CR,LF,BELL,'Only CPU interrupts 00, 04, 06, 0D, 40 or F0 are valid
                      for this test.',CR,LF,'$'

MODEM_SIGNON:         DB      'Load a File from a PC into RAM using the S100Computers IO Board',
                      CR,LF
                      DB      'Zilog SCC Ports A1H & A3H. Requires RTS & CTS, 38,400 Baud.',CR,LF
                      , '$'
SSC_MSG_INIT          DB      'SCC Port A initilized to 38,400 Baud.',CR,LF,LF,'$'
RAM_DESTINATION       DB      CR,LF,'Enter destination in RAM for data (up to 5 digits): $'
P_RAM_DESTINATION     DB      CR,LF,'Enter destination in RAM for data (up to 8 digits): $'
DOWNLOAD_MSG          DB      'Downloading file Started.$'
SPEED_MSG             DB      'Serial Port is set to 38,400 Baaud$'
RMSG                  DB      CR,LF,'WAITING FOR SECTOR #$'
ERRSOH                DB      'H Received',CR,LF,'Did not get Correct SOH',CR,LF,'$'
MODEM_ERR2            DB      CR,LF,'Bad Sector # in Header',CR,LF,'$'
MODEM_ERR3            DB      CR,LF,'Bad Checksum for Sector',CR,LF,'$'
TOUTM                 DB      CR,LF,'Timeout! $'
QUITM                 DB      CR,LF,'+++ MULTIPLE ERRORS ENCOUNTERED +++'
                      DB      CR,LF,'Type Q To Quit, R To Retry:$'
RAM_MSG               DB      'H. If OK will write to RAM location $'
FINISH_MSG            DB      'Down loading of file complete. No Errors$'
TRANS_DONE            DB      CR,LF,LF,'Data Transfer Is Complete',CR,LF,LF,'$'
BAD_HEADER            DB      CR,LF,'Unable to get a valid file header!',CR,LF,'$'
ENTER_RAM_LOC         DB      CR,LF,'Enter start RAM destination (1000H - FF000H) (xx000H): $'
START_POINTER         DB      CR,LF,'Will load data starting at RAM location $'
ABORT_MSG             DB      CR,LF,LF,'Invalid Character or Program Aborted',CR,LF,'$'

IDE_SIGNON0           DB      CR,LF,LF,'IDE HDisk Test Menu Routines. $'
IDE_SIGNON4           DB      'A=Select Drive A B=Select Drive B C=Boot CPM D=Set Sec Display
                      $'
IDE_SIGNON1           DB      'On',CR,LF,'$'
IDE_SIGNON2           DB      'Off',CR,LF,'$'
IDE_SIGNON3           DB      'E=Clear Sec Buff F=Format Disk H=HEX Math I=Next Sec',
                      CR,LF
                      DB      'J=Previous Sec L=Set LBA Value N=Power Down O=Disk ID',
                      CR,LF
                      DB      'Q=LBA Display R=Read Sector S=Seq Sec Rd U=Power Up',

```

```

CR,LF
,CR,LF
IDE_HARDWARE
INIT_1_ERROR:
INIT_2_ERROR:
BAD_DRIVE:
msgmdl
msgsn
msgrev
msgcy
msghd
msgsc
msgCPMTRK
msgCPMSEC
msgLBA
MSGBracket
H_MSG_CRLF
NotDoneYet
CONFIRM_WR_MSG
msgrd
msgwr
SET_LBA_MSG
SEC_RW_ERROR
ERR_REG_DATA
ENTERRAM_SECL
ENTERRAM_HEAD
ENTERRAM_FTRKL
ENTERRAM_TRKL
ENTERRAM_TRKH
ENTER_HEAD
ENTER_COUNT
ENTERRAM_DMA
OVER_COUNT_10
OVER_COUNT_19
DRIVE_BUSY
DRIVE_NOT_READY
DRIVE_WR_FAULT
UNKNOWN_ERROR
BAD_BLOCK
UNRECOVER_ERR
READ_ID_ERROR
SEC_NOT_FOUND
INVALID_CMD
TRK0_ERR
UNKNOWN_ERROR1
CONTINUE_MSG
FORMAT_MSG_A
FORMAT_MSG_B
ATHOME_MSG
AT_START_MSG
AT_END_MSG
FILL_MSG
READN_MSG
buffer.'

```

DB 'V=Read N Sectors W=Write Sector X=Wr N Sectors Y=Copy A->B'↵

DB 'Z=Verify A=B ESC) Back to Main Menu',CR,LF

DB LF,'Current settings:- \$'

DB CR,LF,'Initilizing IDE Board, one moment please... ',CR,LF,'\$'

DB CR,LF,'Initilizing of First Drive failed. Aborting Command.',BELL,↵

DB CR,LF,LF,\$'

DB CR,LF,'Initilizing of Second Drive failed. (Possibly not present). '↵

DB ,BELL,CR,LF,LF,\$'

DB CR,LF,'First Drive ID Informnation appears invalid. '

DB '(Drive possibly not present). ',CR,LF

DB 'Aborting Command.',BELL,CR,LF,LF,\$'

DB CR,LF,'Drive/CF Card Information:- ',CR,LF

DB 'Model: \$'

DB 'S/N: \$'

DB 'Rev: \$'

DB 'Cylinders: \$'

DB ', Heads: \$'

DB ', Sectors: \$'

DB 'CPM TRK = \$'

DB ' CPM SEC = \$'

DB ' (LBA = 00\$'

DB ')\$'

DB 'H',CR,LF,\$'

DB CR,LF,'Command Not Done Yet\$'

DB CR,LF,LF,BELL,'Will erase data on the current drive, '

DB 'are you sure? (Y/N)...\$'

DB 'Sector Read OK',CR,LF,\$'

DB 'Sector Write OK',CR,LF,\$'

DB 'Enter CPM style TRK & SEC values (in hex). ',CR,LF,\$'

DB 'Drive Error, Status Register = \$'

DB 'Drive Error, Error Register = \$'

DB 'Starting sector number,(xxH) = \$'

DB 'Starting HEAD number,(xxH) = \$'

DB 'Enter Starting Track number,(xxH) = \$'

DB 'Track number (LOW byte, xxH) = \$'

DB 'Track number (HIGH byte, xxH) = \$'

DB 'Head number (01-0f) = \$'

DB 'Number of sectors to R/W (xxH) = \$'

DB 'Enter DMA Adress (Up to 5 digits, xxxxxH) = \$'

DB CR,LF,'1 & 9 sectors. Only!',CR,LF,\$'

DB CR,LF,'1 & 18 sectors. Only!',CR,LF,\$'

DB 'Drive Busy (bit 7) stuck high. Status = \$'

DB 'Drive Ready (bit 6) stuck low. Status = \$'

DB 'Drive write fault. Status = \$'

DB 'Unknown error in status register. Status = \$'

DB 'Bad Sector ID. Error Register = \$'

DB 'Uncorrectable data error. Error Register = \$'

DB 'Error setting up to read Drive ID',CR,LF,\$'

DB 'Sector not found. Error Register = \$'

DB 'Invalid Command. Error Register = \$'

DB 'Track Zero not found. Error Register = \$'

DB 'Unknown Error. Error Register = \$'

DB CR,LF,'To Abort enter ESC. Any other key to continue. \$'

DB 'Fill disk sectors of Disk [A] with 0E5H\$'

DB 'Fill disk sectors of Disk [B] with 0E5H\$'

DB CR,LF,BELL,'Already on Track 0, Sector 0\$'

DB CR,LF,BELL,'Already at start of disk!\$'

DB CR,LF,BELL,'At end of Disk!\$'

DB CR,LF,'Sector buffer area cleared to 0000....\$'

DB CR,LF,'Read multiple sectors from current disk/CF card to RAM ↵

DB CR,LF,'How many 512 byte sectores (xx HEX):\$'

```

WRITEN_MSG      DB      CR,LF,'Write multiple sectors RAM buffer CURRENT disk/CF card.'
                DB      CR,LF,'How many 512 byte sectores (xx HEX):$'
READN_S_MSG     DB      CR,LF,'Read Sector to RAM buffer. $'
WRITEN_S_MSG    DB      CR,LF,'Write Sector from RAM buffer. $'

DiskCopyMsg     DB      CR,LF,'Copy CPM Partition on Drive A to Drive B (Y/N)? $'
DiskVerifyMsg   DB      CR,LF,'Will verify CPM Partition on Drive A to Drive B.$'
CopyDone        DB      CR,LF,'Disk Copy Done.$'
VERIFY_ERR      DB      CR,LF,BELL,'Verify Error. $'
VerifyDone      DB      CR,LF,'Disk Verify Done.$'
CR_To_Continue  DB      CR,LF,'Hit any key to continue.$'
OK_CR_MSG       DB      ' OK',CR,LF,'$'
COPY_ERR        DB      CR,LF,BELL,'Sector Copy Error.$'
CURRENT_MSG_A   DB      ' <<<<< Current Drive = [A] >>>>>',CR,LF,LF,'$'
CURRENT_MSG_B   DB      ' <<<<< Current Drive = [B] >>>>>',CR,LF,LF,'$'
FORMAT_ERR      DB      CR,LF,BELL,'Sector Format Error$'
ERR_MSG         DB      CR,LF,BELL,'Invalid Command (or code not yet done)',CR,LF,'$'

IBM_SIGNON_MSG  DB      CR,LF,LF,'IBM PC BIOS Initilizing$'
IBM_MENU1       DB      CR,LF,LF,'IBM-PC BIOS Test Menu.      (Debug Flag = $'
IBM_MENU_ON     DB      'ON)',CR,LF,'$'
IBM_MENU_OFF    DB      'OFF)',CR,LF,'$'
IBM_MENU2       DB      'A=Timer Test          B=Propeller/LAVA/VGA      C=MS-DOS Boot      ✓
                (Floppy)',CR,LF
                DB      'D=Toggle Debug Flag      E=Key Press Test      F=Consol Out Test ✓
                ',CR,LF
                DB      'G=Keyboard Buffer Test      H=INT 10H CMDs      I=Print Screen      ✓
Test',CR,LF
                DB      'J=RAM Byte READ Test      K=RAM Word READ Test      L=RAM Byte WRITE ✓
Test',CR,LF
                DB      'M=RAM Word WRITE Test      O=Out to Serial Port      P=MS-DOS Boot      ✓
                (HDISK)',CR,LF
                DB      'Q=CHS Hex Display Test      S=5" Floppy Sec RD Test T=3" Floppy Sec ✓
RD Test',CR,LF
                DB      'U=HDisk Sec RD Test      W=HDisk Sector R/W Test Y=Floppy Boot Sec ✓
                Info',CR,LF
                DB      'Z=Hard Disk MBR Info      (ESC) Back to Main Menu',CR,LF,LF,'>$'

NMI_MSG         DB      CR,LF,BELL,'Recieved an NMI Interrupt.',CR,LF,'$'
ZFDC_FAIL_MSG   DB      CR,LF,BELL,'ZFDC Board failed to initilize',CR,LF,'$'
ZFDC_OK_MSG     DB      CR,LF,'ZFDC Board Initilize OK',CR,LF,'$'
PIC_INIT_MSG    DB      CR,LF,'Initilizing 8259A PIC (Port 20H, Ints 0 & 1 only)$'
RESET_FAIL_MSG  DB      CR,LF,BELL,'Reset of floppy drive failed.',CR,LF,'$'
HRESET_FAIL_MSG DB      CR,LF,BELL,'Reset of Hard Disk drive failed.',CR,LF,'$'
BOOT_FAIL_MSG   DB      CR,LF,BELL,'Boot sector read on floppy drive failed.',CR,LF,'$'
BOOT_OK_MSG     DB      CR,LF,'Boot Sector Loader Signature Valid (AA55H).',CR,LF,'Now      ✓
                Booting MS-DOS.....',CR,LF,LF,'$'
READ_ERR_MSG    DB      CR,LF,BELL,'Floppy Sector Read Error. Error returned = $'
WRITE_ERR_MSG   DB      CR,LF,BELL,'Floppy Sector Write Error. Error returned = $'
HREAD_ERR_MSG   DB      CR,LF,BELL,'HDisk Multi-Sector Read Error.$'
HWRITE_ERR_MSG  DB      CR,LF,BELL,'HDisk Multi-Sector Write Error.$'
HOME_ERR_MSG    DB      CR,LF,BELL,'Disk reset error.',CR,LF,'$'
NO_BASIC_MSG    DB      CR,LF,BELL,'BASIC Handler error.',CR,LF,'$'
NO_BREAK_MSG    DB      CR,LF,BELL,'Keyboard Break Handler error.',CR,LF,'$'
NO_COMM_MSG     DB      CR,LF,BELL,'Serial Communications Handler error.',CR,LF,'$'
CASSETTE_MSG    DB      CR,LF,BELL,'Cassette Handler error. AH=$'
FBOOT_DOS_MSG   DB      CR,LF,'Booting MS-DOS from 5" Floppy Disk$'
HBOOT_DOS_MSG   DB      CR,LF,'Booting MS-DOS from HARD Disk$'
KEY_TEST_MSG    DB      CR,LF,'Software Interrupt driven Keyboard Input test (ESC to Abort) ✓
                ',CR,LF,'$'
IN_CHAR_MSG     DB      CR,LF,'Please characters on keyboard:- $'
GOT_CHAR_MSG    DB      'H <--- Hex value of character recieved via software Int 16H (&      ✓
                8259A Int 9H).',CR,LF,'$'
CO_TEST_MSG     DB      CR,LF,'Software Interrupt driven Console/Video out test',CR,LF,'$'
OUT_CHAR_MSG    DB      '<--- Character Recieved$'

```



```

TIMER_TEST_MSG DB CR,LF,'8259A Interrupt driven Timer Test$'
TIMER_DATA_MSG DB CR,LF,'Enter any key to read timer data. (ESC to Abort)$'
TIMER_LOW_MSG DB CR,LF,'Timer Low Value = $'
TIMER_HIGH_MSG DB 'H',CR,LF,'Timer High Value = $'
TIMER_OFLOW_MSG DB 'H',CR,LF,'Timer Overflow Value = $'
BUFF_TEST_MSG DB CR,LF,'Type keyboard characters as fast as you can!',CR,LF,'$'
SQRDHFAILMSG DB CR,LF,BELL,'Error reading sectors from HARD disk',CR,LF,'$'
SQRD5FAILMSG DB CR,LF,BELL,'Error reading sectors from 5" Floppy disk',CR,LF,'$'
SQRD3FAILMSG DB CR,LF,BELL,'Error reading sectors from 3" Floppy disk',CR,LF,'$'
SQRDHOKMSG DB CR,LF,'Read sectors from HARD disk OK!',CR,LF,'$'
SQRD5OKMSG DB CR,LF,'Read sectors from 5" 360K Floppy disk OK!$'
SQRD3OKMSG DB CR,LF,'Read sectors from 3" 1.44M Floppy disk OK!',CR,LF,'$'
DEBUG_SET_MSG DB CR,LF,'Set Debug level (0 = OFF, 1 = INTs only, 2 = +HDisk Info, 3
= +Floppy Info) $'
DUMP_ON1_MSG DB CR,LF,'Debug flag ON (Level 1)',CR,LF,'$'
DUMP_ON2_MSG DB CR,LF,'Debug flag ON (Level 2)',CR,LF,'$'
DUMP_ON3_MSG DB CR,LF,'Debug flag ON (Level 3)',CR,LF,'$'
DUMP_OFF_MSG DB CR,LF,'Debug flag OFF',CR,LF,'$'
SEC_5RD_MSG DB CR,LF,'Sequentially read sectors from 5" Floppy disk',CR,LF,'$'
SEC_3RD_MSG DB CR,LF,'Sequentially read sectors from 3" Floppy disk',CR,LF,'$'
SEC_HDRD_MSG DB CR,LF,'Read sector from HARD Disk test using Int 13H',CR,LF,'$'
ROM_ERR_MSG DB CR,LF,BELL,'Checksum error found in ROM (C8000H-F6000H). Got AL= $'
NOT_DONE_MSG DB CR,LF,BELL,'Code Not done yet',CR,LF,'$'
INVALID_AH_FMSG DB CR,LF,BELL,'Invalid AH paramater in Floppy Handler. AH=$'
INVALID_AH_HMSG DB CR,LF,BELL,'Invalid AH paramater in HDisk Handler. AH=$'
SIO_TEST_MSG DB CR,LF,'Serial Port (A3H) Test.'
DB CR,LF,'Enter any text. (ESC to stop).',CR,LF,'>','$'
SIO_INIT_ERR DB CR,LF,'Serial Port Initilization Error. AH=$'
SIO_ERR DB CR,LF,'Error sending character to Serial Port. AH=$'
INT_13F_MSG DB CR,LF,'Int 13H (Floppy)$'
INT_40F_MSG DB CR,LF,'Int 40H (<--Floppy)$'
INT_13H_MSG DB CR,LF,'Int 13H (*HDisk*)$'

INT_AX_MSG DB CR,LF,'AX=$'
INT_BX_MSG DB 'H BX=$'
INT_CX_MSG DB 'H CX=$'
INT_DX_MSG DB 'H DX=$'
INT_SI_MSG DB 'H',CR,LF,'SI=$'
INT_DI_MSG DB 'H DI=$'
INT_BP_MSG DB 'H BP=$'
INT_SP_MSG DB 'H SP=$'
INT_CS_MSG DB CR,LF,'CS=$'
INT_DS_MSG DB 'H DS=$'
INT_ES_MSG DB 'H ES=$'
INT_SS_MSG DB 'H SS=$'
INT_FS_MSG DB 'H FS=$'
INT_GS_MSG DB 'H GS=$'
IP_ADDRESS_MSG DB 'IP=$'

INT_1AH_MSG DB CR,LF,'Int 1AH (Time)$'
INT_10H_MSG DB CR,LF,'Int 10H (VIDEO)$'
INT_15H_MSG DB CR,LF,'Int 15H (Cassette)$'
SIDE_REQUEST_MSG DB CR,LF,'Read from Side A or Side B (A/B) $'
SIDE_A_SET_MSG DB CR,LF,'Will read from Side A',CR,LF,'$'
SIDE_B_SET_MSG DB CR,LF,'Will read from Side B',CR,LF,'$'
FORMAT_ERR_MSG DB CR,LF,'ZFDC Track Format error $'
CMOS_CLOCK_MSG DB CR,LF,BELL,'CMOS RTC Error',CR,LF,'$'
CMOS_STUCK_MSG DB CR,LF,BELL,'CMOS RTC "Stuck" Error',CR,LF,'$'
CMOS_RANGE_MSG DB CR,LF,BELL,'CMOS RTC Incorrect BCD values Error',CR,LF,'$'
PATCH_1_MSG DB CR,LF,'Moved RAM at 100H-$'
PATCH_2_MSG DB 'H to RAM at E0000H-E$'
PATCH_3_MSG DB 'H',CR,LF,'Jumping to RAM location E0000H',CR,LF,'$'

SECTOR_NUM_MSG DB CR,LF,'Starting requested Sector = $'
HRESET_OK_MSG DB CR,LF,'Reset of Hard Disk drive OK.',CR,LF,'$'
RD_ERR_MSG DB CR,LF,BELL,'Sector READ Error Returned.'

```

```

        DB      CR,LF,'Head = $'
TRACK_MSG      DB      'H  Track = $'
SEC_MSG        DB      'H  Sector = $'
WR_ERR_MSG     DB      CR,LF,BELL,'Sector WRITE Error Returned.'
                DB      CR,LF,'Head = $'
ESC_END_MSG    DB      CR,LF,'Press ESC to Abort. Any other key to continue $'
SEQAT500       DB      CR,LF,LF,'Sector(s) loaded @ 0000:500H.'
                DB      CR,LF,'Head = $'
CR_TAB_MSG     DB      CR,LF,'          $'
LBA_TEST_MSG   DB      CR,LF,'Test for LBA on IDE drive #2 (using LBA mode)$'
CHS_TEST_MSG   DB      CR,LF,'Test for CHS on IDE drive #2 (using non-LBA mode)$'
TRKL_NUM       DB      CR,LF,'Enter TRACK/Cylinder number (LOW byte, xxH) = $'
TRKH_NUM       DB      CR,LF,'Enter TRACK/Cylinder number (HIGH byte, xxH) = $'
HEAD_NUM       DB      CR,LF,'Enter HEAD number, (0-FH, 0xH) = $'
SECTOR_NUM     DB      CR,LF,'Enter SECTOR number (xxH) = $'
CHECK_DISPLAY_MSG DB    CR,LF,'Check the IDE Board HEX display.$'
BOOT_3RD_MSG   DB      CR,LF,'Display Floppy Boot Sector Information.',CR,LF,'$'
DRIVE_SELECT_MSG DB    CR,LF,'Please select floppy disk (A or B) $'
BOOT_INFO_FAIL_MSG DB   CR,LF,'Error reading Boot disk sector.$',CR,LF
BOOT_INFOOKMSG DB      CR,LF,'Floppy Boot Sector Information:-',CR,LF,LF,'$'

JMP_MSG        DB      '      Boot JMP Vector',CR,LF,'$'
NAME_MSG       DB      '      OEM Name',CR,LF,'$'
BYTES_MSG      DB      '      Bytes/Sec',CR,LF,'$'
CLUSTER_MSG    DB      '      Sec/Cluster',CR,LF,'$'
RES_MSG        DB      '      Reserved Sectors',CR,LF,'$'
FATS_MSG       DB      '      FATS',CR,LF,'$'
ROOT_MSG       DB      '      Root Dir Entries',CR,LF,'$'
SECTORS_MSG    DB      '      Sectors',CR,LF,'$'
MEDIA_MSG      DB      '      Media Byte',CR,LF,'$'
FAT_SEC_MSG    DB      '      FAT Sectors',CR,LF,'$'
SEC_TRK_MSG    DB      '      Sectors/Track',CR,LF,'$'
HEADS_MSG      DB      '      Heads',CR,LF,'$'
HIDDEN_MSG     DB      '      Hidden Sectors',CR,LF,'$'
HUGE_MSG       DB      '      Huge Sectors',CR,LF,'$'
DRIVE_NO_MSG   DB      '      Drive #',CR,LF,'$'
RESERVED_MSG   DB      '      Reserved',CR,LF,'$'
BOOT_SIG_MSG   DB      '      Boot Signature',CR,LF,'$'
VOL_ID_MSG     DB      '      Volume ID',CR,LF,'$'
VOLUME_MSG     DB      '      Volume Label',CR,LF,'$'
SYS_TYPE_MSG   DB      '      File Sys Type',CR,LF,LF,'$'
NO_MBL_MSG     DB      CR,LF,BELL,'Invalid Floppy Boot Loader Signature detected',CR,LF,'$'

BOOT_MBR_MSG   DB      CR,LF,'Reading Hard Disk MBR sector, (C=0, H=0, S=1)',CR,LF,'$'
BOOT_MBR_FAIL_MSG DB   CR,LF,BELL,'Error reading Hard Disk MBR sector',CR,LF,'0'
MBR_INFOOKMSG  DB      'Hard Disk Master Boot Record:-',CR,LF,'$'

DISK_SIG_MSG   DB      '      Hard Disk Signature',CR,LF,'$'
NULS_MSG       DB      '      Usually Nulls (Optional)',CR,LF,LF,'$'
PT1_MSG        DB      '      First Partition Table',CR,LF,'$'
PT2_MSG        DB      '      Second Partition Table',CR,LF,'$'
PT3_MSG        DB      '      Third Partition Table',CR,LF,'$'
PT4_MSG        DB      '      Forth Partition Table',CR,LF,'$'
SIGNATURE_MSG  DB      '      LBR Signature Word',CR,LF,'$'
STATUS_MSG     DB      '      Status Byte, $'
STLBA_MSG      DB      '      Start CHS Address, $'
PAR_TYPE_MSG   DB      '      Partition Type, $'
ECHS_MSG       DB      '      End CHS Address',CR,LF,'$'
SLB_MSG        DB      '      Start LBA Address, $'
ELBA_MSG       DB      '      End LBA Address',CR,LF,LF,'$'
CYL_MSG        DB      'H Cyl=$'
HD_MSG         DB      '      Head=$'
BRAC1_MSG     DB      'H ($'
OF_MSG         DB      'H of $'
BRAC2_MSG     DB      'H)',CR,LF,'$'
DRIVE1_MSG     DB      '      on Drive A',CR,LF,'$'

```

```

DRIVE2_MSG      DB      ' on Drive B',CR,LF,'$'
HRW_TEST_MSG    DB      CR,LF,'Hard Disk Sector R/W test using INT 13H',CR,LF
                DB      CR,LF,'>>> WARNING <<< Data on Disk will be overwritten. Continue..<
                .(Y/N) $'
ONE_MOMENT_MSG  DB      CR,LF,'One moment while IDE Drive is being initilized',CR,LF,'$'
ASK_WR_MSG      DB      CR,LF,'Write data back to Hard Disk...(Y/N)$'
START_DATA_MSG  DB      'H Start of Data =',CR,LF,'$'
SEC_READ_OK     DB      CR,LF,'Sector(s) read OK',CR,LF,'$'
SEC_BACK_OK     DB      CR,LF,'Sector(s) written back OK',CR,LF,'$'
LOOP_ESC_MSG    DB      CR,LF,'Will now continously R/W sectors until ESC is entered. CR to<
                start',CR,LF,'$'

VIDIO_TEST_MSG  DB      CR,LF,'Int 10H tests for control of Video Board I/O',CR,LF
                DB      CR,LF,'Enter value of [AX], (xxxxH) $'
ENTER_BX_MSG    DB      CR,LF,'Enter value of [BX], (xxxxH) $'
ENTER_CX_MSG    DB      CR,LF,'Enter value of [CX], (xxxxH) $'
ENTER_DX_MSG    DB      CR,LF,'Enter value of [DX], (xxxxH) $'
ACTIVATE_INT_MSG DB      CR,LF,'Enter CR to implement the INT 10H interrupt, (ESC to Abort) <
                $'

VID_PARM_TBD_MSG DB      CR,LF,'Int 10H Video paramater not yet implemented'
                DB      CR,LF,' ','$'
VID_PARM_TBD1_MSG DB      CR,LF,'Int 10H Video paramater not fully completed'
                DB      CR,LF,' ','$'
VID_PARM_MSG     DB      CR,LF,'Invalid Int 10H Video paramater',CR,LF,'$'
VIDIO_OUTPUT_MSG DB      CR,LF,' Set MSDOS (INT 10H) Console Output Menu'
                DB      CR,LF,' 0 = MSDOS output will be to Propeller Board.'
                DB      CR,LF,' 1 = MSDOS Output will be to CGA/VGA Board.'
                DB      CR,LF,' 2 = MSDOS Output will be to LAVA Board.'
                DB      CR,LF,'Please enter selection. (ESC to abort):$'
VIDIO_LAVA_MSG   DB      CR,LF,'MSDOS output will be to LAVA Board',CR,LF,'$'
VIDIO_PROP_SMSG  DB      CR,LF,'MSDOS output will be to Propeller Board',CR,LF,'$'
VIDIO_VGA_MSG    DB      CR,LF,'MSDOS output will be to CGA/VGA Board',CR,LF,'$'
VIDIO_PROP_MSG   DB      'MSDOS output will be to Propeller Board$'
VIDIO_VGA_SMSG   DB      'MSDOS output will be to CGA/VGA Board$'
VIDIO_LAVA_SMSG  DB      'MSDOS output will be to LAVA Board$'
INT10_ERR_MSG    DB      CR,LF,'Sorry invalid selection. Must be 0,1, or 2 $'
PSCR_TEST_MSG    DB      CR,LF,'Will Print (CGA/VGA) screen on Printer',CR,LF,'$'
PSCR_TEST_LEN    EQU    $-PSCR_TEST_MSG-3
PRN_INIT_STR     DB      0H                                ;<--- I cannot get the PCL-6 Codes <
                below to work with my printer
;                DB      1BH,'E'                                ;PCL-6 reset
;                DB      1BH,'%12345X',0                       ;Universal Exit
;                DB      1BH,'&','1',01H,'O',0                 ;Landscape Orientation (Cannot seem<
                to get these to work)

TIME_ERROR_MSG   DB      CR,LF,'RTC Error',CR,LF,0
Time_Msg         DB      'Time=',0
GAP_Msg          DB      ' ',0
Date_Msg         DB      'Date=',0
SET_TIME_MSG     DB      'Do you wish to set the time and date (Y/N): $'
Input_Hours_Msg  DB      CR,LF,'Please Enter Hours (2 digits, 00-24) ',0
Input_Minutes_Msg DB      CR,LF,'Please Enter Minutes (2 digits, 00-60) ',0
Input_Seconds_Msg DB      CR,LF,'Please Enter Seconds (2 digits, 00-60) ',0
Input_Year_Msg   DB      CR,LF,'Please Enter Year (2 digits, 20xx) 20',0
Input_Month_Msg  DB      CR,LF,'Please Enter Month (2 digits, 00-12) ',0
Input_Day_Msg    DB      CR,LF,'Please Enter day (2 digits, 01-31) ',0

ROMCHECK_MSG     DB      CR,LF,'Initilizing VGA ROM at C000:0000H',0
ROMCHECK_MSG_OK  DB      CR,LF,'VGA ROM Initilized, returned back to BIOS.',CR,LF,0
NO_VGA_MSG       DB      CR,LF,'No VGA ROM at C000:0000H',0
VGA_OK_MSG       DB      CR,LF,'Int 15H VGA Initilization Done',CR,LF,0

PMODE_SIGNON0    DB      CR,LF,LF,'80386/80486 (Protected Mode) Test Menu Routines.'
                DB      CR,LF

```

```

        DB      'A-Memmap      B-          C-          D-Disp RAM  E-',CR,LF
        DB      'F-Fill RAM    G-Goto     H-Math      I-Interrupts J-PM RAM tests',
CR,LF
        DB      'K-Menu       L-8259A   M-Move RAM  N-          O-Back to 8086
Real Mode',CR,LF
        DB      'P-          Q-Ports   R-Registers S-Subs RAM  T-Disp RAM (32
bit Words)',CR,LF
        DB      'V-Verify    W-XModem  X-BrkPoints Y-Exe > 16M Z-Z80',CR,LF,'$'

MSG_PROTECTED DB      '3 8 6   4 8 6 MONITOR VERSION V1.74 IS NOW IN PROTECTED MODE!  $'
INT_EAX_MSG   DB      CR,LF,'EAX=$'
INT_EBX_MSG   DB      'H  EBX=$'
INT_ECX_MSG   DB      'H  ECX=$'
INT_EDX_MSG   DB      'H  EDX=$'

INT_ESI_MSG   DB      'H',CR,LF,'ESI=$'
INT_EDI_MSG   DB      'H  EDI=$'
INT_EBP_MSG   DB      'H  EBP=$'
INT_ESP_MSG   DB      'H  ESP=$'

INT_DR0_MSG   DB      'H',CR,LF,'DR0=$'
INT_DR1_MSG   DB      'H  DR1=$'
INT_DR2_MSG   DB      'H  DR2=$'
INT_DR3_MSG   DB      'H  DR3=$'

INT_DR6_MSG   DB      'H',CR,LF,'DR6=$'
INT_DR7_MSG   DB      'H  DR7=$'
INT_FLAGS_MSG DB      'H  Flags=$'

PRO_CLEANUP   DB      CR,LF,BELL,'PM>$'
SIGNON1       db      CR,LF,'80386/80486 Is now in Protected Mode. Stack pointer = $'
ABOVE_16MB_MSG DB      CR,LF,'Past S-100 Bus address range
0-16MB.',CR,LF,LF,'$'
LISTMATCHES   DB      CR,LF,'First RAM = $'
LISTMATCHES2  DB      'H,  Second RAM = $'
LISTMATCHES3  DB      'H,  Range = $'
GET_ABS_LOC   DB      CR,LF,LF,'Go to PM RAM Location (32 Bit address, Note Must be PM
Code) = $'
WILL_JMP_TO   DB      CR,LF,'Will JMP to PM Code location $'
START_AT_MSG  DB      CR,LF,'Start = $'
END_AT_MSG    DB      '  End = $'

UNASSIGNED_1_INT_MSG DB      CR,LF,'Un-assigned Vector Interrupt # $'
UNASSIGNED_3_INT_MSG DB      CR,LF,'Un-assigned Vector Interrupt (In Protected Mode)$'
NOT386CPU_MSG  DB      CR,LF,'80386/80486 CPU not present.',CR,LF,'$'
UNKNOWN_INT_MSG DB      CR,LF,'Unknown Interrupt Request!',CR,LF,'$'
DEBUG_CONTINUE_MSG DB      CR,LF,'INT #1 (Debug Exception TRAP).  Press ESC to Abort $
TRACE_CONTINUE_MSG DB      'H',CR,LF,'Continue Tracing (Y/N)? $'
BREAKPOINT_MENU DB      CR,LF,'Set or Clear a Breakpoint Register (Enter S or C): $
BREAK_BAD      DB      CR,LF,'Not a valid menu option. Please try again',CR,LF,'$'
SET_N_REGISTER DB      CR,LF,'SET 80386/80486 Hardware Breakpoint Register DR0,
DR1, DR2 or DR3'
CLEAR_N_REGISTER DB      CR,LF,'CLEAR 80386/80486 Hardware Breakpoint Register DR0,
DR1, DR2 or DR3'
ENTER_BREAKPOINT DB      CR,LF,'Enter Breakpoint Register (0,1,2,3): $'
: $'
BREAKPOINT_ACTIVE DB      CR,LF,'Breakpoint is now active',CR,LF,'$'
BREAKPOINT_OFF    DB      CR,LF,'Breakpoint is now inactive',CR,LF,'$'
DEFAULT_8259_INT1 DB      CR,LF,'Default 8259A PM Interrupt INT#$'
DEFAULT_8259_INT2 DB      'H.  IP=$'

PM_RAM_TEST    DB      CR,LF,'Protected Mode RAM Hardware Tests (Reset required to

```

```

        STOP some tests)'
        DB      CR,LF,'0  Continiously read RAM at a specified location.  ✓
(To look at CPU signals)'
        DB      CR,LF,'1  Write 20H Bytes, 10H Words, 0FH DWords at a      ✓
specified location'
        DB      CR,LF,'2  Move 800H Bytes, 400H Words, 100H DWords from/to ✓
a specified location'
        DB      CR,LF,'3  Fast PM 8MB S100 RAM hardware test (10000H -      ✓
7FFFFFFH).'
        DB      CR,LF,'4  Fast PM 16MB S100 RAM hardware test (10000H -      ✓
FFFFFFH).'
        DB      CR,LF,'5  Fast PM 16MB 80386/80486 RAM hardware test        ✓
(2000000H - 2FFFFFFH).'
        DB      CR,LF,'6  Fast PM 32MB 80386/80486 RAM hardware test        ✓
(2000000H - 3FFFFFFH).'
        DB      CR,LF,'7  Continous PM RAM hardware test (Defined          ✓
Locations).'
        DB      CR,LF,'8  Identify bad RAM mezzanine boards on 32MB RAM     ✓
board.'
        DB      CR,LF,LF,'Enter menu Option: (ESC to abort) $'

PM_RAM_TEST_LOC      DB      CR,LF,'Enter the RAM test start location (+CR) $'
PM_RAM_WILL_DO       DB      'H',CR,LF,'Will now read continously RAM at location $'
P_WR_JMSG            DB      CR,LF,'Enter start location to write bytes, words and ✓
        dwords in RAM (+CR) $'
P_MOV_JMSG          DB      CR,LF,'Enter start,end locations for the RAM move (+CR) $'
P_JMSG              DB      CR,LF,'Please enter start, ending address (+CR) $'

JMSG                DB      CR,LF,'Continous RAM 0-1MB hardware test.$'
STARTJMSG          DB      CR,LF,'Starting RAM test. Hit ESC any time to abort',CR,LF,✓
        '$'
RAM_Test_Count      DB      CR,'RAM test loop count = $'

ZERO_FILL_JMSG      DB      CR,LF,'Filling RAM with Zeros. Hit ESC any time to abort', ✓
        CR,LF,LF,'$'
CHK_FILL_JMSG       DB      CR,LF,'Checking RAM was filled with BYTE 0H, replacing with ✓
        BYTE 55H.',CR,LF,LF,'$'
CHK_WORD_JMSG       DB      CR,LF,'Checking RAM was filled with BYTE 55H, replacing ✓
        with WORD 1234H.',CR,LF,LF,'$'
CHK_DWORD_JMSG      DB      CR,LF,'Checking RAM was filled with WORD 1234H, replacing ✓
        with DWORD 12345678H.',CR,LF,LF,'$'
FILLED_DWORD_JMSG   DB      CR,LF,'Checking RAM was filled with DWORD 12345678H.',CR,LF, ✓
        ,LF,'$'

BAD_Z_AT_MSG        DB      CR,BELL,'Zero fill error at: $'
BAD_55_AT_MSG       DB      CR,BELL,'55H fill error at: $'
BAD_1234_AT_MSG     DB      CR,BELL,'1234H fill error at: $'
BAD_12345678_AT_MSG DB      CR,BELL,'12345678H fill error at: $'
UNTIL_MSG           db      'H  Until $'
STATUS_UPDATE_MSG   DB      CR,'Current location = $'
BACKSPACE_9_MSG     DB      BS,BS,BS,BS,BS,BS,BS,BS,BS,BS,'$'
AL_EQUAL_MSG        DB      BELL,'H  Got EAX=$'
LAST_LOC_MSG        DB      CR,'Last tested location = $'

AACHK_DONE_MSG      DB      CR,BELL,BELL,'RAM address lines check finished',CR,LF,'$'

TESTING_MEZ_MSG     DB      CR,LF,'Testing the four Mezzanine RAM boards.....',CR,LF,0
BAD_MEZ             DB      CR,LF,'R/W Byte error found on Mezzanine board in ',0
BAD_MEZ_0           DB      'P103 socket.',CR,LF,0
BAD_MEZ_1           DB      'P104 socket.',CR,LF,0
BAD_MEZ_2           DB      'P105 socket.',CR,LF,0
BAD_MEZ_3           DB      'P106 socket.',CR,LF,0
MEZ_TEST_DONE       DB      CR,LF,'Mezzanine boards test done.',CR,LF,0

BAD_MOVE_MSG        DB      CR,LF,'Error(s) detected with move. Error at $'
PM_RAM_START        DB      CR,LF,'Enter the start location (Above 500H) $'

```



```
DB 000H,000H,000H,0FCH,000H,000H,000H,000H ;
DB 000H,000H,000H,000H,000H,030H,030H,000H ;
DB 006H,00CH,018H,030H,060H,0C0H,080H,000H ;
DB 07CH,0C6H,0CEH,0DEH,0F6H,0E6H,07CH,000H ;
DB 030H,070H,030H,030H,030H,030H,0FCH,000H ;
DB 078H,0CCH,00CH,038H,060H,0CCH,0FCH,000H ;
DB 078H,0CCH,00CH,038H,00CH,0CCH,078H,000H ;
DB 01CH,03CH,06CH,0CCH,0FEH,00CH,01EH,000H ;
DB 0FCH,0C0H,0F8H,00CH,00CH,0CCH,078H,000H ;
DB 038H,060H,0C0H,0F8H,0CCH,0CCH,078H,000H ;
DB 0FCH,0CCH,00CH,018H,030H,030H,030H,000H ;
DB 078H,0CCH,0CCH,078H,0CCH,0CCH,078H,000H ;
DB 078H,0CCH,0CCH,07CH,00CH,018H,070H,000H ;
DB 000H,030H,030H,000H,000H,030H,030H,000H ;
DB 000H,030H,030H,000H,000H,030H,030H,060H ;
DB 018H,030H,060H,0C0H,060H,030H,018H,000H ;
DB 000H,000H,0FCH,000H,000H,0FCH,000H,000H ;
DB 060H,030H,018H,00CH,018H,030H,060H,000H ;
DB 078H,0CCH,00CH,018H,030H,000H,030H,000H ;
DB 07CH,0C6H,0DEH,0DEH,0DEH,0C0H,078H,000H ;
DB 030H,078H,0CCH,0CCH,0FCH,0CCH,0CCH,000H ;
DB 0FCH,066H,066H,07CH,066H,066H,0FCH,000H ;
DB 03CH,066H,0C0H,0C0H,0C0H,066H,03CH,000H ;
DB 0F8H,06CH,066H,066H,066H,06CH,0F8H,000H ;
DB 0FEH,062H,068H,078H,068H,062H,0FEH,000H ;
DB 0FEH,062H,068H,078H,068H,060H,0F0H,000H ;
DB 03CH,066H,0C0H,0C0H,0CEH,066H,03EH,000H ;
DB 0CCH,0CCH,0CCH,0FCH,0CCH,0CCH,0CCH,000H ;
DB 078H,030H,030H,030H,030H,030H,078H,000H ;
DB 01EH,00CH,00CH,00CH,0CCH,0CCH,078H,000H ;
DB 0E6H,066H,06CH,078H,06CH,066H,0E6H,000H ;
DB 0F0H,060H,060H,060H,062H,066H,0FEH,000H ;
DB 0C6H,0EEH,0FEH,0FEH,0D6H,0C6H,0C6H,000H ;
DB 0C6H,0E6H,0F6H,0DEH,0CEH,0C6H,0C6H,000H ;
DB 038H,06CH,0C6H,0C6H,0C6H,06CH,038H,000H ;
DB 0FCH,066H,066H,07CH,060H,060H,0F0H,000H ;
DB 078H,0CCH,0CCH,0CCH,0DCH,078H,01CH,000H ;
DB 0FCH,066H,066H,07CH,06CH,066H,0E6H,000H ;
DB 078H,0CCH,0E0H,070H,01CH,0CCH,078H,000H ;
DB 0FCH,0B4H,030H,030H,030H,030H,078H,000H ;
DB 0CCH,0CCH,0CCH,0CCH,0CCH,0CCH,0FCH,000H ;
DB 0CCH,0CCH,0CCH,0CCH,0CCH,0CCH,078H,030H,000H ;
DB 0C6H,0C6H,0C6H,0D6H,0FEH,0EEH,0C6H,000H ;
DB 0C6H,0C6H,06CH,038H,038H,06CH,0C6H,000H ;
DB 0CCH,0CCH,0CCH,078H,030H,030H,078H,000H ;
DB 0FEH,0C6H,08CH,018H,032H,066H,0FEH,000H ;
DB 078H,060H,060H,060H,060H,060H,078H,000H ;
DB 0C0H,060H,030H,018H,00CH,006H,002H,000H ;
DB 078H,018H,018H,018H,018H,018H,078H,000H ;
DB 010H,038H,06CH,0C6H,000H,000H,000H,000H ;
DB 000H,000H,000H,000H,000H,000H,000H,0FFH ;
DB 030H,030H,018H,000H,000H,000H,000H,000H ;
DB 000H,000H,078H,00CH,07CH,0CCH,076H,000H ;
DB 0E0H,060H,060H,07CH,066H,066H,0DCH,000H ;
DB 000H,000H,078H,0CCH,0C0H,0CCH,078H,000H ;
DB 01CH,00CH,00CH,07CH,0CCH,0CCH,076H,000H ;
DB 000H,000H,078H,0CCH,0FCH,0C0H,078H,000H ;
DB 038H,06CH,060H,0F0H,060H,060H,0F0H,000H ;
DB 000H,000H,076H,0CCH,0CCH,07CH,00CH,0F8H ;
DB 0E0H,060H,06CH,076H,066H,066H,0E6H,000H ;
DB 030H,000H,070H,030H,030H,030H,078H,000H ;
DB 00CH,000H,00CH,00CH,00CH,0CCH,0CCH,078H ;
DB 0E0H,060H,066H,06CH,078H,06CH,0E6H,000H ;
DB 070H,030H,030H,030H,030H,030H,078H,000H ;
DB 000H,000H,0CCH,0FEH,0FEH,0D6H,0C6H,000H ;
DB 000H,000H,0F8H,0CCH,0CCH,0CCH,0CCH,000H ;
```



```

    DB      00000000b      ;G(0) B(0) 0 0 Limit[19..16]
    DB      00h           ;Base[31..24]

                                ;GDT[5]:Executable, read-only code, base address
for IDT is IDT_BASE

                                ;granularity bit (G) set (making the limit 4GB)
    DW      000Fh         ;Limit[15..0] (16*4K)
    DW      0000h         ;Base[15..0]
    DB      IDT_BASE      ;Base[23..16]
    DB      10011010b     ;P(1) DPL(00) S(1) 1 C(0) R(1) A(0)
    DB      11001111b     ;G(1) D(1) 0 0 Limit[19..16]
    DB      00h           ;Base[31..24]

GDT_SIZE EQU ($ - Gdt)      ;<<<< Size of GDT, in bytes

GdtDesc:                    ;<<< GDT descriptor >>>
    DW      GDT_SIZE - 1  ;GDT limit
    DD      GDT_BASE_ADDRESS ;GDT base address (Note, relocated to 0E0000H in
RAM above)

IdtDesc:                    ;<<< IDT descriptor >>>
    DW      IDT_SIZE - 1  ;IDT limit
    DD      IDT_BASE_ADDRESS ;IDT base address (Note, relocated to E0100H in RAM
above)

ridt:  DW      03ffh      ; The base of the IDT for real-mode interrupts use
       DD      0
;
;-----
;-----

    DB      '<----- END OF 80386/80486 Monitor V1.74 (John Monahan, 7/15/2019) '
    DB      '

DIAG_TEST:
    IN      AL,IOBYTE      ;Start at Reset location, few bytes available to
FFFFFH
    CMP     AL,03FH        ;If 3F then diagnostic, '?' continously of CRT
    JZ     XLOOP
    JMP     INIT           ;(Start of this monitor)

XLOOP:  NOP               ;For hardware address debug viewing
    XOR     BX,BX
    MOV     DS,BX         ;Read even & odd byte from RAM

    MOV     AL,[BX]
    MOV     AL,[BX+1]
    MOV     AX,word [BX]
    MOV     AX,word [BX+1]

    IN      AL,IOBYTE      ;see if we need a different character to output
(checks I/O)
    OUT     01H,AL
    JMP     XLOOP

    %if     MONITOR_ROM
    TIMES  0FFF0H-($-$$) DB 0

    JMP     word 0F000H:DIAG_TEST ;Not clear why but need long jump for board
hardware

;LZZZ:  IN      AL, IOBYTE      ;<<<<<<<<<< BASIC HARDWARE TEST at reset address
>>>>>>>>
;       OUT     01,AL         ;For initial hardware testing only
;       CMP     AL,3FH

```

```

;      JMP      LZZZ
;      JMP      word 0:500H

;ZZZ:  mov      al,33h
;      OUT      01h,al          ;Used only for logic probe hardware debugging etc.
;      jmp      ZZZ

;      TIMES 0FFFEH-($-$$) DB 0
;      DB      0FCH          ;"Model Number" IBM PC/AT (At FFFEh)
;      DB      0H           ;Skip Checksum
%endif

;----- LOW RAM VARIABLES (Used mainly by PC-BIOS section) -----
;-----
;      absolute      2H*4
NMIint:   resw      2          ;Non-maskable interrupt location (8H)

;      absolute      5H*4
PrintScreen: resw      2      ;Print Screen function

;      absolute      8H*4          ;Location for our hardware interrupts (20H, Same as
;      IBM-PC hardware)
Start8259A_Ints resw      2      ;
;      8      Timer Tic          TIMER          \
;      9      Keypressed        KEYHND          \|
;      A      Reserved          DUMMY_RETURN   \|
;      B      Comm Hardware      DUMMY_RETURN   \|Normal
;
;      location for
;      hardware interrupts
;      C      Comm Hardware      DUMMY_RETURN   /IBM
;      D      Disk Hardware      DUMMY_RETURN   /
;      E      Diskette Hardware  DUMMY_RETURN   /
;      F      Printer Hardware   DUMMY_RETURN   /

;      absolute      10H*4
CRTINT   resw      2          ;Software interrupt used in this BIOS (and IBM-PC/
;      AT)

;      absolute      13H*4
MAIN_DISK_VEC resw      2      ;Disk (Hard & Floppy) software interrupt
;      absolute      (13H*4)+2
MAIN_DISK_SEG resw      2      ;Disk software interrupt segment (Normally this CS)

;      absolute      1DH*4          ;Pointer to Video Board paramaters table
VID_PARM_PTR resw      2
;      absolute      (1DH*4)+2
VID_PARM_PTR_SEG resw      2      ;Video Board Table segment (0 here)

;      absolute      1EH*4          ;Pointer to Floppy Disk paramaters table
FDISK_PARMS resw      2          ;On MSDOS Boot, this points to the boot Floppy Disk
;      Variables Table
;      absolute      (1EH*4)+2
FDISK_PARMS_SEG resw      2      ;Disk Variables Table segment (Normally this CS)

;      absolute      1FH*4
EXT_CHAR_PTR resw      2          ;For Graphics mode extra characters pointers
;      absolute      1FH*4
EXT_CHAR_PTR_SEG resw      2      ;For Graphics mode extra characters pointers
;      segment (Normally this CS)

;      absolute      40H*4
OLD_DISK_VEC resw      2          ;Pointer to the original PC Floppy Disk Int Vector

```

```

        (relocated because of HDISK)
        absolute      (40H*4)+2
OLD_DISK_SEG  resw    2          ;New Floppy Disk software interrupt segment  ✓
        (Normally this CS)

        absolute      41H*4
HDISK_PARMS   resw    2          ;Pointer to HARD DISK #1 paramater table
        absolute      (41H*4)+2
HDISK_PARMS_SEG resw    2          ;HARD DISK paramater table segment (Normally this  ✓
        CS)

        absolute      43H*4
EXT_CHAR_PTR2  resw    2          ;10CH, Pointer to Graphics Character set
        absolute      (43H*4)+2
EXT_CHAR_PTR2_SEG resw    2          ;Pointer to Graphics Character Set Segment

        absolute      46H*4
HDISK2_PARMS   resw    2          ;Pointer to HARD DISK #2 paramater table
        absolute      (46H*4)+2
HDISK2_PARMS_SEG resw    2          ;HARD DISK paramater table segment (Normally this  ✓
        CS)

        absolute      400H
        BIOS)          ;Low RAM data area (set the same as for IBM-PC  ✓

RS232_BASE    resw    4          ;Addresses for RS232 Adaptors (if any)
PRINTER_BASE  resw    4          ;Address of Printers (if any)

EQFLAG        resw    1          ;equipment flag (two bytes)
MFG_TST       resb    1          ;MFG initilization flag (not used)
memrsz        resw    1          ;memory size
expram        resw    1          ;expansion ram size

KB_FLAG       resb    1          ;417H
KB_FLAG_1     resb    1          ;Second byte of keyboard status
chrcnt        resb    1          ;characters in buffer (Alt_Keypad on PC)

bufhd         resw    1          ;keyboard buffer head      (40:1AH)
buftl         resw    1          ;keyboard buffer tail      (40:1CH)
keybuff       resw    16         ;keyboard data buffer      (40:1EH)
kbend         resw    1          ;end of buffer
chrmax equ    32                ;buffer length
; \
; \
; Keyboard buffer area
; /
; /

        absolute      43EH

SEEK_STATUS   resb    1          ;Seek status (40:3EH)
CURRENT_HEAD  resb    1          ;On IBM PC, motor status (40:3FH)
CURRENT_DRIVE resb    1          ;On IBM PC, motor count (40:40H)

IBM_DISK_STATUS resb    1          ;Returned disk status (40:41H)
;
DMA_OFFSET    resw    1          ;DMA offset address for controller (On PC this  ✓
        area is used by FDC)
DMA_SEGMENT   resw    1          ;DMA segmant address for controller
CURRENT_SECTOR resb    1
CURRENT_TRACK resb    1
CURRENT_TRACK_HIGH resb 1

```

```

        absolute      449H          ;Video board paramaters

CRT_MODE      resb    1          ;Video Display Mode (40:49H)
CRT_COLS      resw    1
CRT_LEN       resw    1
CRT_START     resw    1
CURSOR_POSN   resw    8          ;IBM has 8

CURSOR_MODE   resw    1          ;Cursor Type (40:60H)
ACTIVE_PAGE   resb    1
ADDR_6845     resw    1
CRT_MODE_SET  resb    1
CRT_PALLETTE  resb    1

IO_ROM_INIT   resw    1          ;Anchor location to implement extra ROMS
IO_ROM_SEG    resw    1
INTR_FLAG     resb    1

timlow        resw    1          ;timer low count (40:6CH) for timer
timhi         resw    1          ;timer high count
timofl        resb    1          ;timer overflow flag

BIOS_BREAK    resb    1          ;Bit 7 = 1 if break key pressed (40:71H)
RESET_FLAG    resw    1          ;1234H if KB reset underway (40:72H)

;Additional data stores on IBM-AT
DISK_STATUS1  resb    1          ;(40:74H) Hard Disk Data Areas
HF_NUM        resb    1
CONTROL_BYTE  resb    1
PORT_OFF      resb    1

PRINT_TIM_OUT resw    2          ;Printer & RS232 Time-out variables
RS232_TIM_OUT resw    2

BUFFER_START  resw    1          ;Additional Keyboard data area (on IBM-AT)
BUFFER_END    resw    1

        absolute      48BH          ;;To keep same a AT

LAST_RATE     resb    1          ;(40:88H) Addditional Floppy data

HF_STATUS     resb    1          ;(40:8CH) Additional HDisk data area
HF_ERROR      resb    1
HF_INT_FLAG   resb    1
HF_CNTRL      resb    1

DSK_STATE     resw    2          ;(40:90H) Additional Diskette Area (must be 0 for
MS-DOS 4.01)
DSK_TRK       resb    3

KB_FLAG_2     resb    1          ;497H, Additional keyboard LED flag (on AT)

; (40:98H) RTC additional data area
USER_FLAG     resw    1          ;offset address of user wait flag
USER_FLAG_SEG resw    1          ;segment      "      "      "
RTC_LOW       resw    1          ;user RTC low word
RTC_HIGH      resw    1          ;user RTC high word
RTC_WAIT_FLAG resb    1          ;user wait active

;Extra data areas used by this BIOS (seem to be OK
not used by IBM)

CONSOLE_FLAG  resw    1          ;0000 if MSDOS output to Propeller board, 0001 to
LAVA board, 0002 to VGA Video board.

```

```

ZFDC_ERR_CODE   resb    1           ;Error code returned by ZFDC controller in AH for error ✓
DEBUG_FLAG     resb    1           ;If not Zero display track, side, sector etc info during disk R/W ✓
ZFDC_INIT_FLAG resb    1           ;Flag to indicate ZFDC board has been initilised
SECTORS_TO_DO  resb    1           ;Number of sectors to transfer in current operation
SECTORS_DONE   resb    1           ;Number actually transferred
VERIFY_FLAG    resb    1           ;0 for normal sector reads, NZ, if just sector verifyfs required ✓
ES_STORE       resw    1           ;Used for INT 10H, String write

PM_BUFFER_START resw    2           ;For My Protected Mode Keyboard Int Routine
PM_BUFFER_END  resw    2           ;This are is unused on the IBM-PC/AT

absolute      500H
STATUS_BYTE   resb    1           ;To keep things the same as for the IBM_PC ;Flag for print screen routine

absolute      0B800H           ;IBM-PC Color Video Board RAM area

Video_Ram     resw    16384 *2      ;Video RAM area (IF, Lomas or other S100 PC Video board is used) ✓
absolute      7c00h           ;0000:7c00H

DOS_BOOT_LOC: resw    1           ;<---MS-DOS/FreeDOS BOOT LOCATION
absolute      7c00h+510       ;0000:7dfeH

DOS_BOOT_SIGNATURE: resw    1      ;<---MS-DOS Valid Boot Signature Location (0AA55H)
;Remember there is a high RAM data area used (only) for the IDE Board ✓
;diagnostic functions. These variables will normally be accessed as SS:[BP] ✓
;This is used by the IDE drive diagnostic commands ONLY. We need an area ✓
;to store buffers in RAM. In a full 1MG system they will at D000:E000H ✓
;Remember also the stack is normally at D000:FFFCH
absolute      0E000H         ;For SS:BP -> D000:E000H

RAM_DRIVE_SEC resw    1           ;This area will be in top of RAM well below stack (used by IDE Board sections) ✓
RAM_DRIVE_TRK resw    1
RAM_DRIVE_HEAD resw    1
RAM_DRIVE_COUNT resw    1
RAM_SEC       resw    1
RAM_TRK       resw    1
DELAYStore    resw    1
RAM_DMA       resw    1
RAM_DMA_STORE resw    1
SECTOR_COUNT  resw    1
CURRENT_IDE_DRIVE resw    1
DISPLAY_FLAG  resw    1

absolute      0E100H         ;For SS:BP -> D000:E000H

IDE_Buffer     resb    200H       ;512 Byte buffer for IDE Sector R/W
IDE_Buffer2    resb    200H       ;512 Byte buffer for IDE Sector Verify

```