

```

; This is an monitor for the S100computers.com 8086 board (and later 8088,80286 boards)
; It started from the simple monitor in Byte on Nov 1980 but is enlarged and
; modified to work with the S100Computers 8086 Board, IDE Board, ZFDC board, MSDOS Support (PIC & RTC) Board and other
; hardware as well. More recently it has been extensively enlarged to contain the interrupt based functions required
; to run a Microsoft's MS-DOS (V4.01) or FreeDOS emulating an IBM-PC BIOS ROM.
;
;   John Monahan, San Ramon, CA   (monahan@vitasoft.org)
; History
; V1.0           ;Original version sometime in 1982
; V2.1   3/12/1983
; V2.2   11/12/09   ;Modified for simple I/O. Ports info command added
; V2.3   11/18/09   ;Reset FAR jump to start of monitor, added Register display
; V2.3.1 11/19/09   ;Allow intersegment FAR jump with G command
; V2.4   2/18/10    ;Write version to reside at F:F000H (to be loaded with a CPM loader from disk)
; V2.5   8/26/10    ;Add S100Computers Serial IO Board & RTC Board. Input IOBYTE (EFh) for JMP to 0:500H
; V2.5.1 8/26/10    ;Stack & Flag below EPROM in high memory
; V2.5.2 8/27/10    ;Stack etc in low memory. AP/PM for clock (with DAS opcode)
; V2.5.3 8/27/10    ;Check if after a reset a direct jump to CPM86 in RAM is required (rather than this monitor).
; V2.6   5/7/11     ;Added IDE Board diagnostic package
; V2.7   5/9/11     ;Aruba trip, complete overhaul while traveling.
; V2.8   5/14/11    ;Finished IDE drive additions
; V2.9   5/17/11    ;Switched over to using SI and DI registers for memory move etc functions
; V3.0   5/31/11    ;Corrected Sector display routines
; V3.1   6/1/11     ;Corrected memory Map display and move memory routines
; V3.2   6/7/11     ;Corrected CF Drive A=B Verify routine
; V3.3   6/8/11     ;Corrected CF Drive A->B copy routine
; V3.4   6/8/11     ;BP used for all IDE routines thus freeing dependance on a fixed RAM location
; V3.5   6/10/11   ;Corrected Disk format routine. Corrected Drive ID routine
; V3.6   6/19/11   ;Corrected Monitor signon message at start
; V4.0   7/20/11   ;Splice in IBM-PC/MS-DOS Interrupt routines. Enlarged Monitor now starts at FC000H
; V4.1   7/31/11   ;Correct CICO routine so it is not case sensitive
; V4.2   8/3/11    ;Vector Int's 0 & 1 working OK.
; V4.3   8/4/2011  ;MS-DOS 2.01 loading from floppy fine on 5" SS Disks (only)!
; V4.4   8/20/2011 ;Added special MS-DOS FFDC commands to read DDDS DOS Disks. Now works with IBMs PC-DOS up to V3.1
; V4.5.1 8/23/2011 ;Corrected length check with GET5DIGIST etc.
; V4.5.2 8/23/2011 ;Added "PATCH" to quickly test RAM/Debug versions of this code.
; V5.0   8/26/2011 ;MS-DOS hard disk caspability
; V5.1   9/1/2011  ;Corrected bug in IDE (WR_LBA) routine. Was not sending High Cylinder! (not used with CPM!)
; V5.2   9/6/2011  ;Move to 27C256 EEPROMS (Will no longer fit in 27C64's). Address starts at F000:8000H
; V5.3   9/7/2011  ;Last version written for Digital Research ASM86 assembler. (Too big, get symbol overflow)
; V6.0   9/8/2011  ;Major rewrite to work with NASM Assembler. (Sorry I did not do this earlier. Much better Assembler)
; V6.1   9/11/2011 ;Corrected IDE disk compare routine.
; V6.2   9/12/2011 ;Added IDE memu options to test LBA & CHS display on IDE Board HEX display LED's
; V6.3   9/13/2011 ;Added IBM-BIOS menu option the Read/Write a block of contiguous sectors the the IDE Drive
; V6.4   9/16/2011 ;Added cursor addressing to video output functions. FDISK now displays correctly.
; V6.5   9/17/2011 ;Corrected printer I/O
; V6.6a  10/1/2011 ;Changed patch to E000:2000H along with JMPF
; V6.7   10/1/2011 ;Added CGA video board routines for MS-DOS outputs (Major changes to Console IO routine, INT 10H)
; V6.7b  10/1/2011 ;Added AT-BIOS INT 10, Write String function
; V6.7c  10/1/2011 ;IO Byte switch to redirect CRT Output to CGA/VGA Display
; V6.8   10/4/2011 ;"O" CMD to relocate total Monitor to RAM at E000:8000H
; V6.9   10/5/2011 ;Initilize CGA RAM memory variables in @449H. Cleanup SETUP_IBM_BIOS:
; V7.0   10/9/2011 ;General cleanup
; V7.1   10/15/2011 ;Added Print Screen function to IBM BIOS
; V7.2   10/18/2011 ;Added Ctl+Alt+Del, Pause etc to keyboard functions.

```

```

; V7.3 11/22/2011 ;Added menu options to set time & date with CMOS-RTC on S100Computers/N8VEM MSDOS Support board
; V7.4 11/23/2011 ;Switched over to using 8253 timer tick exactly as IBM-AT does.
; V7.5 11/23/2011 ;Improve 8259A/keyboard test
; V7.51 11/26/2011 ;Clear 8259A on power up
; V7.6 12/27/2011 ;Fixed lack of CR/LF for "S" CMD. Changed "P" CMD to display RAM words ("D" displays RAM Bytes)
; V7.7 2/19/2011 ;Allow IOBYTE to decide if extra ROMS are to be initilized
; V7.8 3/10/2012 ;IOBYTE = 0BFH, forces diagnostic test at FFFF0H
; V7.9 3/27/2012 ;Corrected IDE Board hanging with diagnostic if only one or no drives present, Also numerous other small bugs
; V8.0 3/31/2012 ;Corrected "L" command initilizing 8259A to not allow ints during initialization
; V8.1 3/31/2012 ;Corrected Set Time for MS-DOS Board Dallas RTC Chip
; V8.2 5/4/2012 ;Major Upgrade, Added LAVA-10 Video display output
; V8.3 7/6/2012 ;IOBYTE debug changes at end.
; V8.4 7/7/2012 ;Problem finding default MSDOS video output.
; V8.5 8/13/2012 ;MSDOS not booting up with CGA board corrected
; V8.6 8/14/2012 ;MSDOS not booting up with 80286 board was not defaulting to Propeller board (CONSOLE_FLAG not using ES:=0)
; V8.7a 10/21/2012 ;Changed "L" command. Was not working correctly for 8259A test. Byte[CONSOLE_FLAG] errors
; V8.8a 10/21/2102 ;Change CONSOLE_FLAG to word. This way less chance or random 0,1,or 2 appearing in RAM at startup
; V9.0 2/6/2013 ;Spliced in many modifications & improvements from RM 80386 monitor. Add Modem routine
; V9.1 2/8/2013 ;Fixed (80386) JZ,JNZ jumps so they are within range for 8086. --- REMOVED 80386 CODE ---
; V9.2 2/15/2013 ;Patch: cleaned, up now starts at 100H in RAM
; V9.3 5/3/2013 ;Patch done for 8086/8088, 100H -> E8000H (Note. Different from 80386 Monitor)
; V9.3A 5/3/2013 ;Treat 8086/80286 and 8088 CPU board ROM locations different. Removed Y command
; V9.4 5/7/2013 ;Improved U command, general cleanup
; V9.5 5/17/2013 ;Simplify checking/initilizing VGA EPROM (VGA_ROM_CHECK:)
; V9.6 5/23/2013 ;Added INT 15H, AH=44H for Cirrus Logic VGA Board initialization
; V9.7 7/10/2013 ;Rearranged & set to 0 low RAM storage variables at ~500H
; V9.8 7/12/2013 ;Add coded at FF065H to jump to VIDEO_IO routines (For EGA Board)
; V9.8a 7/12/2013 ;Corrected low RAM initialization of INT verctor relocations
; V10.0 7/15/2013 ;EGA board working is S100 bus with ISA->S100 converter. Changed equates for 80286 EEPROMS
; V10.1 7/29/2013 ;European Cruise updates
; V10.2 8/31/2013 ;Correct bit display for memory compare error (VERIFY:)
; V10.3 10/23/2013 ;Stop duplicate "ZFDC not present" message upon initialization
; V10.31 6/14/2014 ;Minor change to scroll up routine
; V10.32 7/17/2014 ;Correction of Y command in IDE_SIGNON3 menu
; V10.33 7/25/2014 ;Added capability to switch back to Z80 with Z command utilizing the V2 SMB (port EEH).
; V10.33a 8/8/2014 ;Remove the '.' diagnostic character for CGA screen scroll etc. put in normal space character
;
;
; To Do:-
; Caps Lock key is showing as ^ on for MS-DOS command line on Propeller & LAVA video boards (Fix on propeller board)
;
;
;
; Notes...
; This fairly extensive 8086+ monitor consists of 3 main sections. It assumes an 8086 (does not use opcodes of the 80286+)
; Section 1. This is a classical monitor. Display, change RAM/ports etc.
; Section 2. This is a self-contained set of routines run diagnostic tests on the S100Computers/N8VEM IDE board.
; Section 3. This fairly complex section. It emulates most of the IBM-PC ROM BIOS interrupts (hard & soft) such that MS-DOS
; (V4.01)/FreeDOS can be run on the system - without DOS disk modifications.
;
;
; In the final EEPROM, code will be placed at F8000H for the 8088/8086 Boards (or F0000H for the S100Computers/N8VEM 80286 board).
; This is because the 8086/8088 boards only have capacity for 32K using 28C256 EEPROMS. The 80286 can fit 64K with EEPROMS.
; (BTW, the 8086/8088 boards can accomidate 64K using UV-EPROMS (27C256's) and so can reside at F0000H if required).
;
;
; In all cases the stack is at DFFFCH & IDE Board RAM buffers/BP are at DE000H.
; For debugging/testing this monitor normally will reside in RAM at E8000H
; Note, the stack is still at DFFFCH & IDE RAM buffer/BP at DE000H.
;
;

```

```

; This monitor needs a valid stack in RAM. It first checks if there is valid RAM in high memory below the ROM
; (The EEROM is usually at F000:0000H). If so it will set the SS to D000H and the SP to FFFCH. This puts it out of the way
; of everything in low RAM. If it does not detect RAM there, it will search for a valid segment at top of RAM downwards and
; put the stack there.
;
; That is the only RAM the main PM monitor needs. However the IDE drive diagnostic routines require much more (sector buffers etc.)
; For these I have set the SS:BP to DE000H. We use SS:BP throughout to access that RAM for the IDE Board diagnostic section.
;
; Remember also, that RAM at 0-3FFH is initialized to trap all 8086 interrupts. If you want this, activate the
; SETUP_INT_TABLE routine at the start of this code. Otherwise they are not used/activated unless you use the "L" and "I" commands.

; Most monitor commands are modeled after the old TDL/Zapple/Z80 commands. Because we are now dealing with potentially up
; to 1MG of RAM for many commands, the start, end RAM locations etc. can take up to 5 digits.
; However the actual span/range for any command is limited to 64K.
;
; The following example fills RAM with 76H from 1A000H to 21234H.
; F1A000,21234,76
; Of course for the lowest 64K of RAM the "normal" 4,3,2 or 1 byte formats can be used
; F123,456,76
; Note because of the 64K range limitation the following will give an error
; F1A000,31234,76 or F1A000,2A001,76
;
; In general hitting the ESC key will abort any long display/command function.
; In all cases, to accept data, finish the entry with a CR.
; So if the display says "xxxxH" you enter up to 4 hex digits than a CR (No "H" is required).
;
; The Console OUT routines CAN be different, The "Normal" monitor and IDE diagnostic sections ALWAYS go through the
; Propeller driven (or any serial type) Console out routine (CO: etc). This by default is also the case
; when the IBM-BIOS sections are activated. However if the Console output is redirected to the CGA/VGA board (INT 10H etc),
; then CO: is not used. Instead CO goes to the IBM BIOS video board output. This is controlled by the [CONSOLE_FLAG] byte in low RAM
; or by switches on the IOBYTE port (see below).
;
; Likewise, the Console IN routines CAN be different. The "Normal" monitor and IDE diagnostic sections ALWAYS go through the
; Propeller driven (or any serial type) Console IN routine (CI:, CICO, etc).
; However when the IBM BIOS section is active (X Menu command, booting up MSDOS etc.), Keyboard input is ALWAYS interrupt
; driven, and requires the 8259A PIC etc. It uses the input from the propeller board, but each key press interrupt
; places the data in the IBM-PC style RAM buffer for later retrieval.

; If the 8259A interrupt functions are not working this section (MS-DOS CI), will hang! You can use the 8259A diagnostics command
; (Main menu, "L" command) to debug this section beforehand.
;
; For Old (< V5.2) Versions Assembled with Digital Research's ASM86, see this section in those files.
;
; For all New Versions (> V6.0) Assemble to a binary file with the excellent/free MSDOS/FreeDOS, NASM.EXE Assembler
; NASM -f bin 8086.A86 -o 8086.bin -l 8086.lst
;
; This will make an 8 bit format .bin file
;
; There are a number of ways to test/run this monitor. Until you actually have this monitor in EEPROM in high memory, you
; can run it low RAM (say 4800H). Until you have such a working version you must have your 8086 after reset jump to this
; test monitor in low RAM at 4800H. Remember in this case you will may have to hand code the stack to a different segment/location.
;
; To move it across to your CPM80 disk file system (Telnet/Modem/serial connection, whatever. I use PCLOAD.COM).
; PCLOAD.COM can be downloaded from the www.S100Computers.com web site. You can use this program to place the code
; anywhere in the lower 64K space (or if you have the S100Computers/N8VEM Z80 board, anywhere in the 1M 8086 address space).
;

```

```

; After switching to your 8086 Board (IN port EDH), have the 8086 jump to there with
; @FFFF0H:- EA 00 xx 00 00 Where xx is a lower 64K, 1K boundary (eg. EA 00 48 00 00).
;
; Later when you have the EPROM monitor working, for debugging, you can use the 8086 monitor "W" command to load
; a .bin file sent from a PC (using the XMODEM format) to anywhere in RAM, normally at E8000H
; and then use the "G" command to jump to the start of the test monitor.
;
; Remember for debugging, the code must start at E8000H. The first 8000H bytes in the code will be 0's for the 8086/8088 boards
; so with the "W" command set the load address to E0000H to have the actual monitor reside at E8000H. Again this is because the 8086 & 8088
; boards only accommodate 32K of EEPROM. As mentioned above, the code can begin at E0000H for both these boards with 27C256's or on the 80286
board.
;
; As soon as you get things going, burn a EEPROM version that resides at F8000H.
; After switching to your 8086/8088 Board (IN port EDH), the Monitor should immediately come up.
;
; From then on, it is best to keep RAM test versions up in the 8086 high RAM. That way you can test MSDOS etc.
; I use the location E8000H. You can use the Monitor "W" and "G" Commands
; This saves keystrokes, for the many times you do this!
;
; To burn two 28C256 EEPROM's with a Wellon VP280 or V290 Programmer...
; Load .BIN file. Select Even bytes (1st of 2) for one ROM and "From File HEX address" and "Buffer Address"
; leave 0000 in the dialog boxes, do not change "File Size (HEX) either".
; Repeat for ODD addresses. In each case the Edit Box code should appear from 4000H-7FFFH if the ROM is read back.
;
; To burn a single 28C256 EEPROM (for the 8088 CPU board) with a Wellon VP280/VP290 Programmer...
; From "File HEX address" = 8000, do not change "Buffer Address" or "File Size (HEX)"
; (The Edit BOX the code should appear at 0000H-7FFFH).
;
; To burn two (Even & Odd Bytes) 27128 EEPROM's with a Wellon VP280 Programmer...
; From "File HEX address" = 8000, do not change "Buffer Address" or "File Size (HEX)"
; (The Edit BOX the code should appear at 0000H-3FFFH).
;
; One final note, the monitor has now got quite large with only a few bytes to spare to fit in
; the F8000H - FFFFFH range. If you add more code you may need to remove other code or shorten the text messages
; If you are using the 80286 board you have can use the full 27C256 EEPROMS and have the code start at F0000H.
; (Without patching the 8086 board jumpers you cannot do this with this board).
; Alternatively you can use the 80386 Monitor.
;

```

```

SCROLL      EQU    01H          ; Set scroll direction UP.
BELL        EQU    07H
SPACE       EQU    20H
BS          EQU    08H
TAB         EQU    09H          ; TAB ACROSS (8 SPACES FOR SD-BOARD)
CR          EQU    0DH
LF          EQU    0AH
FF          EQU    0CH
QUIT        EQU    11H          ; Turns off any screen enhancements (flashing, underline etc).
ESC         EQU    1BH
DELETE      EQU    7FH
BACKS       EQU    08H
CLEAR       EQU    1AH          ; TO CLEAR SCREEN
SOH         EQU    1          ; For Modem etc.
EOT         EQU    4
ACK         EQU    6
NAK         EQU    15H

```



```

USB_RXE      EQU      80H          ;If Bit 7 = 0, data available to recieve by S-100 Computer
USB_TXE      EQU      40H          ;If Bit 6 = 0 data CAN be written for transmission to PC

BASE_PORT    EQU      0A1H
MODEM_CTL_PORT EQU      BASE_PORT    ;A1H
MODEM_SEND_MASK EQU      4
SEND_READY   EQU      4            ;VALUE WHEN READY
MODEM_RECV_MASK EQU      1
RECV_READY   EQU      1            ;BIT ON WHEN READY
MODEM_DATA_PORT EQU      BASE_PORT+2 ;A3H

RECVD_SECT_NO EQU      100H         ;BP Offset for Recieved Sector Number
SECTNO        EQU      101H         ;BP Offset for CURRENT SECTOR NUMBER
ERRCT         EQU      102H         ;BP Offset for ERROR COUNT
MODEM_ERR_LIMIT EQU      8          ;Max number of Modem serial port re-reads aborting
MODEM_RTS_DELAY EQU      1          ;Time to check Modem RTS line (See XMODEM_LOAD & P_XMODEM_LOAD). Not critical.

```

```

;----- S100Computers SMB Board -----

```

```

IOBYTE      EQU      0EFH          ;IOBYTE Port on S100Computers SMB Board.

```

```

;IOBYTE = SENSE SWITCHES AT PORT 0EFH

```

```

;
; BIT MAP OF PORT 0EFH:- X X X X X X X X (11111111=NORMAL CONFIG)

```

```

; | | | | | | | | ..For Z80 Monitor, 0=CONSOLE DATA TO PRINTER ALSO
; | | | | | | | | .....For 8086 Monitor, 0=Force MSDOS Consol output to CGA/VGA Board instead of Propeller board
; | | | | | | | | .....For 8086 Monitor, 0=Do not initilize extra ROMS
; | | | | | | | | .....For 8086 Monitor, 0=Debug data for all MSDOS 10H & 15H INT's to Serial Port and external display
; | | | | | | | | .....Unused
; | | | | | | | | .....For Z80 Monitor, 0=ALL Consol I/O via ACIA Serial port on S100Computers Serial-IO Board
; | | | | | | | | .....For CPM3, 0=Force reformat of Memory disk upon any CPM3 cold re-boot
; |
; | .....For CPM3, 0=Write protect Memory disk for CPM3
; | .....For 8086 Monitor, 0=Prevent doing a JMPF to 500H after 8086 reset (to CPM86 boot)
; Normally a test is made to see if the CPM86 Boot is already in RAM at 500H
; If it is, a 8086 reset will bypass the monitor and go directly there.
; (see Init: in 8086 Monitor)

```

```

; Note if IOBYTE = 00xxxxxx, This will force the hardware diagnostic test after reset.
; (See code at FFFF0H in this 8086 monitor)
;
;
;

```

```

;----- S100Computers MSDOS BOARD PORT ASSIGNMENTS

```

```

NS_EOI      equ      20h           ;Non specific end of interrupt command
MASTER_PIC_PORT equ      20h       ;Hardware port the 8259A is assigned (two ports 20H & 21H)

MasterICW1  equ      0001011B      ;EDGE triggered, 4 bytes, single Master, ICW4 needed
MasterICW2  equ      8H            ;Base address for 8259A Int Table (IBM-PC uses 8X4 = 20H)
MasterICW3  equ      0H            ;No slave
MasterICW4  equ      00000011B     ;No special mode, non buffer, Auto EOI, 8086. ;<<<<,

```

```

CMOS_PORT      EQU      70H          ;Base Port for CMOS Chip
CMOS_VALID     EQU      0DH          ;To check DS12887 CMOS chip is present and OK (Note AT-BIOS uses 0EH)
CMOS_REGA      EQU      0AH          ;CMOS REGISTER A

TIMER          EQU      40H          ;Base port of 8254
TIM_CTL        EQU      43H
COUNTS_SEC    EQU      18
COUNTS_MIN    EQU      1092
COUNTS_HOUR   EQU      07H          ;Seems this value is used with AT/CMOS chip (was 65543 on PC)

UPDATE_TIMER   EQU      80H

CMOS_SECONDS   EQU      0H           ;RAM offsets for CMOS Registers
CMOS_MINUTES   EQU      2H
CMOS_HOURS     EQU      4H

;----- S100Computers IDE BOARD PORT ASSIGNMENTS (30-34H)

;Ports for 8255 chip. Change these to specify where the 8255 is addressed,
;and which of the 8255's ports are connected to which IDE signals.
;The first three control which 8255 ports have the IDE control signals,
;upper and lower data bytes. The fourth one is for mode setting for the
;8255 to configure its ports, which must correspond to the way that
;the first three lines define which ports are connected.

IDEportA       EQU      030H          ;lower 8 bits of IDE interface
IDEportB       EQU      031H          ;upper 8 bits of IDE interface
IDEportC       EQU      032H          ;control lines for IDE interface
IDECtrlPort    EQU      033H          ;8255 configuration port
IDEDrivePort   EQU      034H          ;To select the 1st or 2nd CF card/drive

IDE_Reset_Delay EQU      020H          ;Time delay for reset/initialization (~66 uS, with 8MHz 8086, 1 I/O wait state)

READcfg8255    EQU      10010010b     ;Set 8255 IDEportC out, IDEportA/B input
WRITEcfg8255   EQU      10000000b     ;Set all three 8255 ports output

;IDE control lines for use with IDEportC.

IDEa0line      EQU      01H           ;direct from 8255 to IDE interface
IDEa1line      EQU      02H           ;direct from 8255 to IDE interface
IDEa2line      EQU      04H           ;direct from 8255 to IDE interface
IDEcs0line     EQU      08H           ;inverter between 8255 and IDE interface
IDEcs1line     EQU      10H           ;inverter between 8255 and IDE interface
IDEwrline      EQU      20H           ;inverter between 8255 and IDE interface
IDERdline      EQU      40H           ;inverter between 8255 and IDE interface
IDERstline     EQU      80H           ;inverter between 8255 and IDE interface
;
;Symbolic constants for the IDE Drive registers, this makes the
;code more readable than always specifying the address pins

REGdata        EQU      IDEcs0line
REGerr          EQU      IDEcs0line + IDEa0line
REGseccnt      EQU      IDEcs0line + IDEa1line
REGsector      EQU      IDEcs0line + IDEa1line + IDEa0line
REGcylinderLSB EQU      IDEcs0line + IDEa2line

```

```

REGcylinderMSB EQU    IDEcs0line + IDEa2line + IDEa0line
REGshd         EQU    IDEcs0line + IDEa2line + IDEalline    ;(0EH)
REGcommand     EQU    IDEcs0line + IDEa2line + IDEalline + IDEa0line    ;(0FH)
REGstatus      EQU    IDEcs0line + IDEa2line + IDEalline + IDEa0line
REGcontrol     EQU    IDEcs1line + IDEa2line + IDEalline
REGastatus     EQU    IDEcs1line + IDEa2line + IDEalline + IDEa0line

;IDE Command Constants.  These should never change.

COMMANDrecal   EQU    10H
COMMANDread    EQU    20H
COMMANDwrite   EQU    30H
COMMANDinit    EQU    91H
COMMANDid      EQU    0ECH
COMMANDspindown EQU    0E0H
COMMANDspinup  EQU    0E1H
;
; IDE Status Register:
; bit 7: Busy 1=busy, 0=not busy
; bit 6: Ready 1=ready for command, 0=not ready yet
; bit 5: DF 1=fault occured on the IDE drive
; bit 4: DSC 1=seek complete
; bit 3: DRQ 1=data request ready, 0=not ready to xfer yet
; bit 2: CORR 1=correctable error occured
; bit 1: IDX vendor specific
; bit 0: ERR 1=error occured

MAXSEC         EQU    3DH                ;Sectors per track for CF my Memory drive, Kingston CF 8G. (CPM format, 0-3CH)
                ;translates to LBA format of 1 to 3D sectors, for a total of 61 sectors/track.
                ;This CF card actually has 3F sectors/track. Will use 3D for my CPM86 system because
                ;my Seagate drive has 3D sectors/track. Don't want different CPM86.SYS files around
                ;so this program will also work with a Seagate 6531 IDE drive

DOS_MAXSEC     EQU    3FH                ;For MS-DOS BIOS Setting "Hard Disk" to Custom type (CF Card, 63 Sectors/track)
DOS_MAXHEADS   EQU    10H                ;16 head(s)
DOS_MAXCYL_L   EQU    0FFH               ;Low Byte maximum cylinder (sent via INT 13H's in CH)
DOS_MAXCYL     EQU    1024               ;Max cylinders
DOS_MAXSEC_CYL EQU    0FFH               ;3FH, maximum sector number (bits 5-0)+ two Cyl High Bits (Sectors numbered 1....x)

;-----S100Computers PORTS FOR FOR Z80/WD2793 FDC Board

S100DATAA     EQU    10H                ;IN, S100 Data port to GET data to from FDC Board
S100DATAB     EQU    10H                ;OUT, S100 Data port to SEND data to FDC Board
S100STATUSA   EQU    11H                ;Status port for A
S100STATUSB   EQU    11H                ;Status port for B
RESETZFDCPORT EQU    13H                ;Port to reset ZFDC Z80 CPU.

STATUSDELAY   EQU    20                  ;Time-out for waiting for ZFDC Board handshake signal (Now, ~0.5 seconds @ 8MHz 8086)
SECTOR_TIMEOUT EQU    400H               ;Value for sector R/W status check countdown (For 6-8MHz 8086, not critical)

ZFDCUNINITIALIZED EQU    0FFH           ;If ZFDC is not yet initilized
ZFDCNOTWORKING EQU    0FEH              ;If ZFDC is not working
ZFDCNOTPRESENT EQU    0FDH              ;If ZFDC board is absent
ZFDCINITIALIZED EQU    000H             ;If ZFDC is initilized OK

```



```

STD81BM      EQU      1          ;ZFDC Board Format table # for IBM 8" SDSS Disk
MSDOS2       EQU      13H       ;Disk format type # for ZFDC board (MS-DOS V2.0 Disk, 512 X 9 Sec/Track)
IBM144       EQU      15H       ;Disk format type # for 1.4M DDDS, 18 X 512 Byte Sectors, 80 Tracks

CMD_SET_FORMAT EQU      4H          ;This will select a specified drive and assign a disk format table to that drive
CMD_SET_DRIVE EQU      5H          ;This will select a specified drive (0,1,2,3)
CMD_SET_TRACK EQU      7H          ;This will set head request to a specified track
CMD_SET_SIDE EQU      8H          ;This will set side request to a specified side
CMD_SET_SECTOR EQU      9H        ;This will set sector request to a specified sector
CMD_SET_HOME EQU      0AH        ;This will set head request to Track 0 of CURRENT drive
CMD_SEEEK_TRACK EQU      0EH      ;Seek to track to (IY+DRIVETRACK) with the track verify bit set on CURRENT drive/format
CMD_FORMAT_TRACK EQU      16H     ;Format the floppy disk in the of the CURRENT drive using the current format assigned to that disk
CMD_HANDSHAKE EQU      21H       ;Handshake command only sent during board initialization/testing

;These new commands are required for R/W MSDOS Double sided disks
CMD_DOS_RD_MULTI_SEC EQU 2BH     ;MS-DOS, Read data from multiple sectors starting at the CURRENT sector.
CMD_DOS_WR_MULTI_SEC EQU 2CH     ;MS-DOS, Write data to multiple sectors starting at the CURRENT sector.
CMD_GET_SIDE EQU 2DH             ;Get the current selected side of the current selected drive
CMD_DOS_SET_SECTOR EQU 2EH      ;MS-DOS, Set current sector for the next sec R/W

```

```

;Possible ERROR codes returned from the ZFDC Board:-
;These will be translated into ASCII strings in the error reporting function.
;See the ZFDC code for a complete set of possible error coded returned byt the ZFDC Board

```

```

NO_ERRORS_FLAG EQU 00H          ;No Errors flag for previous cmd, sent back to S-100 BIOS
CONFIRM_FORMAT EQU 32H          ;Confirm disk format cmd request
DISK_WP_ERR EQU 31H            ;Sector write error, Disk is write protected
ABORT_FLAG EQU 3AH             ;Special error flag to signify the user aborted a command

ZFDC_ABSENT EQU 3BH            ;If ZFDC Board is absent
ZFDC_INIT_ERROR EQU 3CH        ;If ZFDC initialization error

TIMEOUT_ERROR EQU 3DH          ;Error flag to signify the previous command timed out
CMD_RANGE_ERR EQU 3EH          ;CMD out or range.

MAX_ERRORS EQU 3FH             ;0 to 3FH errors only

;Meanings for disk status (as returned by IBM BIOS ROM)
seekerr equ 40h                ;seek failed
hdwerr equ 20h                 ;controller chip failed
crcerr equ 10h                 ;crc error
dmaerr equ 09h                 ;DMA across 64k boundary
wpterr equ 03h                 ;write protected disk
rnferr equ 04h                 ;sector not found
timerr equ 80h                 ;Floppy time out error
cmderr equ 01h                 ;Floppy bad command for controller

msize equ 280H                 ;Total RAM memory size, (640K)
romdat equ 0h                  ;Data area for ROM usage (DS will be set to 0H for data at 400H....)

```

```

;----- CGA/VGA/XVGA Video board equates -----

```

```

c6845port Equ 3d0h             ;base port for Lomas/CGA colour board

```

```

bw6845port      Equ    3b0h          ;base port for b/w card
Index_Reg_Count Equ    16            ;Count of 6845 Index registers

;----- LAVA-10 Video board equates -----

LavaStatus      EQU    090H          ;Status Port
LavaData        EQU    091H          ;Data port

;LAVA Commands:-
COPY$MEMORY     EQU    010H
WRITE$MEMORY    EQU    020H
READ$MEMORY     EQU    030H
DRAW$TEXT       EQU    040H
READ$CSR        EQU    036H
WRITE$CSR       EQU    022H

L_CRT_WIDTH     EQU    800           ;Pixels across per line
L_CRT_HEIGHT    EQU    600           ;Pixels (16 per line)
L_BELOW_SCREEN  EQU    601           ;Area of LAVA screen RAM not visible (Use as a clear buffer area, EOL etc)
L_CHARS_PER_LINE EQU    99           ;99X8 = 792
L_SCREEN_LINES  EQU    37           ;37X16 = 592
L_CHAR_WIDTH    EQU    8             ;Character pixel width
L_CHAR_HEIGHT   EQU    16           ;Character pixel height

L_WHITE_COLOR   EQU    0FFFFH
L_BLACK_COLOR   EQU    00000H
L_BLUE_COLOR    EQU    00F0FH
L_GREEN_COLOR   EQU    008F0H

;-----Other Hardware Equates -----

HOLD_STATE      EQU    80H           ;Set Keyboard flag to indicate a Pause is required
NO_HOLD_STATE   EQU    7FH           ;To clear the above flag

SW86            EQU    0EDH          ;INPUT FROM THIS PORT SWITCHES THE 8086/80286 BACK to the Z80 in hardware
SW86_TM        EQU    0EEH          ;Output 00H to this port to switch back to Z80 Hardware (on SMB V2 only).
SW68K          EQU    0ECH          ;SWITCHES TO THE 68K TO MASTER MODE FROM THE Z80 CPU, (not used here).

STACK_SEG      EQU    0D000H        ;Normally (Stack D000:FFFCH)
STACK_POINTER   EQU    0FFFCH        ;With 1M RAM Stack will normally be at D000:FFFC
BASE_POINTER    EQU    0E000H        ;Default BP at D000:E000H

;===== Start of BIOS code segment =====

CPU 8086          ;No 80286/386 opcodes
[BITS 16]

SECTION .text

org 0H

%if CPU_8088
TIMES 8000H DB 0H ;To have code in EEPROMS start at F8000H for 8088/8086 board

```



```

        JMP     word 0000H:500H      ;Far Jump to 500H in RAM (where CPM86 resides)

ToMonitor:
        cld                          ;If not, then jump to this 8086 Monitor in ROM
        cli                          ;Set direction up "UP" throughout this monitor, this is the default direction
                                       ;Disabel interrupts

        MOV     AL,10000000B        ;1st LED off, for VISUAL DIAGNOSTIC we are alive
        OUT     DIAG_LEDS,AL        ;LED's will go off one at a time as we progress through initilization

                                       ;We will now set up a valid stack. Normally there will be 1MG of S-100 RAM
                                       ;in the system so there will be RAM below this EEPROM at D000:FFFCH
                                       ;If so, we will place the stack below the EPROM.
                                       ;If however there is less memory we will find the highest RAM and place
                                       ;the stack at the top of availabel RAM

        mov     ax,cs                ;Note cs will be F000H (or E000H)
        mov     ds,ax                ;DS will also be CS:F000H (or E000H)
        mov     es,ax                ;As will ES
        mov     ax,STACK_SEG         ;Will start with D000H. This leaves 64K at E000:0H for debugging/test versions
        mov     ss,ax                ;For now, SS also set to D000H
        mov     sp,STACK_POINTER     ;Initial SP=D000:FFFCH
        mov     bp,BASE_POINTER      ;BP for IDE RAM variables (will normally be SS:[BP] or D000:E000H)

        mov     BX,STACK_POINTER     ;Normally D000:FFFCH
TOP_OF_RAM:
        MOV     AX,[SS:BX]           ;Check if RAM there, if not find TOS
        NOT     AX
        MOV     [SS:BX],AX
        CMP     [SS:BX],AX           ;Is there real RAM there.
        JNZ     NO_RAM               ;If no RAM then search for lower memory

        MOV     SP,BX
        JMP     DoneStack

NO_RAM: MOV     AX,SS                 ;Try 64K lower....
        SUB     AX,1000H
        MOV     SS,AX
        OR     AX,AX
        JNZ     TOP_OF_RAM

        MOV     SP,4FCH              ;Special case if <= 64K RAM
                                       ;Point to a RAM area (0000:4FC), assume we have at least this ammount.
                                       ;In this case BP will be at 0000:E000H. If no RAM there we are out of luck

DoneStack:
        MOV     AL,11000000B        ;2nd LED off, VISUAL DIAGNOSTIC for Stack done
        OUT     DIAG_LEDS,AL

        mov     bx,SIGNON            ;Signon notice
        call    PRINT_STRING         ;Note up to now stack was not used.

        MOV     AL,0FFH              ;Clear Printer strobe, comes up 0 on a reset
        OUT     PRINTER_STROBE,AL

        MOV     AL,11100000B        ;3rd LED off, VISUAL DIAGNOSTIC
        OUT     DIAG_LEDS,AL

```

```

;Initilize the 8259A PIC Controller (This seems to be required to prevent the 8086
;from "locking up" after a power on).
mov     al,MasterICW1
out     MASTER_PIC_PORT,al
mov     al,MasterICW2
out     MASTER_PIC_PORT+1,al
;Ints start at 20H in RAM
mov     al,MasterICW4
out     MASTER_PIC_PORT+1,al
;No slaves above, so 8259A does not expect ICW3

mov     al,11111111b
out     MASTER_PIC_PORT+1,al
;Allow No Ints on 8259A for now

MOV     AL,11110000B
OUT     DIAG_LEDS,AL
;4th LED off, VISUAL DIAGNOSTIC

mov     bx,MSG
call    SPEAK_STRING
;Speak out signon the message

MOV     AL,11111000B
OUT     DIAG_LEDS,AL
;5 LED's off if speech sent

mov     bx,SHOWSTACK
call    PRINT_STRING
;Show current stack position
MOV     AX,SS
CALL    AX_HEXOUT
MOV     CL,':'
CALL    CO
MOV     AX,SP
CALL    AX_HEXOUT
CALL    CRLF

; CALL    SETUP_INT_TABLE
;          ;Setup RM default INT jump table in RAM 0-3FFH

mov     al,01111111b
out     MASTER_PIC_PORT+1,al
;Send 7FH to 8259A and check it is there
in     AL,MASTER_PIC_PORT+1
CMP     AL,01111111b
JZ     PIC_OK
;Should get same value back if 8259A is present

mov     bx,NO_8259A_MSG
call    PRINT_STRING
;Send 8259A not found message

PIC_OK: mov     al,11111111b
out     MASTER_PIC_PORT+1,al
;Allow No Ints on 8259A for now

MOV     AL,11111100B
OUT     DIAG_LEDS,AL
;6 LED's off if INT Jump table setup

IN     AL,KEYIN
;Flush keyboard

MOV     AL,11111110B
OUT     DIAG_LEDS,AL
;7 LED's off, if ALL initilization is done.

WARM_INIT:
cld
;Set direction up
cli
;Disabel interrupts
mov     ax,cs
;Note cs always will be F000H (or E000H when testing)

```

```

        mov     ds,ax           ;DS & ES will be set to F000H as default values within this monitor
        mov     es,ax

MAINLOOP:
        mov     bx,CLEANUP     ;Clear line and '>'
        call    PRINT_STRING

        call    CICO           ;Get a command from Console
        mov     ah,0
        cmp     al,'A'
        jb     WARM_INIT       ;must be A to Z
        cmp     al,'Z'
        jg     WARM_INIT
        jg     WARM_INIT
        sub     al,'A'         ;calculate offset
        shl     al,1           ;X 2
        add     ax,ctable
        mov     bx,ax
        mov     ax,[CS:BX]     ;Get location of routine
        CALL    AX             ;<-----This is the Main Monitor CMD call
        jmp     WARM_INIT     ;finished

```

```

;***** Basic Monitor Commands *****

```

```

;----- PRINT MENU ON CRT -----

```

```

KCMD:  MOV     BX,MAIN_MENU
        CALL    PRINT_STRING
        RET

```

```

;----- MAP the IMG Addresss space -----

```

```

MAP:   call    CRLF           ;Display complete memory map with R=ram, P=PROM and "." empty space
        mov     ax,0
        mov     ds,ax         ;Must start in first segment in DS:
        mov     dl,64         ;character count
        mov     dh,4          ;segment counter(4 lines per segment)
        mov     SI,ax         ;need to reset bx (ds = 0 already)
        call    SHOW_ADDRESS_DS ;start with address, Send to console the address DS+SI

```

```

map1:  mov     ax,[SI]        ;remember ds is assumed
        not     ax            ;complement data
        mov     [SI],ax
        cmp     ax,[SI]      ;did it change
        jne     not_ram
        not     ax           ;correct data
        mov     [SI],ax
        mov     cl,'R'
        jmp     nextbk       ;get next block

```

```

not_ram:cmp  ax,0            ;ffff->0 must be rom if not 0
        jne     prom
        mov     cl','       ;no need to correct data for here

```

```

        jmp     nextbk           ;get next block
prom:   mov     cl,'p'
nextbk: call    CO              ;send the R,P or "."

        ADD     SI,100H         ;check every 100h at a time
        dec     dl              ;64X1000H across
        jnz     map1           ;one line of 64K done

        mov     dl,64           ;reset counter for next line
        dec     dh              ;segment counter
        jnz     noseg
        mov     ax,ds
        add     ax,1000h
        jc     mapdone
        mov     ds,ax
        mov     dh,4
noseg:  CALL    CRLF_CHECK      ;Print current address at start of each line
        call    SHOW_ADDRESS_DS
        jmp     map1
mapdone:ret

;-----Fill memory with a constant value. Up to 64K bytes from xxxxxH to xxxxxH-----
FILL:   CALL    GET5DIGITS      ;Get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
        ;If 5 digits, then the first digit is put in ES (highest nibble)
        PUSH   ES
        PUSH   DI              ;Save start address for now = ES:DI

        CALL    GET5DIGITS

        MOV     SI,DI          ;Put end address in DS:SI
        MOV     AX,ES
        MOV     DS,AX         ;If 5 digits, then the first digit is put in DS

        POP     DI
        POP     ES            ;Start=ES:DI End=DS:SI

        CALL    CLENGTH        ;Length cx = (ds:si-es:di)+1, if >64K then err

        CALL    GET2DIGITS     ;Fill value to AL (CX unaltered)

        ;ES:DI = start address, (DS:SI = end address, not used), CX = count, AL = fill value
        ;Note RAM is es:[di], count in CX
filoop: mov     [ES:DI],al
        inc     DI
        CMP     DI,0          ;Check if we are crossing a segment boundary
        JNZ    filoop1
        MOV     AX,ES
        ADD     AX,1000H
        MOV     ES,AX
filoop1:loop filoop          ;Dec CX to 0

```

```
ret
```

```
;-----Display memory contents (bytes)
```

```
DISPLAY_RAM_BYTES:
```

```
CALL    GET5DIGITS          ;Get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
                                ;If 5 digits, then the first digit is put in ES (highest nibble)

PUSH    ES
PUSH    DI                  ;Save start address for now.

CALL    GET5DIGITS
MOV     SI,DI              ;Put end address in SI
MOV     AX,ES
MOV     DS,AX              ;If 5 digits, then the first digit is put in DS

POP     DI
POP     ES                  ;Start=ES:DI  End=DS:SI

;   AND    DI,0FFF0h        ;even up printout
;   OR     SI,000Fh        ;also nice ending for Ray G.

call    CLENGTH            ;Length cx = (ds:si-es:di)+1, if length > 64K then err

dloop6: CALL    CRLF_CHECK    ;Note BX,CX is saved, ESC at keyboard will abort
call    SHOW_ADDRESS_ES    ;Send start address

MOV     DL,16              ;First print a line of 16 Hex byte values
PUSH    CX
PUSH    DI
PUSH    ES

dloop1: mov     al,[es:di]    ;Will increment DI
call    AL_HEXOUT
call    BLANK
call    Inc_DI_boundary_check ;Will increase DI
DEC     DL                 ;Have we done 16 bytes yet
jnz    dloop1

mov     cx,6
call    TABS                ;Now print ascii for those 16 bytes
                                ;first send 6 spaces

MOV     DL,16              ;16 across again
POP     ES
POP     DI
POP     CX

dloop2: mov     al,[es:DI]
and     al,7fh
cmp     al,' '              ;filter out control characters
jnc    dloop3

dloop4: mov     al,','
dloop3: cmp     al,'~'
jnc    dloop4
PUSH    CX
mov     cl,al
```



```

        call    CO
        POP     CX
        loop   dloop5          ;--CX has total byte count
        ret
dloop5: call   Inc_DI_boundry_check
        DEC     DL             ;Have we done 16 bytes yet
        jnz    dloop2
        JMP     dloop6

Inc_DI_boundry_check:          ;Check if we are crossing a segment boundary
        inc    DI             ;If so, inc [ES]
        CMP    DI,0
        JNZ    bounds1
        MOV    AX,ES
        ADD    AX,1000H
        MOV    ES,AX
bounds1:RET

Inc_SI_boundry_check:          ;Check if we are crossing a segment boundary
        inc    SI             ;If so, inc [DS]
        CMP    DI,0
        JNZ    bounds2
        MOV    AX,DS
        ADD    AX,1000H
        MOV    DS,AX
bounds2:RET

;-----DISPLAY Words Memory -----
;   This routine forces the CPU to do RAM word reads rather than a byte reads.
;   It is used to test the hardware's ability to do 16 bit reads on odd and even addresses.
;   This is very important. "Normal" byte reads will not show such a hardware problem.
;   A block or RAM/ROM read with the "D" & "P" commands must be identical

DISPLAY_RAM_WORDS:
        CALL   GET5DIGITS      ;Get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
                                ;If 5 digits, then the first digit is put in ES (highest nibble)

        PUSH  ES
        PUSH  DI               ;Save start address for now.

        CALL  GET5DIGITS
        MOV   SI,DI            ;Put end address in SI
        MOV   AX,ES
        MOV   DS,AX           ;If 5 digits, then the first digit is put in DS

        POP   DI
        POP   ES              ;Start=ES:DI End=DS:SI

;   AND     DI,0FFF0h         ;even up printout
;   OR      SI,000Fh         ;also nice ending for Ray Gluck.

        call  CLENGTH          ;Length cx = (ds:si-es:di)+1, if length > 64K then err
        shr  cx,1              ;divide by 2 because words

```

```

wdloop6:CALL  CRLF_CHECK          ;Note BX,CX is saved, ESC at keyboard will abort
          call  SHOW_ADDRESS_ES    ;Send start address

          MOV   DL,8              ;First print a line of 16/2 Hex byte values
          PUSH  CX
          PUSH  DI
          PUSH  ES

wdloop1:mov   ax,[es:di]          ;Will increment DI
          call  AL_HEXOUT
          call  BLANK
          mov   al,ah
          call  AL_HEXOUT
          call  BLANK
          call  Inc_DI_boundry_check ;Will increase DI
          call  Inc_DI_boundry_check ;Will increase DI
          DEC   DL                ;Have we done 16 bytes yet
          jnz   wdloop1

          mov   cx,8              ;Now print ascii for those 16 bytes
          call  TABS              ;first send 6 spaces

          MOV   DL,8              ;16/2 across again
          POP   ES
          POP   DI
          POP   CX
wdloop2:mov   ax,[es:DI]
          push  ax
          and   al,7fh
          cmp   al,' '            ;filter out control characters
          jnc   wdloop3
wdloop4:mov   al',' '
wdloop3:cmp   al,'~'
          jnc   wdloop4
          PUSH  CX
          mov   cl,al
          call  CO
          POP   CX
          pop   ax

          mov   al,ah
          and   al,7fh
          cmp   al,' '            ;filter out control characters
          jnc   wdloop7
wdloop8:mov   al',' '
wdloop7:cmp   al,'~'
          jnc   wdloop8
          PUSH  CX
          mov   cl,al
          call  CO
          POP   CX
          loop  wdloop5           ;--CX has total byte count
          ret

wdloop5:call  Inc_DI_boundry_check

```

```

call    Inc_DI_boundry_check
DEC     DL                ;Have we done 16 bytes yet
jnz     wdloop2
JMP     wdloop6

```

```

;-----MOVE Memory -----

```

```

MOVE:   CALL    GET5DIGITS        ;Get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
                                ;If 5 digits, then the first digit is put in ES (highest nibble)
        PUSH   ES                ;Do everything relative to first ES value
        PUSH   DI                ;Save start address for now.

        CALL   GET5DIGITS
        MOV    SI,DI              ;Put end address in SI
        MOV    AX,ES
        MOV    DS,AX             ;If 5 digits, then the first digit is put in DS

        POP    DI
        POP    ES                ;Start=ES:DI  End=DS:SI

        call   CLENGTH           ;Length cx = (ds:si-es:di)+1, if length > 64K then err

        PUSH   ES
        PUSH   DI                ;Save Start Address ES:DI
        PUSH   CX                ;Save length

        CALL   GET5DIGITS        ;For Destination, get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
        MOV    SI,DI              ;Put destination address in DS:SI
        MOV    AX,ES
        MOV    DS,AX             ;If 5 digits, then the first digit is put in DS

        POP    CX                ;Get length
        POP    DI                ;Get start ES:DI  destination DS:SI
        POP    ES                ;Get back the initial ES value (often 0)

MOVE1:  MOV     AL,[ES:DI]        ;Note cannot use MOVSB opcode because of segment boundaries
        MOV     [DS:SI],AL
        CALL   Inc_DI_boundry_check ;Check if we are crossing a segment boundary
        CALL   Inc_SI_boundry_check
MOVE3:  LOOP   MOVE1
        RET

```

```

;-----SUBSTITUTE Memory -----

```

```

SUBSTITUTE:
        CALL   GET5DIGITS        ;Get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
                                ;If 5 digits, then the first digit is put in ES (highest nibble)
nusloop:CALL  CRLF
        call   SHOW_ADDRESS_ES
        mov    cx,8              ;Display 8 bytes per line
sloop:  call   BLANK

```

```

mov     al,[es:DI]
push   cx
push   ax
call   AL_HEXOUT
mov     cl,'-'
call   CO
pop     ax
pop     cx
call   GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged), terminator in AH
cmp     ah,CR               ;CR signals we are done
je      qtest
cmp     ah,ESC              ;Also ESC
je      qtest
cmp     ah,' '              ;is a SP so skip to next byte
je      snext1
mov     [es:DI],al
snext1: inc    DI
        CMP    DI,0
        JNZ   snext2
        MOV   AX,ES
        ADD  AX,1000H
        MOV  ES,AX
snext2: loop  sloop
        jmp  nusloop
qtest:  ret

```

;-----Verify Memory Contents -----

```

VERIFY: CALL  GET5DIGITS           ;Get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
        PUSH  ES                   ;If 5 digits, then the first digit is put in ES (highest nibble)
        PUSH  DI                   ;Do everything relative to first ES value
        ;Save start address for now.

        CALL  GET5DIGITS
        MOV   SI,DI                ;Put end address in DS:DI
        MOV   AX,ES
        MOV   DS,AX                ;If 5 digits, then the first digit is put in DS

        POP   DI
        POP   ES                   ;Start=ES:SI  End=DS:DI

        call  CLENGTH              ;Length cx = (ds:si-es:di)+1, if length > 64K then err

        PUSH  ES
        PUSH  DI                   ;Save Start Address
        PUSH  CX                   ;Save length

        CALL  GET5DIGITS           ;For Destination, get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
        MOV   SI,DI                ;Put destination address in DS:SI
        MOV   AX,ES
        MOV   DS,AX                ;If 5 digits, then the first digit is put in DS

        POP   CX
        POP   DI

```

```

        POP     ES                ;Get back the initial ES value (often 0)

        MOV     BX,0              ;Count of mis-matches

VERIFY1:MOV  AL,[ES:DI]           ;cannot use cmps because of segments
        CMP     AL,[DS:SI]
        JZ      MATCH_OK
        call    verr
MATCH_OK:
        INC     DI
        CMP     DI,0              ;Check if we are crossing a segment boundary
        JNZ     VERIFY2
        MOV     AX,ES
        ADD     AX,1000H
        MOV     ES,AX

VERIFY2:INC  SI
        CMP     SI,0              ;Check if we are crossing a segment boundary
        JNZ     VERIFY3
        MOV     AX,DS
        ADD     AX,1000H
        MOV     DS,AX

VERIFY3:LOOP VERIFY1
        CMP     BX,0              ;Was there any errors
        JNZ     TOTAL_MISMATCHES
        MOV     BX,MATCHES_OK
        CALL    PRINT_STRING
TOTAL_MISMATCHES:
        RET

verr:   CMP     BX,0              ;Save count, print error
        JNZ     SKIP_DIFF_MSG

        PUSH    DS
        MOV     AX,CS
        MOV     DS,AX
        MOV     BX,DIFF_Header_Msg
        CALL    PRINT_STRING
        POP     DS

SKIP_DIFF_MSG:
        CALL    CRLF              ;There is a mis-match show values
        call    SHOW_ADDRESS_ES
        PUSH    CX

        MOV     CX,6
        call    TABS
        mov     al,[ES:DI]
        PUSH    AX
        call    AL_HEXOUT
        CALL    BLANK
        POP     AX
        call    AL_BINOUT

        MOV     CX,5

```

```

call    TABS
call    SHOW_ADDRESS_DS

MOV     CX,6
call    TABS
mov     al,[ds:SI]
PUSH   AX
call    AL_HEXOUT
CALL   BLANK
POP    AX
call    AL_BINOUT

POP    CX
call   CTRL_CHECK
INC    BX           ;This prevents the header being show each time
RET                    ;Return verr

```

;----- Simple test of RAM (Continous)-----

```

TEST_RAM:
mov     bx,JMSG           ;Will test memory forever
call    PRINT_STRING

CALL   GET5DIGITS        ;Get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
                           ;If 5 digits, first digit entered to ES (Highest nibble)

PUSH   ES
PUSH   DI                 ;Save start address for now.

CALL   GET5DIGITS
MOV    SI,DI              ;Put end address in DS:SI
MOV    AX,ES
MOV    DS,AX              ;If 5 digits, then the first digit is put in DS

POP    DI
POP    ES                 ;Start=ES:BX End=DS:DX

CALL   CLENGTH           ;Length cx = (ds:SI-es:DI)+1, if length > 64K then err

MOV    DX,0               ;Test loop count

PUSH   CX                 ;CX has length
mov    bx,STARTJMSG      ;Test memory until ESC
call   PRINT_STRING
POP    CX

mtest1: push  cx
        push  di

mtloop: mov   al,[es:DI]
        mov   ah,al       ;Store value currently in RAM
        not  al
        mov  [es:DI],al
        mov  al,[es:DI]
        not  al

```

```

        cmp     al,ah
        jne     terr
        mov     [es:DI],ah
tnext:  inc     DI
        CMP     DI,0
        JNZ     tnext2
        mov     AX,ES
        ADD     ax,1000H
        MOV     ES,AX
tnext2: call    CTRL_CHECK           ;See if an abort is requested
        loop   mtloop               ;Repeat for "length" number of bytes

        mov     bx,RAM_Test_Count
        CALL    PRINT_STRING
        inc     dx
        MOV     AX,DX
        CALL    AX_HEXOUT
        mov     bx,H_MSG             ;H.
        CALL    PRINT_STRING
        pop     di                   ;Repeat the whole process
        pop     cx
        jmp     mttest1             ;test forever

terr:   push    DX
        mov     dx,ax               ;save data in dx
        CALL    CRLF
        call    SHOW_ADDRESS_ES
        mov     ax,dx               ;get back data
        xor     al,ah               ;identify bits
        mov     dx,ax
        call    AL_HEXOUT
        call    BLANK
        mov     ax,dx
        call    AL_BINOUT
        pop     dx
        jmp     tnext

;----- QUERY PORTS -----
QUERY:  call    CICO                 ;is it input or output
        cmp     al,'I'
        jz     input
        cmp     al,'O'
        jz     output
        jmp     ERR                 ;if not QI or QO then error

input:  call    GET4DIGITS           ;Get 8 or 16 bit value (2 or 4 digits) to DI, terminator in AH
        call    CRLF
        mov     dx,DI
        in     al,dx                ;Note will assume here we have just an 8 bit port
        push   ax
        call    AL_HEXOUT           ;Show value in HEX

```

```

    call    BLANK
    pop     ax
    call    AL_BINOUT           ;Show value in binary
    ret

output: call    GET4DIGITS       ;Get 8 or 16 bit value (2 or 4 digits) to DI, terminator in AH
    mov     dx,DI
    CALL    GET2DIGITS         ;Output value to AL (BX unaltered)
    PUSH   AX
    CALL    CRLF
    POP    AX
    out    dx,al              ;Send 8 bit value in AL to port at [DX]
    RET

;----- GO TO A RAM LOCATION -----
GOTO:  mov     bx,GET_SEG_MSG    ;Segment=
    call    PRINT_STRING
    call    GET4DIGITS         ;Get (up to) 16 bit value (4 digits) to BX.
    PUSH   DI                 ;Save Segment (in [DI]) on stack

    mov     bx,GET_OFFS_MSG     ;Offset=
    call    PRINT_STRING
    call    GET4DIGITS
    PUSH   DI                 ;Save Offset (in [DI]) on stack
    RETF                    ;Will pop offset, then CS and go there Note RETF!

;----- SWITCH CONTROL BACK TO Z80 (Master) -----
Z80:   in     al,SW86           ;This switches control back over to Z80
    MOV     AL,00000000B       ;Or reset TMA-O back to Z80 control.
    OUT    SW86_TM,AL
    nop
    nop
    nop
    nop
    nop
    JMP    BEGIN

;----- HEX MATH -----
HEXMATH:
    mov     bx,MATH_MSG       ;HEX MATH
    call    PRINT_STRING
    call    GET4DIGITS
    push   DI                 ;save data for the moment

```



```

call    GET4DIGITS
push   DI
mov    bx,MATH_HEADER1
call   PRINT_STRING
pop    DI                ;get back data2 (DI=data2)
pop    BX                ;and data1 (BX=data1)

push   DI                ;save them again for below
push   BX
add    BX,DI
call   BX_HEXOUT        ;Show addition (data1+data2)
mov    bx,MATH_HEADER2
call   PRINT_STRING
pop    BX                ;get back data1 one more time
pop    DI                ;and data2
sub    bx,DI            ;data1-data2
call   BX_HEXOUT
MOV    BX,H_MSG_CRLF
call   PRINT_STRING
ret

```

```

;----- Display all active IO input ports in the system -----
;          64K of 16 & 8 bit ports

```

```

INPORTS:mov    bx,PORTS_IN_MSG
call   PRINT_STRING
MOV    SI,0FFFFH        ;Display 12 lines, 4 ports across
MOV    BP,0000H        ;Will contain port number

LOOPIO: MOV    DX,BP
CMP    DL,SW86          ;INPUT FROM THIS PORT SWITCHES THE 80286 BACK TO THE Z80 (SKIP)
JZ    NEXT_P
CMP    DL,SW68K        ;INPUT FROM THIS PORT SWITCHES IN THE 68K CPU (Do not activate)
JZ    NEXT_P

IN     AX,DX            ;Is it 0FFFFH
CMP    AX,0FFFFH
JZ    NEXT_P          ;If so skip

MOV    AX,BP
CALL   AX_HEXOUT        ;Print Port Address
MOV    CL,'-'          ;Put in a "->"
CALL   CO
MOV    CL,'>'
CALL   CO
MOV    DX,BP
IN     AX,DX            ;Get port WORD data (note, 8 bits even port Input will be in AH)
CALL   AX_HEXOUT
CALL   BLANK
MOV    CL,'-'          ;Put in a "->"
CALL   CO
MOV    CL,'>'
CALL   CO
MOV    DX,BP

```

```

        IN     AL,DX           ;Get port BYTE data
        CALL  AL_HEXOUT

SKIP2:  CALL  BLANK           ;4 ports across
        CALL  BLANK

        INC   SI              ;Next cursor position count
        MOV   AX,SI
        AND   AX,0003H
        CMP   AX,0003H
        JNZ   NEXT_P
        CALL  CRLF

NEXT_P: INC   BP              ;Next Port until 0000H
        OR   BP,BP
        JZ   SKIP3
        MOV   AX,BP
        AND   AX,00FFH       ;256 ports at a time
        JNZ  LOOPIO
        mov   BX,MORE_MSG    ;Contineue (Y/N)
        call PRINT_STRING
        call CICO
        cmp   al,'Y'
        JNZ  SKIP3
        CALL CRLF
        JMP  LOOPIO
SKIP3:  CALL  CRLF           ;Routine done/aborted
        RET

```

```

;-----
REGISTERS:                ;RM Display all the CPU Registers
        PUSH  AX            ;Save everything
        PUSH  BX
        PUSH  CX
        PUSH  DX
        PUSH  SI
        PUSH  DI
        PUSH  BP

        PUSHF
        PUSHF
        PUSH  SP            ;we will display reverse this order
        PUSH  BP
        PUSH  DI
        PUSH  SI

        PUSH  DX
        PUSH  CX
        PUSH  BX
        PUSH  AX

        MOV   BX,INT_AX_MSG ;"AX="
        CALL PRINT_STRING
        POP   AX

```

```

CALL    AX_HEXOUT

MOV     BX,INT_BX_MSG           ;"H BX="
CALL   PRINT_STRING
POP     AX
CALL   AX_HEXOUT

MOV     BX,INT_CX_MSG           ;"H CX="
CALL   PRINT_STRING
POP     AX
CALL   AX_HEXOUT

MOV     BX,INT_DX_MSG           ;"H DX="
CALL   PRINT_STRING
POP     AX
CALL   AX_HEXOUT

MOV     BX,INT_SI_MSG           ;"SI="
CALL   PRINT_STRING
POP     AX
CALL   AX_HEXOUT

MOV     BX,INT_DI_MSG           ;"DI="
CALL   PRINT_STRING
POP     AX
CALL   AX_HEXOUT

MOV     BX,INT_BP_MSG           ;"BP="
CALL   PRINT_STRING
POP     AX
CALL   AX_HEXOUT

MOV     BX,INT_SP_MSG           ;"SP="
CALL   PRINT_STRING
POP     AX
ADD     AX,14                   ; Adjust because we first saved stuff above (PUSHAD)
CALL   AX_HEXOUT

MOV     BX,INT_FLAGS_MSG        ;[Flags]=
CALL   PRINT_STRING
POP     AX                       ;Flags to AX
MOV     AL,AH
CALL   AL_BINOUT                ;Output lower 16 bits
POP     AX
CALL   AL_BINOUT

MOV     BX,INT_CS_MSG           ;"CS="
CALL   PRINT_STRING
MOV     AX,CS
CALL   AX_HEXOUT

MOV     BX,INT_DS_MSG           ;"DS="
CALL   PRINT_STRING
MOV     AX,DS
CALL   AX_HEXOUT

```

```

MOV     BX,INT_ES_MSG           ;"ES="
CALL    PRINT_STRING
MOV     AX,ES
CALL    AX_HEXOUT

MOV     BX,INT_SS_MSG           ;"SS="
CALL    PRINT_STRING
MOV     AX,SS
CALL    AX_HEXOUT

MOV     BX,H_MSG_CRLF
CALL    PRINT_STRING

POP     BP                       ;Get Back Everything
POP     DI
POP     SI
POP     DX
POP     CX
POP     BX
POP     AX
RET

```

;----- THIS IS A ROUTINE TO SET THE CURRENT TIME & DATE FOR THE DALLAS RTC CHIP ON THE MS-DOS SUPPORT BOARD -----

```

SET_TIME_DATE:
CALL    RAW_GETTIME             ;First Show Time/Date
CALL    CRLF                    ;First set Time

MOV     BX,SET_TIME_MSG
CALL    PRINT_STRING
CALL    CICO
CMP     AL,'Y'
JZ      SET_TIME0
RET

SET_TIME0:
CALL    InputTime               ;CH = HOURS, CL = Minutes, DH = Seconds all in BCD
CALL    UPD_IN_PR               ;CHECK FOR UPDATE IN PROCESS
JNC     SET_TIME1               ;GO AROUND IF OK
JMP     RTC_ERROR               ;IF ERROR

SET_TIME1:
PUSH    DX                       ;Save Data
MOV     DL,-2                    ;-2 goes to 0 for PORT_INC_2
CLI                                           ;INTERRUPTS OFF DURING WRITES

CALL    PORT_INC_2              ;SET ADDRESS OF SECONDS
POP     DX
MOV     AL,DH
OUT     CMOS_PORT+1,AL          ;Send Seconds

CALL    PORT_INC_2              ;SET ADDRESS OF MINUTES
MOV     AL,CL

```

```

    OUT    CMOS_PORT+1,AL        ;Send Minutes

    CALL   PORT_INC_2           ;SET ADDRESS OF HOURS
    MOV    AL,CH
    OUT    CMOS_PORT+1,AL        ;Send Hours

    CALL   CRLF
                                ;Now Set date
    CALL   UPD_IN_PR            ;CHECK FOR UPDATE IN PROCESS
    JNC    SET_DATE1           ;GO AROUND IF OK
    JMP    RTC_ERROR            ;IF ERROR

SET_DATE1:
    CALL   InputDate           ;CH = CENTURY, CL = Year, DH = Month, DL = Day all in BCD
    PUSH  DX                   ;Save 2X
    PUSH  DX
    MOV    DL,6
    CLI                                     ;INTERRUPTS OFF DURING WRITES

    CALL   PORT_INC           ;SET ADDRESS OF DAYS (Port 7)
    POP    DX
    MOV    AL,DL
    OUT    CMOS_PORT+1,AL      ;Send Days

    CALL   PORT_INC           ;SET ADDRESS OF MONTHS
    POP    DX
    MOV    AL,DH
    OUT    CMOS_PORT+1,AL      ;Send Months

    CALL   PORT_INC           ;SET ADDRESS OF YEARS
    MOV    AL,CL
    OUT    CMOS_PORT+1,AL      ;Send Seconds

    MOV    DL,31H             ;POINT TO CENTURY BYTE SAVE AREA
    CALL   PORT_INC           ;
    MOV    AL,CH
    OUT    CMOS_PORT+1,AL      ;Send Century

    JMP    RAW_GETTIME

;----- THIS IS A ROUTINE TO PLACE TIME & DATE ON CONSOLE AT THE CURRENT CURSOR POSITION -----

RAW_GETTIME:
    CALL   CRLF
    MOV    BX,Time_Msg
    CALL   PRINT_STRING
    CALL   LOAD_TIME
    CALL   DisplayTime

    MOV    BX,GAP_Msg
    CALL   PRINT_STRING

    MOV    BX,Date_Msg

```

```

CALL PRINT_STRING
CALL LOAD_DATE
CALL DisplayDate
RET

LOAD_TIME:                                ;Load up registers with TIME info
CALL UPD_IN_PR                            ;CHECK FOR UPDATE IN PROCESS
JNC RTC_2A                                ;GO AROUND IF OK
JMP RTC_ERROR                             ;IF ERROR

RTC_2A: MOV DL,-2                          ;-2 goes to 0 for PORT_INC_2
      CLI                                ;INTERRUPTS OFF DURING READ
      CALL PORT_INC_2                    ;SET ADDRESS OF SECONDS
      IN AL,CMOS_PORT+1                 ;Get BCD value returned
      MOV DH,AL                         ;SAVE IN DH
      CALL PORT_INC_2                    ;SET ADDRESS OF MINUTES
      IN AL,CMOS_PORT+1                 ;Get BCD value returned
      MOV CL,AL                         ;SAVE IN CL
      CALL PORT_INC_2                    ;SET ADDRESS OF HOURS
      IN AL,CMOS_PORT+1                 ;Get BCD value returned
      STI
      MOV CH,AL                         ;SAVE
      MOV DL,0                          ;SET DL TO ZERO
      CLC                                ;Clear carry flag to indicate all is OK
      RET

LOAD_DATE:                                ;Load up registers with Date info
CALL UPD_IN_PR                            ;CHECK FOR UPDATE IN PROCESS
JNC RTC_2B                                ;GO AROUND IF OK
JMP RTC_ERROR                             ;IF ERROR

RTC_2B: MOV DL,6                          ;
      CLI                                ;INTERRUPTS OFF DURING READ
      CALL PORT_INC                     ;POINT TO DAY
      IN AL,CMOS_PORT+1
      MOV CH,AL                          ;TEMPORY SAVE HERE (Return in DL)

      CALL PORT_INC                     ;POINT TO MONTH
      IN AL,CMOS_PORT+1
      MOV DH,AL                          ;SAVE

      CALL PORT_INC                     ;POINT TO YEAR
      IN AL,CMOS_PORT+1
      MOV CL,AL                          ;SAVE
      MOV DL,31H                         ;POINT TO CENTURY BYTE SAVE AREA
      CALL PORT_INC                     ;
      IN AL,CMOS_PORT+1                 ;GET VALUE
      STI
      MOV DL,CH                          ;GET DAY BACK
      MOV CH,AL
      CLC                                ;Clear carry flag to indicate all is OK
      RET

RTC_ERROR:
MOV BX,TIME_ERROR_MSG
CALL PRINT_STRING

```

```

    STI
    STC                ;Set carry flag to indicate all is NOT OK
    RET                ;Back to main menu

PORT_INC:
    INC    DL          ;INCREMENT ADDRESS
    MOV    AL,DL
    OUT    CMOS_PORT,AL
    RET

PORT_INC_2:
    ADD    DL,2        ;INCREMENT ADDRESS
    MOV    AL,DL
    OUT    CMOS_PORT,AL
    RET

INITIALIZE_STATUS:   ;Initilize the RTC
    PUSH   DX          ;SAVE
    MOV    DL,09H
    CLI                    ;INTERRUPTS MASKED DURING RESET
    CALL   PORT_INC
    MOV    AL,26H
    OUT    CMOS_PORT+1,AL ;INITIALIZE 'A' REGISTER
    CALL   PORT_INC
    MOV    AL,82H       ;SET 'SET BIT' FOR CLOCK INITIALIZATION
                    ;AND 24 HOUR MODE
    OUT    CMOS_PORT+1,AL ;INITIALIZE 'B' REGISTER
    CALL   PORT_INC
    IN     AL,CMOS_PORT+1 ;READ REGISTER 'C' TO INITIALIZE
    CALL   PORT_INC
    IN     AL,CMOS_PORT+1 ;READ REGISTER 'D' TO INITIALIZE
    STI
    POP    DX          ;RESTORE
    RET

UPD_IN_PR:           ;Check we are ready to read clock
    PUSH   CX
    MOV    CX,600      ;SET LOOP COUNT
UPDATE:  MOV    AL,0AH  ;ADDRESS OF [A] REGISTER
    CLI                    ;INTERRUPTS MASKED DURING RESET
    OUT    CMOS_PORT,AL
    JMP    $+2          ;I/O TIME DELAY
    IN     AL,CMOS_PORT+1 ;READ IN REGISTER [A]
    TEST   AL,80H      ;IF 8XH--> UIP BIT IS ON (CANNOT READ TIME)
    JZ     UPD_IN_PREND
    LOOP   UPDATE      ;Try again
    STC                    ;SET CARRY FOR ERROR
    XOR    AX,AX
    ;
UPD_IN_PREND:
    POP    CX
    RET                ;RETURN

;Display time
; Arrive with CH = HOURS IN BCD

```

```

;           CL = Minutes in BCD
;           DH = Seconds in BCD
DisplayTime:
    PUSH    BX
    PUSH    DX
    PUSH    CX
    MOV     AL,CH
    CALL    PRINT_REG           ;Hours. Convert BCD to ASCII
    MOV     CL,':'
    CALL    CO
    POP     CX
    MOV     AL,CL
    CALL    PRINT_REG           ;Minutes. Convert BCD to ASCII
    MOV     CL,':'
    CALL    CO
    POP     DX
    MOV     AL,DH
    CALL    PRINT_REG           ;Seconds. Convert BCD to ASCII
    POP     BX
    RET

;Input time
;   Return CH = HOURS IN BCD
;           CL = Minutes in BCD
;           DH = Seconds in BCD
InputTime:
    PUSH    BX
    MOV     BX,Input_Hours_Msg
    CALL    PRINT_STRING
    CALL    GET2BCD             ;Return with 2 BCD digits in AL
    MOV     CH,AL
    PUSH    CX
    MOV     BX,Input_Minutes_Msg
    CALL    PRINT_STRING
    CALL    GET2BCD             ;Return with 2 BCD digits in AL
    POP     CX
    MOV     CL,AL
    PUSH    CX
    MOV     BX,Input_Seconds_Msg
    CALL    PRINT_STRING
    CALL    GET2BCD             ;Return with 2 BCD digits in AL
    MOV     DH,AL
    PUSH    DX
    POP     DX
    POP     CX
    POP     BX
    RET

;Display date
;   Return CH = CENTURY IN BCD
;           CL = Year in BCD
;           DH = Month in BCD
;           DL = Day in BCD
DisplayDate:
    PUSH    BX

```



```

PUSH    DX
PUSH    DX
PUSH    CX
MOV     AL,CH
CALL    PRINT_REG           ;Century (19/20).  Convert BCD to ASCII
POP     CX
MOV     AL,CL
CALL    PRINT_REG           ;Year.  Convert BCD to ASCII
MOV     CL,'/'
CALL    CO
POP     DX
MOV     AL,DH
CALL    PRINT_REG           ;Month.  Convert BCD to ASCII
MOV     CL,'/'
CALL    CO
POP     DX
MOV     AL,DL
CALL    PRINT_REG           ;Day.  Convert BCD to ASCII
POP     BX
RET

```

```

PRINT_REG:           ;Print BCD in [AL]
PUSH    AX
MOV     CL,4
RCR    AX,CL
AND    AL,0FH
ADD    AL,30H
MOV     CL,AL           ;Write high byte mins to CRT
CALL    CO
POP     AX
AND    AL,0FH
ADD    AL,30H
MOV     CL,AL
CALL    CO
RET

```

```

;Input Date
;   Return CH = CENTURY IN BCD
;   CL = Year in BCD
;   DH = Month in BCD
;   DL = Day in BCD

```

```

InputDate:
PUSH    BX
MOV     BX,Input_Year_Msg
CALL    PRINT_STRING
CALL    GET2BCD           ;Return with 2 BCD digits in AL
MOV     CL,AL
MOV     CH,20H           ;Assume 20 for century
PUSH    CX               ;Save
MOV     BX,Input_Month_Msg
CALL    PRINT_STRING
CALL    GET2BCD           ;Return with 2 BCD digits in AL
MOV     DH,AL
PUSH    DX               ;Save
MOV     BX,Input_Day_Msg

```

```

CALL PRINT_STRING
CALL GET2BCD           ;Return with 2 BCD digits in AL
POP DX                ;Get back
MOV DL,AL
POP CX                ;Get back
POP BX
RET

```

```

GET2BCD:              ;Return with 2 BCD digits in AL
CALL CICO
mov ah,0
CMP AL,ESC           ;Abort if ESC
JNZ BCD_OK
JMP INIT             ;Back to start of Monitor

```

```

BCD_OK: SUB AL,'@'
SHL AL,1
SHL AL,1
SHL AL,1
SHL AL,1
PUSH AX
CALL CICO
SUB AL,'@'
AND AL,0FH
MOV CL,AL
POP AX
OR AL,CL
RET

```

```

;----- Run diagnostic tests on the 8259A PIC. -----
;Configured below for the S100Computers PIC/RTC S-100 and MSDOS Support Boards
;We will fill out all 256 Interrupt vectors with a diagnostic routine to show
;what interrupt was triggered if not the 8259A bit 1 int.

```

```

TEST_8259:           ;"L" Main menu option
mov bx,PIC_SIGNON   ;Send a 8259A Test signon message
call PRINT_STRING

CALL SETUP_INT_TABLE ;Setup Int table (0-400H in RAM)

mov ax,cs           ;Note this is just a simplified sub-section of the SETUP_IBM_BIOS routine
mov ds,ax           ;DS is this ROM's CS
sub ax,ax
mov es,ax           ;ES: = 0H in RAM for STOW's below, DS: = CS:(here).
CLD                ;Default to direction up

mov di,3fcH         ;Int FFH seems to false trigger on 80386 board (not 8086 board!)
mov ax,dummy_return ;Have it point to Dummy return in this monitor
stosw              ;(ES: used for final location)

mov cx,8            ;Set all 8 hardware interrupts for 8259A (at I/O port address 20H)
mov si,vec_tbl_8259A ;Move the pointers in vec_tbl-8259A to low RAM starting at 20H
mov di,Start8259A_Ints ;Note DS:(=CS:) is source, ES: is destination

```

```

T2_8259:movsw
        inc    di                ;Skip over the segment pointer (already done above), to next vector offset
        inc    di
        loop   T2_8259

        mov    cx,16             ;Set all 16 MS-DOS software interrupts locations
        mov    si,vec_tbl_soft_ints
        mov    di,CRTINT        ;Start location in low RAM
T3_8259:movsw
        inc    di                ;Note DS: (=CS:) is source, ES: is destination
        inc    di                ;Skip over the segment pointer (already done above), to next vector offset
        loop   T3_8259          ;Note this sets up the VID_PARAMATER_TABLES & INITIAL FLOPPY PARMS TABLE as well

        mov    ax,keybuff       ;Keyboard buffer interrupt pointers
        mov    [es:bufhd],ax     ;Head of buffer = end of buffer
        mov    [es:buftrl],ax   ;buffer end
        mov    byte [es:chrcnt],0 ;Character count

        mov    al,11111111b     ;Block all INTs initially
        out    MASTER_PIC_PORT+1,al

        mov    al,MasterICW1    ;Initilize the 8259A PIC Controller
        out    MASTER_PIC_PORT,al
        mov    al,MasterICW2
        out    MASTER_PIC_PORT+1,al ;Ints starts at 20H in RAM
        mov    al,MasterICW4
        out    MASTER_PIC_PORT+1,al ;No slaves above, so 8259 does not expect ICW3

        mov    al,11111101b     ;Allow V1 (ONLY) on 8259A
        out    MASTER_PIC_PORT+1,al
        sti

T51_8259:
        MOV    BX,IN_CHAR_MSG   ;'Type one character'
        CALL  PRINT_STRING

T5_8259:
        MOV    AH,01H           ;Check if anything there
        int    16H              ;Get Keyboard status. Console Input Handler (Software Interrupt 16H)
        JZ    T5_8259

        MOV    AH,0H            ;Get actual character from buffer
        int    16H              ;Get Character. Console Input Handler (Software Interrupt 16H)

        CMP    AL,ESC           ;We are done if an ESC character
        JZ    T6_8259
        MOV    CL,AL
        CALL  CO                 ;Display character recieved
        sti
        JMP   T5_8259

T6_8259:
        mov    al,11111111b     ;Do not Allow V1 on 8259A again
        out    MASTER_PIC_PORT+1,al
        cli
        JMP   ToMonitor         ;Turn hardware int's back off

```

```
;----- INTERRUPT MODE JUMP TABLE -----
; Note some of the code below is for the 80286 (and 80386 CPU's).
```

```
RM_INT_JUMP_TABLE:                ;Unfortunately we have to do all 256 possible routines!
DB 6AH,0H                          ;Quirk with NASM forces 80H and above to a word so use DB's
jmp word RM_Zero_INT_Routine       ;0 Divide by 0
DB 6AH,1H                          ; In every case below we push a byte on the stack to identify the INT
jmp word RM_TRACE_INT_Routine     ;1 CPU Trace Interrupt
DB 6AH,2H
jmp word RM_NMI_INT_Routine        ;2 NMI default INT
DB 6AH,3H
jmp word RM_CC_INT_Routine         ;3 Software CC Interrupt
DB 6AH,4H
jmp word RM_Overflow_INT_Routine  ;4 Overflow INT
DB 6AH,5H
jmp word RM_Bounds_INT_Routine    ;5 Bounds Check, FAULT
DB 6AH,6H
jmp word RM_Opcode_INT_Routine    ;6 Invalid Opcode, FAULT
DB 6AH,7H
jmp word RM_Device_INT_Routine    ;7 Device not available, FAULT
DB 6AH,8H
jmp word RM_DFault_INT_Routine    ;8 Double fault Fault
DB 6AH,9H
jmp word RM_MathSeg_INT_Routine   ;9 Math Coprocessor Segment error
DB 6AH,0AH
jmp word RM_TSS_INT_Routine       ;10 Invalid TSS (+ Error Number)
DB 6AH,0BH
jmp word RM_Segment_INT_Routine   ;11 Segment Error (+ Error Number)
DB 6AH,0CH
jmp word RM_Stack_INT_Routine     ;12 Stack Exception (+ Error Number)
DB 6AH,0DH
jmp word RM_General_INT_Routine   ;13 General Protection (+ Error Number)
DB 6AH,0EH
jmp word RM_Page_INT_Routine      ;14 Page error, FAULT
DB 6AH,0FH
jmp word RM_Intel_INT_Routine     ;15 Intel reserved TRAP

DB 6AH,10H
jmp word RM_Coprocessor_INT_Routine ;16 Co-processor error, FAULT
DB 6AH,11H
jmp word RM_Default_INT_Routine
DB 6AH,12H
jmp word RM_Default_INT_Routine
DB 6AH,13H
jmp word RM_Default_INT_Routine
DB 6AH,14H
jmp word RM_Default_INT_Routine
DB 6AH,15H
jmp word RM_Default_INT_Routine
DB 6AH,16H
jmp word RM_Default_INT_Routine
DB 6AH,17H
jmp word RM_Default_INT_Routine
```

```
DB      6AH,18H
jmp     word RM_Default_INT_Routine
DB      6AH,19H
jmp     word RM_Default_INT_Routine
DB      6AH,1AH
jmp     word RM_Default_INT_Routine
DB      6AH,1BH
jmp     word RM_Default_INT_Routine
DB      6AH,1CH
jmp     word RM_Default_INT_Routine
DB      6AH,1DH
jmp     word RM_Default_INT_Routine
DB      6AH,1EH
jmp     word RM_Default_INT_Routine
DB      6AH,1FH
jmp     word RM_Default_INT_Routine

DB      6AH,20H
jmp     word RM_Default_INT_Routine
DB      6AH,21H
jmp     word RM_Default_INT_Routine
DB      6AH,22H
jmp     word RM_Default_INT_Routine
DB      6AH,23H
jmp     word RM_Default_INT_Routine
DB      6AH,24H
jmp     word RM_Default_INT_Routine
DB      6AH,25H
jmp     word RM_Default_INT_Routine
DB      6AH,26H
jmp     word RM_Default_INT_Routine
DB      6AH,27H
jmp     word RM_Default_INT_Routine
DB      6AH,28H
jmp     word RM_Default_INT_Routine
DB      6AH,29H
jmp     word RM_Default_INT_Routine
DB      6AH,2AH
jmp     word RM_Default_INT_Routine
DB      6AH,2BH
jmp     word RM_Default_INT_Routine
DB      6AH,2CH
jmp     word RM_Default_INT_Routine
DB      6AH,2DH
jmp     word RM_Default_INT_Routine
DB      6AH,2EH
jmp     word RM_Default_INT_Routine
DB      6AH,2FH
jmp     word RM_Default_INT_Routine

DB      6AH,30H
jmp     word RM_Default_INT_Routine
DB      6AH,31H
jmp     word RM_Default_INT_Routine
DB      6AH,32H
jmp     word RM_Default_INT_Routine
```

```
DB      6AH,33H
jmp     word RM_Default_INT_Routine
DB      6AH,34H
jmp     word RM_Default_INT_Routine
DB      6AH,35H
jmp     word RM_Default_INT_Routine
DB      6AH,36H
jmp     word RM_Default_INT_Routine
DB      6AH,37H
jmp     word RM_Default_INT_Routine
DB      6AH,38H
jmp     word RM_Default_INT_Routine
DB      6AH,39H
jmp     word RM_Default_INT_Routine
DB      6AH,3AH
jmp     word RM_Default_INT_Routine
DB      6AH,3BH
jmp     word RM_Default_INT_Routine
DB      6AH,3CH
jmp     word RM_Default_INT_Routine
DB      6AH,3DH
jmp     word RM_Default_INT_Routine
DB      6AH,3EH
jmp     word RM_Default_INT_Routine
DB      6AH,3FH
jmp     word RM_Default_INT_Routine

DB      6AH,40H
jmp     word RM_Default_INT_Routine
DB      6AH,41H
jmp     word RM_Default_INT_Routine
DB      6AH,42H
jmp     word RM_Default_INT_Routine
DB      6AH,43H
jmp     word RM_Default_INT_Routine
DB      6AH,44H
jmp     word RM_Default_INT_Routine
DB      6AH,45H
jmp     word RM_Default_INT_Routine
DB      6AH,46H
jmp     word RM_Default_INT_Routine
DB      6AH,47H
jmp     word RM_Default_INT_Routine
DB      6AH,48H
jmp     word RM_Default_INT_Routine
DB      6AH,49H
jmp     word RM_Default_INT_Routine
DB      6AH,4AH
jmp     word RM_Default_INT_Routine
DB      6AH,4BH
jmp     word RM_Default_INT_Routine
DB      6AH,4CH
jmp     word RM_Default_INT_Routine
DB      6AH,4DH
jmp     word RM_Default_INT_Routine
DB      6AH,4EH
```

```
jmp     word RM_Default_INT_Routine
DB     6AH,4FH
jmp     word RM_Default_INT_Routine

DB     6AH,50H
jmp     word RM_Default_INT_Routine
DB     6AH,51H
jmp     word RM_Default_INT_Routine
DB     6AH,52H
jmp     word RM_Default_INT_Routine
DB     6AH,53H
jmp     word RM_Default_INT_Routine
DB     6AH,54H
jmp     word RM_Default_INT_Routine
DB     6AH,55H
jmp     word RM_Default_INT_Routine
DB     6AH,56H
jmp     word RM_Default_INT_Routine
DB     6AH,57H
jmp     word RM_Default_INT_Routine
DB     6AH,58H
jmp     word RM_Default_INT_Routine
DB     6AH,59H
jmp     word RM_Default_INT_Routine
DB     6AH,5AH
jmp     word RM_Default_INT_Routine
DB     6AH,5BH
jmp     word RM_Default_INT_Routine
DB     6AH,5CH
jmp     word RM_Default_INT_Routine
DB     6AH,5DH
jmp     word RM_Default_INT_Routine
DB     6AH,5EH
jmp     word RM_Default_INT_Routine
DB     6AH,5FH
jmp     word RM_Default_INT_Routine

DB     6AH,60H
jmp     word RM_Default_INT_Routine
DB     6AH,61H
jmp     word RM_Default_INT_Routine
DB     6AH,62H
jmp     word RM_Default_INT_Routine
DB     6AH,63H
jmp     word RM_Default_INT_Routine
DB     6AH,64H
jmp     word RM_Default_INT_Routine
DB     6AH,65H
jmp     word RM_Default_INT_Routine
DB     6AH,66H
jmp     word RM_Default_INT_Routine
DB     6AH,67H
jmp     word RM_Default_INT_Routine
DB     6AH,68H
jmp     word RM_Default_INT_Routine
DB     6AH,69H
```

```

jmp     word RM_Default_INT_Routine
DB     6AH,6AH
jmp     word RM_Default_INT_Routine
DB     6AH,6BH
jmp     word RM_Default_INT_Routine
DB     6AH,6CH
jmp     word RM_Default_INT_Routine
DB     6AH,6DH
jmp     word RM_Default_INT_Routine
DB     6AH,6EH
jmp     word RM_Default_INT_Routine
DB     6AH,6FH
jmp     word RM_Default_INT_Routine

DB     6AH,70H
jmp     word RM_Default_INT_Routine
DB     6AH,71H
jmp     word RM_Default_INT_Routine
DB     6AH,72H
jmp     word RM_Default_INT_Routine
DB     6AH,73H
jmp     word RM_Default_INT_Routine
DB     6AH,74H
jmp     word RM_Default_INT_Routine
DB     6AH,75H
jmp     word RM_Default_INT_Routine
DB     6AH,76H
jmp     word RM_Default_INT_Routine
DB     6AH,77H
jmp     word RM_Default_INT_Routine
DB     6AH,78H
jmp     word RM_Default_INT_Routine
DB     6AH,79H
jmp     word RM_Default_INT_Routine
DB     6AH,7AH
jmp     word RM_Default_INT_Routine
DB     6AH,7BH
jmp     word RM_Default_INT_Routine
DB     6AH,7CH
jmp     word RM_Default_INT_Routine
DB     6AH,7DH
jmp     word RM_Default_INT_Routine
DB     6AH,7EH
jmp     word RM_Default_INT_Routine
DB     6AH,7FH
jmp     word RM_Default_INT_Routine

DB     6AH,80H                ;Quirk with NASM forces 80H and above to a word!
jmp     word RM_Default_INT_Routine ;So use DB's
DB     6AH,81H
jmp     word RM_Default_INT_Routine
DB     6AH,82H
jmp     word RM_Default_INT_Routine
DB     6AH,83H
jmp     word RM_Default_INT_Routine
DB     6AH,84H

```



```
jmp    word RM_Default_INT_Routine
DB    6AH,85H
jmp    word RM_Default_INT_Routine
DB    6AH,86H
jmp    word RM_Default_INT_Routine
DB    6AH,87H
jmp    word RM_Default_INT_Routine
DB    6AH,88H
jmp    word RM_Default_INT_Routine
DB    6AH,89H
jmp    word RM_Default_INT_Routine
DB    6AH,8AH
jmp    word RM_Default_INT_Routine
DB    6AH,8BH
jmp    word RM_Default_INT_Routine
DB    6AH,8CH
jmp    word RM_Default_INT_Routine
DB    6AH,8DH
jmp    word RM_Default_INT_Routine
DB    6AH,8EH
jmp    word RM_Default_INT_Routine
DB    6AH,8FH
jmp    word RM_Default_INT_Routine

DB    6AH,90H
jmp    word RM_Default_INT_Routine
DB    6AH,91H
jmp    word RM_Default_INT_Routine
DB    6AH,92H
jmp    word RM_Default_INT_Routine
DB    6AH,93H
jmp    word RM_Default_INT_Routine
DB    6AH,94H
jmp    word RM_Default_INT_Routine
DB    6AH,95H
jmp    word RM_Default_INT_Routine
DB    6AH,96H
jmp    word RM_Default_INT_Routine
DB    6AH,97H
jmp    word RM_Default_INT_Routine
DB    6AH,98H
jmp    word RM_Default_INT_Routine
DB    6AH,99H
jmp    word RM_Default_INT_Routine
DB    6AH,9AH
jmp    word RM_Default_INT_Routine
DB    6AH,9BH
jmp    word RM_Default_INT_Routine
DB    6AH,9CH
jmp    word RM_Default_INT_Routine
DB    6AH,9DH
jmp    word RM_Default_INT_Routine
DB    6AH,9EH
jmp    word RM_Default_INT_Routine
DB    6AH,9FH
jmp    word RM_Default_INT_Routine
```

```
DB      6AH,0A0H
jmp     word RM_Default_INT_Routine
DB      6AH,0A1H
jmp     word RM_Default_INT_Routine
DB      6AH,0A2H
jmp     word RM_Default_INT_Routine
DB      6AH,0A3H
jmp     word RM_Default_INT_Routine
DB      6AH,0A4H
jmp     word RM_Default_INT_Routine
DB      6AH,0A5H
jmp     word RM_Default_INT_Routine
DB      6AH,0A6H
jmp     word RM_Default_INT_Routine
DB      6AH,0A7H
jmp     word RM_Default_INT_Routine
DB      6AH,0A8H
jmp     word RM_Default_INT_Routine
DB      6AH,0A9H
jmp     word RM_Default_INT_Routine
DB      6AH,0AAH
jmp     word RM_Default_INT_Routine
DB      6AH,0ABH
jmp     word RM_Default_INT_Routine
DB      6AH,0ACH
jmp     word RM_Default_INT_Routine
DB      6AH,0ADH
jmp     word RM_Default_INT_Routine
DB      6AH,0AEH
jmp     word RM_Default_INT_Routine
DB      6AH,0AFH
jmp     word RM_Default_INT_Routine

DB      6AH,0B0H
jmp     word RM_Default_INT_Routine
DB      6AH,0B1H
jmp     word RM_Default_INT_Routine
DB      6AH,0B2H
jmp     word RM_Default_INT_Routine
DB      6AH,0B3H
jmp     word RM_Default_INT_Routine
DB      6AH,0B4H
jmp     word RM_Default_INT_Routine
DB      6AH,0B5H
jmp     word RM_Default_INT_Routine
DB      6AH,0B6H
jmp     word RM_Default_INT_Routine
DB      6AH,0B7H
jmp     word RM_Default_INT_Routine
DB      6AH,0B8H
jmp     word RM_Default_INT_Routine
DB      6AH,0B9H
jmp     word RM_Default_INT_Routine
DB      6AH,0BAH
jmp     word RM_Default_INT_Routine
```

```
DB      6AH,0BBH
jmp     word RM_Default_INT_Routine
DB      6AH,0BCH
jmp     word RM_Default_INT_Routine
DB      6AH,0BDH
jmp     word RM_Default_INT_Routine
DB      6AH,0BEH
jmp     word RM_Default_INT_Routine
DB      6AH,0BFH
jmp     word RM_Default_INT_Routine

DB      6AH,0C0H
jmp     word RM_Default_INT_Routine
DB      6AH,0C1H
jmp     word RM_Default_INT_Routine
DB      6AH,0C2H
jmp     word RM_Default_INT_Routine
DB      6AH,0C3H
jmp     word RM_Default_INT_Routine
DB      6AH,0C4H
jmp     word RM_Default_INT_Routine
DB      6AH,0C5H
jmp     word RM_Default_INT_Routine
DB      6AH,0C6H
jmp     word RM_Default_INT_Routine
DB      6AH,0C7H
jmp     word RM_Default_INT_Routine
DB      6AH,0C8H
jmp     word RM_Default_INT_Routine
DB      6AH,0C9H
jmp     word RM_Default_INT_Routine
DB      6AH,0CAH
jmp     word RM_Default_INT_Routine
DB      6AH,0CBH
jmp     word RM_Default_INT_Routine
DB      6AH,0CCH
jmp     word RM_Default_INT_Routine
DB      6AH,0CDH
jmp     word RM_Default_INT_Routine
DB      6AH,0CEH
jmp     word RM_Default_INT_Routine
DB      6AH,0CFH
jmp     word RM_Default_INT_Routine

DB      6AH,0D0H
jmp     word RM_Default_INT_Routine
DB      6AH,0D1H
jmp     word RM_Default_INT_Routine
DB      6AH,0D2H
jmp     word RM_Default_INT_Routine
DB      6AH,0D3H
jmp     word RM_Default_INT_Routine
DB      6AH,0D4H
jmp     word RM_Default_INT_Routine
DB      6AH,0D5H
jmp     word RM_Default_INT_Routine
```

```
DB      6AH,0D6H
jmp     word RM_Default_INT_Routine
DB      6AH,0D7H
jmp     word RM_Default_INT_Routine
DB      6AH,0D8H
jmp     word RM_Default_INT_Routine
DB      6AH,0D9H
jmp     word RM_Default_INT_Routine
DB      6AH,0DAH
jmp     word RM_Default_INT_Routine
DB      6AH,0DBH
jmp     word RM_Default_INT_Routine
DB      6AH,0DCH
jmp     word RM_Default_INT_Routine
DB      6AH,0DDH
jmp     word RM_Default_INT_Routine
DB      6AH,0DEH
jmp     word RM_Default_INT_Routine
DB      6AH,0DFH
jmp     word RM_Default_INT_Routine

DB      6AH,0E0H
jmp     word RM_Default_INT_Routine
DB      6AH,0E1H
jmp     word RM_Default_INT_Routine
DB      6AH,0E2H
jmp     word RM_Default_INT_Routine
DB      6AH,0E3H
jmp     word RM_Default_INT_Routine
DB      6AH,0E4H
jmp     word RM_Default_INT_Routine
DB      6AH,0E5H
jmp     word RM_Default_INT_Routine
DB      6AH,0E6H
jmp     word RM_Default_INT_Routine
DB      6AH,0E7H
jmp     word RM_Default_INT_Routine
DB      6AH,0E8H
jmp     word RM_Default_INT_Routine
DB      6AH,0E9H
jmp     word RM_Default_INT_Routine
DB      6AH,0EAH
jmp     word RM_Default_INT_Routine
DB      6AH,0EBH
jmp     word RM_Default_INT_Routine
DB      6AH,0ECH
jmp     word RM_Default_INT_Routine
DB      6AH,0EDH
jmp     word RM_Default_INT_Routine
DB      6AH,0EEH
jmp     word RM_Default_INT_Routine
DB      6AH,0EFH
jmp     word RM_Default_INT_Routine

DB      6AH,0F0H
jmp     word word RM_Default_INT_Routine
```

```

DB      6AH,0F1H
jmp     word RM_Default_INT_Routine
DB      6AH,0F2H
jmp     word RM_Default_INT_Routine
DB      6AH,0F3H
jmp     word RM_Default_INT_Routine
DB      6AH,0F4H
jmp     word RM_Default_INT_Routine
DB      6AH,0F5H
jmp     word RM_Default_INT_Routine
DB      6AH,0F6H
jmp     word RM_Default_INT_Routine
DB      6AH,0F7H
jmp     word RM_Default_INT_Routine
DB      6AH,0F8H
jmp     word RM_Default_INT_Routine
DB      6AH,0F9H
jmp     word RM_Default_INT_Routine
DB      6AH,0FAH
jmp     word RM_Default_INT_Routine
DB      6AH,0FBH
jmp     word RM_Default_INT_Routine
DB      6AH,0FCH
jmp     word RM_Default_INT_Routine
DB      6AH,0FDH
jmp     word RM_Default_INT_Routine
DB      6AH,0FEH
jmp     word RM_Default_INT_Routine
IRET

;For 0FFH just return. (Noise on INTA line?)

RM_Default_INT_Routine:
;Unless told otherwise, all the above Ints will come here.
PUSH   AX ;Save only what will be changed. (Note. IRET has already saves the flags)
PUSH   BX
PUSH   BP
MOV    BP,SP
MOV    BX,UNASSIGNED_1_INT_MSG ;"Un-assigned Int #"
CALL  PRINT_STRING ;Note PRINT_STRING always uses the CS: override for the BX pointer
MOV    AX,[BP+6] ;Get INT# send by the above INT Jump
CALL  AL_HEXOUT
MOV    BX,H_MSG_CRLF
POP    BP
INT_INFO_DONE: ;General INT Fault return
CALL  PRINT_STRING
POP    BX
POP    AX
ADD   SP,2 ;Balance up stack,return
IRET ;Remember the byte saved on the stack is extended to a word by the CPU

RM_Zero_INT_Routine: ;Int #0, Divide by Zero, (Return address to error, so ABORT)
PUSH   AX
PUSH   BX ;Note BP is not saved
MOV    BX,DIVIDE_MSG ;"Divide by 0 INT #0"
INT_HALT:
CALL  PRINT_STRING

```

```

MOV     BX,CPU_HALTED_MSG           ;The CPU is Halted +CRLF
CALL   PRINT_STRING
POP     BX
POP     AX                           ;In case further INT's
ADD     SP,2                          ;Balance up stack,return
HLT                                           ;Halt for all FAULTS (does not matter Stack is messed up, we will reset CPU)

RM_NMI_INT_Routine:                    ;NMI Trap (INT#2)
PUSH   AX
PUSH   BX
MOV    BX,NMI_FAULT_MSG
JMP   INT_INFO_DONE

RM_Overflow_INT_Routine:               ;Int #4, Overflow TRAP
PUSH   AX
PUSH   BX
MOV    BX,OVERFLOW_ERR_MSG
JMP   INT_INFO_DONE

RM_Bounds_INT_Routine:                ;Int #5, Bounds Check, (Return address to error, so ABORT)
PUSH   AX
PUSH   BX
MOV    BX,BOUNDS_ERR_MSG
JMP   INT_HALT

RM_Opcode_INT_Routine:                ;Int #6, Invalid Opcode, (Return address to error, so ABORT)
PUSH   AX
PUSH   BX
MOV    BX,INVALID_ERR_MSG
JMP   INT_HALT

RM_Device_INT_Routine:                ;Int #7, Math Coprocessor not available, (Return address to error, so ABORT)
PUSH   AX
PUSH   BX
MOV    BX,DEVICE_ERR_MSG
JMP   INT_HALT

RM_DFault_INT_Routine:                ;Int #8, Double, (Return address to error, so ABORT)
PUSH   AX
PUSH   BX
MOV    BX,DOUBLE_ERR_MSG
JMP   INT_HALT

RM_MathSeg_INT_Routine:                ;Int #9, No Coprocessor, (ABORT anyway)
PUSH   AX
PUSH   BX
MOV    BX,COPROCESSOR_ERR_MSG
JMP   INT_HALT

RM_TSS_INT_Routine:                   ;Int #10, Invalid TSS
PUSH   AX
PUSH   BX
MOV    BX,INVALID_TSS_ERR_MSG
JMP   INT_HALT

RM_Segment_INT_Routine:                ;Int #11, Segment not present

```

```

PUSH  AX
PUSH  BX
MOV   BX, SEGMENT_ERR_MSG
JMP   INT_HALT

```

```

RM_Stack_INT_Routine:                ;Int #12, Stack Exception
PUSH  AX
PUSH  BX
MOV   BX, STACK_ERR_MSG
JMP   INT_HALT

```

```

RM_General_INT_Routine:              ;Int #13, General protection error (+ ERROR #)
PUSH  AX
PUSH  BX
MOV   BX, GENERAL_ERR_MSG
JMP   INT_HALT

```

```

RM_Page_INT_Routine:                ;Int #14, Page fault
PUSH  AX
PUSH  BX
MOV   BX, PAGE_ERR_MSG
JMP   INT_INFO_DONE

```

```

RM_Intel_INT_Routine:               ;Int #15, Intel reserved Int
PUSH  AX
PUSH  BX
MOV   BX, RESERVED_ERR_MSG
JMP   INT_INFO_DONE

```

```

RM_Coprocessor_INT_Routine:        ;Int #16 Cprocessor Error
PUSH  AX
PUSH  BX
MOV   BX, COPROCESSOR_ERR_MSG
JMP   INT_HALT

```

```

RM_CC_INT_Routine:                 ;INT #3, Software CC Interrupt
CALL  REGISTERS                    ;Display Real Mode Registers
PUSH  AX
PUSH  BX
PUSH  CX
PUSH  BP
MOV   BP, SP
MOV   BX, IP_ADDRESS_MSG          ;IP=
CALL  PRINT_STRING
MOV   AX, [BP+12]                 ;Get return IP address on stack, SEGMENT
CALL  AX_HEXOUT
MOV   CL, ':'
CALL  CO
MOV   AX, [BP+10]                 ;Get return IP address on stack, OFFSET
CALL  AX_HEXOUT
MOV   BX, H_MSG_CRLF
CALL  PRINT_STRING
POP   BP

```

```

    POP     CX
    POP     BX
    POP     AX
    ADD     SP,2           ;Balance up stack,return
    IRET           ;Remember the byte saved on the stack is extended to a word by the CPU

```

```

RM_TRACE_INT_Routine:           ;INT#1, trace mode
    CALL    REGISTERS           ;Display Real Mode Registers
    PUSH    AX
    PUSH    BX
    PUSH    CX
    PUSH    BP
    MOV     BP,SP
    MOV     BX,IP_ADDRESS_MSG   ;IP=
    CALL    PRINT_STRING
    MOV     AX,[BP+12]           ;Get return IP address on stack, SEGMENT
    CALL    AX_HEXOUT
    MOV     CL,':'
    CALL    CO
    MOV     AX,[BP+10]           ;Get return IP address on stack, OFFSET
    CALL    AX_HEXOUT
    MOV     BX,H_MSG_CRLF
    CALL    PRINT_STRING
    POP     BP
    POP     CX
    POP     BX
    POP     AX
    ADD     SP,2           ;Balance up stack,return
    IRET

```

```

TRACE_MODE_ON:                 ;Turn on CPU trace mode
    PUSH    AX
    PUSHF           ;EFLAGS to stack
    POP     AX
    OR     AX,0100H   ;Turn ON trace Bit
    PUSH    AX
    POPF           ;Move back into EFLAGS
    POP     AX
    RET

```

```

TRACE_MODE_OFF:                ;Turn off CPU trace mode
    PUSH    AX
    PUSHF           ;EFLAGS to stack
    POP     AX
    AND    AX,0FEFFH  ;Turn OFF trace Bit
    PUSH    AX
    POPF           ;Move back into EFLAGS
    POP     AX
    RET

```

```

;----- Run diagnostic software Interrupt tests -----

```

```

;>>>>>>>> Make sure the Timer interrupt (VI0) is not active. <<<<<<<<<<<<

```



```

; >>>>>>>>> Remove jumper if necessary on board          <<<<<<<<<<<<
;
; We will fill out all 256 Interrupt vectors with a diagnostic routine to show
; what interrupt was triggered. A menu with a few samples is provided.
;

SOFT_INTS:
    mov     bx,INT_SIGNON          ;Send a signon message
    call   PRINT_STRING
    CLD                               ;Default to direction up
    CLI                               ;No hardware Ints

    mov     ax,cs                  ;Note this is just a simplified sub-section of the SETUP_IBM_BIOS routine
    mov     ds,ax                  ;DS is this ROM's CS

    CALL   SETUP_INT_TABLE          ;Fill all RM 8086 interrupts initially with a default error trapping pointer

    CALL   GET2DIGITS              ;Input value to AL

    CMP     AH,ESC                 ;Was an escape requested
    JZ      INTS_DONE

    CMP     AL,0
    JZ      DIVIDE_CHECK
    CMP     AL,4
    JZ      OVERFLOW_CHECK
    CMP     AL,6
    JZ      INVALID_CHECK
    CMP     AL,0DH
    JZ      BAD_GP_FAULT_CHECK
    CMP     AL,40H
    JZ      BAD_SOFT_40_CHECK
    CMP     AL,0FOH
    JZ      BAD_SOFT_F0_CHECK
    JMP     NOT_FAULTS

DIVIDE_CHECK:
    CALL   CRLF
    MOV     AX,0FFFFH
    MOV     BX,0
    DIV     BX                      ;Try divide by 0
    CALL   CRLF
    JMP     SOFT_INTS              ;Normally will not get here

OVERFLOW_CHECK:
    CALL   CRLF
    INT     4
    CALL   CRLF
    JMP     SOFT_INTS

INVALID_CHECK:
    CALL   CRLF
    INT     6
    CALL   CRLF
    JMP     SOFT_INTS

BAD_GP_FAULT_CHECK:
    CALL   CRLF
    INT     0DH

```

```

        CALL    CRLF
        JMP     SOFT_INTS
BAD_SOFT_40_CHECK:
        CALL    CRLF
        INT     40H
        CALL    CRLF
        JMP     SOFT_INTS
BAD_SOFT_F0_CHECK:
        CALL    CRLF
        INT     0F0H
        CALL    CRLF
        JMP     SOFT_INTS

NOT_FAULTS:
        CALL    CRLF
        MOV     BX,INT_RANGE_MSG
        CALL    PRINT_STRING
        JMP     SOFT_INTS
INTS_DONE:
        RET

```

;----- Routine to Setup the RM Interrupt jump table in RAM (0-400H) -----

```

SETUP_INT_TABLE:                                ;Note we assume INTS are turned off
        PUSHF
        PUSH   AX
        PUSH   BX
        PUSH   CX
        PUSH   DS
        PUSH   ES
        PUSH   SI
        PUSH   DI

        mov    ax,cs                            ;Note this is just a simplified sub-section of the SETUP_IBM_BIOS routine
        mov    ds,ax                            ;DS is this ROM's CS
        sub    ax,ax
        mov    es,ax                            ;ES: = 0H in RAM for STOW's below, DS: = CS:(here).
        CLD                                     ;Default to direction up
        CLI                                     ;Just in case

        mov    cx,256                           ;Fill all 8086 interrupts initially with a default error trapping pointer
        sub    di,di                            ;Clear destination register start at RAM 0H
        sub    bx,bx                            ;Start at location 0
SETI1:  mov    ax,bx
        add    AX,RM_INT_JUMP_TABLE            ;Set to illustrate non assigned int
        stosw                                  ;Remember ES: is used for final location with STOSW
        mov    ax,cs                            ;Interrupt segment pointer to here (always the same).
        stosw                                  ;<-- Note the default segment will be this CS for all ints below
        add    bx,5                             ;Point to next int routine below in the 256 list
        loop  SETI1

        POP    DI
        POP    SI
        POP    ES
        POP    DS

```

```

POP    CX
POP    BX
POP    AX
POPF
RET

```

```

;----- LOAD XMODEM FILE via CONSOLE-IO PORT -----

```

```

XMODEM_LOAD:
mov    bx,MODEM_SIGNON          ;Send Modem signon message
call   PRINT_STRING
CLD                                       ;Default to direction up
CLI                                       ;No hardware Ints

mov    ax,cs                     ;Just in case different
mov    ds,ax                     ;DS is this ROM's CS

PUSH   BP
MOV    BP,SP                    ;Will store certain variables well below stack
MOV    byte [BP-RECVD_SECT_NO],0
MOV    byte [BP-SECTNO],0
MOV    byte [BP-ERRCT],0

CALL   INIT_SCC                 ;MASTER RESET THE ZILOG SCC
                                           ;GOBBLE UP GARBAGE CHARS FROM THE LINE
mov    bx,RAM_DESTINATION       ;Ask for destination
call   PRINT_STRING
CALL   GET5DIGITS               ;Get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
                                           ;If 5 digits, then the first digit is put in ES (highest nibble)

CMP    AL,ESC
JZ     MODEM_DONE

CALL   CRLF

MOV    CH,MODEM_RTS_DELAY       ;TIMEOUT DELAY
CALL   RECV

MOV    BX,START_POINTER         ;"Will load data starting at RAM location "
CALL   PRINT_STRING
call   SHOW_ADDRESS_ES_NOSPACE   ;Show address
MOV    BX,H_MSG_CRLF
CALL   PRINT_STRING
CALL   CRLF

MOV    BX,DOWNLOAD_MSG          ;Speak "Downloading file"
CALL   SPEAK_STRING

RECV_LOOP:
                                           ;<<< MAIN RECIEVE LOOP
XOR    AX,AX                    ;GET 0
MOV    [BP-ERRCT],AL           ;Start error count with 0
RECV_HDR:
PUSH   BX
MOV    BX,RMSG                 ;Reading sector message
CALL   PRINT_STRING

```

```

MOV     AL, [BP-SECTNO]
INC     AL
CALL    AL_HEXOUT
MOV     BX, RAM_MSG           ;"H.  IF OK, will write to RAM location"
CALL    PRINT_STRING
call    SHOW_ADDRESS_ES_NOSPACE ;Show address
MOV     BX, H_MSG
CALL    PRINT_STRING
POP     BX

MOV     CH, (20*MODEM_RTS_DELAY) ;20 SEC TIMEOUT
CALL    RECV
JNB     RHNTO                 ;WE ARE OK, NO TIMEOUT

RECV_HDR_TIMEOUT:
MOV     BX, TOUTM             ;PRINT TIMEOUT MESSAGE
CALL    PRINT_STRING
MOV     AL, [BP-ERRCT]
CALL    AL_HEXOUT            ;FALL INTO CR/LF
CALL    CRLF

RECV_SECT_ERR:                ;PURGE THE LINE OF INPUT CHARS
MOV     CH, MODEM_RTS_DELAY   ;~1 SEC W/NO CHARS
CALL    RECV
JNB     RECV_SECT_ERR         ;LOOP UNTIL SENDER DONE
MOV     AL, NAK
CALL    SEND                  ;SEND NAK
MOV     AL, [BP-ERRCT]        ;Inc Error Count (ERRCT)
INC     AL
MOV     [BP-ERRCT], AL
CMP     AL, MODEM_ERR_LIMIT   ;Currently set for 5 trys
JB      RECV_HDR              ;Go try again
CALL    CHECK_FOR_QUIT
JZ      RECV_HDR              ;Try again
MOV     BX, BAD_HEADER        ;'Unable to get a valid file header!'
CALL    PRINT_STRING
JMP     MODEM_DONE            ;Abort back to Monitor start

RHNTO:  CMP     AL, SOH         ;GOT CHAR - MUST BE SOH
JZ      GOT_SOH
OR      AL, AL                 ;00 FROM SPEED CHECK?
JNZ     L_2
JMP     RECV_HDR

L_2:    CMP     AL, EOT
JNZ     L_3
JMP     GOT_EOT

L_3:    CALL    AL_HEXOUT
MOV     BX, ERRSOH            ;'H Received',CR,LF,'Did not get Correct SOH'
CALL    PRINT_STRING
JMP     RECV_SECT_ERR

GOT_SOH:                ;We got correct SOH so now get data
MOV     CH, MODEM_RTS_DELAY
CALL    RECV
JB      RECV_HDR_TIMEOUT
MOV     DH, AL                 ;D=BLK #

```

```

MOV     CH,MODEM_RTS_DELAY
CALL   RECV                ;GET CMA'D SECT #
JB     RECV_HDR_TIMEOUT
NOT    AL
CMP    AL,DH                ;GOOD SECTOR #?
JZ     RECV_SECTOR

MOV    BX,MODEM_ERR2        ;'+BAD SECTOR # IN HDR'
CALL   PRINT_STRING
JMP    RECV_SECT_ERR

RECV_SECTOR:                ;Now get 128 Bytes
MOV    AL,DH                ;GET SECTOR #
MOV    [BP-RECVD_SECT_NO],AL
MOV    CL,0                 ;INIT CKSUM
MOV    BL,80H               ;128 Byte sectors always

RECV_CHAR:
MOV    CH,MODEM_RTS_DELAY   ;~1 SEC TIMEOUT
CALL   RECV                ;GET CHAR
JNB    MODL_4
JMP    RECV_HDR_TIMEOUT

MODL_4: MOV    [ES:DI],AL     ;<<< STORE CHAR >>>
INC    DI
DEC    BL                   ;128 Bytes done yet?
JNZ    RECV_CHAR

                                ;NEXT VERIFY CHECKSUM
MOV    DH,CL                ;SAVE CHECKSUM
MOV    CH,MODEM_RTS_DELAY   ;TIMEOUT
CALL   RECV                ;GET CHECKSUM
JNB    MODL_5
JMP    RECV_HDR_TIMEOUT

MODL_5:
CMP    AL,DH                ;CHECK
JNZ    RECV_CKSUM_ERR
MOV    AL,[BP-RECVD_SECT_NO] ;GOT A SECTOR, WRITE IF = 1+PREV SECTOR
MOV    CH,AL                ;SAVE IT
MOV    AL,[BP-SECTNO]       ;GET PREV
INC    AL                   ;CALC NEXT SECTOR #
CMP    AL,CH                ;MATCH?
JNZ    DO_ACK

MOV    AL,[BP-RECVD_SECT_NO] ;Indicate we transferred a sector
MOV    [BP-SECTNO],AL       ;UPDATE SECTOR #
DO_ACK: MOV    AL,ACK
CALL   SEND
JMP    RECV_LOOP

RECV_CKSUM_ERR:
MOV    BX,MODEM_ERR3
CALL   PRINT_STRING
JMP    RECV_SECT_ERR

GOT_EOT:
MOV    AL,ACK                ;DONE - CLOSE UP SHOP
                                ;ACK THE EOT

```

```

        CALL SEND
        CALL CRLF
        MOV BX, FINISH_MSG          ;Speak downloading finished
        CALL SPEAK_STRING
        MOV BX, TRANS_DONE
EXIT2:  CALL PRINT_STRING
MODEM_DONE:
        XOR AL, AL
        POP BP                      ;RESTORE IT
        RET

EXIT1:  MOV BX, ABORT_MSG
        JMP EXIT2

INIT_SCC:
;INITITIALIZE THE ZILOG SCC SERIAL B PORT
        MOV BX, SSC_MSG_INIT          ;Say Initalizing ACIA/SCC
        CALL PRINT_STRING
        MOV CH, 14                    ;Byte count (14), for below
        MOV BX, SCCINIT              ;Table of Zilog SCC Initalization values
SCC_1:  MOV AL, [CS:BX]
        OUT MODEM_CTL_PORT, AL        ;Program the SCC Channel B (A1,A3 or 10,12H) for 19K Baud
        INC BX
        DEC CH
        JNZ SCC_1
        MOV BX, SPEED_MSG            ;Speak, baud rate set
        CALL SPEAK_STRING
        RET

;---- SERIAL PORT GET CHARACTER ROUTINE ----
RECV:  PUSH DX                      ;SAVE
        MOV AL, 5H                    ;Lower RTS line
        OUT MODEM_CTL_PORT, AL        ;Sel Reg 5
        MOV AL, 11101010B            ;EAH
        OUT MODEM_CTL_PORT, AL
        NOP
        NOP
MSEC:  MOV DX, 8000H                  ;~0.1 SEC DCR COUNT
MWTI:  IN AL, MODEM_CTL_PORT
        AND AL, MODEM_RECV_MASK
        CMP AL, RECV_READY
        JZ MCHAR                      ;GOT CHAR
        DEC DX                          ;COUNT DOWN
        JNZ MWTI                        ;FOR TIMEOUT
        DEC CH                          ;DCR # OF SECONDS
        JNZ MSEC                        ;MODEM TIMED OUT RECEIVING
        POP DX                          ;RESTORE DX
        STC                              ;CARRY SHOWS TIMEOUT
        RET

MCHAR: IN AL, MODEM_DATA_PORT
        POP DX                          ;RESTORE DE
        LAHF                             ;CALC CHECKSUM
        XCHG AL, AH
        PUSH AX
        XCHG AL, AH

```

```

        ADD     AL,CL
        MOV     CL,AL
        POP     AX
        XCHG   AL,AH
        OR      AL,AL                ;TURN OFF CARRY TO SHOW NO TIMEOUT
        RET

SEND:   LAHF
        XCHG   AL,AH
        PUSH   AX
        XCHG   AL,AH
        ADD     AL,CL                ;CALC CKSUM
        MOV     CL,AL
SENDW:  IN     AL,MODEM_CTL_PORT     ;Don't worry PC is always fast enough
        AND    AL,MODEM_SEND_MASK
        CMP    AL,SEND_READY
        JNZ    SENDW
        POP    AX                    ;GET CHAR
        XCHG   AL,AH
        SAHF
        OUT    MODEM_DATA_PORT,AL    ;Raise RTS line to prevent the next character arriving
        MOV    AL,5H                 ;while the CPU is busy processing info
        OUT    MODEM_CTL_PORT,AL     ;Sel Reg 5
        MOV    AL,11101000B         ;E8H
        OUT    MODEM_CTL_PORT,AL
        RET

CHECK_FOR_QUIT:
                                ;MULTIPLE ERRORS, ASK IF TIME TO QUIT
        XOR    AL,AL                ;GET 0
        MOV    [BP-ERRCT],AL        ;RESET ERROR COUNT
        MOV    BX,QUITM
        CALL   PRINT_STRING
        CALL   CICO
        PUSH   AX
        CALL   CRLF
        POP    AX
        CMP    AL,'R'
        JZ     DONE_CHECK
        CMP    AL,'Q'
        JZ     NOT_DONE_CHECK
        CMP    AL,ESC
        JZ     NOT_DONE_CHECK
        JMP    CHECK_FOR_QUIT

NOT_DONE_CHECK:
        OR     AL,AL                ;TURN OFF ZERO FLAG

DONE_CHECK:
        RET

```

```

;*****

```

```

;
; Module to Test and diagnose the www.S100Computers.com IDE Board
;
; Instead of using the CPM86 style DS:[BX] format, we will use SS:[BP] so the the buffers
; can reside at the top segment of available RAM. Normally this will be F000:7000H but the monitor
; will not assume the full 1MG address space is available.
; See the monitor initialization section where BP is setup.
;
;
;*****
MYIDE:  MOV     BP,DISPLAY_FLAG           ;Do we have detail sector data display flag on or off
        MOV     AL,OFFH                 ;Set default to detailed sector display
        MOV     [BP],AL

        MOV     BX,IDE_HARDWARE         ;"Initilizing IDE Drive hardware"
        CALL    PRINT_STRING

        CALL    CLEAR$ID$BUFFER        ;Clear ID Buffer

        CALL    SET_DRIVE_A            ;Select the first Drive/CF card
        CALL    IDEinit                ;Initialize the board and drive #0. If there is no drive abort
        JZ     INIT1_OK

        MOV     BX,INIT_1_ERROR
        CALL    PRINT_STRING
        JMP     INIT

INIT1_OK:
        CALL    CLEAR$ID$BUFFER        ;Clear ID Buffer

        CALL    SET_DRIVE_B            ;Select the second Drive/CF card (Do not mess with CPM Drive 0)
        CALL    IDEinit                ;Initialize drive #1. If there is no drive abort
        JZ     INIT2_OK

        CALL    CLEAR$ID$BUFFER        ;Clear ID Buffer

        MOV     BX,INIT_2_ERROR
        CALL    PRINT_STRING           ;Warn second IDE drive did not initilize
        ;Since first drive was OK we will still go to INIT2_OK

INIT2_OK:
        CALL    SET_DRIVE_A            ;Back to first drive/CF Card

        CALL    DRIVE_ID               ;Get the drive 0 ID info. If there is no drive just abort
        JZ     INIT3_OK

        MOV     BX,BAD_DRIVE           ;"Error obtaining the Drive ID"
        CALL    PRINT_STRING
        JMP     INIT

INIT3_OK:
        MOV     BP,(IDE_Buffer+12)     ;Check we have a valid IDE drive
        MOV     AX,[BP]                ;Note always SS: = CS:
        OR     AX,AX                   ;If there are zero sectors then something wrong
        JNZ    INIT4_OK

```



```

        MOV     BX,BAD_DRIVE           ;"Error obtaining first Drive ID"
        CALL   PRINT_STRING
        JMP    INIT

INIT4_OK:
        MOV     BP,RAM_DMA             ;Set default position will be first sector block
        MOV     word[BP],IDE_Buffer    ;DMA always initially to IDE_Buffer,

        MOV     BP,RAM_SEC
        MOV     word[BP],0H            ;Sec 0
        MOV     BP,RAM_TRK
        MOV     word[BP],0H            ;Track 0

        CALL   IDEinit                ;For some reason this need to be here after getting the drive ID.
                                           ;otherwise sector #'s are off by one! (Probably because on non-LBA reads)
        CALL   WR_LBA                 ;Update LBA on "1st" drive

;----- MAIN IDE DRIVE DIAGNOSTIC MENU -----
IDE_LOOP:
        MOV     AX,CS                  ;Just in case somehow they changed somewhere below
        MOV     DS,AX
        MOV     ES,AX

        MOV     BX,IDE_SIGNON0        ;List IDE command options
        CALL   PRINT_STRING

        MOV     BP,CURRENT_IDE_DRIVE
        MOV     AL,[BP]
        OR     AL,AL
        JNZ    SIGN_B
        MOV     BX,CURRENT_MSG_A
        JMP    IDE_LOOP0
SIGN_B: MOV     BX,CURRENT_MSG_B
IDE_LOOP0:
        CALL   PRINT_STRING

        MOV     BX,IDE_SIGNON4        ;List IDE command options
        CALL   PRINT_STRING

        MOV     BP,DISPLAY_FLAG
        MOV     AL,[BP]                ;Do we have detail sector data display flag ON or OFF
        OR     AL,AL                  ;NZ = on
        JNZ    IDE_LOOP1
        MOV     BX,IDE_SIGNON1        ;"ON"
        JMP    IDE_LOOP2
IDE_LOOP1:
        MOV     BX,IDE_SIGNON2        ;"OFF"
IDE_LOOP2:
        CALL   PRINT_STRING
        MOV     BX,IDE_SIGNON3        ;List IDE command options
        CALL   PRINT_STRING

```

```

CALL    DISPLAY_POSITION    ;Display current Track,sector,head#

CALL    CRLF
MOV     BX,IDE_MENU        ;Enter a command
CALL    PRINT_STRING

call    CICO                ;Get a command from Console
mov     ah,0
CMP     AL,ESC              ;Abort if ESC
JNZ     NOT_ESC
JMP     INIT                ;Back to start of Monitor

NOT_ESC:cmp    al,'A'        ;Find meuu option from table
        jb     IDE_LOOP      ;must be A to Z
        cmp    al,'Z'
        jg     IDE_LOOP
        sub    al,'A'        ;calculate offset
        shl    al,1          ;X 2
        add    ax,IDE_TABLE  ;Note DS:=CS:
        mov    bx,ax
CALL    CRLF
mov     ax,[cs:bx]          ;get location of routine CS:[BX]
call    ax                  ;<----- This is the IDE Menu CMD call
        jmp    IDE_LOOP      ;finished

;          INDIVIDUAL IDE DRIVE MENU COMMANDS

;-----Select Drive/CF card -----
SET_DRIVE_A:                ;Select First Drive
        MOV     AL,0
SELECT_DRIVE:
        MOV     BP,CURRENT_IDE_DRIVE
        MOV     [BP],AL
        OUT    IDEDrivePort,AL    ;Select Drive 0 or 1
        RET

SET_DRIVE_B:                ;Select Drive 1
        MOV     AL,1
        JMP    SELECT_DRIVE

;----- Do the IDentify drive command, and display the IDE_Buffer -----
DRIVE_ID:
        CALL    IDEwaitnotbusy
        JNB    L_5
        XOR    AX,AX
        DEC    AX              ;NZ if error
        RET                  ;If Busy return NZ

L_5:  MOV     DH,COMMANDid
        MOV     DL,REGcommand
        CALL    IDEwr8D        ;issue the command

        CALL    IDEwaitdrq     ;Wait for Busy=0, DRQ=1

```

```

JNB     L_6
JMP     SHOWerrors

L_6:    MOV     CH,0                ;256 words
        MOV     BP,IDE_Buffer      ;Store data here (remember CS: = SS:)
        CALL    MoreRD16           ;Get 256 words of data from REGdata port to ss:[BP]

        MOV     BX,msgmdl          ;print the drive's model number
        CALL    PRINT_STRING
        MOV     BP,(IDE_Buffer + 54)
        MOV     CH,10              ;Character count in words
        CALL    Print_ID_Info      ;Print [HL], [B] X 2 characters
        CALL    CRLF
                                           ; print the drive's serial number
        MOV     BX,msgsn
        CALL    PRINT_STRING
        MOV     BP,(IDE_Buffer + 20)
        MOV     CH,5               ;Character count in words
        CALL    Print_ID_Info
        CALL    CRLF
                                           ;PRINT_STRING the drive's firmware revision string
        MOV     BX,msgrev
        CALL    PRINT_STRING
        MOV     BP,(IDE_Buffer + 46)
        MOV     CH,2
        CALL    Print_ID_Info      ;Character count in words
        CALL    CRLF
                                           ;print the drive's cylinder, head, and sector specs
        MOV     BX,msgcy
        CALL    PRINT_STRING
        MOV     BP,(IDE_Buffer + 2)
        CALL    Print_ID_HEX
        MOV     BX,msghd
        CALL    PRINT_STRING
        MOV     BP,(IDE_Buffer + 6)
        CALL    Print_ID_HEX
        MOV     BX,msgsc
        CALL    PRINT_STRING
        MOV     BP,(IDE_Buffer + 12) ;Sectors/track
        CALL    Print_ID_HEX
        CALL    CRLF
        XOR     AX,AX              ;Ret Z
        RET

```

; Print a string located [BP] (Used only by the above DISK ID routine)

```

Print_ID_Info:
        MOV     CL,[BP+1]          ;Text is low byte high byte format
        CALL    CO
        MOV     CL,[BP]
        CALL    CO
        INC     BP
        INC     BP
        DEC     CH
        JNZ     Print_ID_Info

```

```

RET

; Print a 16 bit number, located [BP] (Used only by the above DISK ID routine)
; (Note Special Low Byte First. Used only for Drive ID)

Print_ID_HEX:
MOV     AL,[BP+1]           ;Index to high byte first
CALL    AL_HEXOUT
MOV     AL,[BP]            ;Now low byte
CALL    AL_HEXOUT
RET

;----- Read the current selected sector (based on LBA) to the IDE Buffer
READ_SEC:
MOV     AX,CS
MOV     DS,AX
MOV     BP,RAM_DMA
MOV     word [BP],IDE_Buffer ;DMA initially to IDE_Buffer

CALL    READSECTOR

JZ      Main1B
CALL    CRLF                ;Here if there was a problem
RET

Main1B: MOV     BX,msgrd      ;Sector read OK
CALL    PRINT_STRING

MOV     BP,DISPLAY_FLAG    ;Do we have detail sector data display flag on or off
MOV     AL,[BP]            ;NZ = on
OR      AL,AL
JNZ     SHOW_SEC_RDATA
RET

SHOW_SEC_RDATA:
MOV     BP,RAM_DMA
MOV     word [BP],IDE_Buffer ;DMA initially to IDE_Buffer
CALL    DISPLAY_SEC
MOV     BX,CR_To_Continue
CALL    PRINT_STRING
CALL    CI
RET

;----- Write the current selected sector (based on LBA) from the IDE Buffer
WRITE_SEC:
MOV     AX,CS
MOV     DS,AX
MOV     BX,CONFIRM_WR_MSG  ;Are you sure?
CALL    PRINT_STRING
CALL    CICO
CMP     AL,'Y'
JZ      WR_SEC_OK1
CALL    CRLF                ;Here if there was a problem
RET

```

```

WR_SEC_OK1:
    MOV     BP, RAM_DMA
    MOV     word [BP], IDE_Buffer    ;DMA initially to IDE_Buffer

    CALL    WRITESECTOR            ;Will write whatever is in the IDE_Buffer

    JZ      Main2B
    CALL    CRLF                    ;Here if there was a problem
    RET

Main2B: MOV     BX, msgrd            ;Sector written OK
    CALL    PRINT_STRING

    MOV     BP, DISPLAY_FLAG        ;Do we have detail sector data display flag on or off
    MOV     AL, [BP]                ;NZ = on
    OR      AL, AL
    JNZ     SHOW_SEC_WDATA
    RET

SHOW_SEC_WDATA:
    MOV     BP, RAM_DMA
    MOV     word [BP], IDE_Buffer    ;DMA initially to IDE_Buffer
    CALL    DISPLAY_SEC
    MOV     BX, CR_To_Continue
    CALL    PRINT_STRING
    CALL    CI
    RET

;----- Set a new LBA value from imputed Track/Sec info. Send to drive
SET_LBA: MOV     AX, CS
    MOV     DS, AX
    MOV     BX, SET_LBA_MSG        ;Set new LBA and send to drive
    CALL    PRINT_STRING
    CALL    GEN_HEX32_LBA          ;Get new CPM style Track & Sector number and put them in RAM at RAM_SEC & RAM_TRK
    JB      main3b                 ;Ret C set if abort/error
    CALL    WR_LBA                 ;Update LBA on drive
main3b: CALL    CRLF
    RET

;----- Toggle detailed sector display on/off
DISPLAY:
    MOV     AX, CS
    MOV     DS, AX
    MOV     BP, DISPLAY_FLAG        ;Do we have detail sector data display flag on or off
    MOV     AL, [BP]                ;NZ = on
    NOT     AL
    MOV     [BP], AL
    RET

;----- Point current sector to next sector
NEXT_SECT:

```

```

        CALL    GET_NEXT_SECT
        JNZ    AT_END
        RET

AT_END:  MOV     BX,AT_END_MSG           ;Tell us we are at end of disk
        CALL   PRINT_STRING
        RET

;----- Point current sector to previous sector
PREV_SECT:
        CALL   GET_PREV_SECT
        JNZ    AT_START
        RET

AT_START:
        MOV    BX,AT_START_MSG         ;Tell us we are at start of disk
        CALL   PRINT_STRING
        RET

;----- Sequentially read sectors from disk starting at current LBA position
SEQ_SEC_RD:
        MOV    AX,CS
        MOV    DS,AX
        CALL   IDEwaitnotbusy
        JNB    MORE_SEC
        JMP    SHOWerrors

MORE_SEC:
        CALL   CRLF
        MOV    BP,RAM_DMA              ;Set DMA initially to IDE_Buffer

        MOV    CL,'<'
        CALL   CO
        MOV    AX,BP
        CALL   AX_HEXOUT

        MOV    word [BP],IDE_Buffer
        MOV    CL,','
        CALL   CO
        MOV    AX,[BP]
        CALL   AX_HEXOUT
        MOV    CL,'>'
        CALL   CO

        CALL   READSECTOR              ;If there are errors they will show up in READSECTOR
        JZ     SEQOK

        MOV    BX,CONTINUE_MSG         ;If an error ask if we wish to continue
        CALL   PRINT_STRING
        CALL   CICO
        CMP    AL,ESC                  ;Abort if ESC
        JNZ    SEQOK
        RET

SEQOK:  CALL   DISPLAY_POSITION        ;Display current Track,sector,head#

```

```

MOV     BP,DISPLAY_FLAG           ;Do we have detail sector data display flag on or off
MOV     AL,[BP]                   ;NZ = on
OR      AL,AL
JZ      MORES2
MOV     BP,RAM_DMA                ;Point DMA to IDE_Buffer again
MOV     word [BP],IDE_Buffer
CALL    DISPLAY_SEC

MORES2: CALL    CSTS                ;Any keyboard character will stop display
JZ      NO_WAIT
CALL    CI
MOV     BX,CONTINUE_MSG
CALL    PRINT_STRING
CALL    CI
CMP     AL,ESC
JNZ     NO_WAIT
RET                                           ;Bug, is returning to monitor, must be a stack problem!
NO_WAIT:CALL    GET_NEXT_SECT       ;Point LBA to next sector
JZ      MORE_SEC                   ;Note will go to last sec on disk unless stopped
RET

;----- Read N Sectors to disk
;Note unlike the normal sector read, this routine increments the DMA address after each sector read

N_RD_SEC:
MOV     AX,CS
MOV     DS,AX
MOV     BX,READN_MSG
CALL    PRINT_STRING
CALL    GET2DIGITS                   ;Hex to AL

MOV     BP,SECTOR_COUNT            ;store sector count
MOV     [BP],AL

MOV     BP,RAM_DMA_STORE
MOV     word [BP],IDE_Buffer       ;DMA_STORE initially to IDE_Buffer

NextRSec:
MOV     BX, READN_S_MSG
CALL    PRINT_STRING
CALL    WR_LBA                       ;Update LBA on drive
CALL    DISPLAY_POSITION            ;Display current Track,sector,head#

MOV     BP,RAM_DMA_STORE
MOV     AX,[BP]                     ;Get last value of DMA address
MOV     BP,RAM_DMA
MOV     [BP],AX                     ;Store it in DMA address

CALL    READSECTOR                  ;Actully, Sector/track values are already updated

MOV     BP,RAM_DMA

```

```

MOV     AX,[BP]                ;Store it in DMA_STORE address
MOV     BP, RAM_DMA_STORE
MOV     [BP],AX

MOV     BP,SECTOR_COUNT
MOV     AL,[BP]
DEC     AL
MOV     [BP],AL
JNZ     NEXT_SEC_NRD
RET

NEXT_SEC_NRD:
CALL    GET_NEXT_SECT
JZ      NextRSec
MOV     BX,AT_END_MSG          ;Tell us we are at end of disk
CALL    PRINT_STRING
RET

;----- Write N Sectors to disk
;Note unlike the normal sector write routine, this routine increments the DMA address after each write.

N_WR_SEC:
MOV     AX,CS
MOV     DS,AX
MOV     BX,CONFIRM_WR_MSG      ;Are you sure?
CALL    PRINT_STRING
CALL    CICO
CMP     AL,'Y'
JZ      WR_SEC_OK2
CALL    CRLF                    ;Here if there was a problem
RET

WR_SEC_OK2:
MOV     BX,WRITEN_MSG
CALL    PRINT_STRING
CALL    GET2DIGITS              ;Hex to AL

MOV     BP,SECTOR_COUNT        ;store sector count
MOV     [BP],AL

MOV     BP, RAM_DMA_STORE
MOV     word [BP],IDE_Buffer    ;DMA_STORE initially to IDE_Buffer

NextWSec:
MOV     BX, WRITEN_S_MSG
CALL    PRINT_STRING
CALL    WR_LBA                  ;Update LBA on drive
CALL    DISPLAY_POSITION        ;Display current Track,sector,head#

MOV     BP, RAM_DMA_STORE
MOV     AX,[BP]                ;Get last value of DMA address
MOV     BP, RAM_DMA
MOV     [BP],AX                ;Store it in DMA address

```



```

CALL    WRITESECTOR          ;Actully, Sector/track values are already updated

MOV     BP, RAM_DMA
MOV     AX, [BP]              ;Store it in DMA_STORE address
MOV     BP, RAM_DMA_STORE
MOV     [BP], AX

MOV     BP, SECTOR_COUNT
MOV     AL, [BP]
DEC     AL
MOV     [BP], AL
JNZ     NEXT_SEC_NWR
RET

NEXT_SEC_NWR:
CALL    GET_NEXT_SECT
JZ      NextWSec
MOV     BX, AT_END_MSG        ;Tell us we are at end of disk
CALL    PRINT_STRING
RET

;----- Format current disk
FORMAT:
MOV     AX, CS
MOV     DS, AX
MOV     BP, CURRENT_IDE_DRIVE
MOV     AL, [BP]
OR      AL, AL
JNZ     FORM_B
MOV     BX, FORMAT_MSG_A
JMP     FORM_X
FORM_B: MOV     BX, FORMAT_MSG_B
FORM_X: CALL    PRINT_STRING
MOV     BX, CONFIRM_WR_MSG    ;Are you sure?
CALL    PRINT_STRING
CALL    CICO
CMP     AL, 'Y'
JZ      FORMAT_OK
RET

FORMAT_OK:
MOV     AX, 0                 ;Back to CPM sector 0
MOV     BP, RAM_SEC           ;Get Current Sector
MOV     [BP], AX             ;0 to CPM Sectors

MOV     BP, RAM_TRK           ;And track
MOV     [BP], AX

MOV     AX, 0E5E5H            ;First set Sector pattern to E5's
CALL    RAM_FILL
CALL    CRLF

NEXT_FORMAT:
MOV     BP, RAM_DMA           ;Point DMA to the area
MOV     word [BP], IDE_Buffer

```

```

        CALL    WRITESECTOR          ;Will return error if there was one
        JZ      NEXTF1              ;Z means the sector write was OK

        MOV     BX,FORMAT_ERR        ;Indicate an error
        CALL    PRINT_STRING
        CALL    SHOW_TRACK_SEC       ;Show current location of error
        CALL    CRLF
        JMP     FNEXTSEC3

NEXTF1: MOV     BP,RAM_SEC            ;Get Current Sector
        MOV     AX,[BP]
        OR      AX,AX                ;At start of each track give an update
        JNZ    FNEXTSEC2

        CALL    SHOW_TRACK

FNEXTSEC2:
        CALL    CSTS                 ;Any keyboard character will stop display
        JZ      FNEXTSEC1
        CALL    CI                    ;Flush character

FNEXTSEC3:
        MOV     BX,CONTINUE_MSG
        CALL    PRINT_STRING
        CALL    CICO
        CMP     AL,ESC
        JNZ    FNEXTSEC1

F_DONE: MOV     AL,0                  ;Login drive A:
        CALL    SELECT_DRIVE
        MOV     BP,CURRENT_IDE_DRIVE
        MOV     [BP],AL
        RET

FNEXTSEC1:
        CALL    GET_NEXT_SECT
        JZ      NEXT_FORMAT
        MOV     BX,AT_END_MSG        ;Tell us we are at end of disk
        CALL    PRINT_STRING
        JMP     F_DONE

;----- Copy Drive A: to Drive B: -----
COPY_AB:
        MOV     AX,CS
        MOV     DS,AX
        MOV     BX,DiskCopyMsg
        CALL    PRINT_STRING
        CALL    CICO
        CMP     AL,'Y'
        JZ      COPY_AB1
        JMP     C_DONE

COPY_AB1:
        MOV     BP, RAM_SEC          ;Start with CPM sector 0
        MOV     AX,0
        MOV     [BP],AX
        MOV     BP, RAM_TRK         ;Start with CPM Track 0
        MOV     AX,0

```

```

MOV     [BP],AX           ;High & Low Track to 0
CALL    CRLF
CALL    CRLF

NextDCopy:
MOV     AL,0              ;Login drive A:
CALL    SELECT_DRIVE

CALL    WR_LBA            ;Update LBA on "A:" drive

MOV     BP,RAM_DMA
MOV     word [BP],IDE_Buffer ;DMA initially to IDE_Buffer

CALL    READSECTOR       ;Get sector data from A: drive to buffer

MOV     AL,1              ;Login drive B:
CALL    SELECT_DRIVE

CALL    WR_LBA            ;Update LBA on "B:" drive

MOV     BP,RAM_DMA
MOV     word [BP],IDE_Buffer ;DMA initially to IDE_Buffer

CALL    WRITESECTOR      ;Write buffer data to sector on B: drive
JZ      COPY_OK1

MOV     BX,COPY_ERR       ;Indicate an error
CALL    PRINT_STRING
CALL    SHOW_TRACK_SEC    ;Show current location of error
CALL    CRLF
JMP     COPY_OK3

COPY_OK1:
MOV     BP,RAM_SEC        ;Get Current Sector
MOV     AX,[BP]
OR      AX,AX             ;At start of each track give an update
JNZ     COPY_OK2

CALL    SHOW_TRACK

COPY_OK2:
CALL    CSTS              ;Any keyboard character will stop display
JZ      C_NEXTSEC1
CALL    C_I               ;Flush character

COPY_OK3:
MOV     BX,CONTINUE_MSG
CALL    PRINT_STRING
CALL    CICO
CMP     AL,ESC
JNZ     C_NEXTSEC1

C_DONE: MOV     AL,0       ;Login drive A:
CALL    SELECT_DRIVE
MOV     BP,CURRENT_IDE_DRIVE
MOV     [BP],AL
RET

```

```

C_NEXTSEC1:
    CALL    GET_NEXT_SECT        ;Update to next sector/track
    JNZ     C_NEXTSEC2
    JMP     NextDCopy

C_NEXTSEC2:
    MOV     BX, CopyDone         ;Tell us we are all done.
    CALL    PRINT_STRING
    JMP     C_DONE

;----- Verify Drive A: = B: -----
VERIFY_AB:
    MOV     AX, CS
    MOV     DS, AX
    MOV     BX, DiskVerifyMsg
    CALL    PRINT_STRING

    MOV     BP, RAM_SEC          ;Start with CPM sector 0
    MOV     AX, 0
    MOV     [BP], AX
    MOV     BP, RAM_TRK         ;Start with CPM Track 0
    MOV     AX, 0
    MOV     [BP], AX           ;High & Low Track to 0

    CALL    CRLF
    CALL    CRLF

NextVCopy:
    MOV     AL, 0                ;Login drive A:
    CALL    SELECT_DRIVE

    CALL    WR_LBA                ;Update LBA on "A:" drive

    MOV     BP, RAM_DMA
    MOV     word [BP], IDE_Buffer ;DMA initially to IDE_Buffer

    CALL    READSECTOR           ;Get sector data from A: drive to buffer

    MOV     AL, 1                ;Login drive B:
    CALL    SELECT_DRIVE

    CALL    WR_LBA                ;Update LBA on "B:" drive

    MOV     BP, RAM_DMA
    MOV     word [BP], IDE_Buffer2 ;DMA initially to IDE_Buffer2

    CALL    READSECTOR

    MOV     DI, IDE_Buffer2
    MOV     SI, IDE_Buffer
    MOV     CX, 512              ;Length of sector in words

NEXT_CMP:
    MOV     AL, [SS:DI]          ;Note we have to use SS:
    CMP     AL, [SS:SI]

```

```

        JNZ     VER_ERROR
        INC     DI
        INC     SI
        LOOP   NEXT_CMP           ;CX will contain count of words done so far, (0 if done OK)
        JMP     VERIFY_OK

VER_ERROR:
        MOV     BX,VERIFY_ERR           ;Indicate an error
        CALL   PRINT_STRING
        CALL   SHOW_TRACK_SEC          ;Show current location of error
        MOV     BX,DRIVE1_MSG          ;' Drive A',CR,LF
        CALL   PRINT_STRING

        MOV     SI,IDE_Buffer
        MOV     CX,512                ;Length of sector in words

VER_SOURCE:
        MOV     AL, [SS:SI]            ;Note we have to use SS:
        CALL   AL_HEXOUT
        INC     SI
        LOOP   VER_SOURCE
        CALL   CRLF
        CALL   SHOW_TRACK_SEC          ;Show current location of error
        MOV     BX,DRIVE2_MSG          ;' Drive B',CR,LF
        CALL   PRINT_STRING

        MOV     SI,IDE_Buffer2
        MOV     CX,512                ;Length of sector in words

VER_DEST:
        MOV     AL, [SS:DI]            ;Note we have to use SS:
        CALL   AL_HEXOUT
        INC     DI
        LOOP   VER_DEST
        CALL   CRLF
        JMP     VERIFYT                ;Do not ask for a continue message here. Just continue
                                        ;If you want it change to VERIFYT1

VERIFY_OK:
        MOV     BP,RAM_SEC              ;Get Current Sector
        MOV     AX,[BP]
        OR      AX,AX                  ;At start of each track give an update
        JNZ     VERIFYT

        CALL   SHOW_TRACK

VERIFYT:CALL   CSTS                    ;Any keyboard character will stop display
        JZ     V_NEXTSEC1
        CALL   CI                      ;Flush character

VERIFYT1:
        MOV     BX,CONTINUE_MSG
        CALL   PRINT_STRING
        CALL   CICO
        CMP     AL,ESC
        JNZ     V_NEXTSEC1
        JMP     V_NEXTSEC3

V_NEXTSEC1:
        CALL   GET_NEXT_SECT          ;Update to next sector/track
        JNZ     V_NEXTSEC2

```

```

        JMP     NextVCopy
V_NEXTSEC2:
        MOV     BX,VerifyDone           ;Tell us we are all done.
        CALL    PRINT_STRING
V_NEXTSEC3:
        MOV     AL,0                    ;Login drive A:
        CALL    SELECT_DRIVE
        MOV     BP,CURRENT_IDE_DRIVE
        MOV     [BP],AL
        RET

```

```
;----- Fill RAM buffer with 0's
```

```

RAMCLEAR:
        MOV     AX,CS
        MOV     DS,AX
        MOV     AX,0
RAM_FILL:
        MOV     BP,IDE_Buffer
        MOV     CX,256                 ;512 bytes total
CLEAR1:  MOV     [BP],AX               ;Note this will be SS:BP
        INC     BP
        INC     BP
        LOOP    CLEAR1

        MOV     BX,FILL_MSG
        CALL    PRINT_STRING
        RET

```

```
;----- Power up a Hard Disk
```

```

SPINUP: MOV     DH,COMMANDspinup
spup2:  MOV     DL,REGcommand
        CALL    IDEwr8D
        CALL    IDEwaitnotbusy
        JNB    L_7
        JMP     SHOWerrors
L_7:    OR      AL,AL                 ;Clear carry
        RET

```

```
;----- Tell the Hard disk to power down
```

```

SPINDOWN:
        CALL    IDEwaitnotbusy
        JNB    L_8
        JMP     SHOWerrors
L_8:    MOV     DH,COMMANDspindown
        JMP     spup2

```

```
;----- Back to parent 8086 Monitor commands
```

```
QUIT_IDE:
    JMP     INIT
```

```
;===== Support Routines FOR IDE MODULE =====
```

```
;Generate an LBA sector number with data input from CPM style Track# & Sector#
```

```
GEN_HEX32_LBA:
    MOV     BX,ENTERRAM_SECL      ;Enter sector number, low
    CALL    PRINT_STRING
    CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
    MOV     BP,RAM_SEC
    MOV     [BP],AL              ;Note: no check that data is < MAXSEC
    CALL    CRLF

    MOV     BX,ENTERRAM_TRKL      ;Enter low byte track number
    CALL    PRINT_STRING
    CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
    MOV     BP,RAM_TRK
    MOV     [BP],AL
    CALL    CRLF

    MOV     BX,ENTERRAM_TRKH      ;Enter high byte track number
    CALL    PRINT_STRING
    CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
    MOV     BP,RAM_TRK+1
    MOV     [BP],AL
    XOR     AL,AL
    OR      AL,AL                ;To return NC
    RET
```

```
DISPLAY_POSITION:                ;Display current track,sector & head position
```

```
    MOV     BX,msgCPMTRK        ;Display in LBA format
    CALL    PRINT_STRING        ;---- CPM FORMAT ----
    MOV     BP,RAM_TRK+1
    MOV     AL,[BP]              ;High TRK byte
    CALL    AL_HEXOUT
    DEC     BP
    MOV     AL,[BP]              ;Low TRK byte
    CALL    AL_HEXOUT
```

```
    MOV     BX,msgCPMSEC
    CALL    PRINT_STRING        ;SEC = (16 bits)
    MOV     BP,RAM_SEC+1        ;High Sec
    MOV     AL,[BP]
    CALL    AL_HEXOUT
    DEC     BP
    MOV     AL,[BP]              ;Low sec
    CALL    AL_HEXOUT
```

```
;---- LBA FORMAT ----
```

```
    MOV     BX,msgLBA
```

```

CALL PRINT_STRING          ;(LBA = 00 (<-- Old "Heads" = 0 for these drives).

MOV BP, RAM_DRIVE_TRK+1   ;High "cylinder" byte
MOV AL, [BP]
CALL AL_HEXOUT
DEC BP
MOV AL, [BP]              ;Low "cylinder" byte
CALL AL_HEXOUT

MOV BP, RAM_DRIVE_SEC
MOV AL, [BP]
CALL AL_HEXOUT
MOV BX, MSGBracket        ;)$
CALL PRINT_STRING
RET

SHOW_TRACK_SEC:           ;Display current (CPM) track, sector
MOV BX, msgCPMTRK
CALL PRINT_STRING        ;---- CPM FORMAT ----
MOV BP, RAM_TRK+1
MOV AL, [BP]             ;High TRK byte
CALL AL_HEXOUT
DEC BP
MOV AL, [BP]            ;Low TRK byte
CALL AL_HEXOUT
MOV BX, msgCPMSEC
CALL PRINT_STRING

MOV BP, RAM_SEC         ;Low Sec (Only)
MOV AX, [BP]
CALL AL_HEXOUT
MOV BX, H_Msg
CALL PRINT_STRING
RET

SHOW_TRACK:
MOV BX, msgCPMTRK
CALL PRINT_STRING        ;---- CPM FORMAT ----
MOV BP, RAM_TRK+1
MOV AL, [BP]            ;High TRK byte
CALL AL_HEXOUT
MOV BP, RAM_TRK
MOV AL, [BP]            ;Low TRK byte
CALL AL_HEXOUT
MOV BX, OK_CR_MSG
CALL PRINT_STRING        ;---- CPM FORMAT ----
RET

DISPLAY_SEC:             ;Print a DISPLAY_SEC of the data in the 512 byte IDE_Buffer (RAM_DMA)
CALL CRLF                ;Note written so it can be easily converted to a "normal: DS: based" routine
MOV BP, RAM_DMA          ;Get Current DMA Address
MOV SI, [BP]             ;Both DS:DI & SI point to buffer
MOV DI, SI
MOV DH, 32               ;print 32 lines

```



```

SF172: CALL    CRLF
        call   SHOW_ADDRESS_SS           ;Show SS:SI
        mov    cx,2                       ;send 2 spaces
        call   TABS
        MOV    DL,16                       ;32 characters across
SF175: MOV    AL,[SS:SI]
        CALL   AL_HEXOUT                 ;Display A on CRT/LCD
        MOV    AL,'~'
        CALL   CO
        INC    SI
        DEC    DL
        JNZ   SF175

        mov    cx,3                       ;first send 3 spaces
        call   TABS

        MOV    DL,16                       ;24 across again
Sloop2: mov    al,[SS:DI]
        and    al,7fh
        cmp    al,' '                     ;filter out control characters
        jnc    Sloop3
Sloop4: mov    al,'.'
Sloop3: cmp    al,'~'
        jnc    Sloop4
        mov    cl,al
        call   CO
        INC    DI
        DEC    DL
        JNZ   Sloop2
        DEC    DH
        JNZ   SF172                       ;--DH has total byte count
        CALL   CRLF
        ret

;Point to next sector.  Ret Z if all OK      NZ if at end of disk
GET_NEXT_SECT:
        MOV    BP, RAM_SEC                ;Get Current Sector
        MOV    AX, [BP]
        INC    AX
        MOV    [BP], AX                   ;0 to MAXSEC CPM Sectors
        CMP    AX, MAXSEC-1               ;Assumes < 255 sec /track
        JNZ   NEXT_SEC_DONE

        MOV    AX, 0                       ;Back to CPM sector 0
        MOV    [BP], AX

        MOV    BP, RAM_TRK                ;Bump to next track
        MOV    AX, [BP]
        INC    AX
        CMP    AX, 100H                   ;Tracks 0-0FFH only
        JZ    AT_DISK_END
        MOV    [BP], AX

NEXT_SEC_DONE:
        CALL   WR_LBA                     ;Update the LBC pointer

```

```

        XOR     AX,AX
        RET                               ;Ret z if all OK
AT_DISK_END:
        XOR     AX,AX
        DEC     AX
        RET

;Point to previous sector.  Ret Z if all OK
GET_PREV_SECT:
        MOV     BP, RAM_SEC               ;Get Current Sector
        MOV     AX, [BP]
        CMP     AX, 0
        JZ      PREVIOUS_TRACK
        DEC     AX
        MOV     [BP], AX                  ;0 to MAXSEC CPM Sectors
        JMP     PREVIOUS_SEC_DONE

PREVIOUS_TRACK:
        MOV     AX, MAXSEC-1              ;Back to CPM last sector on previous track
        MOV     [BP], AX

        MOV     BP, RAM_TRK              ;Bump to next track
        MOV     AX, [BP]
        CMP     AX, 0                     ;If On track 0 already then problem
        JNZ     AT_00
        DEC     AX
        MOV     [BP], AX

PREVIOUS_SEC_DONE:
        CALL    WR_LBA                     ;Update the LBC pointer
        XOR     AX, AX                     ;Return Z if all OK
        RET

AT_00:  MOV     BX, ATHOME_MSG
        CALL    PRINT_STRING
        XOR     AX, AX
        DEC     ax                         ;NZ if problem
        RET

;
SHOWerrors:
        CALL    CRLF
        MOV     DL, REGstatus              ;Get status in status register
        CALL    IDerd8D
        MOV     AL, DH
        AND     AL, 1H
        JNZ     MoreError                  ;Go to REGerr register for more info
                                              ;All OK if 01000000

        PUSHF                               ;<<< Save for return below
        AND     AL, 80H
        JZ      NOT7
        MOV     BX, DRIVE_BUSY             ;Drive Busy (bit 7) stuck high.  Status =
        CALL    PRINT_STRING
        JMP     DONEERR

```

```

NOT7:  AND    AL,40H
       JNZ    NOT6
       MOV    BX,DRIVE_NOT_READY    ;Drive Not Ready (bit 6) stuck low.  Status =
       CALL  PRINT_STRING
       JMP    DONEERR

NOT6:  AND    AL,20H
       JNZ    NOT5
       MOV    BX,DRIVE_WR_FAULT     ;Drive write fault.    Status =
       CALL  PRINT_STRING
       JMP    DONEERR

NOT5:  MOV    BX,UNKNOWN_ERROR
       CALL  PRINT_STRING
       JMP    DONEERR

MoreError:                                ;Get here if bit 0 of the status register indicted a problem
       MOV    DL,REGerr              ;Get error code in REGerr
       CALL  IDErd8D
       MOV    AL,DH
       PUSHF                          ;<<<< Save flags for below

       AND    AL,10H
       JZ     NOTE4
       MOV    BX,SEC_NOT_FOUND
       CALL  PRINT_STRING
       JMP    DONEERR

NOTE4: AND    AL,80H
       JZ     NOTE7
       MOV    BX,BAD_BLOCK
       CALL  PRINT_STRING
       JMP    DONEERR

NOTE7: AND    AL,40H
       JZ     NOTE6
       MOV    BX,UNRECOVER_ERR
       CALL  PRINT_STRING
       JMP    DONEERR

NOTE6: AND    AL,4H
       JZ     NOTE2
       MOV    BX,INVALID_CMD
       CALL  PRINT_STRING
       JMP    DONEERR

NOTE2: AND    AL,2H
       JZ     NOTE1
       MOV    BX,TRK0_ERR
       CALL  PRINT_STRING
       JMP    DONEERR

NOTE1: MOV    BX,UNKNOWN_ERROR1
       CALL  PRINT_STRING
       JMP    DONEERR

```

```

DONEERR:POPF                ;>>>> get back flags
    PUSH    AX
    CALL    AL_BINOUT        ;Show error bit pattern
    CALL    CRLF
    POP     AX
    XCHG   AL,AH
    OR     AL,AL            ;Set Z flag
    STC
    RET                ;Set Carry flag

;=====
; IDE Drive BIOS Routines written in a format that can be used with CPM86 (Note MSDOS/DOS has its own
; modules see further below. However instead of using DS:[BX] (as we do in the CPM86 BIOS), throughout we
; will use SS:[BP] so the the buffers can reside at the top segment of available RAM.
; Normally this will be D000:E000H (below the ROM) but the monitor will not assume that there is a
; full 1MG address space available and may put them lower. See monitor initialization code at start.
;=====

IDEinit:                    ;Initilze the 8255 and drive then do a hard reset on the drive,
                            ;By default the drive will come up initilized in LBA mode.
    MOV     AL,READcfg8255   ;10010010b
    OUT    IDECtrlPort,AL   ;Config 8255 chip, READ mode

    MOV     AL,IDErstline
    OUT    IDEportC,AL      ;Hard reset the disk drive

    MOV     CH,IDE_Reset_Delay ;;Time delay for reset/initilization (~66 uS, with 8MHz 8086, 1 I/O wait state)
ResetDelay:
    DEC     CH
    JNZ    ResetDelay       ;Delay (IDE reset pulse width)
    XOR    AL,AL
    OUT    IDEportC,AL      ;No IDE control lines asserted

    CALL    DELAY_SHORT     ;Allow time for CF/Drive to recover

    MOV     DH,11100000b    ;Data for IDE SDH reg (512bytes, LBA mode,single drive,head 0000)
;    MOV     DH,10100000b    ;For Trk,Sec,head (non LBA) use 10100000 (This is the mode we use for MSDOS)
                            ;Note. Cannot get LBA mode to work with an old Seagate Medalist 6531 drive.
                            ;have to use the non-LBA mode. (Common for old hard disks).
    MOV     DL,REGshd       ;00001110,(0EH) for CS0,A2,A1,
    CALL    IDEwr8D         ;Write byte to select the MASTER device

    MOV     CH,03H         ;<<< May need to adjust delay time
WaitInit:
    MOV     DL,REGstatus    ;Get status after initilization
    CALL    IDErd8D        ;Check Status (info in [DH])
    MOV     AL,DH
    AND    AL,80H
    JZ     DoneInit        ;Return if ready bit is zero
    CALL    DELAY_LONG     ;Long delay, drive has to get up to speed
    DEC     CH
    JNZ    WaitInit
    XOR    AL,AL

```

```

        DEC     AL
        RET     ;Return NZ. Well check for errors when we get back
DoneInit:
        RET     ;Return Z indicating all is well

DELAY_LONG:
        ;Long delay (Seconds) for hard disk to get up to speed
        PUSH   CX
        PUSH   DX
        MOV    CX,0FFFFH
DELAY2: MOV    DH,2      ;May need to adjust delay time to allow cold drive to
DELAY1: DEC    DH      ;to speed
        JNZ   DELAY1
        DEC   CX
        JNZ   DELAY2
        POP   DX
        POP   CX
        RET

DELAY_SHORT:
        MOV    AX,8000H ;DELAY ~32 MS (DOES NOT SEEM TO BE CRITICAL)
DELAY3: DEC    AX
        JNZ   DELAY3
        RET

        ;Read a sector, specified by the 4 bytes in LBA
        ;Z on success, NZ call error routine if problem
READSECTOR:
        CALL   WR_LBA   ;Tell which sector we want to read from.
        ;Note: Translate first in case of an error otherwise we
        ;will get stuck on bad sector
        ;make sure drive is ready
        CALL   IDEwaitnotbusy
        JNB   L_19
        JMP   SHOWerrors ;Returned with NZ set if error

L_19:  MOV    DH,COMMANDread
        MOV    DL,REGcommand
        CALL   IDEwr8D   ;Send sec read command to drive.
        CALL   IDEwaitdrq ;wait until it's got the data
        JNB   L_20
        JMP   SHOWerrors

L_20:  MOV    BP,RAM_DMA ;Get Current DMA Address at SS:RAM_DMA
        MOV    AX,[BP]  ;Note SS: is assumed here
        MOV    BP,AX
        MOV    CH,0     ;Read 512 bytes to [HL] (256X2 bytes)

MoreRD16:
        MOV    AL,REGdata ;REG register address
        OUT   IDEportC,AL

        OR    AL,IDERdline ;08H+40H, Pulse RD line
        OUT   IDEportC,AL

```

```

    IN     AL,IDEportA           ;Read the lower byte first
    MOV   [BP],AL
    INC   BP
    IN     AL,IDEportB         ;THEN read the upper byte
    MOV   [BP],AL
    INC   BP

    MOV   AL,REGdata           ;Deassert RD line
    OUT   IDEportC,AL
    DEC   CH
    JNZ   MoreRD16

    MOV   DL,REGstatus
    CALL  IDErd8D
    MOV   AL,DH
    AND   AL,1H
    JZ    L_21
    CALL  SHOWerrors           ;If error display status
L_21:  RET

                                           ;Write a sector, specified by the 3 bytes in LBA (_IX+0)",
                                           ;Z on success, NZ to error routine if problem
WRITESECTOR:
    CALL  WR_LBA               ;Tell which sector we want to read from.
                                           ;Note: Translate first in case of an error otherwise we
                                           ;will get stuck on bad sector
                                           ;make sure drive is ready
    CALL  IDEwaitnotbusy
    JNB   L_22
    JMP   SHOWerrors

L_22:  MOV   DH,COMMANDwrite
    MOV   DL,REGcommand
    CALL  IDEwr8D             ;tell drive to write a sector
    CALL  IDEwaitdrq         ;wait until it wants the data
    JNB   L_23
    JMP   SHOWerrors

L_23:  MOV   BP, RAM_DMA       ;Get Current DMA Address
    MOV   AX,[BP]
    MOV   BP,AX
    MOV   CH,0               ;256X2 bytes

    MOV   AL,WRITEcfg8255
    OUT   IDECtrlPort,AL

WRSEC1_IDE:
    MOV   AL,[BP]
    INC   BP
    OUT   IDEportA,AL       ;Write the lower byte first
    MOV   AL,[BP]
    INC   BP
    OUT   IDEportB,AL       ;THEN High byte on B

    MOV   AL,REGdata
    PUSH AX

```

```

OUT     IDEportC,AL           ;Send write command
OR      AL,IDEwrlne          ;Send WR pulse
OUT     IDEportC,AL
POP     AX
OUT     IDEportC,AL           ;Send write command
DEC     CH
JNZ     WRSEC1_IDE

MOV     AL,READcfg8255        ;Set 8255 back to read mode
OUT     IDECtrlPort,AL

MOV     DL,REGstatus
CALL   IDErd8D
MOV     AL,DH
AND     AL,1H
JZ      L_24
CALL   SHOWerrors            ;If error display status
L_24:   RET

WR_LBA:                               ;Write the logical block address to the drive's registers
                                           ;Note we do not need to set the upper nibble of the LBA
                                           ;It will always be 0 for these small CPM drives (so no High Cylinder
                                           ;numbers etc).

MOV     BP,RAM_SEC
MOV     AX,[BP]                ;LBA mode, Low sectors go directly
INC     AX                     ;Sectors are numbered 1 -- MAXSEC (even in LBA mode)
MOV     BP,RAM_DRIVE_SEC
MOV     [BP],AL                ;For Diagnostic Diaplay Only
MOV     DH,AL
MOV     DL,REGsector           ;Send info to drive
CALL   IDEwr8D                 ;Write to 8255 A Register
                                           ;Note: For drive we will have 0 - MAXSEC sectors only

MOV     BP,RAM_TRK
MOV     AX,[BP]
MOV     BP,RAM_DRIVE_TRK
MOV     [BP],AL
MOV     DH,AL                  ;Send Low TRK#
MOV     DL,REGcylinderLSB
CALL   IDEwr8D                 ;Write to 8255 A Register

MOV     BP,RAM_DRIVE_TRK+1
MOV     [BP],AH
MOV     DH,AH                  ;Send High TRK#
MOV     DL,REGcylinderMSB
CALL   IDEwr8D                 ;Send High TRK# (in DH) to IDE Drive
CALL   IDEwr8D_X               ;Special write to 8255 B Register (Not A) to update LED HEX Display
                                           ;High 8 bits ignored by IDE drive

MOV     DH,1                   ;For CPM, one sector at a time
MOV     DL,REGsecnt
CALL   IDEwr8D                 ;Write to 8255 A Register
RET

                                           ;Special version for MS-DOS system BIOS (see IBM BIOS Section)

```

```

DOS_WR_LBA:                                ;This will display Head, Cylinder and Sector on the LED HEX display
                                           ;instead of LBA sector numbers.
MOV    DH,[CURRENT_HEAD]                  ;OR in head info to lower 4 bits
AND    DH,0FH                              ;Just in case
OR     DH,10100000B                       ;Set to >>>> NON-LBA mode <<<<<
MOV    DL,REGshd                          ;Send "Head #" (in DH) to IDE drive
CALL   IDEwr8D

MOV    DH,[CURRENT_TRACK_HIGH]            ;Send High TRK#
MOV    DL,REGcylinderMSB
CALL   IDEwr8D                            ;Send High TRK# (in DH) to IDE Drive

MOV    DH,[CURRENT_HEAD]                  ;Get head info to lower 8 bits of the special
AND    DH,0FH                              ;top two LED HEX displays.
SHL    DH,1                               ;These 8 (high) data lines are ignored by the IDE drive
SHL    DH,1
SHL    DH,1
SHL    DH,1
OR     DH,[CURRENT_TRACK_HIGH]           ;Will display the Head in top nibble and the two bits of the HIGH bits
MOV    DL,REGcylinderMSB                 ;of the high cylinder in the low nibble.
CALL   IDEwr8D_X                         ;Special output to 8255 B Register (Not A) to update LED HEX Display ONLY

MOV    DH,[CURRENT_TRACK]                ;Get low Track #
MOV    DL,REGcylinderLSB                 ;Send Low TRK# (in DH)
CALL   IDEwr8D                            ;Special write to 8255 B Register (Not A)

MOV    DH,[CURRENT_SECTOR]               ;Bits 0-5 only (currently 1-17)
MOV    DL,REGsector                      ;Send "Sector#"
CALL   IDEwr8D                            ;Write to 8255 A Register

MOV    DH,[SECTORS_TO_DO]                ;# of CONTIGOUS sectors to send
MOV    DL,REGsecct̄
CALL   IDEwr8D                            ;Write to 8255 A Register
RET

IDEwaitnotbusy:                          ;Drive READY if 01000000
MOV    CH,0FFH
MOV    AH,0FFH                            ;Delay, must be above 80H for 4MHz Z80. Leave longer for slower drives
PUSH   BX                                  ;AH is not changed in IDErd8D below

MoreWait:
MOV    DL,REGstatus                      ;wait for RDY bit to be set
CALL   IDErd8D                            ;Note AH or CH are unchanged
MOV    AL,DH
AND    AL,11000000B
XOR    AL,01000000B
JZ     DONE_NOT_BUSY
DEC    CH
JNZ    MoreWait
DEC    AH
JNZ    MoreWait
STC                                        ;Set carry to indicate an error
POP    BX
RET

DONE_NOT_BUSY:

```



```

OR      AL,AL          ;Clear carry it indicate no error
POP     BX
RET

;Wait for the drive to be ready to transfer data.
;Returns the drive's status in Acc
IDEwaitdrq:
MOV     CH,0FFH
MOV     AL,0FFH       ;Delay, must be above 80H for 4MHz Z80. Leave longer for slower drives
PUSH    BX

MoreDRQ:
MOV     DL,REGstatus  ;wait for DRQ bit to be set
CALL    IDErd8D       ;Note AH or CH are unchanged
MOV     AL,DH
AND     AL,10001000B
CMP     AL,00001000B
JZ      DoneDRQ
DEC     CH
JNZ     MoreDRQ
DEC     AH
JNZ     MoreDRQ
STC                    ;Set carry to indicate error
POP     BX
RET

DoneDRQ:
OR      AL,AL          ;Clear carry
POP     BX
RET

CLEAR$ID$BUFFER:      ;Clear the ID Buffer area
MOV     AX,2020H      ;Clear to spaces
MOV     BP,IDE_Buffer ;Remember CS: = SS
MOV     CX,256        ;512 bytes total
CLEAR2: MOV    [BP],AX ;Note this will be SS:[BP]
INC     BP
INC     BP
LOOP    CLEAR2

MOV     AX,0H         ;Put in 0's for cylinder,heads,sectors etc
MOV     BP,IDE_Buffer
MOV     CX,7          ;14 bytes total
CLEAR3: MOV    [BP],AX ;Note this will be SS:[BP]
INC     BP
INC     BP
LOOP    CLEAR3
RET

```

```

;-----
; Low Level 8 bit R/W to the drive controller. These are the routines that talk
; directly to the drive controller registers, via the 8255 chip.
; Note the 16 bit Sector I/O to the drive is done directly
; in the routines READSECTOR & WRITESECTOR for speed reasons.

```

```

IDErD8D:                                ;READ 8 bits from IDE register @ [DL], return info in [DH]
MOV   AL,DL                               ;select IDE register
OUT   IDEportC,AL                          ;drive address onto control lines

OR    AL,IDErdline                         ;RD pulse pin (40H)
OUT   IDEportC,AL                          ;Assert read pin

IN    AL,IDEportA                           ;return with data in [DH]
MOV   DH,AL

MOV   AL,DL                               ;<---Ken Robbins suggestion
OUT   IDEportC,AL                          ;Drive address onto control lines

XOR   AL,AL
OUT   IDEportC,AL                          ;Zero all port C lines
RET

IDEwr8D:                                ;WRITE Data in [DH] to IDE register @ [DL]
MOV   AL,WRITEcfg8255                       ;Set 8255 to write mode
OUT   IDECtrlPort,AL

MOV   AL,DH                               ;Get data put it in 8255 A port
OUT   IDEportA,AL

MOV   AL,DL                               ;select IDE register
OUT   IDEportC,AL

OR    AL,IDEwrline                         ;lower WR line
OUT   IDEportC,AL

MOV   AL,DL                               ;<-- Ken Robbins suggestion, raise WR line
OUT   IDEportC,AL                          ;deassert RD pin

XOR   AL,AL                               ;Deselect all lines including WR line
OUT   IDEportC,AL

MOV   AL,READcfg8255                       ;Config 8255 chip, read mode on return
OUT   IDECtrlPort,AL
RET

IDEwr8D_X:                               ;WRITE Data in [DH] to IDE register @ [DL]
MOV   AL,WRITEcfg8255                       ;Set 8255 to write mode
OUT   IDECtrlPort,AL

MOV   AL,DH                               ;Get data and put it in 8255 >>>> Port B <<<<
OUT   IDEportB,AL

MOV   AL,DL                               ;select IDE register
OUT   IDEportC,AL

OR    AL,IDEwrline                         ;lower WR line
OUT   IDEportC,AL

MOV   AL,DL                               ;<-- Ken Robbins suggestion, raise WR line

```

```

OUT    IDEportC,AL          ;Deassert RD pin

XOR    AL,AL                ;Deselect all lines including WR line
OUT    IDEportC,AL

MOV    AL,READcfg8255       ;Config 8255 chip, read mode on return
OUT    IDECtrlPort,AL
RET

```

```

;*****
;
;   "BIOS" section to allow MS-DOS 4.1 to run on non-IBM hardware.
;   8086 assembly language for the NASM assembler. This is a highly
;   modified version of a BIOS first written by LogiCom Inc back in 1985.
;*****
;
;   The normal interrupts for the IBM, and their entry points
;   in this code are as follows:
;
; Int  Name                BIOS entry
;  0   Divide by zero      DUMMY_RETURN
;  1   Single Step         DUMMY_RETURN
;  2   Non-maskable        NMIINT
;  3   Breakpoint          DUMMY_RETURN
;  4   Overflow            DUMMY_RETURN
;  5   Print Screen        DUMMY_RETURN
;  6   Reserved            DUMMY_RETURN
;  7   Reserved            DUMMY_RETURN
;  8   Timer Tic           TIMER
;  9   Keypressed          KEYHND
;  A   Reserved            DUMMY_RETURN
;  B   Comm Hardware       DUMMY_RETURN
;  C   Comm Hardware       DUMMY_RETURN
;  D   Disk Hardware       DUMMY_RETURN
;  E   Diskette Hardware   DUMMY_RETURN
;  F   Printer Hardware    DUMMY_RETURN
;
; 10   Video Output        CONOUT      (10 through 1F are
; 11   Equipment check     EQUIP       software interrupts)
; 12   Memory Size         MEMSIZ
; 13   Disk I/O            DISKIO      <----- ALL DISK IO (Floppy & HDISK)
; 14   Comm I/O            COMMIO
; 15   Cassette I/O        DUMMY_RETURN
; 16   Keyboard I/O        CONIN
; 17   Printer I/O        LSTOUT
; 18   Basic                DUMMY_RETURN
; 19   Bootstrap           BOOT_DOS_INT
; 1A   Time of Day         TIME_OF_DAY
; 1B   Keyboard Break      DUMMY_RETURN
; 1C   User timer tic      DUMMY_RETURN
; 1D   Video Init.         VIDEO_PARM

```

```

; 1E Diskette Parms    DISK_BASE (Pointer only)
; 1F Graphics Char    0
;
; 40 Copy of Disk/IO  DISKIO (for systems with a HDISK)

IBM_BIOS:
cli                    ;No interrupts yet please
MOV    BX,IBM_SIGNON_MSG ;Announce we are here
CALL   PRINT_STRING     ;Note PRINT_STRING always uses the CS: override for the BX pointer

push   DS
XOR    AX,AX            ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV    DS,AX
mov    byte [DEBUG_FLAG],0 ;Debug mode normally off
POP    DS

CALL   SETUP_IBM_BIOS  ;Initilize RAM and hardware

IBM_LOOP:
CALL   CRLF
MOV    BX,IBM_MENU1    ;Enter start of menu
CALL   PRINT_STRING

XOR    AX,AX            ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV    DS,AX
CMP    byte [DEBUG_FLAG],0 ;Debug mode (normally off)
POP    DS

JNZ    MENU_ON
MOV    BX,IBM_MENU_OFF ;Enter "OFF"
CALL   PRINT_STRING
JMP    IBM_LOOP1

MENU_ON:
MOV    BX,IBM_MENU_ON  ;Enter "ON"
CALL   PRINT_STRING

IBM_LOOP1:
MOV    BX,IBM_MENU2    ;Enter the rest of the menu
CALL   PRINT_STRING

MOV    AX,CS
MOV    DS,AX           ;Just to be safe for below

call   CICO            ;Get a command from Console
mov    ah,0
CMP    AL,ESC          ;Abort if ESC
JNZ    NOT_ESC_IBM
JMP    INIT            ;Back to start of Monitor

NOT_ESC_IBM:
cmp    al,'A'          ;Find meuu option from table
jb     IBM_LOOP        ;must be A to Z
cmp    al,'Z'
jg     IBM_LOOP
sub    al,'A'          ;calculate offset
shl   al,1             ;X 2
add   ax,IBM_TABLE     ;Note DS:=CS: in this monitor by default

```

```

mov     bx,ax
CALL   CRLF
mov     ax,[cs:bx]           ;get location of routine CS:[BX]
call   ax                   ;<----- This is the PC-BIOS Menu CMD call
jmp     IBM_LOOP           ;finished

;----- Initilize RAM and hardware to look like an IBM-PC setup
;XXXX:
;
SETUP_IBM_BIOS:
    mov     ax,cs
    mov     ds,ax           ;DS is this ROM's CS

    sub     ax,ax
    mov     es,ax         ;ES: = 0H in RAM for STOW's below
    CLD                ;Default to direction up

    CALL   SETUP_INT_TABLE      ;Fill all RM 8086 interrupts initially with a default error trapping pointer

    mov     di,PrintScreen      ;Setup PrintScreen vector in low RAM (at 14H)
    mov     ax,PrintScreenRoutine ;Have it point to the relevent return in this monitor
    stosw                ;(ES: used for final location)

    mov     cx,8              ;Set all 8 hardware interrupts for 8259A (at I/O port address 20H)
    mov     si,vec_tbl_8259A   ;Move the pointers in vec_tbl-8259A to low RAM starting at 20H
    mov     di,Start8259A_Ints ;Note DS:(=CS:) is source, ES: is destination
iloop1: movsw
    inc     di                ;Skip over the segment pointer (already done above), to next vector offset
    inc     di
    loop   iloop1

    mov     cx,16             ;Set all 16 software interrupts
    mov     si,vec_tbl_soft_ints
    mov     di,CRTINT
iloop2: movsw
    inc     di                ;Note DS: (=CS:) is source, ES: is destination
    inc     di                ;Skip over the segment pointer (already done above), to next vector offset
    inc     di
    loop   iloop2

    MOV     CX,IVGA_VAL_LEN      ;Some RAM variables need to be initilized for S-100 Lomas CGA Board (@0:449H)
    MOV     SI,INITIAL_VGA_VALUES
    MOV     DI,CRT_MODE        ;0:449H
iloop3: movsw
    loop   iloop3            ;Note DS: (=CS:) is source, ES: is destination
                                ;To be safe, do not use "rep" in case marginal EPROM's cannot handle speed.

    IN     AL,IOBYTE
    TEST   AL,2                ;Bit 1 of IOBYTE Port will force output to CGA/VGA
    JNZ   NO_FORCE_CGA_DISPLAY ;is there a request to switch CRT outputs
    MOV   word [ES:CONSOLE_FLAG],1 ;1= Force console output to CGA/VGA Video Board upon MS_DOS Bootup,
TO_VGA: MOV   BX,VIDIO_VGA_MSG ;Video to VGA
    CALL  PRINT_STRING
    JMP   DONE_SWAP

NO_FORCE_CGA_DISPLAY:

```

```

CMP     word [ES:CONSOL_FLAG],1 ;Already requested by "B" menu main command?
JZ      TO_VGA

CMP     word [ES:CONSOL_FLAG],2 ;Is output already set for LAVA board by "B" menu main command?
JNZ     TO_PROP_BRD ;Not 2, then definately not LAVA

MOV     BX,VIDIO_LAVA_MSG ;Announce we are going to Lava Board. (There is a 1/32K chance RAM had 02H at CONSOL_FLAG at startup)
CALL   PRINT_STRING ;Note PRINT_STRING always uses the CS: override for the BX pointer
JMP    DONE_SWAP

TO_PROP_BRD:
MOV     word [ES:CONSOL_FLAG],0 ;Default, Force Console output to Propeller Video Board if anything else

DONE_SWAP:
;The 496H-490H area needs to be 0's for MS-DOS 4.01
;Clear the whole IBM-AT "extra store area" to 0's
;It seems MSDOS V4.01 counts on at least the diskette area being 0's
;It hangs on a boot otherwise! Count of bytes in the area
mov     cx,(496H-490H)
mov     di,DSK_STATE
xor     AX,AX
i loop4: MOV     [ES:DI],AX ;ES: = 0, is destination
inc     di ;Skip over the segment pointer (already done above), to next vector offset
inc     di
loop   i loop4

;Now a few special case situations...
;Note, in every case ES:=0, is destination segment

MOV     AX,CRT_CHAR_GEN ;7CH, Upper 128 Bytes of 256 Byte character set
mov     DI,EXT_CHAR_PTR ;(1FH*4) (Note no valid table is actully present for 8088/8086 EEPROMS)
stosw

MOV     AX,OLD_DISKIO ;100H, We need to handle software Int 40H (The relocated old INT 13H PC Bios Floppy I/O)
mov     DI,OLD_DISK_VEC ;(40H*4)
stosw

MOV     AX,FDISK_3PARAM_TBL ;We need to move the boot diskette paramater table to Int 1EH*4 area. (Use 1.44M 3" Floppy)
mov     DI,FDISK_PARMS
stosw

MOV     AX,HDISK_PARM_TBL ;104H, Setup the default HARD DISK #1, table POINTER offset
mov     DI,HDISK_PARMS ;(41H*4),
stosw

MOV     AX,CRT_CHAR_GEN ;10CH, 256 Byte character set
mov     DI,EXT_CHAR_PTR2 ;(43H*4)
stosw

MOV     AX,HDISK_PARM_TBL ;118H, Setup the same default HARD DISK #2, table POINTER offset
mov     DI,HDISK2_PARMS ;(46H*4)
stosw ;ES: 0, is destination segment

;Now set up the memory variables
XOR     AX,AX ;Now set DS: (=0) to data area for ROM usage in low RAM @400H

```

```

MOV     DS,AX
mov     word [expram],msize-64           ;show expansion ram size
mov     word [memrsz],msize             ;and total memory size (640K)
mov     word [EQFLAG],0100001001100001B ;set equipment flag so IBM is happy

;bit 0    disk drives present
;bit 1    8087 Present
;bit 2    Mouse present
;bit 3    ----
;bits 4,5 default to colour card
;         00 EGA
;         01 40X25 Color
;         10 80X25 Color
;         11 80X25 Monochrome
;bits 6,7 floppy drives -1 (if bit 0 =1)
;bit 8    DMA support installed (PCjr, Tandy)
;bits 9,10,11 number of serial ports
;bit 12   no game adaptor
;bit 13   serial printer attachd (PCjr)
;bits 14,15 no of printers

mov     ax,keybuff                     ;keyboard interrupt pointers
mov     [bufhd],ax
mov     [buftl],ax
mov     byte [chrcnt],0

mov     byte [VERIFY_FLAG],0 ;Initially set for sector reads (rather than sector verifies)

;Initilize hardware to emulate IBM-PC settings
;Send a signon about initilizing the 8259A
mov     bx,PIC_INIT_MSG
call    PRINT_STRING

mov     al,MasterICW1                 ;Initilize the 8259A PIC Controller
out     MASTER_PIC_PORT,al
mov     al,MasterICW2                 ;Ints starts at 20H in RAM
out     MASTER_PIC_PORT+1,al
mov     al,MasterICW4                 ;No slaves above, so 8259 does not expect ICW3
out     MASTER_PIC_PORT+1,al

mov     al,11111111b                 ;No V0 & V1 for now
out     MASTER_PIC_PORT+1,al

;Initilize the timer
;Sel TIM 0, LSB,MSB,Mode 3
MOV     AL,36H
OUT     TIM_CTL,AL
;Write to Timer mode register (43H)
MOV     AL,0
OUT     TIMER,AL
;LSB = 0
OUT     TIMER,AL
;MSB = 0

;Next move the current time into the system tick bytes in low RAM
;Remember DS: is already set to data area for ROM usage in low RAM (400H)

mov     word [timlow],0               ;Default setup timer/RTC default values
mov     word [timhi],0
mov     word [timofl],0               ;Set clock tick info to 0 in low ram

```

```

MOV     AL,CMOS_VALID           ;Before getting current CMOS time check chip is there and working
OUT     CMOS_PORT,AL
JMP     SHORT $+2              ;Delay
IN      AL,CMOS_PORT+1
SUB     AL,80H                 ;Check bad battery is OK. (Note different from AT. Dallas DS12887 says valid = 80H)
JNZ     TOD_ERROR              ;If Not valid leave timer at 0

SUB     CX,CX
UIP:    MOV     AL,CMOS_REGA
OUT     CMOS_PORT,AL
JMP     SHORT $+2
IN      AL,CMOS_PORT+1
TEST    AL,UPDATE_TIMER
JZ      READ_SECONDS
LOOP    UIP
JMP     TOD_ERROR1             ;CMOS clock "stuck"

READ_SECONDS:
MOV     AL,CMOS_SECONDS
OUT     CMOS_PORT,AL
JMP     SHORT $+2
IN      AL,CMOS_PORT+1

CMP     AL,059H                 ;within range 0-59
JA      TOD_ERROR2

CALL    CVT_BINARY
MOV     BL,COUNTS_SEC
MUL     BL
MOV     CX,AX
MOV     AL,CMOS_MINUTES
OUT     CMOS_PORT,AL
JMP     SHORT $+2
IN      AL,CMOS_PORT+1

CMP     AL,059H                 ;Within range 0-59
JA      TOD_ERROR2

CALL    CVT_BINARY
MOV     BX,COUNTS_MIN           ;1092
MUL     BX
ADD     AX,CX
MOV     CX,AX
MOV     AL,CMOS_HOURS
OUT     CMOS_PORT,AL
JMP     SHORT $+2
IN      AL,CMOS_PORT+1
CMP     AL,023H                 ;0-23
JA      TOD_ERROR2
CALL    CVT_BINARY
MOV     DX,AX
MOV     BL,COUNTS_HOUR         ;7
MUL     BL
ADD     AX,CX
ADC     DX,0000H
mov     [timhi],DX             ;Store in RAM
mov     [timlow],AX

```



```

;      mov     DX,0080H
;      mov     AX,340H
;      mov     [timhi],DX          ;Store in RAM
;      mov     [timlow],AX

      JMP     TOD_DONE

TOD_ERROR:
      MOV     BX,CMOS_CLOCK_MSG    ;Error reading CMOS Clock chip
      CALL   PRINT_STRING
      JMP     TOD_DONE

TOD_ERROR1:
      MOV     BX,CMOS_STUCK_MSG    ;Error reading CMOS Clock chip
      CALL   PRINT_STRING
      JMP     TOD_DONE

TOD_ERROR2:
      MOV     BX,CMOS_RANGE_MSG    ;Error reading CMOS Clock chip
      CALL   PRINT_STRING
      JMP     TOD_DONE

TOD_DONE:
      CLI
      IN      AL,MASTER_PIC_PORT+1 ;Allow timer tick
      AND    AL,0FEH
      OUT    MASTER_PIC_PORT+1,AL
      STI

INIT_VGA:                                ;We will try and initilize the CGA/VGA video board RAM area/ports anyway (even if not used)
      MOV     AX,0B800H              ;Segment of CGA Board RAM
      mov     di,[EQFLAG]
      and     di,30h                ;Isolate crt switches (This is what IBM PC has - not used here!)
                                      ;bits 4,5 default to colour card
                                      ;      00 EGA
                                      ;      01 40X25 Color
                                      ;      10 80X25 Color
                                      ;      11 80X25 Monochrome

      cmp     di,30h
      jne     INIT_VGA1
      mov     ax,0B000h              ;Segment for Monochrome card

INIT_VGA1:
      mov     es,ax                  ;Set ES: to point to video area
      MOV     AL,03H                ;Default to 80X25 Color
      MOV     DI,0                  ;CGA/VGA Board. If B/W card then DI = 30H

      CALL   VGA_INIT               ;<<<<<< Initilize the video board to 80X25 >>>>>>
                                      ;This seem OK because IBM-CGA board comes up fine with the
                                      ;ISA->S100 Adaptor board. Also the Lomas S-100 CGA board comes up fine.

      MOV     AH,0H                 ;Initilize Serial Port (Used for debugging display if required)
      MOV     AL,80H                ;This sets for 9600 Baud. (However we will run at 38,400, see INT 14H)
      MOV     DX,0
      int     14H                   ;Serial out Handler (Software Interrupt 14H)

```

```

IN      AL,IOBYTE      ;Allow IOBYTE to abort initilizing extra ROMS starting at C0000H
TEST    AL,4
JNZ     VGA_ROM_CHECK ;<<< Check for VGA ROM at C000:0000H >>>
RET     ;Else skip/ignore looking for a VGA ROM

;Next, check if the is an extra ROM's/Software on board. This follows the IBM
;format by looking at C0000H-F6000H (on 2K pages) for 55H,AAH and (length/512)
;in the 3rd byte. (Note this BIOS is larger, should stop at D0000H)
;We will just force initilization of the one VGA ROM if present, at C0000H
;Can add more if required later.

VGA_ROM_CHECK:
;If a valid "ROM" then we do a Call Far to byte 3 in that ROM/Code.
;It assumes that the code there will finish with a far return.
MOV     DX,0C000H      ;Will just look for Video ROM, so start at C0000H
MOV     DS,DX          ;DS=C000H
SUB     BX,BX
MOV     AX,[BX]        ;[DS:BX] C000:0H
CMP     AX,0AA55H      ;Is the indicator flag there
JNZ     NO_ROM

MOV     BX,ROMCHECK_MSG ;Announce we found a ROM at C000:0H
CALL    PRINT_STRING   ;Remember PRINT_STRING always uses the CS: override for the BX pointer
;so no need to mess with DS

MOV     AX,40H         ;Set ES=DSEG
MOV     ES,AX          ;ES=40H
PUSH    DX             ;Set things up just like IBM did (Just in case)!
MOV     word [ES:IO_ROM_INIT],0003H ;Offset @ 467H
MOV     [ES:IO_ROM_SEG],DS ;Load segment @ 469H

CALL    0C000H:0003H  ;<<< Initilize EGA/VGA ROM >>>>
;Note we assume there are no other extra ROM's

PUSH    AX             ;Just in case values are needed
PUSH    BX
MOV     BX,ROMCHECK_MSG_OK ;VGA ROM Initilized, returned back to BIOS.
CALL    PRINT_STRING  ;Note PRINT_STRING always uses the CS: override for the BX pointer
POP     BX
POP     AX

POP     DX             ;From above

mov     ax,40h         ;Test for EGA/VGA
mov     es,ax
mov     ah,12h
mov     bx,0FF10h
int     10h           ;Video Get EGA Info
cmp     BH,0FFh      ;If EGA or later present BH != FFh
je      not_ega
and     byte[es:EQFLAG],11001111b ;Set video flag in equipment list to EGA/VGA
;bits 4,5 default to colour card
;          00 EGA
;          01 40X25 Color
;          10 80X25 Color
;          11 80X25 Monochrome

not_ega:

```

```

mov     ah,1
mov     ch,0F0h
int     10h                ;Set cursor type
call    clear_screen      ;clear display
push    cs
pop     ds
RET

```

```

NO_ROM:
MOV     BX,NO_VGA_MSG      ;Announce no VGA ROM present
CALL    PRINT_STRING      ;Note PRINT_STRING always uses the CS: override for the BX pointer
RET

```

```

clear_screen:
mov     dx,184Fh          ; Lower right corner of scroll
xor     cx,cx             ; Upper left corner of scroll
mov     ax,600h           ; Blank entire window
mov     bh,7              ; Set regular cursor
int     10h              ; Call video service scroll
mov     ah,2              ; Set cursor position
xor     dx,dx             ; upper left corner
mov     bh,0              ; page 0
int     10h              ; call video service
mov     ax,0500h         ; Set active display page zero
int     10h
ret

```

```

CVT_BINARY:                ;Convert BCD in [AL] to Binary in [AL]
PUSH    CX
PUSH    AX
AND     AX,0FH
MOV     CX,AX              ;Save low digit
POP     AX
PUSH    CX                ;On Stack
MOV     CL,4
ROR     AX,CL
AND     AL,0FH

MOV     CL,10
MUL    CL

POP     CX
ADD     AX,CX              ;Add in low digit
POP     CX
RET

```

```

;----- Menu CMD to Boot MS-DOS from a Floppy Disk using this BIOS

```

```

MMENU_FBOOT_DOS:          ;Come here from main menu. Debug mode ALWAYS off
push    DS
PUSH    AX
XOR     AX,AX              ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV     DS,AX

```



```

Next_Key:
    MOV     BX,IN_CHAR_MSG      ;Input character =
    CALL   PRINT_STRING

Next_Key1:
    MOV     AH,01H              ;Check if anything there
    int    16H                  ;Get Keyboard status. Console Input Handler (Software Interrupt 16H)
    JZ     Next_Key1

    MOV     AH,0H              ;Get actual character from buffer
    int    16H                  ;Get Character. Console Input Handler (Software Interrupt 16H)

    CMP     AL,ESC
    JZ     Key_Done
;   MOV     CL,AL
;   CALL   CO                    ;Send direct to Console
;   CALL   AL_HEXOUT             ;Display the hex character recieved
    MOV     BX,GOT_CHAR_MSG     ;Recieved character =
    CALL   PRINT_STRING
    JMP     Next_Key

Key_Done:
    mov     al,11111111b        ;Do not Allow V1 on 8259A again
    out    MASTER_PIC_PORT+1,al
    cli                    ;Turn hardware int's back off
    JMP     IBM_BIOS

;----- Menu CMD to test Console out code using this BIOS

MENU_CO_TEST:
    MOV     BX,CO_TEST_MSG      ;Keyboard test
    CALL   PRINT_STRING

Next_CO:MOV     BX,IN_CHAR_MSG      ;Input character =
    CALL   PRINT_STRING
    CALL   CI                    ;Return the char in AL
    CMP     AL,ESC
    JZ     CO_Done
    PUSH   AX
    MOV     CL,AL
    CALL   CO
    MOV     BX,OUT_CHAR_MSG      ;"<---- Character recieved",CR,LF, Char displayed via Int 10H ="
    CALL   PRINT_STRING
    POP    AX

    MOV     AH,0EH              ;AH=0EH = TTY output, char in AL
    int    10H                  ;Console out Handler (Software Interrupt 10H)

    CALL   CRLF
    JMP     Next_CO

CO_Done:
    cli                    ;Turn hardware int's back off
    JMP     IBM_BIOS

```

;----- Menu CMD to test combined key-in / video out using this BIOS

MENU_BUFF_IO:

```
MOV  BX,BUFF_TEST_MSG      ;Keyboard buffer test
CALL PRINT_STRING

mov  al,11111101b          ;Allow V1 on 8259A now
out  MASTER_PIC_PORT+1,al

sti                                     ;Enable hardware interrupts
```

Next_CI:

```
MOV  AH,01H                ;Check if anything there
int  16H                   ;Get Keyboard status. Console Input Handler (Software Interrupt 16H)
JZ   Next_CI

MOV  AH,0H                 ;Get actual character from buffer to AL
int  16H                   ;Get Character. Console Input Handler (Software Interrupt 16H)

CMP  AL,ESC
JZ   CO_Done

MOV  AH,0EH                ;AH=0EH = TTY output, char in AL
int  10H                   ;Console out Handler (Software Interrupt 10H)
JMP  Next_CI
```

;----- Menu CMD to test Serial Port character output using this BIOS to a serial terminal
; Make sure you have the Baud rate is the same on both ends. (We will leave it at 38,4000 Baud)

MENU_SIO_TEST:

```
MOV  BX,SIO_TEST_MSG      ;Output to Serial port test
CALL PRINT_STRING

MOV  AH,0H                ;AH=0 Initilize Port
MOV  AL,80H               ;This sets for 9600 Baud. However we will run at 38,400 (see INT 14H)
MOV  DX,0

int  14H                  ;Serial out Handler (Software Interrupt 14H)

OR   AH,AH                ;Any errors
JZ   Next_SIO

PUSH AX
MOV  BX,SIO_INIT_ERR      ;Error initilizing Serial port
CALL PRINT_STRING
POP  AX
MOV  AL,AH
CALL AL_HEXOUT
MOV  BX,H_MSG_CRLF
CALL PRINT_STRING
JMP  IBM_BIOS
```

```

Next_SIO:
    CALL    CI                ;Return the char in AL
    CMP    AL,ESC
    JZ     SIO_DoneTest

    PUSH   AX
    MOV    CL,AL
    CALL   CO
    POP    AX

    MOV    AH,01H            ;AH=char output, char in AL
    MOV    DX,0

    int    14H              ;Serial out Handler   (Software Interrupt 14H)

    OR     AH,AH            ;Any errors
    JZ     Next_SIO
    PUSH   AX
    MOV    BX,SIO_ERR       ;Error sending to Serial port
    CALL   PRINT_STRING
    POP    AX
    MOV    AL,AH
    CALL   AL_HEXOUT
    MOV    BX,H_MSG_CRLF
    CALL   PRINT_STRING
    JMP    IBM_BIOS

SIO_DoneTest:
    JMP    IBM_BIOS

;----- Menu CMD to test Timer code using this BIOS

MENU_TIMER_TEST:
    MOV    BX,TIMER_TEST_MSG ;Timer test
    CALL   PRINT_STRING

    mov    al,11111110b      ;Allow V0 on 8259A now
    out    MASTER_PIC_PORT+1,al

    sti                    ;Enable hardware interrupts

Next_Timer:
    MOV    BX,TIMER_DATA_MSG ;Get Timer values
    CALL   PRINT_STRING

    CALL   CI                ;Return the char in AL
    CMP    AL,ESC
    JZ     Timer_Done

    MOV    BX,TIMER_LOW_MSG  ;timlow =
    CALL   PRINT_STRING
    PUSH   DS
    XOR    AX,AX            ;Set DS to data area for ROM usage in low RAM @ 400H....)

```

```

MOV     DS,AX
mov     AX,[timlow]
CALL    AX_HEXOUT

MOV     BX,TIMER_HIGH_MSG      ;timhi =
CALL    PRINT_STRING
mov     AX,[timhi]
CALL    AX_HEXOUT

MOV     BX,TIMER_OFLOW_MSG     ;timofl =
CALL    PRINT_STRING
mov     AX,[timofl]
CALL    AX_HEXOUT
MOV     BX,H_Msg                ;"H$"
CALL    PRINT_STRING
POP     DS
JMP     Next_Timer

Timer_Done:
mov     al,11111111b           ;Do not Allow V0 on 8259A again
out     MASTER_PIC_PORT+1,al
cli     ;Turn hardware int's back off
JMP     IBM_BIOS

;----- Menu CMD to test Floppy Disk (5") sequential sector reads using this BIOS
; Will read sequentially up to 9 X 512 byte sectors from 5" DDDS 360K floppy (9 Sec/Track)
; into RAM using the ZFDC controller board. (IBM says never more than
; 9 sectors at a time for this type of disk, actually never changes the track #, but the
; ZFDC can handle this if it did anyway!)
; Will always read into RAM starting at 500H using the ZFDC controller board

FSEQ_5RD_TEST:
PUSH    DS                    ;Save Monitor current DS
XOR     AX,AX                 ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV     DS,AX

MOV     BX,SEC_5RD_MSG        ;Say Reading sectors
CALL    PRINT_STRING

MOV     AL,0H                 ;Flag to indicate ZFDC board is NOT Initilized
MOV     [ZFDC_INIT_FLAG],AL   ;DS is already set for low RAM area

CALL    INIT_ZFDC              ;Initilize the ZFDC board hardware

CMP     byte [ZFDC_INIT_FLAG],0FFH ;Is Board initilized correctly
JZ     ZFDC_5OK1
POP     DS                    ;Balance up Monitor stack
JMP     IBM_BIOS

ZFDC_5OK1:
mov     dl,01H                ;Drive 1, side A
mov     ah,0H

int     13h                   ;AH=0, reset floppy disk system

JNC     RESET_5OK1

```



```

MOV     BX,RESET_FAIL_MSG
CALL   PRINT_STRING
POP     DS                ;Balance up stack
JMP     IBM_BIOS

RESET_50K1:
MOV     BX,SIDE_REQUEST_MSG
CALL   PRINT_STRING
call   CICO                ;Get a command from Console
PUSH   AX
MOV     BX,CRLFMSG         ;"CR,LF"
CALL   PRINT_STRING
POP     AX
CMP     AL,'B'
JZ     B5_SIDE
MOV     BX,SIDE_A_SET_MSG
CALL   PRINT_STRING
MOV     DX,0001H          ;Side A (DL bit 7 = 0 so Floppy disk)
JMP    OVER5_SIDE
B5_SIDE:MOV BX,SIDE_B_SET_MSG
CALL   PRINT_STRING
MOV     DX,0101H          ;Side B, Disk 1 (ZFDC #2)

OVER5_SIDE:
PUSH   DX                ;Save side info for below

MOV     BX,ENTERRAM_FTRKL  ;"Track number,(xxH)"
CALL   PRINT_STRING
CALL   GET2DIGITS         ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
MOV     CH,AL
PUSH   CX                ;Save for below
MOV     BX,H_MSG_CRLF     ;"H CR,LF"
CALL   PRINT_STRING

MOV     BX,ENTERRAM_SECL  ;"Starting sector number,(xxH) = "
CALL   PRINT_STRING
CALL   GET2DIGITS         ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
POP     CX
MOV     CL,AL
PUSH   CX                ;Save Track & Sec for below
MOV     BX,H_MSG_CRLF     ;"H CR,LF"
CALL   PRINT_STRING

SEQ_50K4:
MOV     BX,ENTER_COUNT    ;Enter # of sectors
CALL   PRINT_STRING
CALL   GET2DIGITS         ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
CMP     AL,09
JBE    S50K3
S50K5: MOV BX,OVER_COUNT_10
CALL   PRINT_STRING
JMP    SEQ_50K4           ;Try again
S50K3: OR  AL,AL
JZ     S50K5

```

```

PUSH  AX                ;Save sector count (already in AL)
MOV   BX,H_MSG_CRLF    ;"H CR,LF"
CALL  PRINT_STRING

SUB   AX,AX
MOV   ES,AX
MOV   BX,500H          ;Will always dump data to 0000:500H
POP   AX
POP   CX                ;Track, Sec
POP   DX                ;Side & Drive 0
mov   ah,02h           ;Read x sectors (IBM has a max of 15 sectors/call fot IBM-AT)
                                ;on a 1.2M Floppy disk in their IBM PC-AT Bios. I assume 18 for 1.44 Disk)
                                ;(This is where MS-DOS loads MSDOS.SYS from on disk)
                                ;AH=2, CX=0001, read 6 byte sectors -- as in early MSDOS systems!

int   13H

JNC   SEQ_5OK1         ;If NC then no errors
MOV   BX,SQRD5FAILMSG
CALL  PRINT_STRING
POP   DS                ;Balance up Monitor stack
JMP   IBM_BIOS         ;Will return back up to start of Monitor

SEQ_5OK1:
MOV   BX,SQRD5OKMSG
CALL  PRINT_STRING

MOV   CX,16            ;Display the first 16 bytes at ES:BX in RAM
SUB   AX,AX
MOV   ES,AX
MOV   BX,500H          ;Will always dump data to 0000:500H

CALL  SIMPLE_SECTOR_DUMP ;Dump first CX bytes of sector data at ES:BX on CRT
POP   DS                ;Balance up stack
JMP   IBM_BIOS         ;All done

;----- Menu CMD to test Floppy Disk (3") sequential sector reads using this BIOS
; Will read sequentially 18 X 512 byte sectors from 3" DDDS 1.44M floppy (18 Sec/Track)
; into RAM using the ZFDC controller board. (IBM says never more than
; 18 sectors at a time for this type of disk)
; Will always read into RAM starting at 500H using the ZFDC controller board

FSEQ_3RD_TEST:
PUSH  DS                ;Save Monitor current DS
XOR   AX,AX            ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV   DS,AX

MOV   BX,SEC_3RD_MSG   ;Say Reading sectors
CALL  PRINT_STRING

MOV   AL,0H            ;Flag to indicate ZFDC board is NOT Initilized
MOV   [ZFDC_INIT_FLAG],AL ;DS is already set for low RAM area

CALL  INIT_ZFDC         ;Initilize the ZFDC board hardware

CMP   byte [ZFDC_INIT_FLAG],0FFH ;Is Board initilized correctly
JZ    ZFDC_3OK1

```

```

        POP     DS                ;Balance up stack
        JMP     IBM_BIOS

ZFDC_3OK1:
        mov     dl,0H            ;Drive 0, side A
        mov     ah,0H

        int     13H             ;AH=0, reset floppy disk system

        JNC     RESET_3OK1
        MOV     BX,RESET_FAIL_MSG
        CALL    PRINT_STRING
        POP     DS                ;Balance up stack
        JMP     IBM_BIOS

RESET_3OK1:
        MOV     BX,SIDE_REQUEST_MSG
        CALL    PRINT_STRING
        call    CICO              ;Get a command from Console
        PUSH   AX
        MOV     BX,CRLFMSG        ;"CR,LF"
        CALL    PRINT_STRING
        POP     AX
        CMP     AL,'B'
        JZ     B3_SIDE
        MOV     BX,SIDE_A_SET_MSG
        CALL    PRINT_STRING
        MOV     DX,0000H         ;Side A (DL bit 7 = 0 so Floppy disk)
        JMP     OVER3_SIDE
B3_SIDE:MOV     BX,SIDE_B_SET_MSG
        CALL    PRINT_STRING
        MOV     DX,0100H         ;Side B, Disk 0

OVER3_SIDE:
        PUSH   DX                ;Save side for below

        MOV     BX,ENTERRAM_FTRKL ;"Track number,(xxH)"
        CALL    PRINT_STRING
        CALL    GET2DIGITS        ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
        MOV     CH,AL
        PUSH   CX                ;Save for below
        MOV     BX,H_MSG_CRLF    ;"H CR,LF"
        CALL    PRINT_STRING

        MOV     BX,ENTERRAM_SECL ;"Starting sector number,(xxH) = "
        CALL    PRINT_STRING
        CALL    GET2DIGITS        ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
        POP     CX
        MOV     CL,AL
        PUSH   CX                ;Save Track & Sec for below
        MOV     BX,H_MSG_CRLF    ;"H CR,LF"
        CALL    PRINT_STRING

SEQ_3OK4:
        MOV     BX,ENTER_COUNT   ;Enter # of sectors

```

```

CALL PRINT_STRING
CALL GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
CMP AL,18
JBE S30K3
S30K5: MOV BX,OVER_COUNT_19
CALL PRINT_STRING
JMP SEQ_30K4              ;Try again
S30K3: OR AL,AL
JZ S30K5

PUSH AX                   ;Save sector count (already in AL)
MOV BX,H_MSG_CRLF        ;"H CR,LF"
CALL PRINT_STRING

SUB AX,AX
MOV ES,AX
MOV BX,500H              ;Will always dump data to 0000:500H
POP AX
POP CX                   ;Track, Sec
POP DX                   ;Side & Drive 0
mov ah,02h               ;Read x sectors (IBM has a max of 15 sectors/call fot IBM-AT)
                           ;on a 1.2M Floppy disk in their IBM PC-AT Bios. I assume 18 for 1.44 Disk)
                           ;(This is where MS-DOS loads MSDOS.SYS from on disk)
                           ;AH=2, CX=0001, read 6 byte sectors -- as in early MSDOS systems!

int 13H

JNC SEQ_30K1              ;If NC then no errors
MOV BX,SQRD5FAILMSG
CALL PRINT_STRING
POP DS                   ;Balance up stack
JMP IBM_BIOS             ;Will return back up to start of Monitor

SEQ_30K1:
MOV BX,SQRD30KMSG        ;Read sectors from 3" 1.44M Floppy disk OK
CALL PRINT_STRING

MOV CX,16                 ;Display the first 16 bytes at ES:BX in RAM
SUB AX,AX
MOV ES,AX
MOV BX,500H              ;Will always dump data to 0000:500H

CALL SIMPLE_SECTOR_DUMP  ;Dump first CX bytes of sector data at ES:BX on CRT
POP DS                   ;Balance up stack
JMP IBM_BIOS             ;All done

;----- Menu CMD to test HDISK sequential sector READ's using this BIOS
; Will read 512 byte sectors from 2nd IDE CF-Card
; into RAM starting at 500H using the IDE controller board
HSEQ_RD_TEST:
PUSH DS                   ;Save Monitor current DS
XOR AX,AX                 ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV DS,AX

MOV BX,SEC_HDRD_MSG      ;Say Reading sectors
CALL PRINT_STRING

```

```

MOV     BX,ONE_MOMENT_MSG      ;One moment while IDE disk is being initilized
CALL   PRINT_STRING

CALL   SET_DRIVE_B           ;Select the second Drive/CF card
CALL   IDEinit               ;Initialize drive 1. If there is no drive abort
JZ     HSEQ_RD1

MOV     BX,INIT_2_ERROR        ;Warn second IDE drive did not initilize
CALL   PRINT_STRING
POP     DS                    ;From above at start
JMP    IBM_BIOS              ;Will return back up to start of Monitor

HSEQ_RD1:
  mov   dl,80H                ;Hard Disk
  mov   ah,0H
  int   13h                  ;AH=0, reset floppy disk system

  JNC   HRESET_OK1
  MOV   BX,HRESET_FAIL_MSG    ;"Reset of HDisk Failed"
  CALL  PRINT_STRING
  POP   DS                    ;From above at start
  JMP   IBM_BIOS              ;Will return back up to start of Monitor

HRESET_OK1:
  XOR   AX,AX                 ;Set DS to data area for ROM usage in low RAM @ 400H....)
  MOV   DS,AX

  MOV   BX,HRESET_OK_MSG      ;"Reset of HDisk OK"
  CALL  PRINT_STRING

AGAIN:  MOV   BX,ENTERRAM_HEAD  ;"Starting HEAD number, (xxH) = "
  CALL  PRINT_STRING
  CALL  GET2DIGITS             ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
  AND   AL,0FH
  MOV   [CURRENT_HEAD],AL
  MOV   BX,H_MSG_CRLF         ;"H CR,LF"
  CALL  PRINT_STRING

  MOV   BX,ENTERRAM_FTRKL     ;"Track number, (xxH) "
  CALL  PRINT_STRING
  CALL  GET2DIGITS             ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
  MOV   [CURRENT_TRACK],AL
  MOV   BX,H_MSG_CRLF         ;"H CR,LF"
  CALL  PRINT_STRING

  MOV   BX,ENTERRAM_SECL     ;"Starting sector number, (xxH) = "
  CALL  PRINT_STRING
  CALL  GET2DIGITS             ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
  AND   AL,00111111B
  MOV   [CURRENT_SECTOR],AL
  MOV   BX,H_MSG_CRLF         ;"H CR,LF"
  CALL  PRINT_STRING

  MOV   BX,ENTER_COUNT        ;Enter # of sectors
  CALL  PRINT_STRING

```

```

CALL    GET2DIGITS           ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
MOV     [SECTORS_TO_DO],AL
MOV     BX,H_MSG_CRLF       ;"H CR,LF"
CALL    PRINT_STRING

MOV     BX,LOOP_ESC_MSG     ;"Will continuously loop until ESC to abort "
CALL    PRINT_STRING
CALL    CI                   ;Wait for CR to start
CMP     AL,CR
JZ      XSEQ_5OK4
POP     DS                   ;From above at start
JMP     IBM_BIOS            ;Will return back up to start of Monitor

XSEQ_5OK4:
SUB     AX,AX
MOV     ES,AX
MOV     DS,AX
MOV     BX,500H             ;Will always dump data to 0000:500H

MOV     AH,02               ;Read sector(s)
MOV     AL,[SECTORS_TO_DO]
MOV     CH,[CURRENT_TRACK]
MOV     CL,[CURRENT_SECTOR]
MOV     DH,[CURRENT_HEAD]
MOV     DL,80H

INT     13H                 ;Disk I/O Int

JNC     READ_OK
JMP     RD_ERROR

READ_OK:
MOV     BX,SEC_READ_OK     ;Sector(s) read OK
CALL    PRINT_STRING

MOV     CX,16               ;Display the first 16 bytes at ES:BX in RAM
SUB     AX,AX
MOV     ES,AX
MOV     DS,AX               ;Just to be safe below also
MOV     BX,500H            ;Will always dump data to 0000:500H

CALL    SIMPLE_SECTOR_DUMP ;Dump first CX bytes of sector data at ES:BX on CRT

CALL    CSTS                ;Any keyboard character will stop display
JZ      HSEC_R7
CALL    CI
MOV     BX,CONTINUE_MSG
CALL    PRINT_STRING
CALL    CI
CMP     AL,ESC
JZ      IBM_BIOS1

HSEC_R7:
CALL    CRLF
MOV     CL,[CURRENT_SECTOR]
INC     CL
CMP     CL,DOS_MAXSEC      ;1-63 Sectors for custom Drive
JLE     R_SAME_HEAD

```

```

MOV     DH, [CURRENT_HEAD]
INC     DH
CMP     DH, DOS_MAXHEADS-1      ;(0...15), 16 heads Total for custom Drive
JLE     R_SAME_TRACK
MOV     byte [CURRENT_SECTOR],1 ;Back to sector 1
MOV     byte [CURRENT_HEAD],0  ;back to head 0
MOV     CH, [CURRENT_TRACK]    ;Next track
INC     CH
MOV     [CURRENT_TRACK], CH
JMP     XSEQ_50K4              ;Do next sector block

R_SAME_TRACK:
MOV     byte [CURRENT_SECTOR],1 ;Back to sector 1
MOV     [CURRENT_HEAD], DH     ;Next head
JMP     XSEQ_50K4              ;Do next sector block

R_SAME_HEAD:
MOV     [CURRENT_SECTOR], CL
JMP     XSEQ_50K4              ;Do next sector block

IBM_BIOS1:
POP     DS
JMP     IBM_BIOS

RD_ERROR:
MOV     BX, RD_ERR_MSG          ;"Read Error Sector Head ="
CALL    PRINT_STRING
MOV     AL, [CURRENT_HEAD]
CALL    AL_HEXOUT
MOV     BX, TRACK_MSG           ;"H Track ="
CALL    PRINT_STRING
MOV     AL, [CURRENT_TRACK]
CALL    AL_HEXOUT
MOV     BX, SEC_MSG             ;"H Sector ="
CALL    PRINT_STRING
MOV     AL, [CURRENT_SECTOR]
CALL    AL_HEXOUT
MOV     BX, H_MSG_CRLF          ;"H CR,LF"
CALL    PRINT_STRING
POP     DS                      ;Balance up stack
JMP     IBM_BIOS

;----- IBM Menu CMD to check Sector R/W functions on IDE Board using INT 13H.

HSEC_RW_TEST:
PUSH    DS
MOV     BX, HRW_TEST_MSG        ;Test Sector INT 13H Reade Write on Drive #2
CALL    PRINT_STRING

CALL    CICO
CMP     AL, 'Y'
JZ      HSEC_RW0
POP     DS                      ;Balance up stack

```

```

        JMP     IBM_BIOS

HSEC_RW0:
MOV     BX,ONE_MOMENT_MSG      ;One moment while IDE disk is being initilized
CALL   PRINT_STRING

        CALL   SET_DRIVE_B      ;Select the second Drive/CF card
CALL   IDEinit                 ;Initialize drive 1. If there is no drive abort
JZ     HSEC_RW1

MOV     BX,INIT_2_ERROR        ;Warn second IDE drive did not initilize
CALL   PRINT_STRING
POP     DS                     ;Balance up stack
JMP     IBM_BIOS

HSEC_RW1:
mov     dl,80H                 ;Reset Hard Disk
mov     ah,0H
int     13h                   ;AH=0, reset floppy disk system

JNC     HSEC_RW2
MOV     BX,HRESET_FAIL_MSG    ;"Reset of HDisk Failed"
CALL   PRINT_STRING
POP     DS                     ;From above at start
JMP     IBM_BIOS              ;Will return back up to start of Monitor

HSEC_RW2:
XOR     AX,AX                  ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV     DS,AX

MOV     BX,HRESET_OK_MSG     ;"Reset of HDisk OK"
CALL   PRINT_STRING

HSEC_RW3:
MOV     BX,ENTERRAM_HEAD      ;"Starting HEAD number, (xxH) = "
CALL   PRINT_STRING
CALL   GET2DIGITS             ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
AND     AL,0FH
MOV     [CURRENT_HEAD],AL
MOV     BX,H_MSG_CRLF        ;"H CR,LF"
CALL   PRINT_STRING

MOV     BX,ENTERRAM_FTRKL     ;"Track number, (xxH) "
CALL   PRINT_STRING
CALL   GET2DIGITS             ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
MOV     [CURRENT_TRACK],AL
MOV     BX,H_MSG_CRLF        ;"H CR,LF"
CALL   PRINT_STRING

MOV     BX,ENTERRAM_SECL     ;"Starting sector number, (xxH) = "
CALL   PRINT_STRING
CALL   GET2DIGITS             ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
AND     AL,00111111B
MOV     [CURRENT_SECTOR],AL
MOV     BX,H_MSG_CRLF        ;"H CR,LF"
CALL   PRINT_STRING

```



```

MOV     BX,ENTER_COUNT           ;Enter # of sectors
CALL    PRINT_STRING
CALL    GET2DIGITS               ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
MOV     [SECTORS_TO_DO],AL
MOV     BX,H_MSG_CRLF           ;"H CR,LF"
CALL    PRINT_STRING

MOV     BX,LOOP_ESC_MSG         ;"Will continously loop until ESC to abort "
CALL    PRINT_STRING
CALL    CI                       ;Wait for CR to start
CMP     AL,CR
JZ      HSEC_RW4
POP     DS                       ;From above at start
JMP     IBM_BIOS                 ;Will return back up to start of Monitor

HSEC_RW4:
SUB     AX,AX
MOV     ES,AX
MOV     DS,AX                   ;just in case
MOV     BX,500H                 ;Will always dump data to 0000:500H

MOV     AH,02                   ;Read sector(s)
MOV     AL,[SECTORS_TO_DO]
MOV     CH,[CURRENT_TRACK]
MOV     CL,[CURRENT_SECTOR]
MOV     DH,[CURRENT_HEAD]
MOV     DL,80H

INT     13H                     ;Disk I/O Int

JNC     HSEC_RW5
JMP     RD_ERROR

HSEC_RW5:
MOV     CX,16                   ;Display the first 16 bytes at ES:BX in RAM
SUB     AX,AX
MOV     ES,AX
MOV     DS,AX                   ;Just in case
MOV     BX,500H                 ;Will always dump data to 0000:500H

CALL    SIMPLE_SECTOR_DUMP      ;Dump first CX bytes of sector data at ES:BX on CRT

SUB     AX,AX                   ;Now WRITE the secti=or back
MOV     ES,AX
MOV     DS,AX                   ;just in case
MOV     BX,500H                 ;Will always dump data to 0000:500H

MOV     AH,03                   ;Write sector(s)
MOV     AL,[SECTORS_TO_DO]
MOV     CH,[CURRENT_TRACK]
MOV     CL,[CURRENT_SECTOR]
MOV     DH,[CURRENT_HEAD]
MOV     DL,80H

INT     13H                     ;Write sector(s)

```

```

JNC     HSEC_RW6
JMP     WR_ERROR

HSEC_RW6:
MOV     BX,SEC_BACK_OK           ;Sector(s) written BACK OK
CALL    PRINT_STRING

CALL    CSTS                     ;Any keyboard character will stop display
JZ      HSEC_RW7
CALL    CI
MOV     BX,CONTINUE_MSG
CALL    PRINT_STRING
CALL    CI
CMP     AL,ESC
JZ      IBM_BIOS2

HSEC_RW7:
CALL    CRLF
MOV     CL,[CURRENT_SECTOR]
INC     CL
CMP     CL,DOS_MAXSEC           ;1-63 Sectors for custom Drive
JLE     WR_SAME_HEAD
MOV     DH,[CURRENT_HEAD]
INC     DH
CMP     DH,DOS_MAXHEADS-1       ;(0...15), 16 heads Total for custom Drive
JLE     WR_SAME_TRACK
MOV     byte [CURRENT_SECTOR],1 ;Back to sector 1
MOV     byte [CURRENT_HEAD],0   ;back to head 0
MOV     CH,[CURRENT_TRACK]      ;Next track
INC     CH
MOV     [CURRENT_TRACK],CH
JMP     HSEC_RW4               ;Do next sector block

WR_SAME_TRACK:
MOV     byte [CURRENT_SECTOR],1 ;Back to sector 1
MOV     [CURRENT_HEAD],DH       ;Next head
JMP     HSEC_RW4               ;Do next sector block

WR_SAME_HEAD:
MOV     [CURRENT_SECTOR],CL
JMP     HSEC_RW4               ;Do next sector block

IBM_BIOS2:
POP     DS
JMP     IBM_BIOS

WR_ERROR:
MOV     BX,WR_ERR_MSG           ;"Write Error Sector Head ="
CALL    PRINT_STRING
MOV     AL,[CURRENT_HEAD]
CALL    AL_HEXOUT
MOV     BX,TRACK_MSG           ;"H Track ="
CALL    PRINT_STRING
MOV     AL,[CURRENT_TRACK]
CALL    AL_HEXOUT

```

```

MOV     BX,SEC_MSG           ;"H Sector ="
CALL   PRINT_STRING
MOV     AL,[CURRENT_SECTOR]
CALL   AL_HEXOUT
MOV     BX,H_MSG_CRLF       ;"H CR,LF"
CALL   PRINT_STRING
POP     DS                   ;Balance up stack
JMP     IBM_BIOS

```

```

;----- IBM Menu CMD to check HEX display / LBA selection on IDE Board.
;          Should show High Cylinder, Low Cylinder and Sector # in Hex Display on IDE Board

```

LBA_DISPLAY_TEST:

```

MOV     BX,LBA_TEST_MSG     ;Test LBA on Drive #2
CALL   PRINT_STRING

CALL   SET_DRIVE_B         ;Select the second Drive/CF card
CALL   IDEinit             ;Initialize drive 1. If there is no drive abort
JZ     LBA_002

MOV     BX,INIT_2_ERROR     ;Warn second IDE drive did not initialize
CALL   PRINT_STRING
POP     DS
JMP     IBM_BIOS

```

LBA_002:

```

CALL   CRLF
MOV     DH,11100000B        ;<<<< Set to LBA mode, head 0
MOV     DL,REGshd           ;Send "Head #" (in DH)
CALL   IDEwr8D             ;Write to 8255 A Register

MOV     BX,TRKH_NUM         ;Enter High byte track number
CALL   PRINT_STRING
CALL   GET2DIGITS          ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
MOV     DH,AL
MOV     DL,REGcylinderMSB
CALL   IDEwr8D             ;Send High TRK# (in DH)
CALL   IDEwr8D_X           ;Special write to 8255 B Register (Not A) to update LED HEX Display
;High 8 bits ignored by IDE drive

MOV     BX,TRKL_NUM         ;"Low Track number, (xxH) "
CALL   PRINT_STRING
CALL   GET2DIGITS          ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
MOV     DH,AL              ;Get low Track #
MOV     DL,REGcylinderLSB
CALL   IDEwr8D             ;Send Low TRK# (in DH)
CALL   IDEwr8D             ;Special write to 8255 A

MOV     BX,SECTOR_NUM      ;"Sector number, (xxH) = "
CALL   PRINT_STRING
CALL   GET2DIGITS          ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
MOV     DH,AL              ;Sector 1, Bits 0-5 only (currently 1-17)
MOV     DL,REGsector
CALL   IDEwr8D             ;Send "Sector#"
CALL   IDEwr8D             ;Write to 8255 A Register

MOV     AL,READcfg8255     ;Set 8255 back to read mode

```

```

OUT     IDECtrlPort,AL
MOV     BX,CHECK_DISPLAY_MSG ;Check display
CALL   PRINT_STRING
RET                                           ;We arrive here from IDE Menu, return

```

```

;----- IBM Menu CMD to check HEX display CHS selection on IDE Board.
;          Should show Cylinder, Head and Sector # in Hex Display on IDE Board

```

CHS_DISPLAY_TEST:

```

MOV     BX,CHS_TEST_MSG           ;Test CHS on Drive #2
CALL   PRINT_STRING

CALL   SET_DRIVE_B               ;Select the second Drive/CF card
CALL   IDEinit                   ;Initialize drive 1. If there is no drive abort
JZ     CHS_002

MOV     BX,INIT_2_ERROR           ;Warn second IDE drive did not initialize
CALL   PRINT_STRING
POP     DS
JMP    IBM_BIOS

```

CHS_002:

```

CALL   CRLF
OR     DH,10100000B               ;Set to >>>> NON-LBA mode <<<<<
MOV     DL,REGshd                 ;Send "Head #" (in DH)
CALL   IDEwr8D                   ;Write to 8255 A Register

MOV     BX,TRKH_NUM               ;"Cylinder number High, (xxH)
CALL   PRINT_STRING
CALL   GET2DIGITS                 ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
AND     AL,00000011B             ;Only 2 bits accepted
MOV     DH,AL
PUSH   AX                         ;Save for below
MOV     DL,REGcylinderMSB
CALL   IDEwr8D                   ;Send High TRK# (in DH) to IDE Drive

MOV     BX,HEAD_NUM               ;Enter Head number (0-FH)
CALL   PRINT_STRING
CALL   GET2DIGITS                 ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
MOV     DH,AL
AND     DH,0FH                   ;top two LED HEX displays.
SHL    DH,1                       ;These 8 (high) data lines are ignored by the IDE drive
SHL    DH,1
SHL    DH,1
SHL    DH,1
POP     AX                         ;Get the tow bits of the high cylinder
OR     DH,AL
MOV     DL,REGcylinderMSB         ;of the high cylinder in the low nibble.
CALL   IDEwr8D_X                 ;Special output to 8255 B Register (Not A) to update LED HEX Display ONLY

MOV     BX,TRKL_NUM               ;"Low Cylinder number, (xxH) "
CALL   PRINT_STRING
CALL   GET2DIGITS                 ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
MOV     DH,AL                     ;Get low Track #

```

```

MOV     DL,REGcylinderLSB      ;Send Low TRK# (in DH)
CALL    IDEwr8D                ;Special write to 8255 A

MOV     BX,SECTOR_NUM          ;"Sector number, (xxH) = "
CALL    PRINT_STRING
CALL    GET2DIGITS             ;Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged)
MOV     DH,AL                  ;Sector 1, Bits 0-5 only (currently 1-17)
MOV     DL,REGsector          ;Send "Sector#"
CALL    IDEwr8D                ;Write to 8255 A Register

MOV     AL,READcfg8255         ;Set 8255 back to read mode
OUT     IDECtrlPort,AL
MOV     BX,CHECK_DISPLAY_MSG   ;Check display
CALL    PRINT_STRING
JMP     IBM_BIOS               ;Will return back up to start IBM Menu

```

```

;----- Menu command to dump a floppy BOOT sector on the CRT
; Note must have a functional INT 13H routine for this section to work

```

```
DUMP_B_SEC:
```

```

PUSH    DS                    ;Save Monitor current DS
XOR     AX,AX                 ;Set DS to data area for ROM usage in low RAM (400H)
MOV     DS,AX

MOV     BX,BOOT_3RD_MSG       ;Say Reading Boot sector
CALL    PRINT_STRING

MOV     AL,0H                 ;Flag to indicate ZFDC board is NOT Initilized
MOV     [ZFDC_INIT_FLAG],AL   ;DS is already set for low RAM area

CALL    INIT_ZFDC             ;Initilize the ZFDC board hardware

CMP     byte [ZFDC_INIT_FLAG],0FFH ;Is Board initilized correctly
JZ      BS_ZFDC_3OK1
pop     ds                    ;Balance up Monitor stack
JMP     IBM_BIOS

```

```
BS_ZFDC_3OK1:
```

```

MOV     BX,DRIVE_SELECT_MSG   ;Floppy disk A: or B:
CALL    PRINT_STRING

call    CICO                  ;Get a command from Console
PUSH    AX
MOV     BX,CRLFMSG            ;"CR,LF"
CALL    PRINT_STRING
POP     AX
CMP     AL,'B'
JZ      B_DRIVE_SEL
MOV     DX,0000H              ;Side A, Disk 0
JMP     OVER_DRIVE_SEL

```

```
B_DRIVE_SEL:
```

```
MOV     DX,00001H            ;Side A, Disk 1
```

```
OVER_DRIVE_SEL:
```

```

PUSH    DX                ;Save side for below

mov     ah,0H
int     13h                ;AH=0, reset floppy disk system

JNC     BS_RESET_3OK1
MOV     BX,RESET_FAIL_MSG
CALL    PRINT_STRING
pop     dx
pop     ds                ;Balance up stack
JMP     IBM_BIOS

BS_RESET_3OK1:
SUB     AX,AX
MOV     ES,AX
MOV     BX,500H            ;Will always dump data to 0000:500H

POP     DX                ;Side & Drive 0
MOV     CX,0001           ;1st sector on track 0
MOV     AL,1              ;1 sector
mov     ah,02h           ;Read 1 sector

int     13H

JNC     BS_SEQ_3OK1       ;If NC then no errors
MOV     BX,BOOT_INFO_FAIL_MSG
pop     ds                ;Balance up Monitor stack
JMP     IBM_BIOS         ;Will return back up to start of Monitor

BS_SEQ_3OK1:
MOV     BX,BOOT_INFOOKMSG
CALL    PRINT_STRING

SUB     AX,AX
MOV     DS,AX
MOV     SI,500H           ;Will always dump data to 0000:500H

LODSB                      ;WRITE 1 BYTE BYTE, DS:[SI++] -> AL
CALL    AL_HEXOUT
LODSB
CALL    AL_HEXOUT
LODSB
CALL    AL_HEXOUT
MOV     BX,JMP_MSG        ;"  BOOT JUMP VECTOR"
CALL    PRINT_STRING

MOV     DL,8
BS_1:  LODSB                ;Get a byte from RAM, DS:[SI++] -> AL
MOV     CL,AL
CALL    CO
DEC     DL
JNZ     BS_1
MOV     BX,NAME_MSG       ;"  OEM NAME"
CALL    PRINT_STRING

```

```

LODSW
CALL AX_HEXOUT
MOV BX, BYTES_MSG ;" Bytes/Sec"
CALL PRINT_STRING
LODSB
CALL AL_HEXOUT
MOV BX, CLUSTER_MSG ;" Sec/Cluster"
CALL PRINT_STRING
LODSW
CALL AX_HEXOUT
MOV BX, RES_MSG ;" Reserved Sectors"
CALL PRINT_STRING
LODSB
CALL AL_HEXOUT
MOV BX, FATS_MSG ;" FATS"
CALL PRINT_STRING
LODSW
CALL AX_HEXOUT
MOV BX, ROOT_MSG ;" Root Dir Entries"
CALL PRINT_STRING
LODSW
CALL AX_HEXOUT
MOV BX, SECTORS_MSG ;" Sectors"
CALL PRINT_STRING
LODSB
CALL AL_HEXOUT
MOV BX, MEDIA_MSG ;" Media Byte"
CALL PRINT_STRING
LODSW
CALL AX_HEXOUT
MOV BX, FAT_SEC_MSG ;" FAT Sectors"
CALL PRINT_STRING
LODSW
CALL AX_HEXOUT
MOV BX, SEC_TRK_MSG ;" Sectors/Track"
CALL PRINT_STRING
LODSW
CALL AX_HEXOUT
MOV BX, HEADS_MSG ;" Heads"
CALL PRINT_STRING
LODSW
CALL AX_HEXOUT
LODSW
CALL AX_HEXOUT
MOV BX, HIDDEN_MSG ;" Hidden Sectors"
CALL PRINT_STRING
LODSW
CALL AX_HEXOUT
LODSW
CALL AX_HEXOUT
MOV BX, HUGE_MSG ;" Huge Sectors"
CALL PRINT_STRING
LODSB
CALL AL_HEXOUT
MOV BX, DRIVE_NO_MSG ;" Drive #"
CALL PRINT_STRING

```

```

LODSB
CALL AL_HEXOUT
MOV BX,RESERVED_MSG ;" Reserved"
CALL PRINT_STRING
LODSB
CALL AL_HEXOUT
MOV BX,BOOT_SIG_MSG ;" Boot Signature"
CALL PRINT_STRING
LODSW
CALL AX_HEXOUT
LODSW
CALL AX_HEXOUT
MOV BX,VOL_ID_MSG ;" Volunme ID"
CALL PRINT_STRING

BS_2: MOV DL,11 ;Get a byte from RAM, DS:[SI++] -> AL
LODSB ;
MOV CL,AL
CALL CO
DEC DL
JNZ BS_2
MOV BX,VOLUME_MSG ;" Volume Label"
CALL PRINT_STRING

BS_3: MOV DL,8 ;Get a byte from RAM, DS:[SI++] -> AL
LODSB ;
CALL AL_HEXOUT
DEC DL
JNZ BS_3
MOV BX,SYS_TYPE_MSG ;" File Sys Type"
CALL PRINT_STRING

pop ds ;Balance up Monitor DS from stack
JMP IBM_BIOS ;All done

;
;----- Menu command to dump the Hard Disk MBR (Master Boot Record) Info on the CRT
; Note must have a functional INT 13H routine for this section to work

DUMP_MBR:
PUSH DS ;Save Monitor current DS
XOR AX,AX ;Set DS to data area for ROM usage in low RAM (400H)
MOV DS,AX

MOV BX,BOOT_MBR_MSG ;Say Reading MBR sector
CALL PRINT_STRING

CALL SET_DRIVE_B ;Select the second Drive/CF card
CALL IDEinit ;Initialize drive 1. If there is no drive abort
JZ MBR_002

MOV BX,INIT_2_ERROR ;Warn second IDE drive did not initilize
CALL PRINT_STRING
POP DS
JMP IBM_BIOS

```



```

MBR_002:
  SUB    AX,AX
  MOV    ES,AX
  MOV    BX,500H                ;Will always dump data to 0000:500H

  MOV    DX,0080H              ;Head 0, HDIdk 0
  MOV    CX,0001                ;1st sector on track 0
  MOV    AL,1                    ;read 1 sector
  mov    ah,02h                 ;Read 1 sector

  int    13H

  JNC    MBR_003                ;If NC then no errors
  MOV    BX,BOOT_MBR_FAIL_MSG
  pop    ds                      ;Balance up Monitor stack
  JMP    IBM_BIOS                ;Will return back up to start of Monitor

MBR_003:
  MOV    BX,MBR_INFOCKMSG
  CALL   PRINT_STRING

  SUB    AX,AX
  MOV    DS,AX
  MOV    SI,500H + 1B8H          ;Will always dump data to 0000:500H

  LODSB                                ;WRITE 1 BYTE BYTE, DS:[SI++] -> AL
  CALL   AL_HEXOUT
  LODSB
  CALL   AL_HEXOUT
  LODSB
  CALL   AL_HEXOUT
  LODSB
  CALL   AL_HEXOUT
  MOV    BX,DISK_SIG_MSG          ;" Disk Signature (Optional)"
  CALL   PRINT_STRING

  LODSB
  CALL   AL_HEXOUT
  LODSB
  CALL   AL_HEXOUT
  MOV    BX,NULS_MSG              ;" Usually Nulls (Optional)"
  CALL   PRINT_STRING

  LODSB                                ;0
  CALL   AL_HEXOUT
  MOV    BX,STATUS_MSG            ;"          Status Byte"
  CALL   PRINT_STRING
  MOV    BX,PT1_MSG               ;"First Partition Table "
  CALL   PRINT_STRING
  CALL   DUMP_PTBL

  LODSB                                ;0
  CALL   AL_HEXOUT
  MOV    BX,STATUS_MSG            ;"          Status Byte"
  CALL   PRINT_STRING

```

```

MOV     BX,PT2_MSG           ;"Second Partition Table "
CALL    PRINT_STRING
CALL    DUMP_PTBL

LODSB                   ;0
CALL    AL_HEXOUT
MOV     BX,STATUS_MSG       ;"           Status Byte"
CALL    PRINT_STRING
MOV     BX,PT3_MSG         ;"Third Partition Table "
CALL    PRINT_STRING
CALL    DUMP_PTBL

LODSB                   ;0
CALL    AL_HEXOUT
MOV     BX,STATUS_MSG       ;"           Status Byte"
CALL    PRINT_STRING
MOV     BX,PT4_MSG         ;"Forth Partition Table "
CALL    PRINT_STRING
CALL    DUMP_PTBL

LODSW
CALL    AX_HEXOUT
MOV     BX,SIGNATURE_MSG    ;" LBR Signature Word "
CALL    PRINT_STRING

pop     ds                 ;Balance up Monitor DS from stack
JMP     IBM_BIOS           ;All done

```

```

DUMP_PTBL:
LODSB                   ;1-3
CALL    AL_HEXOUT
LODSB
CALL    AL_HEXOUT
LODSB
CALL    AL_HEXOUT
MOV     BX,STLBA_MSG       ;"           Start CHS Address"
CALL    PRINT_STRING

LODSB                   ;4
CALL    AL_HEXOUT
MOV     BX,PAR_TYPE_MSG    ;"           Partitio Type"
CALL    PRINT_STRING

LODSB                   ;5-7
CALL    AL_HEXOUT
LODSB
CALL    AL_HEXOUT
LODSB
CALL    AL_HEXOUT
MOV     BX,ECHS_MSG       ;"           End CHS Address"
CALL    PRINT_STRING

LODSW                   ;8-B
CALL    AX_HEXOUT
LODSW

```

```

CALL  AX_HEXOUT
MOV   BX,SLB_MSG      ;"      Start LBA Address"
CALL  PRINT_STRING

LODSW                ;C-F
CALL  AX_HEXOUT
LODSW
CALL  AX_HEXOUT
MOV   BX,ELBA_MSG    ;"      End LBA Address"
CALL  PRINT_STRING
RET

```

```

;----- Menu CMD to turn on/off BIOS dump info for reads/writes using this BIOS
;   DEBUG_FLAG = 0 if no debugging info sent to serial terminal
;   DEBUG_FLAG = 1 send just INT's info
;   DEBUG_FLAG = 2 send more detailed information

```

```
DEBUG_ON_OFF:
```

```

push  ds
XOR   AX,AX          ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV   DS,AX

```

```

MOV   BX,DEBUG_SET_MSG
CALL  PRINT_STRING
call  CICO           ;Look for 0,1 2 (only)
CMP   AL,'1'
MOV   byte [DEBUG_FLAG],01H
MOV   BX,DUMP_ON1_MSG
JZ    DUMP_DONE

```

```

CMP   AL,'2'
MOV   byte [DEBUG_FLAG],02H
MOV   BX,DUMP_ON2_MSG
JZ    DUMP_DONE

```

```

CMP   AL,'3'
MOV   byte [DEBUG_FLAG],03H
MOV   BX,DUMP_ON3_MSG
JZ    DUMP_DONE

```

```

MOV   byte [DEBUG_FLAG],0
MOV   BX,DUMP_OFF_MSG

```

```
DUMP_DONE:
```

```

CALL  PRINT_STRING
POP   DS
RET

```

```

;*****
;
;   Bootstrap Handler      (IBM-PC Software Interrupt 19H)

```

```

;
;           SYSTEM - BOOTSTRAP LOADER
;
; For a floppy the BIOS will try to read sector 1, head 0, track 0 from drive A:
; to 0000h:7C00h.  If this fails we will just abort.
;
; For the IDE/CF Cards the BIOS will try to read sector 1, head 0, track 0 from
; drive #2 of the IDE Board to 0000h:7C00h.  If this fails we will just abort.
;
;
; For a hard disk, the BIOS will read sector 1, head 0, track 0 of the 2nd CF-Card
; on the Dual IDE board.  This sector should contain a master bootstrap loader and
; a partition table (see http://www.ctyme.com/intr/rb-2270.htm#Table650).
;
; After loading the master boot sector at 0000h:7C00h,
; the master bootstrap loader is given control with:-
;
;           CS:IP = 0000h:7C00h.
;           DH = access bits 7-6,4-0: Don't care
;           bit 5:=0 device supported by INT 13.
;           DL = boot drive
;                   00h first floppy
;                   80h first hard disk
;
; True IBM PCs and most clones issue an INT 18 (cassette) if neither floppy nor hard
; disk have a valid boot sector.  We will just abort.
;
; To accomplish a warm boot equivalent to Ctrl-Alt-Del, store 1234h in
; 0040h:0072h and jump to FFFF:0000h.  For a cold boot equivalent to
; a reset, store 0000h at 0040h:0072h before jumping..
;
; BUG: If when loading the remainder of the DOS system files fails, various versions
; of IBMBIO.COM/IO.SYS incorrectly restore INT 1E before calling INT 19, assuming
; that the boot sector had stored the contents of INT 1E at DS:SI instead of on
; the stack as it actually does.
;
;*****
;
BOOT_DOS_INT:
    STI                                ;Bootstrap Handler (Interrupt 19H)
    CMP     DL,80H                      ;Floppy or HD?  (80H = First HD)
    JNZ     BOOT_FLOPPY
    JMP     BOOT_HDISK                  ;Z then BOOT FLOPPY.  Note if called, ZFDC Board MUST be active (IDE may be offline)

BOOT_FLOPPY:
    PUSH    DS                          ;Save current DS on stack
    XOR     AX,AX                        ;Set DS to data area for ROM usage in low RAM @ 400H....)
    MOV     DS,AX

    MOV     AL,0H                        ;Flag to indicate ZFDC board is NOT Initilized
    MOV     [ZFDC_INIT_FLAG],AL

    CALL    INIT_ZFDC                    ;Initilize the ZFDC board hardware (360K & 1.44M disks)

    CMP     byte [ZFDC_INIT_FLAG],0FFH  ;Is Board initilized correctly

```

```

        POP     DS                ;Balance up stack
        JZ     ZFDC_OK
        JMP     IBM_BIOS         ;Return will drop back to IBM_BIOS location

ZFDC_OK:
        CALL   SET_DRIVE_B      ;Select the second Drive/CF card
        CALL   IDEinit          ;Initialize drive 1. If there is no drive abort
        JZ     FH_RESET_OK

        MOV    BX,INIT_2_ERROR   ;Warn second IDE drive did not initialize
        CALL   PRINT_STRING     ;Continue anyway with ZFDC/Floppy

FH_RESET_OK:
        sub    ax,ax
        mov    ds,ax            ;DS -> 0
        mov    dx,0080H        ;DL = 80L will always boot from IDE #2 disk for now.

        mov    ah,0
        int    13h             ;AH=0, reset floppy disk system

        JNC    F_RESET_OK
        MOV    BX,RESET_FAIL_MSG
        CALL   PRINT_STRING
        JMP    IBM_BIOS        ;Will return back up to IBM_BIOS location

F_RESET_OK:
        XOR    AX,AX
        mov    DS,AX
        mov    ES,AX            ;DS = ES = 0000H
        mov    ax,201h          ;read one sector
        mov    bx,DOS_BOOT_LOC  ;set ES:BX to data destination 7C00H (BB,00,7c)
        mov    cx,0001H        ;Track 0, sec 01
        mov    dx,0000H        ;side A, (DL bit 7 = 0) drive 0,

        int    13H             ;AH=2, CX=1, read 1 (the boot), sector

        JNC    F_BOOT_OK        ;If NC, then no errors
        MOV    BX,BOOT_FAIL_MSG
        CALL   PRINT_STRING
        JMP    IBM_BIOS        ;Will return back up to IBM_BIOS location

F_BOOT_OK:
        XOR    AX,AX
        MOV    DS,AX
        CMP    word [DOS_BOOT_SIGNATURE],0AA55H ;Check we have a valid MBL signature
        JZ     F_BOOT_OK1

        MOV    BX,NO_MBL_MSG    ;No Floppy Boot Loader Signature detected
        CALL   PRINT_STRING
        JMP    IBM_BIOS        ;Will return back up to IBM_BIOS location

F_BOOT_OK1:
        MOV    BX,BOOT_OK_MSG
        CALL   PRINT_STRING

;      Call   CI                ;Wait for CRT input for boot debugging (info at 7C00H)

```

```

MOV     DX,0                ;Required see above
JMP     word 0000H:DOS_BOOT_LOC ;Far Jump, execute the boot code @0:7C00H

; <<< BOOT HDISK . IDE Board MUST be active (ZFDC board may be offline)
BOOT_HDISK:
CALL    SET_DRIVE_B        ;Boot MSDOS (or FreeDOS) from IDE/CF Card
CALL    IDEinit            ;Select the second Drive/CF card
JZ      BOOT_RESET_OK      ;Initialize drive 1. If there is no drive abort

MOV     BX,INIT_2_ERROR     ;Warn second IDE drive did not initialize
CALL    PRINT_STRING
JMP     IBM_BIOS            ;Will return back up to start of Monitor

BOOT_RESET_OK:
PUSH    DS
XOR     AX,AX              ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV     DS,AX

MOV     AL,0H              ;Flag to indicate ZFDC board is NOT Initialized
MOV     [ZFDC_INIT_FLAG],AL

CALL    INIT_ZFDC          ;Initilize the ZFDC board hardware (360K & 1.44M disks)
POP     DS                 ;Balance up stack

BOOT_ZFDC_OK:
sub     ax,ax
mov     ds,ax              ;DS -> 0
mov     dx,0080H          ;DL = 80H will always boot from HDisk #2

mov     ah,0
int     13H               ;AH=0, reset Hard Disk system

JNC     HBOOT_RESET_OK
MOV     BX,RESET_FAIL_MSG
CALL    PRINT_STRING
JMP     IBM_BIOS          ;Will return back up to IBM_BIOS location

HBOOT_RESET_OK:
XOR     AX,AX
mov     DS,AX
mov     ES,AX              ;DS = ES = 0000H
mov     ax,201h           ;read one sector
mov     bx,DOS_BOOT_LOC   ;set ES:BX to data destination 7C00H (BB,00,7c)
mov     cx,0001H         ;Track 0, sec 01 for MBL >>> Boot on Sector 12H <<<
mov     dx,0080H         ;head 0, HDisk 0, (DL bit 7 = 1)

int     13H               ;AH=2, CX=1, read 1 (the boot), sector

JNC     HDOS_BOOT_OK      ;If NC, then no errors
MOV     BX,BOOT_FAIL_MSG
CALL    PRINT_STRING
JMP     IBM_BIOS          ;Will return back up to IBM_BIOS location

HDOS_BOOT_OK:

```

```

MOV     BX,BOOT_OK_MSG
CALL   PRINT_STRING

;      Call    CI                      ;Wait for CRT input for boot debugging
;                               ;(Can reset and look at BOOT sector)

MOV     DX,0080H                      ;Required see above
JMP     word 0000H:DOS_BOOT_LOC ;Far Jump, execute the boot code @0:7C00H

;*****
;
;      Disk I/O Handler      (Software Interrupt 13H & 40H)
;
;Input: AH = 00h      DISK - RESET DISK SYSTEM
;      DL = drive (if bit 7 is set, both hard disks and floppy disks are reset)
;Return:AH = status (see below)
;      CF clear if successful (returned AH=00h)
;      CF set on error
;
;
;Input: AH = 01h      DISK - GET STATUS OF LAST OPERATION
;      DL = drive (bit 7 set for hard disk)
;Return:CF clear if successful (returned status 00h)
;      CF set on error
;      AH = status of previous operation (see below)
;
;
;Input: AH = 02h      READ 03H,WRITE SECTOR DATA
;      AL = number of sectors to read (must be nonzero)
;      CH = low eight bits of cylinder number
;      CL = sector number 1-63 (bits 0-5, high two bits of cylinder (bits 6-7, hard disk only)
;      DH = head number
;      DL = drive number (bit 7 set, for hard disk)
;      ES:BX -> data buffer
;
;Return:CF set on error
;      if AH = 11h (corrected ECC error), AL = burst length
;      CF clear if successful
;      AH = status (see below)
;      AL = number of sectors transferred (only valid if CF set for some BIOSes)
;
;
;Input: AH = 04h      DISK - VERIFY DISK SECTOR(S)
;      AL = number of sectors to verify (must be nonzero)
;      CH = low eight bits of cylinder number
;      CL = sector number 1-63 (bits 0-5) high two bits of cylinder (bits 6-7, hard disk only)
;      DH = head number
;      DL = drive number (bit 7 set, for hard disk)
;      ES:BX -> data buffer (PC,XT,AT with BIOS prior to 1985/11/15)
;
;Return:CF set on error
;      CF clear if successful
;      AH = status (see below)
;      AL = number of sectors verified
;

```

```

;
;Input: AH = 05h      FLOPPY - FORMAT TRACK
;      AL = number of sectors to format
;      CH = track number
;      DH = head number
;      DL = drive number
;      ES:BX -> address field buffer:-
;              00h  BYTE  track number
;              01h  BYTE  head number (0-based)
;              02h  BYTE  sector number
;              03h  BYTE  sector size (00h=128 bytes, 01h=256 bytes, 02h=512, 03h=1024)
;Return:CF set on error
;      CF clear if successful
;      AH = status (see below)
;              Note: On AT or higher, call AH=17h first. The number of sectors per track is read from the diskette
;              parameter table pointed at by INT 1E
;
;Input: AH = 08h      RETURN DRIVE PARAMATERS
;      DL = drive number (bit 7 set, for hard disk)
;      ES:DI = 0000H:0000H
;              Note: For systems predating the IBM AT, this call is only valid for hard disks, as it is implemented
;              by the hard disk BIOS rather than the ROM BIOS. The IBM ROM-BIOS returns the total number of hard disks
;              attached to the system regardless of whether DL >= 80h on entry

;Return:CF set on error
;      CF clear if successful
;      AH = status (see below)
;      AL = 00h on at least some BIOSes
;      BL = drive type (AT/PS2 floppies only)
;              Values for diskette drive type:
;              01h  360K
;              02h  1.2M
;              03h  720K
;              04h  1.44M
;      CH = low eight bits of maximum cylinder number
;      CL = maximum sector number (bits 5-0)
;              high two bits of maximum cylinder number (bits 7-6)
;      DH = maximum head number
;      DL = number of drives
;      ES:DI -> drive parameter table (floppies only)

;Input: AH = 15h      GET DISK TYPE
;      DL = drive number (bit 7 set, for hard disk)

;Return:CF set on error
;      CF clear if successful
;      AH = type code (see below)
;              00h no such drive
;              01h floppy without change-line support
;              02h floppy (or other removable drive) with change-line support
;              03h hard disk
;              CX:DX = number of 512-byte sectors

;RETURNED ERROR CODES IN AH:-
;      00h  successful completion
;      01h  invalid function in AH or invalid parameter

```



```

; 02h address mark not found
; 03h disk write-protected
; 04h sector not found/read error
; 05h reset failed (hard disk)
; 05h data did not verify correctly (TI Professional PC)
; 06h disk changed (floppy)
; 07h drive parameter activity failed (hard disk)
; 08h DMA overrun
; 09h data boundary error (attempted DMA across 64K boundary or >80h sectors)
; 0Ah bad sector detected (hard disk)
; 0Bh bad track detected (hard disk)
; 0Ch unsupported track or invalid media
; 0Dh invalid number of sectors on format (PS/2 hard disk)
; 0Eh control data address mark detected (hard disk)
; 0Fh DMA arbitration level out of range (hard disk)
; 10h uncorrectable CRC or ECC error on read
; 11h data ECC corrected (hard disk)
; 20h controller failure
; 31h no media in drive (IBM/MS INT 13 extensions)
; 32h incorrect drive type stored in CMOS (Compaq)
; 40h seek failed
; 80h timeout (not ready)
; AAh drive not ready (hard disk)
; B0h volume not locked in drive (INT 13 extensions)
; B1h volume locked in drive (INT 13 extensions)
; B2h volume not removable (INT 13 extensions)
; B3h volume in use (INT 13 extensions)
; B4h lock count exceeded (INT 13 extensions)
; B5h valid eject request failed (INT 13 extensions)
; B6h volume present but read protected (INT 13 extensions)
; BBh undefined error (hard disk)
; CCh write fault (hard disk)
; E0h status register error (hard disk)
; FFh sense operation failed (hard disk)

```

```

;*****

```

```

OLD_DISKIO:                                ;Come here via INT 40H, (rearly) for the old Floppy Disk relocated INTs
STI                                         ;Normal INT 13H Entry point
PUSH DS                                    ;For all commands use variables in low RAM if needed
PUSH AX
XOR AX,AX                                  ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV DS,AX
POP AX

CMP byte [DEBUG_FLAG],0                    ;Is Floppy Debug mode on
JZ COMMON_DISK_COMMANDS                    ;If not skip to "normal" FDisk routines

PUSH AX
PUSH BX
PUSH CX
MOV BX,INT_40F_MSG                          ;"Int 40H (<--Floppy) AX="
CALL SERIAL_PRINT_STRING
POP CX
POP BX
POP AX

```

```

        CALL    SERIAL_DISPLAY_REGISTERS    ;Display Registers on serial port display (All registers retained)
        JMP     COMMON_DISK_COMMANDS      ;Go to "normal" Disk routines

DISKIO:                                     ;Normal INT 13H Entry point
        STI
        PUSH   DS                          ;For all commands use variables in low RAM if needed
        PUSH   AX
        XOR    AX,AX                        ;Set DS to data area for ROM usage in low RAM @ 400H....)
        MOV    DS,AX
        POP    AX

        CMP    byte [DEBUG_FLAG],0        ;Is Debug mode on
        JZ     COMMON_DISK_COMMANDS      ;If not skip

        PUSH   AX
        PUSH   BX
        PUSH   CX
        TEST   DL,80H                      ;Floppy or HDisk
        JNZ   DISKIO1
        MOV    BX,INT_13F_MSG             ;"Int 13H (Floppy) AX="
        JMP    DISKIO2
DISKIO1:MOV    BX,INT_13H_MSG              ;"Int 13H (** HDisk **) AX="
DISKIO2:CALL   SERIAL_PRINT_STRING
        POP    CX
        POP    BX
        POP    AX
        CALL   SERIAL_DISPLAY_REGISTERS    ;Display Registers on serial port display (All registers retained)
                                                ;Fall through to COMMON_DISK_COMMANDS

COMMON_DISK_COMMANDS:
        TEST   DL,80H                      ;HDisk or Floppy CMD
        JZ     FD_COMMANDS                ;For Floppy disk commands
        JMP    HD_COMMANDS                ;For HDISK Commands

;----- Floppy Disk Commands -----

FD_COMMANDS:
        TEST   AH,AH                        ;Is it a FDisk reset
        JNZ   N_FDISK_RESET
        JMP    FDISK_RESET
N_FDISK_RESET:
        CMP    AH,1                        ;Is it a FDisk status request
        JNZ   N_FDISK_STATUS
        JMP    FDISK_STATUS
N_FDISK_STATUS:
        CMP    AH,2                        ;Is it a FDisk read request
        JNZ   N_FDISK_READ
        MOV    byte [VERIFY_FLAG],0H      ;Turn off verify flag
        JMP    FDISK_READ
N_FDISK_READ:
        CMP    AH,3                        ;Is it a FDisk write request
        JNZ   N_FDISK_WRITE
        JMP    FDISK_WRITE
N_FDISK_WRITE:
        CMP    AH,4                        ;Is it a FDisk Verify request
        JNZ   N_FDISK_VERIFY

```

```

        MOV     byte [VERIFY_FLAG],0ffH           ;Turn on verify flag
        JMP     FDISK_READ                       ;Modified read
N_FDISK_VERIFY:
        CMP     AH,5                             ;Is it a FDisk format request
        JNZ     N_FDISK_FORMAT
        JMP     FDISK_FORMAT
N_FDISK_FORMAT:
        CMP     AH,8                             ;Is it a FDisk paramaters request
        JNZ     N_FDISK_PARAMS
        JMP     FDISK_PARAMS
N_FDISK_PARAMS:
        CMP     AH,15H                           ;GET DISK TYPE (XT 1986/1/10 or later,XT286,AT,PS)
        JNZ     N_FDISK_DASB
        JMP     FDISK_DASB
N_FDISK_DASB:
        CMP     AH,16H                           ;FDisk media change check request
        JNZ     NOT_VALID_DISK
        JMP     FDISK_MEDIA_CHANGE

NOT_VALID_DISK:
                                           ;Thats all for now
        PUSH    AX
        MOV     BX,INVALID_AH_FMSG
        CALL   PRINT_STRING
        POP     AX
        MOV     AL,AH
        CALL   AL_HEXOUT
        MOV     BX,H_MSG_CRLF
        CALL   PRINT_STRING
        mov     byte [IBM_DISK_STATUS],cmderr ;Show bad command
                                           ;Fall through to DONE_DISK

DONE_DISK:
                                           ;Most (but not all), floppy commands come back here before returning to DOS
        mov     ah,[IBM_DISK_STATUS]
        OR     AH,AH                             ;Was there an error
        JZ     ALL_OK
        STC                                       ;Set carry to indicate an error
ALL_OK:
        POP     ds                               ;Get back the original saved DS at start
        RETF   2                                ;Remove the original status flags on return (remember we got here via an INT)

;----- Floppy Disk Routines -----
FDISK_RESET:
                                           ;Home the disk head etc.
        PUSH   BX                               ;Save ALL
        PUSH   CX
        PUSH   DX
        MOV    [CURRENT_DRIVE],DL

        MOV    CL,CMD_SET_DRIVE                 ;Set Drive Drive, ZFDC will just return if current drive
        CALL  S100OUT
        MOV    CL,[CURRENT_DRIVE]
        OR    CL,CL                             ;DL = 0 --> ZFDC Drive #3. DL = 1 -->ZFDC Drive #2
        MOV    CL,3                             ;Default to Drive #3
        JZ    R_FLOPPY
        MOV    CL,2                             ;Drive #2

```



```

MOV     BH,0                ;Always
MOV     BL,04H             ;0=Unknown, 1=360K, 2=1.2M, 3=720K, 4=1.44M
MOV     CH,4FH             ;Max Track 79
MOV     CL,18              ;Max sector
MOV     DH,1               ;Max value of head
MOV     DL,2               ;Number of floppy disks!
mov     byte [IBM_DISK_STATUS],0 ;Show OK
JMP     DONE_DISK         ;and return

FDISK_DASB:                ;AH = 15H, GET DISK TYPE (XT 1986/1/10 or later,XT286,AT,PS)
XOR     AX,AX
MOV     AH,01              ;For now return flag "no disk change line support implemented"
mov     byte [IBM_DISK_STATUS],0 ;Show OK
CLC
JMP     ALL_OK            ;Do not check status, just return

FDISK_MEDIA_CHANGE:       ;AH = 16H
XOR     AX,AX
MOV     AX,06              ;change line not support implemented"
mov     byte [IBM_DISK_STATUS],0 ;Show OK
CLC
JMP     ALL_OK            ;Do not check status, just return

;----- READ FLOPPY DISK SECTORS -----

FDISK_READ:               ;AH=2, Read disk sector(s)
PUSH    BX                 ;Save everything, DS already on stack
PUSH    CX
PUSH    DX
PUSH    ES
PUSH    DI                 ;Used in LES below and DMA_ADJUST

MOV     [SECTORS_TO_DO],AL ;save everything first
MOV     byte [SECTORS_DONE],0
MOV     [CURRENT_TRACK],CH
MOV     [CURRENT_SECTOR],CL
MOV     [CURRENT_HEAD],DH
MOV     [CURRENT_DRIVE],DL
MOV     [DMA_SEGMENT],ES   ;Save for below
MOV     [DMA_OFFSET],BX

CALL    DMA_ADJUST        ;Some DMA controllers cannot cross seg boundries, adjust

READ_COMMON:
MOV     CL,CMD_SET_DRIVE   ;Set Drive Drive, ZFDC will just return if current drive
CALL    S100OUT
MOV     CL,[CURRENT_DRIVE] ;DL from INT call
OR      CL,CL              ;DL = 0 --> ZFDC Drive #3. DL = 1 -->ZFDC Drive #2
MOV     CL,3               ;Default to Drive #3
JZ      RDD_FLOPPY
MOV     CL,2               ;Drive #2

RDD_FLOPPY:

```

```

CALL S100OUT
CALL WAIT_FOR_ACK ;Return Z (or NZ with error # in [AH])
JZ READ_1
mov byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP ZFDC_READ_ERROR

READ_1:
MOV CL,CMD_SET_TRACK ;Set Track
CALL S100OUT
MOV CL,[CURRENT_TRACK]
CALL S100OUT ;Send Selected track number
CALL WAIT_FOR_ACK ;Return Z (or NZ with error # in [AH])
JZ READ_2
mov byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP ZFDC_READ_ERROR

READ_2:
MOV CL,CMD_SET_SIDE ;Set Drive Side/Head
CALL S100OUT
MOV CL,[CURRENT_HEAD] ;Set side (Head 0,1)
CALL S100OUT
CALL WAIT_FOR_ACK ;Return Z (or NZ with error # in [AH])
JZ READ_3
mov byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP ZFDC_READ_ERROR

READ_3:
MOV CL,CMD_DOS_SET_SECTOR ;Set MS_DOS Sector (Note not CMD_SET_SECTOR for CPM)
CALL S100OUT
MOV CL,[CURRENT_SECTOR]
CALL S100OUT ;Send Selected track number
CALL WAIT_FOR_ACK ;Return Z (or NZ with error # in [AH])
JZ READ_4
mov byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP ZFDC_READ_ERROR

READ_4: MOV CL,CMD_SEEK_TRACK ;Seek to that track (if not already there)
CALL S100OUT
CALL WAIT_FOR_ACK ;Return Z (or NZ with error # in [AH])
JZ READ_5
mov byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP ZFDC_READ_ERROR

READ_5: MOV CL,CMD_DOS_RD_MULTI_SEC ;Routine assumes required Drive Table,Drive,(Side),Track, and sector are already sent to board
CALL S100OUT
MOV CL,[SECTORS_TO_DO] ;Count of sectors to be done (IBM says it will be (1---9 Max)
CMP CL,18 ;IBM says it will always be <= 18 for 3" (9 for 5")
JLE READ_5a
mov byte [IBM_DISK_STATUS],dmaerr ;show as DMA error
JMP ZFDC_READ_ERROR

READ_5a:CALL S100OUT ;Send sector count
CALL WAIT_FOR_ACK ;Return Z (or NZ with error # in [AH])
JZ READ_6
mov byte [IBM_DISK_STATUS],rnferr ;show RNF error
JMP ZFDC_READ_ERROR

```



```

CALL    AL_HEXOUT
MOV     BX,H_MSG_CRLF
CALL    PRINT_STRING
POP     DI                ;Get back all original registers
POP     ES
POP     DX
POP     CX
POP     BX
mov     AL, [SECTORS_DONE] ;Return # of sectors done
JMP     DONE_DISK        ;and return

VERIFY_SECTOR:           ;Special case where we just check sector for CRC errors/verify
MOV     BX,SECTOR_TIMEOUT ;Put in a timeout count (Loop for status reads at most 256X4 times)
VRDSEC1:DEC    BX         ;Dec BC
JNZ     VRDSEC2          ;Will wait 400H times before timing out
MOV     AH,TIMEOUT_ERROR ;Send Timeout error
mov     byte [IBM_DISK_STATUS],timerr ;show as timeout error
JMP     ZFDC_READ_ERROR

VRDSEC2:IN     AL,S100STATUSB ;Send data to ZFDC output
TEST    AL,80H           ;Is ZFDC in INPUT mode, if not wait
JZ      VRDSEC1
TEST    AL,01H           ;Has previous (if any) character been read.
JZ      VRDSEC1          ;Z if not yet ready

IN      AL,S100DATAB     ;Get data
LOOP    VERIFY_SECTOR
JMP     RDSEC5           ;Are there more sectors to verify

;----- WRITE FLOPPY DISK SECTORS -----

FDISK_WRITE:            ;AH=3, Write disk
PUSH    BX                ;Save everything, DS already on stack
PUSH    CX
PUSH    DX
PUSH    ES
PUSH    DI                ;Used in DMA_ADJUST
PUSH    SI                ;Need for LDS below

MOV     [SECTORS_TO_DO],AL ;save everything first
MOV     byte [SECTORS_DONE],0
MOV     [CURRENT_TRACK],CH
MOV     [CURRENT_SECTOR],CL
MOV     [CURRENT_HEAD],DH
MOV     [CURRENT_DRIVE],DL
MOV     [DMA_SEGMENT],ES ;Save for below
MOV     [DMA_OFFSET],BX

CALL    DMA_ADJUST        ;Some DMA controllers cannot cross seg boundries, adjust

WRITE_COMMON:
MOV     CL,CMD_SET_DRIVE ;Set Drive Drive, ZFDC will just return if current drive
CALL    S100OUT
MOV     CL,[CURRENT_DRIVE] ;DL from INT call

```



```

OR      CL,CL                ;DL = 0 --> ZFDC Drive #3.  DL = 1 -->ZFDC Drive #2
MOV     CL,3                 ;Default to Drive #3
JZ      WDD_FLOPPY
MOV     CL,2                 ;Drive #2
WDD_FLOPPY:
CALL    S100OUT
CALL    WAIT_FOR_ACK        ;Return Z (or NZ with error # in [AH])
JZ      WRITE_1
mov     byte [IBM_DISK_STATUS],seekerr ;Show seek error
JMP     ZFDC_WRITE_ERROR

WRITE_1:
MOV     CL,CMD_SET_TRACK    ;<<< Set Track
CALL    S100OUT
MOV     CL,[CURRENT_TRACK]
CALL    S100OUT            ;Send Selected track number
CALL    WAIT_FOR_ACK        ;Return Z (or NZ with error # in [AH])
JZ      WRITE_2
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP     ZFDC_WRITE_ERROR

WRITE_2:
MOV     CL,CMD_SET_SIDE    ;<<< Set Drive Side/Head
CALL    S100OUT
MOV     CL,[CURRENT_HEAD]  ;Set side (Head 0,1)
CALL    S100OUT
CALL    WAIT_FOR_ACK        ;Return Z (or NZ with error # in [AH])
JZ      WRITE_3
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP     ZFDC_WRITE_ERROR

WRITE_3:
MOV     CL,CMD_DOS_SET_SECTOR ;Set MS_DOS Sector (Note not CMD_SET_SECTOR for CPM)
CALL    S100OUT
MOV     CL,[CURRENT_SECTOR]
CALL    S100OUT            ;Send Selected track number
CALL    WAIT_FOR_ACK        ;Return Z (or NZ with error # in [AH])
JZ      WRITE_4
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP     ZFDC_WRITE_ERROR

WRITE_4:
MOV     CL,CMD_SEEK_TRACK   ;<<< Seek to that track (if not already there)
CALL    S100OUT
CALL    WAIT_FOR_ACK        ;Return Z (or NZ with error # in [AH])
JZ      WRITE_5
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP     ZFDC_WRITE_ERROR

WRITE_5:MOV     CL,CMD_DOS_WR_MULTI_SEC ;Routine assumes required Drive Table,Drive,(Side),Track, and sector are already sent to board
CALL    S100OUT
MOV     CL,[SECTORS_TO_DO]   ;Count of sectors to be done (IBM says it will be (1---9 Max)
CMP     CL,18                ;IBM says it will always be <= 18 for 3" (9 for 5")
JLE     WRITE_5a
mov     byte [IBM_DISK_STATUS],dmaerr ;show as DMA error
JMP     ZFDC_WRITE_ERROR

WRITE_5a:CALL    S100OUT        ;Send sector count

```



```

        PUSH    AX
        MOV     BX,WRITE_ERR_MSG
        CALL   PRINT_STRING
        POP     AX
        MOV     AL,AH
        CALL   AL_HEXOUT
        MOV     BX,H_MSG_CRLF
        CALL   PRINT_STRING
WP_DONE:POP     SI
        POP     DI                ;Get back all original registers
        POP     ES
        POP     DX
        POP     CX
        POP     BX
        mov     AL, [SECTORS_DONE] ;Return # of sectors done
        JMP     DONE_DISK         ;and return

F_DISK_WP_ERROR:
        mov     byte [IBM_DISK_STATUS],wpterr ;Write protected disk
        JMP     WP_DONE

;----- FORMAT FLOPPY DISK -----
;Code not tested/complete yet!
FDISK_FORMAT: ;Format the current disk using the ZFDC format track command
        PUSH    BX
        PUSH    CX
        PUSH    DX

        MOV     [CURRENT_DRIVE],DL
        MOV     [CURRENT_TRACK],CH

        CMP     DL,0                ;If first track home heads
        JNZ     FORMAT_F1
        MOV     CL,CMD_SET_HOME      ;Note this is a restore with NO verify. (disk may not be formatted)
        CALL   S100OUT
        CALL   WAIT_FOR_ACK          ;Return Z (or NZ with error # in [AH])
        JZ     FORMAT_F1
        mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
        JMP     ZFDC_FORMAT_ERROR

FORMAT_F1:
        MOV     CL,CMD_FORMAT_TRACK ;Format a complete track on ZFDC controller
        CALL   S100OUT

        MOV     CL,[CURRENT_TRACK] ;Send the track number
        CALL   S100OUT

        MOV     CL,CONFIRM_FORMAT    ;Now send SPECIAL OK to FORMAT Disk flag
        CALL   S100OUT

        ;<<< Now wait until track is formatted >>>
WAIT_F:CALL   S100STAT
        JNZ     TRACK_DONE           ;Wait until ZFDC Board is ready
        MOV     AH,1                 ;NZ, something there!
        int     16H                  ;KEYBOARD - CHECK FOR KEYSTROKE
        JZ     WAIT_F               ;Nothing, then wait some more

```

```

MOV     AH,0                ;Get character
int     16H
CMP     AL,ESC              ;Was an ESC character eneterd
JZ      ZFDC_FORMAT_ERROR
JMP     WAIT_F

TRACK_DONE:
CALL    S100IN              ;Get returned Error # (Note this releases the SEND_DATA routine on the ZFDC board)
CMP     AL,NO_ERRORS_FLAG   ;Was SEND_OK/NO_ERRORS_FLAG sent back from ZFDC Board
JNZ     ZFDC_FORMAT_ERROR
mov     byte [IBM_DISK_STATUS],0 ;and good disk status
POP     DX
POP     CX
POP     BX
JMP     DONE_DISK          ;and return

ZFDC_FORMAT_ERROR:
mov     byte [IBM_DISK_STATUS],cmderr ;Show as CMD error
PUSH    AX
MOV     BX,FORMAT_ERR_MSG
CALL    PRINT_STRING
POP     AX
MOV     AL,AH
CALL    AL_HEXOUT
MOV     BX,H_MSG_CRLF
CALL    PRINT_STRING
POP     DX
POP     CX
POP     BX
mov     AL, [SECTORS_DONE]   ;Return # of sectors done
JMP     DONE_DISK          ;and return

;----- HARD DISK Routines -----

;We will use for MS-DOS Drive C: the second IDE Drive.
;Leaving the first for CPM86 (or, later the second MS-DOS hard disk)

HD_COMMANDS:
TEST    AH,AH                ;Is it a Fdisk reset
JNZ     N_HDISK_RESET
JMP     HDISK_RESET

N_HDISK_RESET:
CMP     AH,1                  ;Is it a HDISK status request
JNZ     N_HDISK_STATUS
JMP     HDISK_STATUS

N_HDISK_STATUS:
CMP     AH,2                  ;Is it a HDISK read request
JNZ     N_HDISK_READ
MOV     byte [VERIFY_FLAG],0H ;Turn off verify flag
JMP     HDISK_READ

N_HDISK_READ:

```

```

        CMP     AH,3                ;Is it a HDISK write request
        JNZ     N_HDISK_WRITE
        JMP     HDISK_WRITE
N_HDISK_WRITE:
        CMP     AH,4                ;Is it a HDISK Verify request
        JNZ     N_HDISK_VERIFY
        MOV     byte [VERIFY_FLAG],0FFH ;Turn on verify flag
        JMP     HDISK_READ          ;Modified read
N_HDISK_VERIFY:
        CMP     AH,5                ;Is it a HDisk format request
        JNZ     N_HDISK_FORMAT
        JMP     HDISK_FORMAT
N_HDISK_FORMAT:
        CMP     AH,8                ;Is it a HDisk paramaters request
        JNZ     N_HDISK_PARAMS
        JMP     HDISK_PARAMS
N_HDISK_PARAMS:
        CMP     AH,9                ;Is it a HDisk Controller Initilize request
        JNZ     N_HDISK_INIT_REQ
        JMP     HDISK_INIT_REQ
N_HDISK_INIT_REQ:
        CMP     AH,0DH              ;Is it a HDisk Reset request (Alternative)
        JNZ     N_HDISK_RESET2
        JMP     HDISK_RESET
N_HDISK_RESET2:
        CMP     AH,10H              ;Is it a HDisk Ready check request
        JNZ     N_HDISK_READY_CHK
        JMP     HDISK_READY_CHK
N_HDISK_READY_CHK:
        CMP     AH,15H              ;Is it a HDISK read DASB request
        JNZ     N_NOT_VALID_DISK
        JMP     HDISK_DASB
N_NOT_VALID_DISK:
        JMP     NOT_VALID_DISK      ;Go to common/floppy error return

HDISK_RESET:
        ;AH = 0, Home the disk head etc.
        CALL    SET_DRIVE_B         ;Select the second Drive/CF card as MS-DOS Drive C:
        CALL    IDEinit             ;Initialize drive 2. If there is no drive abort
        JNZ     HDISK_RESET_ERROR
        mov     byte [SEEK_STATUS],0 ;show good seek status
        mov     byte [IBM_DISK_STATUS],0 ;and good disk status
        JMP     DONE_DISK           ;and return

HDISK_RESET_ERROR:
        MOV     BX,HOME_ERR_MSG
        CALL    PRINT_STRING
        mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
        JMP     DONE_DISK           ;and return (with error)

HDISK_STATUS:
        ;AH = 1
        mov     al,[IBM_DISK_STATUS] ;Return past disk status
        mov     byte [IBM_DISK_STATUS],0 ;reset status in low RAM for next time
        JMP     DONE_DISK           ;and return

```

```

HDISK_PARAMS:                ;AH = 8H Get Hard Drive Params (We will assume one hard disk only, Custom type)
    MOV     AH,0
    MOV     AL,DOS_MAXSEC      ;Do NOT change ES or BX
    MOV     CH,DOS_MAXCYL_L-1 ;0FEH, low eight bits of maximum cylinder number
    MOV     CL,DOS_MAXSEC_CYL ;3FH, maximum sector number (bits 5-0)+ two Cyl High Bits (Sectors numbered 1...x)
                                ;high two bits of maximum cylinder number (bits 7-6)
    MOV     DH,DOS_MAXHEADS-1 ;0FH, (0..15) 16 Heads
    MOV     DL,1               ;Number of Hard Disks
    mov     byte [IBM_DISK_STATUS],0 ;Show OK
    JMP     DONE_DISK          ;and return. This will put AH=0 & Clear CF

HDISK_INIT_REQ:              ;AH = 9H, INITIALIZE CONTROLLER WITH DRIVE PARAMETERS (AT,PS)
HDISK_READY_CHK:            ;AH = 10H, HARD DISK - CHECK IF DRIVE READY
    mov     byte [IBM_DISK_STATUS],0 ;Since we have only one HDisk just return for now
    JMP     DONE_DISK

HDISK_DASB:                  ;AH = 15H, GET DISK TYPE (XT 1986/1/10 or later,XT286,AT,PS)
    MOV     AX,0310H           ;AH, Indicates a Hard Disk
    MOV     CX,000FH
    MOV     DX,0BC10H         ;This is what the AMI Bios returns for our cystem drive (CX:DX = Total sectors)
    mov     byte [IBM_DISK_STATUS],0 ;Show OK
    CLC
    JMP     ALL_OK            ;Clear CF
                                ;Do not check status, just return

HDISK_FORMAT:                ;AH = 05H, Format disk - Return immediately with status ok
    mov     byte [IBM_DISK_STATUS],0 ;show good operation no matter what
    JMP     DONE_DISK          ;and return

;----- READ HARD DISK DISK SECTORS -----

HDISK_READ:
    PUSH    BX                ;Save everything, DS already on stack
    PUSH    CX
    PUSH    DX
    PUSH    ES
    PUSH    DI                ;Used in LES below and DMA_ADJUST

    MOV     [SECTORS_TO_DO],AL ;save everything first
    MOV     byte [SECTORS_DONE],0
    MOV     AL,CL              ;Store Sector
    AND     CL,00111111B       ;Strip High 2 track bits
    MOV     [CURRENT_SECTOR],CL
    MOV     AH,0               ;Shift the top 2 bits of AL into AH
    SHL     AX,1
    SHL     AX,1
    MOV     [CURRENT_TRACK_HIGH],AH
    MOV     [CURRENT_TRACK],CH ;Store low track#
    MOV     [CURRENT_HEAD],DH  ;Store Head#
    MOV     [CURRENT_DRIVE],DL ;Actully for now always drive #2 on IDE Board
    MOV     [DMA_SEGMENT],ES   ;Save for below
    MOV     [DMA_OFFSET],BX

```

```

CALL    DMA_ADJUST                ;Some DMA controllers cannot cross seg boundries, adjust

CMP     byte [DEBUG_FLAG],2      ;Is Detailed Hdisk/Floppy Debug mode on
JL      HREAD_COMMON            ;If not skip
CALL    DUMP_TRACK_PARAMS        ;Dump the Track,Head,Cylinder data to serial debug terminal

HREAD_COMMON:
CALL    DOS_WR_LBA                ;Setup Drive, Track, Sector for MS-DOS formatted disk.
CALL    IDEwaitnotbusy           ;Make sure drive is ready
JNB     HL_19                    ;Carry flag set if problem
CALL    SHOWerrors               ;Show error data on CRT
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP     H_READ_ERROR            ;General read HDisk sector error reporting routine
;and return (with error)

HL_19:  MOV     DH,COMMANDread
MOV     DL,REGcommand
CALL    IDEwr8D                  ;Send Sec read command to drive.
CALL    IDEwaitdrq              ;Wait until it's got the data
JNB     HL_20                    ;Carry flag set if problem
CALL    SHOWerrors               ;Show error data on CRT
mov     byte [IBM_DISK_STATUS],crcerr ;Show as CRC error
JMP     H_READ_ERROR            ;General read HDisk sector error reporting routine
;and return (with error)

HL_20:  LES     DI,[DMA_OFFSET]   ;Point to initial DMA address (ES & DI already saved above)
HRD_LOOP:
MOV     CX,256                   ;ALWAYS read 512 bytes to [CX] (256X2 bytes)

HRD_LOOP_BYTES:
MOV     AL,REGdata                ;REG regsiter address
OUT     IDEportC,AL

OR      AL,IDERdline              ;08H+40H, Pulse RD line
OUT     IDEportC,AL

IN      AL,IDEportA               ;Read the LOWER byte first
STOSB                                ;READ 1 BYTE BYTE, AL->ES:[DI++]
IN      AL,IDEportB               ;THEN read the UPPER byte
STOSB                                ;READ 1 BYTE BYTE, AL->ES:[DI++]

MOV     AL,REGdata                ;Deassert RD line
OUT     IDEportC,AL

LOOP   HRD_LOOP_BYTES            ;256 words, for 512 bytes

CMP     byte [DEBUG_FLAG],2      ;Is Detailed HDISK/Floppy Debug mode on
JL      HRDSEC4                  ;If not skip
CALL    SERIAL_DUMP_RD_SECTOR_DATA ;Dump first 16 bytes of data

HRDSEC4:
MOV     CX,0FFFFH                ;Need to wait until the IDE drive is ready
HRDSEC5:
MOV     DL,REGstatus              ;with status data after potentially a long
;series of sector reads.
CALL    IDERd8D                  ;Returned data in DH

```

```

AND    DH,80H                ;Is IDE Drive still busy (bit 7 low)
JZ     HRDSEC6               ;No, then check returned status
LOOP   HRDSEC5               ;wait until ready
HRDSEC6:
MOV    AL,DH                 ;Was previous command completed without errors
AND    AL,1H                 ;Ret AL=0 for all OK
JZ     HNEXT_SECTOR_RD

CALL   SHOWerrors           ;Show error data on CRT
mov    byte [IBM_DISK_STATUS],crcerr ;Show as CRC error
JMP    H_READ_ERROR        ;General write HDisk sector error reporting routine
                                ;and return (with error)

                                ;We have done one sector, are there more
                                ;On hard disks (with XT and AT BIOSes), a multi-sector read
                                ;continues on the next higher head of the same cylinder and if
                                ;necessary, advances to the next higher cylinder on the first head.
HNEXT_SECTOR_RD:
mov    al,[SECTORS_DONE]
INC    al
mov    [SECTORS_DONE],al    ;Store it
CMP    [SECTORS_TO_DO],al   ;Have we done all yet
JNE    HRD_LOOP

mov    byte [IBM_DISK_STATUS],0 ;Show good operation
HRD_DONE:
POP    DI                    ;Get back all original registers
POP    ES
POP    DX
POP    CX
POP    BX
mov    AL, [SECTORS_DONE]    ;Return # of sectors done
JMP    DONE_DISK            ;and return

H_READ_ERROR:
PUSH   AX
MOV    BX,HREAD_ERR_MSG
CALL  PRINT_STRING
CALL  H_PRINT_CHS           ;Print current Cyl, Head, Sector (DS: points to low RAM data stores)
POP    AX
JMP    HRD_DONE

HDISK_WRITE:                ;Arrive here with DS: pointing to low RAM data area
PUSH   BX                    ;Save everything, DS already on stack
PUSH   CX
PUSH   DX
PUSH   ES
PUSH   DI                    ;Used in LES below and DMA_ADJUST
PUSH   SI                    ;Need for LDS below

MOV    [SECTORS_TO_DO],AL    ;save everything first
MOV    byte [SECTORS_DONE],0
MOV    AL,CL                 ;Store Sector
AND    CL,00111111B         ;Strip High 2 track bits

```



```

MOV     [CURRENT_SECTOR],CL
MOV     AH,0                ;Shift the top 2 bits of AL into AH
SHL     AX,1
SHL     AX,1
MOV     [CURRENT_TRACK_HIGH],AH
MOV     [CURRENT_TRACK],CH  ;Store low track#
MOV     [CURRENT_HEAD],DH  ;Store Head#
MOV     [CURRENT_DRIVE],DL ;Actully for now always drive #2 on IDE Board
MOV     [DMA_SEGMENT],ES   ;Save for below
MOV     [DMA_OFFSET],BX

CALL    DMA_ADJUST         ;Some DMA controllers cannot cross seg boundaries, adjust

CMP     byte [DEBUG_FLAG],2 ;Is Detailed Hdisk/Floppy Debug mode on
JL      HWRITE_COMMON     ;If not skip
CALL    DUMP_TRACK_PARAMS ;Dump the Track,Head,Cylinder data to serial debug terminal

HWRITE_COMMON:
CALL    DOS_WR_LBA        ;Setup Drive, Track, Sector for MS-DOS formatted disk.
CALL    IDEwaitnotbusy    ;Make sure drive is ready
JNB     HW_19             ;Carry flag set if problem
CALL    SHOWerrors        ;Show error data on CRT
mov     byte [IBM_DISK_STATUS],seekerr ;show seek error
JMP     H_WRITE_ERROR     ;General write HDisk sector error reporting routine
                                ;and return (with error)

HW_19:  MOV     DH,COMMANDwrite
MOV     DL,REGcommand
CALL    IDEwr8D           ;Send Sec write command to drive.
CALL    IDEwaitdrq        ;Wait until it's got the data
JNB     HW_20             ;Carry flag set if problem
CALL    SHOWerrors        ;Show error data on CRT
mov     byte [IBM_DISK_STATUS],crcerr ;Show as CRC error
JMP     H_WRITE_ERROR     ;General write HDisk sector error reporting routine
                                ;and return (with error)

HW_20:  PUSH    DS                ;Remember from now on, low RAM DS pointer is no longer valid
MOV     AX,DS
XOR     AX,AX
MOV     ES,AX            ;ES will now temporly have the low RAM pointer
LDS     SI,[DMA_OFFSET]

HWR_LOOP:
MOV     AL,WRITEcfg8255    ;8255 to write mode
OUT     IDECtrlPort,AL
MOV     CX,256            ;ALWAYS read 512 bytes to [CH] (256X2 bytes)

HWR_LOOP_BYTES:
LODSB                      ;WRITE 1 BYTE, DS:[SI++] -> AL
OUT     IDEportA,AL        ;Write the LOWER byte first
LODSB                      ;WRITE 1 BYTE, DS:[SI++] -> AL
OUT     IDEportB,AL        ;THEN UPPER byte on B

MOV     AL,REGdata
PUSH    AX

```

```

OUT     IDEportC,AL           ;Send write command
OR      AL,IDEwrlne         ;Send WR pulse
OUT     IDEportC,AL
POP     AX
OUT     IDEportC,AL           ;Send write command
LOOP    HWR_LOOP_BYTES      ;One sector done

MOV     AL,READcfg8255       ;Set 8255 back to read mode
OUT     IDECtrlPort,AL

MOV     CX,0FFFFH           ;Need to wait until the IDE drive is ready
HW_21: MOV     DL,REGstatus    ;with status data after potentially a long
CALL    IDERd8D             ;Series of sector writes
AND     DH,80H              ;Returned data in DH
AND     DH,80H              ;Is IDE Drive still busy
JZ      HW_22                ;No, then check returned staus
LOOP    HW_21

HW_22: MOV     AL,DH           ;Was previous command completed without errors
AND     AL,1H               ;Ret AL=0 for all OK
JZ      HNEXT_SECTOR_WR

POP     DS                   ;Get back DS for above
CALL    SHOWerrors          ;Show error data on CRT
mov     byte [IBM_DISK_STATUS],crcerr ;Show as CRC error
JMP     H_WRITE_ERROR       ;General write HDisk sector error reporting routine

;We have done one sector, are there more
;On hard disks (with XT and AT BIOSes), a multi-sector read
;continues on the next higher head of the same cylinder and if
;necessary, advances to the next higher cylinder on the first head.
HNEXT_SECTOR_WR:
mov     al,[ES:SECTORS_DONE]
INC     al
mov     [ES:SECTORS_DONE],al ;Store it
CMP     [ES:SECTORS_TO_DO],al ;Have we done all yet
JNZ     HWR_LOOP

POP     DS                   ;Get back DS for above.
mov     byte [IBM_DISK_STATUS],0 ;Show good operation

HWR_DONE:
POP     SI
POP     DI                   ;Get back all original registers
POP     ES
POP     DX
POP     CX
POP     BX
mov     AL,[SECTORS_DONE]    ;Return # of sectors done
JMP     DONE_DISK           ;and return

H_WRITE_ERROR:
MOV     AL,READcfg8255       ;Set 8255 back to read mode
OUT     IDECtrlPort,AL
PUSH    AX
MOV     BX,HWRITE_ERR_MSG   ;"HDisk Sector Write Error"
CALL    PRINT_STRING
CALL    H_PRINT_CHS         ;Print current Cyl, Head, Sector (DS: points to low RAM data stores)

```

```

        POP     AX
        JMP     HWR_DONE

H_PRINT_CHS:                ;DS: points to low RAM data stores
        MOV     BX,HD_MSG           ;" Head = "
        CALL    PRINT_STRING
        MOV     AL,[CURRENT_HEAD]
        CALL    AL_HEXOUT

        MOV     BX,CYL_MSG           ;"H Cyl = "
        CALL    PRINT_STRING
        MOV     AH,[CURRENT_TRACK_HIGH]
        MOV     AL,[CURRENT_TRACK]
        CALL    AX_HEXOUT

        MOV     BX,SEC_MSG           ;"H Sec = "
        CALL    PRINT_STRING
        MOV     AL,[CURRENT_SECTOR]
        CALL    AL_HEXOUT

        MOV     BX,BRAC1_MSG        ;"H ("
        CALL    PRINT_STRING
        MOV     AL,[SECTORS_DONE]
        CALL    AL_HEXOUT

        MOV     BX,OF_MSG           ;"H of "
        CALL    PRINT_STRING
        MOV     AL,[SECTORS_TO_DO]
        CALL    AL_HEXOUT

        MOV     BX,BRAC2_MSG        ;H") "
        CALL    PRINT_STRING
        RET

;----- SUPPORT ROUTINES FOR ZFDC BOARD FOR MSDOS/FREEDOS -----

INIT_ZFDC:
        OUT     RESETZFDCPORT,AL    ;Return 0FFH in [ZFDC_INIT_FLAG] and Z flag set if all OK
                                        ;Do a hardware reset. Does not matter what is in [AL]

        MOV     AX,5                 ;~0.5 second at 10 MHz
        MOV     CX,0                 ;Delay to allow board to setup hardware
WAITD:  LOOP    WAITD                ;Delay for ~0.5 seconds
        DEC     AX
        JNZ     WAITD

        IN      AL,S100DATAB         ;Check the board is there
        CMP     AL,CMD_HANDSHAKE     ;Make sure we get HANDSHAKE byte back
        MOV     AH,ZFDC_ABSENT      ;If not then no ZFDC board present
        JNZ     BADZFDC             ;If not there, just abort

        MOV     AL,CMD_HANDSHAKE     ;Send another byte just to be sure.
        OUT     S100DATAB,AL         ;This clears up ints on ZFDC board
        CALL    WAIT_FOR_ACK         ;Return Z (or NZ with error # in [AH])

        OR     AL,AL

```

```

MOV     AH,ZFDC_INIT_ERROR    ;If not then no ZFDC board present
JNZ     BADZFDC              ;just abort

                                ;Leave drives 0,1 UNFORMATTED/UNINITIALIZED for now

MOV     CL,CMD_SET_FORMAT    ;Send Set Disk Format to Drive CMD for drive #3 (1.44M 3" disk)
CALL    S100OUT
MOV     CL,3                 ;Floppy Drive 3, (ZFDC Board expects a 0H, 1H, 2H or 3H)
CALL    S100OUT
MOV     CL,IBM144           ;1.4M (For MSDOS) DDDS, 18 X 512 Byte Sectors, 80 Tracks. (See ZFDC Board Code for more info)
CALL    S100OUT
CALL    WAIT_FOR_ACK        ;Return Z (or NZ with error # in [AH])
JNZ     BADZFDC

MOV     CL,CMD_SET_FORMAT    ;Send Set Disk Format to Drive CMD for drive #2 (360K 5" disk)
CALL    S100OUT
MOV     CL,2                 ;Floppy Drive 2, (ZFDC Board expects a 0H, 1H, 2H or 3H)
CALL    S100OUT
MOV     CL,MSDOS2           ;5", IBM PC, MSDOS 2.x, 512 byte, DDDS, 9 sector format (See ZFDC Board Code for more info)
CALL    S100OUT
CALL    WAIT_FOR_ACK        ;Return Z (or NZ with error # in [AH])
JNZ     BADZFDC

MOV     CL,CMD_SET_DRIVE    ;<<< Set Drive Drive DOS A: ZFDC will just return if current drive
CALL    S100OUT
MOV     CL,3                 ;Set drive #3 as the current drive
CALL    S100OUT
CALL    WAIT_FOR_ACK        ;Return Z (or NZ with error # in [AH])
JNZ     BADZFDC              ;just abort

PUSH    BX                   ;Return BX unaltered
MOV     AL,0FFH              ;Flag to indicate ZFDC board is setup OK
MOV     [ZFDC_INIT_FLAG],AL ;Note DS is already set for ROM usage in low RAM (400H)
MOV     BX,ZFDC_OK_MSG       ;Announce success
CALL    PRINT_STRING
POP     BX
XOR     AL,AL
RET                                     ;Return Z for all OK

BADZFDC:
PUSH    BX                   ;Return BX unaltered
MOV     AL,0H                ;Flag to indicate ZFDC board is NOT OK
MOV     [ZFDC_INIT_FLAG],AL ;Note DS is already set for ROM usage in low RAM (400H)
MOV     BX,ZFDC_FAIL_MSG     ;Announce failure
CALL    PRINT_STRING
POP     BX
XOR     AL,AL
DEC     AL
RET                                     ;Return NZ WITH ERROR IN AH

DUMP_TRACK_PARAMS:          ;Dump the Track,Head,Cylinder data to serial debug terminal
MOV     CL,CR
CALL    SERIAL_OUT
MOV     CL,LF
CALL    SERIAL_OUT

```

```

MOV     CL,'h'
CALL   SERIAL_OUT
MOV     AL,[CURRENT_HEAD]
CALL   SERIAL_AL_HEXOUT

MOV     CL, '.'
CALL   SERIAL_OUT
MOV     CL, 't'
CALL   SERIAL_OUT
MOV     AL,[CURRENT_TRACK]      ;Note DS is already set for ROM usage in low RAM (400H)
CALL   SERIAL_AL_HEXOUT

```

```

MOV     CL, '.'
CALL   SERIAL_OUT
MOV     CL, 's'
CALL   SERIAL_OUT
MOV     AL,[CURRENT_SECTOR]
CALL   SERIAL_AL_HEXOUT

```

```

MOV     CL, ' '
CALL   SERIAL_OUT
MOV     CL, '#'
CALL   SERIAL_OUT
MOV     AL,[SECTORS_TO_DO]
CALL   SERIAL_AL_HEXOUT
MOV     CL, ','
CALL   SERIAL_OUT
MOV     AL,[SECTORS_DONE]
CALL   SERIAL_AL_HEXOUT
MOV     CL, ' '
CALL   SERIAL_OUT
MOV     CL, ' '
CALL   SERIAL_OUT
RET

```

```

SERIAL_DUMP_RD_SECTOR_DATA:      ;Note this is only for sector reads. ES: is invalid for Writes
    PUSH  AX                      ;Show first 8 bytes of sector data on serial output (for debugging)
    PUSH  BX
    PUSH  CX
    PUSH  DI
    MOV   CX,16                    ;Show first 16 characters
DUMPS1: MOV  AL,[ES:DI]            ;DI will have the current address
    CALL  SERIAL_AL_HEXOUT
    INC  DI
    LOOP DUMPS1
    MOV  BX,CR_TAB_MSG             ;CR to next line then tab in 18 spacs (for multisector reads)
    CALL SERIAL_PRINT_STRING
    POP  DI
    POP  CX
    POP  BX
    POP  AX
    RET

```

```

SIMPLE_SECTOR_DUMP:                ;Dump first CX bytes of sector data at ES:BX on CRT
    PUSH    DS

    PUSH    BX
    PUSH    CX

    PUSH    BX
    PUSH    CX

    XOR     AX,AX                    ;Set DS to data area for ROM usage in low RAM @ 400H....)
    MOV     DS,AX

    MOV     BX,SEQAT500              ;"First [CX] bytes of loaded Sector (@ES:BX) Head ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_HEAD]
    CALL    AL_HEXOUT

    MOV     BX,TRACK_MSG             ;"H  Track ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_TRACK]
    CALL    AL_HEXOUT

    MOV     BX,SEC_MSG               ;"H  Sector ="
    CALL    PRINT_STRING
    MOV     AL,[CURRENT_SECTOR]
    CALL    AL_HEXOUT
    MOV     BX,START_DATA_MSG        ;"H  Start of Data =  CR,LF"
    CALL    PRINT_STRING

    POP     CX                        ;From above
    POP     BX

ONE_LINE_SECTOR1:
    MOV     AX,[ES:BX]               ;High byte/low byte order
    PUSH    AX
    CALL    AL_HEXOUT
    POP     AX
    MOV     AL,AH
    CALL    AL_HEXOUT
    INC     BX
    INC     BX
    LOOP    ONE_LINE_SECTOR1

    CALL    CRLF
    POP     CX                        ;Again from above
    POP     BX

SECTOR_DUMP1:
    PUSH    CX
    MOV     CL,[ES:BX]               ;High byte/low byte order
    and     cl,7fh
    cmp     cl,' '                    ;filter out control characters
    jnc     xloop3
xloop4:  mov     cl,','
xloop3:  cmp     cl,'~'
    jnc     xloop4

```

```

CALL    CO
INC     BX                ;Next character
POP     CX
LOOP    SECTOR_DUMP1
CALL    CRLF
POP     DS                ;Balance up stack
RET

S100STAT:                ;Check if ZFDC has any data for S-100 system
IN      AL,S100STATUSB
TEST    AL,01H           ;Anything there ?
JZ      S100ST1         ;Return 0 if nothing
XOR     AL,AL
DEC     AL               ;Return NZ, & 0FFH in AL if something there
S100ST1:RET

S100IN: IN      AL,S100STATUSB ;Check if ZFDC has any data for S-100 system
TEST    AL,80H         ;Is ZFDC in input mode, if not, wait
JZ      S100IN         ;If low then ZFDC board is still in input mode, wait
TEST    AL,01H
JZ      S100IN
IN      AL,S100DATAA   ;return with character in AL
RET

S100OUT:IN      AL,S100STATUSB ;Send data to ZFDC output (arrive with character to be sent in C)
TEST    AL,80H         ;Is ZFDC in output mode, if not wait
JNZ     S100OUT
TEST    AL,02H         ;Has previous (if any) character been read.
JZ      S100OUT       ;Z if not yet ready
MOV     AL,CL
OUT     S100DATAB,AL
RET

WAIT_FOR_ACK:           ;Delay to wait for ZFDC to return data. There is a timeout of about 2 sec.
PUSH    BX
PUSH    DX
MOV     BX,0
MOV     DL,STATUSDELAY ;Timeout, (about 2 seconds)
XWAIT1: IN      AL,S100STATUSB ;Check if ZFDC has any data for S-100 system
TEST    AL,80H         ;Is ZFDC in input mode
JZ      XWAIT2         ;if low then ZFDC is still in input mode
CALL    S100STAT       ;Wait until ZFDC Board sends something
JZ      XWAIT2
CALL    S100IN         ;Get returned Error # (Note this releases the SENDDATA routine on the ZFDC board)
MOV     AH,AL          ;<<< Store Error Code (if any) in AH
CMP     AL,NO_ERRORS_FLAG ;Was SENDOK/NOERRORSFLAG sent back from ZFDC Board
POP     DX
POP     BX
RET                   ;Return NZ if problem, Z if no problem

XWAIT2: DEC     BH

```

```

JNZ     XWAIT1             ;Try for ~2 seconds
DEC     BH
DEC     BL
JNZ     XWAIT1
DEC     BH
DEC     BL
DEC     DL
JNZ     XWAIT1
XOR     AL,AL
DEC     AL
MOV     AH,3FH             ;Flag as local Time out error
POP     DX                 ;Balance up stack
POP     BX
RET                                     ;Return NZ flag set if timeout & 0FFH in [AL]
                                     ;Error code in AH

```

```

; Adjust DMASEG:DMAOFF via [ES:DI] so that the in DI is the
; smallest possible. This process is called normalization.
; Registers: Only ES and DI altered

```

```

DMA_ADJUST:
MOV     ES,[DMA_SEGMENT]
MOV     DI,[DMA_OFFSET]

PUSH   AX
PUSH   DI
SHR    DI,1             ; Get paragraph to low 12 bits
SHR    DI,1             ; Shift 0's in at hi 4 bits
SHR    DI,1
SHR    DI,1
MOV    AX,ES             ; Get segment to Bx
ADD    AX,DI             ; Add in segment skew
MOV    ES,AX             ; Restore dma segment
POP    DI                 ; Get back original offset
AND    DI,0FH           ; Only need within paragraph

MOV    [DMA_SEGMENT],ES
MOV    [DMA_OFFSET],DI   ;<<< Later use LES (or for Sec Write LDS)
POP    AX
RET

```

```

;*****
;
; Non Maskable Interrupt Handler (for IBM-PC is int #2, or 08H in RAM)
;
;*****

```

```

NMI_hnd:                 ;Non Maskable Interrupt Handler (Note uses current stack!)
PUSHF                     ;Should not get here. If so send warning and continue
PUSH  AX
PUSH  BX
PUSH  CX

```



```

MOV     BX,NMI_MSG           ;Announce we got an NMI Interrupt
CALL    PRINT_STRING        ;Note PRINT_STRING always uses the CS: override for the BX pointer
POP     CX
POP     BX
POP     AX
POPF                                ;Note NMI does not push the flags on to the stack
IRET

;*****
;
;   Print Screen Software Interrupt Handler (14H in RAM)
;
;*****
PrintScrTest:
MOV     BX,PSCR_TEST_MSG    ;Test interrupt from Monitor Menu
CALL    PRINT_STRING        ;Announce we are going to print the screen
                                ;Note PRINT_STRING always uses the CS: override for the BX pointer

MOV     AX,0001H           ;AH = 01h Initialize Printer
MOV     DX,0               ;DX = printer number (00h-02h)
INT     17H                ;Printer Int

PUSH    ES                 ;Used for INT 10H Write String
PUSH    BP
PUSH    DS                 ;Need DS=0
XOR     AX,AX              ;Set DS to data area for ROM usage in low RAM @ 400H....)
MOV     DS,AX
MOV     AX,word [CONSOL_FLAG] ;Save current Console Output device flag
PUSH    AX
MOV     word[CONSOL_FLAG],1 ;Set (temporarily) Console Output device flag to CGA/VGA

MOV     AX,CS
MOV     ES,AX
MOV     BP,PSCR_TEST_MSG   ;ES:BP = string pointer for INT 10H
MOV     CX,PSCR_TEST_LEN   ;CX = string length
MOV     AH,13H             ;AH = 0EH, String Output mode
MOV     AL,1               ;Update cursor, no attribute
MOV     BH,0               ;Page 0
MOV     BL,02              ;Attribute B/W
MOV     DX,0               ;0,0
INT     10H

INT     5H                 ;Call the Print Screen Interrupt routine below

MOV     AX,000CH           ;AH = 00h PRINTER - WRITE CHARACTER, AL=0CH, Flush printer buffer
MOV     DX,0               ;DX = printer number (00h-02h)
INT     17H                ;Printer Int

POP     AX                 ;Get back saved current Console Output device flag
MOV     [CONSOL_FLAG],AX   ;DS still = 0
POP     DS
POP     BP
POP     ES
RET

```

```

PrintScreenRoutine:                ;In PC BIOS is at 0FF54H
    STI                            ;Can allow further interrupts
    push    ds
    push    ax
    push    bx
    push    cx
    push    dx
    xor     ax,ax
    mov     ds,ax
    cmp     byte[STATUS_BYTE],1    ;are we already here
    jz      pexit
    CMP     word [CONSOL_FLAG],0    ;Skip if current Console is Propeller board (0)
    JZ     pexit

    mov     Byte [STATUS_BYTE],byte 1
    MOV     AH,15                   ;request current screen mode
    INT     10H                     ;AL=mode, AH=columns,BH=page

    mov     cl,ah
    mov     ch,25                   ;CX= row & columns count
    call    pcrLf

    push    cx
    mov     ah,3                   ;Get current cursor position

    int     10H

    pop     cx
    push    dx                     ;Save cursor position to DX
    xor     dx,dx                   ;to position 0,0

pri10: mov     ah,2                 ;Directly from IBM ROM BIOS
    int     10h                   ;set cursor
    mov     ah,8
    int     10h                   ;read character
    or      al,al                 ;valid character?
    jnz     pri15
    mov     al,' '

pri15: push    dx
    xor     dx,dx
    xor     ah,ah
    int     17H                   ;print character
    pop     dx
    test   ah,25h                 ;check for error
    jnz     err10
    inc     dl
    cmp     cl,dl
    jnz     pri10                 ;next character
    xor     dl,dl                 ;to col 0
    mov     ah,dl
    push    dx
    call    pcrLf
    pop     dx
    inc     dh
    cmp     ch,dh                 ;all lines done?
    jnz     pri10

```

```

pri20: pop    dx                ;Done, recall cursor position
      mov    ah,2
      int    10h
      mov    byte[STATUS_BYTE],0
      jmp    pexit

```

```

err10: pop    dx
      mov    ah,2
      int    10H                ;Restore cursor position

```

```

err20: mov    byte[STATUS_BYTE],0FFH ;Flag error
pexit: pop    dx
      pop    cx
      pop    bx
      pop    ax
      pop    ds
      IRET                    ;Note IRET

```

```

pcrlf: xor    dx,dx
      xor    ah,ah
      mov    al,LF
      int    17H
      XOR    ah,ah
      mov    al,CR
      int    17H
      ret

```

```

;*****
;

```

```

;   Keypressed Handler      (for IBM-PC is int #9 via 8259A to 24H in RAM)
;

```

```

;   IRQ1 - KEYBOARD DATA READY
;

```

```

;   This interrupt is generated when data is received from the keyboard. This is normally
;   a scan code (from either a keypress OR a key release), but may also be an ACK or NAK
;   of a command on AT-class keyboards. (Note My Propeller Board translates the scan codes ASCII chars)
;

```

```

;   Note: This IRQ may be masked by setting bit 1 on the 8259A I/O port 21h.
;

```

```

;   If the BIOS supports an enhanced (101/102-key)keyboard, it calls INT 15/AH=4Fh after reading the
;   scan code from the keyboard and before further processing all further processing uses the scan code
;   returned from INT 15/AH=4Fh. (This is not done here)
;

```

```

;   The default interrupt handler is at F000h:E987h in 100%-compatible BIOSes. The interrupt handler performs
;   the following actions for certain special keystrokes:-
;

```

```

;   Ctrl-Break clear keyboard buffer, place word 0000h in buffer, invokes INT 1B, and sets flag at 0040h:0071h
;   SysReq invokes INT 15/AH=85h (SysReq is often labeled SysRq)
;   Ctrl-Numlock place system in a tight wait loop until next INT 09
;   <<<<<< None of the above "extra" items are yet implemented >>>>>>
;

```

```

;   Shift-PrtSc invokes INT 05 (This is now implemented here).
;

```

```

;           Ctrl-Alt-Del jump to BIOS startup code (either F000h:FFF0h or the destination of the jump at that address)
;           Pause & Ctrl-Num_Lock will halt Console Output until the next keyboard input
;
;
;*****
keyhnd: push    ax                ;This interrupt can strike any time, so save all
        push    ds
        push    bx
        XOR     AX,AX            ;Set DS to data area for ROM usage in low RAM @ 400H....)
        MOV     DS,AX

        in     al,KEYIN         ;Get KEYBOARD DATA
        CMP     AL,1CH          ;Propeller Board will return 1CH for a "Print Screen" key press
        JNZ    NO_PRN_SCR
        mov     al,NS_EOI       ;End the current interrupt
        OUT    MASTER_PIC_PORT,al

        INT    5H              ;Activate software Print Screen Interrupt

        MOV     AX,000CH        ;AH = 00h PRINTER - WRITE CHARACTER, AL=0CH, Flush printer buffer
        MOV     DX,0            ;DX = printer number (00h-02h)
        INT    17H             ;Printer Int
        POP     BX
        JMP     K27             ;Finish up

NO_PRN_SCR:
        CMP     AL,1DH          ;Propeller Board will return 1DH for "Ctrl+Alt+Del" key press
        JNZ    NO_CAD_SCR
        mov     al,NS_EOI       ;End the current interrupt
        OUT    MASTER_PIC_PORT,al
        JMP     word 0F000H:0FFF0H ;Far Jump to F000H:FFF0H ;To Reset the CPU address

NO_CAD_SCR:
        CMP     AL,1EH          ;Propeller Board will return 1EH for "Pause" key press
        JNZ    NO_PAUSE_SCR
        OR     byte[KB_FLAG_1],HOLD_STATE ;Set flag to indicate a Pause is required
        mov     al,NS_EOI       ;End the current interrupt
        OUT    MASTER_PIC_PORT,al
        POP     BX
        pop     ds
        pop     ax
        IRET

NO_PAUSE_SCR:
        AND     byte[KB_FLAG_1],NO_HOLD_STATE ;Set flag to indicate a NO PAUSE is required
        and     al,7fh          ;strip parity bit (if any)
        mov     bl,[chrCnt]     ;get current character count
        cmp     bl,chrmax       ;is the buffer full?
        jge     keyxt           ;ignore if buffer full
        inc     bl
        mov     [chrCnt],bl     ;store new character count
        mov     bx,[bufTl]      ;get destination address
        mov     [bx],al         ;store the character
        inc     bx              ;bump buffer address
        cmp     bx,keybuff+32   ;at end of buffer?

```

```

        jl      keyhn1          ;skip if not
        mov     bx,keybuff      ;reset to start of buffer
keyhn1: mov     [buftl],bx      ;store adr for next character
keyxt:  pop     bx
        mov     al,NS_EOI
        OUT    MASTER_PIC_PORT,al
K27:   pop     ds
        pop     ax
        iret

;*****
;
;       Timer Handler          (for IBM-PC is int #8 via 8259A to 20H in RAM)
;       IRQ0 - SYSTEM TIMER
;       On a PC this is generated 18.2 times per second by channel 0 of the 8254 system timer.
;       This interrupt is used to keep the time-of-day clock updated. It can strike any time in a program!
;
;*****
;Note:  The IBM PC clock interrupts at
;1193180/65536 counts/sec (Approx 18.2 per second).
;Our clock interrupts at ~60 hz so adjust to approximate
;the IBM clock, the time constants in this routine must be
;adjusted accordingly if accurate time is to be kept by PC-DOS.

timer:  push   ax                ;This interrupt can strike any time, so save all (flags are already saved)
        push  ds
        XOR   AX,AX              ;Set DS to data area for ROM usage in low RAM @ 400H....)
        MOV   DS,AX

        inc   word [timlow]      ;Bump count
        jnz  timer1
        inc   word [timhi]      ;Bump high part of count
timer1: cmp   word [timhi],18h    ;End of a day?
        jnz  timer2              ;24 hours at 3600 sec/hr
        cmp   word [timlow],0b0h ;and 1193180/65536 tics/sec
        jnz  timer2              ;= 1573040 tics (1800B0 hex)

        sub   ax,ax              ;0 to AX
        mov   [timlow],ax
        mov   [timhi],ax
        mov   byte[timofl],1

timer2:INT 1CH                  ;Go to user timer int at 1CH, IRET when done <<<< (Currently just a return)

        sti
        mov   al,NS_EOI          ;End with Send_EOI
        OUT  MASTER_PIC_PORT,al
        pop   ds
        pop   ax
        iret                    ;IRET will return flags

Send_EOI:
        PUSH  AX                ;General routine to send EOI to 85293A

```

```

        mov     al,NS_EOI
        OUT    MASTER_PIC_PORT,al
        POP    AX
dummy_return:
        iret                                ;Remember IRET will pop the flags

;*****
;
;       Time of Day Handler      (For IBM-PC Software Interrupt 1AH)
;
;Input AH = 00h      TIME - GET SYSTEM TIME
;Return:CX:DX = number of clock ticks since midnight
;       AL = midnight flag, nonzero if midnight passed since time last read
;
;
;Input AH = 01h      TIME - SET SYSTEM TIME
;       CX:DX = number of clock ticks since midnight
;Return:Nothing
;
;
;Input: AH = 02h      TIME - GET REAL-TIME CLOCK TIME (AT, XT286, PS)
;       CF clear to avoid a bug
;Return:CF clear if successful
;       CH = hour (BCD)
;       CL = minutes (BCD)
;       DH = seconds (BCD)
;       DL = daylight savings flag (00h standard time, 01h daylight time)
;       CF set on error (i.e. clock not running or in middle of update)
;
;
;Input: AH = 03h      TIME - SET REAL-TIME CLOCK TIME (AT, XT286, PS)
;       CH = hour (BCD)
;       CL = minutes (BCD)
;       DH = seconds (BCD)
;       DL = daylight savings flag (00h standard time, 01h daylight time)
;Return:Nothing
;
;
;Input: AH = 04h      TIME - GET RTC DATE (AT, XT286, PS)
;       CH = century (BCD)
;       CL = year (BCD)
;       DH = month (BCD)
;       DL = day (BCD)
;       CF clear if OK
;
;
;Return:CF clear if successful
;       CH = century (BCD)
;       CL = year (BCD)
;       DH = month (BCD)
;       DL = day (BCD)
;       CF set on error
;
;

```

```

;
;Input: AH = 05h      TIME - SET REAL-TIME CLOCK DATE (AT, XT286, PS)
;      CH = century (BCD)
;      CL = year (BCD)
;      DH = month (BCD)
;      DL = day (BCD)
;Return:Nothing
;
;*****
time_of_day:
    sti
    push    ds
    PUSH   AX
    XOR    AX,AX                ;Set DS to data area for ROM usage in low RAM @ 400H....)
    MOV    DS,AX
    POP    AX

    CMP    byte [DEBUG_FLAG],0 ;Is Debug mode on
    JZ     Xtime_of_day
    CMP    AH,00H              ;Skip simple Get System Time
    JZ     Xtime_of_day
    PUSH   AX
    PUSH   BX
    PUSH   CX
    MOV    BX,INT_1AH_MSG      ;"Int 1AH (Time) AX="
    CALL   SERIAL_PRINT_STRING
    POP    CX
    POP    BX
    POP    AX
    CALL   SERIAL_DISPLAY_REGISTERS ;Display Registers on serial port display (All registers retained)

Xtime_of_day:
    TEST   AH,AH                ;AH=0 read system tick time?
    JZ     READ_TICKS          ;go do it if so
    CMP    AH,1                ;AH = 1 set tick time?
    JZ     SET_TICKS
    CMP    AH,2                ;AH = 2 Get RTC Time?
    JZ     READ_RTC_TIME
    CMP    AH,4                ;AH = 4 Get RTC Date?
    JZ     READ_RTC_DATE
    JMP    TIME_DONE

READ_TICKS:                    ;Read the system tick time
    cli
    mov    al,[timofl]
    mov    byte [timofl],0
    mov    cx,[timhi]
    mov    dx,[timlow]
    sti
    pop    ds
    iret

SET_TICKS:                    ;Set the system tick time
    cli                        ;no interrupts while we set it
    mov    [timlow],dx

```

```

        mov     [timhi],cx
        mov     byte [timofl],0
        sti
TIME_DONE:
        pop     ds
        ired

;AH = 2H, Read CMOS RTC Time
;CH = hour (BCD), CL = minutes (BCD), DH = seconds (BCD), DL = daylight savings flag (00h standard time, 01h
daylight time)
READ_RTC_TIME:
        CALL    LOAD_TIME
        POP     ds
        retf   2
;CF set on error (i.e. clock not running or in middle of update)
;Get back the original saved DS at start
;Remove the original status flags on return (remember we got here via an INT)

;AH = 4H, Read CMOS RTC
;CH = century (BCD), CL = year (BCD), DH = month (BCD), DL = day (BCD)
;CF set on error
READ_RTC_DATE:
        CALL    LOAD_DATE
        POP     ds
        retf   2
;Get back the original saved DS at start
;Remove the original status flags on return (remember we got here via an INT)

;----- Routines to set flag for Consol Output to Propeller or Lava Video board

SET_CO_FLAG:
        MOV     BX,VIDIO_OUTPUT_MSG ;Video Board XY positioning etc tests. Enter AX Value
        CALL    PRINT_STRING
        CALL    CICO
        PUSH   DS
        PUSH   BX
        PUSH   AX
        CALL    CRLF
        POP    AX
        XOR    BX,BX
        MOV    DS,BX
        CMP    AL,'0'
        JZ    CRT_TO_PROPELLER
        CMP    AL,'2'
        JZ    CRT_TO_LAVA
        CMP    AL,'1'
        JZ    CRT_TO_VGA
        MOV    BX,INT10_ERR_MSG ;Invalid Selection
        CMP    AL,ESC
        JNZ   SET_CRT_DONE
        POP    BX
        POP    DS
        RET

CRT_TO_PROPELLER:
        MOV     word[CONSOL_FLAG],0 ;Console output Propeller Video Board
        MOV     BX,VIDIO_PROP_MSG
        CALL    SPEAK_STRING
        MOV     BX,VIDIO_PROP_SMSG ;Video to PROPELLER

```



```

        JMP     SET_CRT_DONE
CRT_TO_LAVA:
        MOV     word[CONSOL_FLAG],2    ;Console output to LAVA Video Board
        CALL    INITLIZE_LAVA         ;Clear Screen, Green/Black Cursor 0,0
        MOV     BX,VIDIO_LAVA_SMSG
        CALL    SPEAK_STRING          ;Speak out the message
        MOV     BX,VIDIO_LAVA_MSG     ;Video to LAVA
        JMP     SET_CRT_DONE
CRT_TO_VGA:
        MOV     word[CONSOL_FLAG],1    ;Console output to CGA/VGA Video Board
        MOV     BX,VIDIO_VGA_SMSG
        CALL    SPEAK_STRING          ;Speak out the message
        MOV     BX,VIDIO_VGA_MSG     ;Video to VGA
        JMP     SET_CRT_DONE
SET_CRT_DONE:
        CALL    PRINT_STRING
        POP     BX
        POP     DS
        RET

;----- Routines to test Video Board Int 10H Functions out using this IBM PC BIOS section
; The value of AH, CX, etc are used to control the positioning of characters on then CRT see below
XY_VIDEO:
        MOV     BX,VIDIO_TEST_MSG     ;Video Board XY positioning etc tests. Enter AX Value
        CALL    PRINT_STRING
        CALL    GET4DIGITS
        PUSH    DI                    ;AX value in DI

        MOV     BX,ENTER_BX_MSG       ;Enter BX Value
        CALL    PRINT_STRING
        CALL    GET4DIGITS
        PUSH    DI                    ;BX value in DI

        MOV     BX,ENTER_CX_MSG       ;Enter CX Value
        CALL    PRINT_STRING
        CALL    GET4DIGITS
        PUSH    DI                    ;CX value in DI

        MOV     BX,ENTER_DX_MSG       ;Enter DX Value
        CALL    PRINT_STRING
        CALL    GET4DIGITS
        PUSH    DI                    ;DX value in DI

        MOV     BX,ACTIVATE_INT_MSG   ;Will now activate the Int 10H command
        CALL    PRINT_STRING

        CALL    CICO
        CMP     AL,ESC
        JNZ    XY_VIDEO1
        JMP     IBM_BIOS

XY_VIDEO1:
        PUSH    DS                    ;Select below which hardware board you are testing
        XOR     AX,AX

```

```

MOV     DS,AX
; MOV   word [CONSOL_FLAG],0 ;Send output to Propeller Video board
; MOV   word [CONSOL_FLAG],1 ;Send output to CGA/VGA Video board
MOV     word [CONSOL_FLAG],2 ;Send output to LAVA-10 Video board
POP     DS

POP     DX
POP     CX
POP     BX
POP     AX

INT     10H ;Carry out the INT 10H interrupt

PUSH    DS
XOR     AX,AX
MOV     DS,AX
MOV     word [CONSOL_FLAG],0 ;Send output back to Propeller Board
POP     DS

MOV     CL,'#'
CALL    CO

CALL    CICO
CMP     AL,ESC
JNZ     XY_VIDEO
JMP     IBM_BIOS

;----- Routines to hold CPU in a loop so RAM read/write hardware signals can be analyzed

;Loop to analyze hardware RAM Read signals
READ_BYTE_TEST:
MOV     BX, BYTE_RTTEST_MSG ;Get RAM location Enter AX Value
CALL    PRINT_STRING
CALL    GET5DIGITS ;Will return ES=000xH, DI = xxxxH
CALL    CRLF
BRTEST: MOV     AL, [ES:DI]
JMP     BRTEST

READ_WORD_TEST:
MOV     BX, WORD_RTTEST_MSG ;Get RAM location Enter AX Value
CALL    PRINT_STRING
CALL    GET5DIGITS ;Will return ES=000xH, DI = xxxxH
CALL    CRLF
WRTEST: MOV     AX, [ES:DI]
JMP     WRTEST ;Note CPU will not return from this loop. Reset required

;Loop to analyze hardware RAM Write signals
WRITE_BYTE_TEST:
MOV     BX, BYTE_WTEST_MSG ;Get RAM location Enter AX Value
CALL    PRINT_STRING
CALL    GET5DIGITS ;Will return ES=000xH, DI = xxxxH
CALL    CRLF

```

```

        MOV     AL,55H
BWTEST: MOV     [ES:DI],AL
        JMP     BWTEST

WRITE_WORD_TEST:
        MOV     BX,WORD_WTEST_MSG      ;Get RAM location Enter AX Value
        CALL   PRINT_STRING
        CALL   GET5DIGITS              ;Will return ES=000xH, DI = xxxxH
        CALL   CRLF
        MOV     AX,5555H
WWTEST: MOV     [ES:DI],AX
        JMP     WWTEST                ;Note CPU will not return from this loop. Reset required

;*****
;XXXXX:
;   Video Output Handler      (Software Int# 10H)
;   Will recognize the following settings:-
;
;Input: AH = 00h      VIDEO - SET VIDEO PARAMATERS
;   AL = Display Mode
;
;Input: AH = 01h      VIDEO - SET TEXT-MODE CURSOR SHAPE
;   CH = cursor start and options (see below)
;   CL = bottom scan line containing cursor (bits 0-4)
;   Bitfields for cursor start and options:
;   7           should be zero
;   6,5        cursor blink.
;               (00=normal, 01=invisible, 10=erratic, 11=slow).
;               (00=normal, other=invisible on EGA/VGA)
;   4-0        topmost scan line containing cursor
;Return Nothing
;
;Input: AH = 02h      VIDEO - SET CURSOR POSITION
;   BH = page number (0-3 in modes 2&3. 0-7 in modes 0&1. 0 in graphics modes)
;   DH = row (00h is top)
;   DL = column (00h is left)
;Return:Nothing
;
;Input: AH = 03h      VIDEO - GET CURSOR POSITION AND SIZE
;   BH = page number (0-3 in modes 2&3. 0-7 in modes 0&1. 0 in graphics modes)
;Return:AX = 0000h    (Phoenix BIOS - only)
;   CH = start scan line of cursor
;   CL = end scan line of cursor
;   DH = row (00h is top)
;   DL = column (00h is left)
;
;Input: AH = 05h      VIDEO - SET PAGE
;   BH = page number (0-3 in modes 2&3. 0-7 in modes 0&1. 0 in graphics modes)
;
;Input: AH = 06h      VIDEO - SCROLL UP WINDOW
;   AL = number of lines by which to scroll up (00h = clear entire window)
;   BH = attribute used to write blank lines at bottom of window
;   CH,CL = row,column of window's upper left corner
;   DH,DL = row,column of window's lower right corner

```

```

;Return:Nothing
;
;Input: AH = 07h      VIDEO - SCROLL DOWN WINDOW
;      AL = number of lines by which to scroll down (00h=clear entire window)
;      BH = attribute used to write blank lines at top of window
;      CH,CL = row,column of window's upper left corner
;      DH,DL = row,column of window's lower right corner
;Return:Nothing
;
;Input: AH = 08h      VIDEO - READ CHARACTER AND ATTRIBUTE AT CURSOR POSITION
;      BH = page number (00h to number of pages - 1) (see #00010)
;Return:      AH = character's attribute (text mode only)
;      AL = character
;
;Input: AH = 09h      VIDEO - WRITE CHARACTER AND ATTRIBUTE AT CURSOR POSITION
;      AL = character to display
;      BH = page number (00h to number of pages - 1)
;      BL = attribute (text mode) or color (graphics mode)
;           if bit 7 set in <256-color graphics mode, character is XOR'ed onto screen
;      CX = number of times to write character
;Return:Nothing

;Input: AH = 0Ah      VIDEO - WRITE CHARACTER ONLY AT CURSOR POSITION
;      AL = character to display
;      BH = page number (00h to number of pages - 1)
;      BL = attribute color (graphics mode)
;           if bit 7 set in <256-color graphics mode, character is XOR'ed onto screen
;      CX = number of times to write character
;Return:Nothing
;
;
;
;Input: AH = 0Eh      VIDEO - TELETYPE OUTPUT
;      AL = character to write
;      BH = page number
;      BL = foreground color (graphics modes only)
;Return:Nothing
;
;
;Input: AH = 0Fh      VIDEO - GET VIDEO PARAMATERS
;Return:
;      AH = Number of CRT Columns
;      AL = Display Mode
;      BH = Current page
;
;*****

```

VIDEO_TABLE:

DW	SET_MODE	;<--0	Set Mode
DW	VIDEO_TBD	;1	Set Cursor Type
DW	SET_CURSOR_POS	;<--2	Set Cursor Positrion
DW	GET_CURSOR_POS	;<--3	Get Cursor Position
DW	VIDEO_TBD	;4	Read Light Pen
DW	SET_PAGE	;<--5	Set page
DW	SCROOL_UP	;<--6	Scoll up [AL] lines
DW	SCROOL_DOWN	;<--7	Scroll down [AL] lines

```

DW      READ_CHAR_ATT      ;<--8  Read Char & Attribute at cursor position
DW      WRITE_AT_CURSOR_ATT ;<--9  Write character & attribute at current cursor position
DW      WRITE_AT_CURSOR    ;<--0AH Write character at current cursor position
DW      VIDEO_TBD          ;0BH   Set Color
DW      VIDEO_TBD          ;0cH   Write Dot
DW      VIDEO_TBD          ;0dH   Read Dot
DW      VIDEO_TTY          ;<--0EH ***** Simple TTY mode *****
DW      GET_VIDEO_PARDS    ;<--0FH Get Video state
DW      VIDEO_TBD          ;10H   reserved
DW      VIDEO_TBD          ;11H   reserved
DW      VIDEO_VGA          ;12H   VIDEO - ALTERNATE FUNCTION SELECT (VGA, MCGA) - VIDEO ADDRESSING
DW      WRITE_STRING       ;13H   Write String
M1L     equ                $-VIDEO_TABLE

CONOUT: STI                ;For now just dump character on Propeller Console IO board
        CLD                ;This section of code will very carefully reproduce everything
        PUSH ES            ;that is in the IBM-PC BIOS ROM
        PUSH DS
        PUSH DX
        PUSH CX
        PUSH BX
        PUSH SI
        PUSH DI
        PUSH BP            ;New for AT BIOS
        PUSH AX            ;<<< Save character (in AH) on stack >>>
        PUSH AX            ;Note extra AX on stack for VIDEO_NOT_FINISHED etc routines below

        PUSH AX            ;Need for Debugging output below
        XOR AX,AX          ;Set DS to data area for ROM usage in low RAM @ 400H....)
        MOV DS,AX
        POP AX

        MOV [ES_STORE],ES  ;Save for AH=13H String write (Normally ES is used for the Video RAM pointer)

        CMP AH,0EH         ;Skip simple TTYOut debugging (too much data)
        JZ  SKIP_VIDEO_DEBUG

        CMP byte [DEBUG_FLAG],0 ;Is Debug mode on
        JNZ SHOW_DEBUG_DATA ;If NZ, then debug mode

        PUSH AX
        IN AL,IOBYTE       ;If bit 3 of Port EFH is 0, Then force Debug Display
        AND AL,08H
        POP AX
        JNZ SKIP_VIDEO_DEBUG

SHOW_DEBUG_DATA:
        PUSH AX
        PUSH BX
        MOV BX,INT_10H_MSG ;"Int 1AH (VIDEO) AX="
        CALL SERIAL_PRINT_STRING
        POP BX
        POP AX
        CALL SERIAL_DISPLAY_REGISTERS ;Display Registers on serial port display (All registers retained)

```

```

SKIP_VIDEO_DEBUG:                ;Use a lookup table to locate the correct AH option
    MOV     AL,AH
    XOR     AH,AH                ;0 to AH
    SAL     AX,1                ;X2 for table lookup
    MOV     SI,AX
    CMP     AX,M1L              ;Check we are within range
    JB     VIDEO_AH_OK

    PUSH    BX                  ;Out of range request
    MOV     BX,INT_10H_MSG      ;"Int 1AH (VIDEO) AX="
    CALL    SERIAL_PRINT_STRING
    POP     BX
    CALL    SERIAL_DISPLAY_REGISTERS ;Display Registers on serial port display (All registers retained)
    POP     AX                  ;Currently there are 2 AX's on stack
    JMP     VIDEO_RETURN

VIDEO_AH_OK:
    MOV     AX,0B800H           ;Segment of CGA Board RAM
    mov     di,[EQFLAG]
    and     di,30h              ;isolate crt switches
    cmp     di,30h
    jne     MX3
    mov     ax,0B000h           ;segment for B/W card
MX3:    mov     es,ax            ;Set ES: to point to video area
    POP     AX                  ;<--- Get requested AH & AL values
    MOV     AH,[CRT_MODE]       ;Current mode now in AH (used by CGA/VGA video board)

    JMP     [CS:SI+VIDEO_TABLE] ;go to appropriate routine with card type in DI
                                       ;mode in AH, video ram in ES and value in AL.

;-----

SET_MODE:
    CMP     word [CONSOL_FLAG],0 ;AH = 0h, AL= Mode VIDEO - GET VIDEO PRAMATERS
    JZ     PROPELLER_SET_MODE    ;Send output to Propeller board (0), VGA Video board (1), or LAVA Board (2)
    CMP     word [CONSOL_FLAG],2
    JZ     LAVA_SET_MODE
    JMP     VGA_SET_MODE         ;Set the display mode of the CGA/VGA Board

PROPELLER_SET_MODE:
    MOV     AX,0003H
    JMP     VIDEO_RETURN

LAVA_SET_MODE:
    ;LAVA has one mode only
    CALL    INITILIZE_LAVA      ;Clear Screen, Green/Black, Cursor 0,0
    MOV     AX,0003H
    JMP     VIDEO_RETURN

;-----

                                ;AH = 02h VIDEO - SET CURSOR POSITION
SET_CURSOR_POS:
                                ;DH = row (00h is top), DL = column (00h is left)
    CMP     word [CONSOL_FLAG],0 ;Send output to Propeller board (0),VGA Video board (1), or LAVA Board (2)
    JZ     PROPELLER_SET_CURSOR_POS
    CMP     word [CONSOL_FLAG],2
    JZ     LAVA_SET_CURSOR_POS
    JMP     VGA_SET_CURSOR_POS

PROPELLER_SET_CURSOR_POS:
    CALL    PROPELLER_SET_CURSOR ;Set Cursor at [DX] on Propeller Board

```

```

        JMP     VIDEO_RETURN
LAVA_SET_CURSOR_POS:      ;Set Cursor at [DX] on LAVA Board
        CALL   L_HIDE_CURSOR      ;DX is unchanged
        CALL   L_SET_CURSOR
        JMP     VIDEO_RETURN

;-----
                                ;AH = 03h      VIDEO - GET CURSOR POSITION AND SIZE
GET_CURSOR_POS:          ;DH = row (00h is top), DL = column (00h is left)
        CMP    word [CONSOL_FLAG],0 ;Send output to Propeller board (0), or Video board (1), or LAVA Board (2)
        JZ     PROPELLER_GET_CURSOR_POS
        CMP    word [CONSOL_FLAG],2
        JZ     LAVA_GET_CURSOR_POS
        JMP     VGA_GET_CURSOR_POS
PROPELLER_GET_CURSOR_POS:
        JMP     VIDEO_NOT_FINISHED ;<<<< Ignore for now
LAVA_GET_CURSOR_POS:
        CALL   L_GET_CURSOR
        JMP     VIDEO_RETURN

;-----
                                ;AH = 05h      VIDEO - SET PAGE
SET_PAGE:              ;BH = page number (0-3 in modes 2&3. 0-7 in modes 0&1. 0 in graphics modes)
        CMP    word [CONSOL_FLAG],0 ;Send output to Propeller board (0), or Video board (1), or LAVA Board (2)
        JZ     PROPELLER_SET_PAGE
        CMP    word [CONSOL_FLAG],2
        JZ     LAVA_SET_PAGE
        JMP     VGA_SET_PAGE
PROPELLER_SET_PAGE:
        MOV    BH,0                ;Always
        JMP     VIDEO_RETURN
LAVA_SET_PAGE:
        MOV    BH,0                ;<<<<< Ignore for now (Add 0 & 1 later)
        JMP     VIDEO_RETURN

;-----
                                ;AH = 06h      VIDEO - SCROLL UP WINDOW
SCROLL_UP:            ;AL = number of lines by which to scroll up (00h = clear entire window)
        CMP    word [CONSOL_FLAG],0 ;Send output to Propeller board (0), or Video board (1), or LAVA Board (2)
        JZ     PROPELLER_SCROLL_UP
        CMP    word [CONSOL_FLAG],2
        JZ     LAVA_SCROLL_UP
        JMP     VGA_SCROLL_UP
PROPELLER_SCROLL_UP:
        OR     CX,CX                ;Start 0,0?, (CH,CL = row,column start, DH,DL = row,column end)
        JZ     SCROLL_UP_0
        PUSH  AX
        PUSH  DX
        MOV   DX,CX                ;At least we will reposition cursor to 0,0
        CALL  PROPELLER_SET_CURSOR ;Set Cursor at [DX]
        POP   DX
        POP   AX
        JMP   VIDEO_NOT_FINISHED ;Will ignore DX for now

```

```

SCROLL_UP_0:
    OR     AL,AL                ;AL has number of lines to scroll
    JNZ   SCROLL_UP_1
    MOV   AL,40                ;0 for current 40 line CRT
SCROLL_UP_1:
    PUSH  AX
    MOV   AH,ESC
    CALL  FAST_CONOUT
    MOV   AH,'D'
    CALL  FAST_CONOUT
    POP   AX
    DEC   AL
    JNZ   SCROLL_UP_1
    JMP   VIDEO_RETURN
LAVA_SCROLL_UP:
    OR     CX,CX                ;Start 0,0?, (CH,CL = row,column start, DH,DL = row,column end)
    JZ    LAVA_SCROLL_UP_L0
    PUSH  AX
    PUSH  DX
    MOV   DX,CX                ;At least we will reposition cursor to 0,0
    CALL  L_SET_CURSOR         ;Set Cursor at [DX]
    POP   DX
    POP   AX
    JMP   VIDEO_NOT_FINISHED  ;Will ignore DX for now
LAVA_SCROLL_UP_L0:
    OR     AL,AL                ;AL has number of lines to scroll
    JNZ   LAVA_SCROLL_UP_L1
    CALL  L_CLEAR_SCREEN       ;AL=0 then clear whole screen
    JMP   VIDEO_RETURN
LAVA_SCROLL_UP_L1:
    PUSH  AX
    CALL  L_SCROLL_UP_1
    POP   AX
    DEC   AL
    JNZ   LAVA_SCROLL_UP_L1
    JMP   VIDEO_RETURN

;-----
SCROOL_DOWN:
    ;AH = 07h      VIDEO - SCROLL DOWN WINDOW
    ;AL = number of lines by which to scroll up (00h = clear entire window)
    CMP   word [CONSOL_FLAG],0 ;Send output to Propeller board (0), Video board (1), or LAVA Board (2)
    JZ    PROPELLER_SCROOL_DOWN
    CMP   word [CONSOL_FLAG],2 ;Send output to Propeller board (0), Video board (1), or LAVA Board (2)
    JZ    LAVA_SCROLL_DOWN
    JMP   VGA_SCROLL_DOWN
PROPELLER_SCROOL_DOWN:
    OR     CX,CX                ;Start 0,0?, (CH,CL = row,column start, DH,DL = row,column end)
    JZ    SCROLL_DOWN_0
    PUSH  AX
    PUSH  DX
    MOV   DX,CX                ;At least we will reposition cursor
    CALL  PROPELLER_SET_CURSOR ;Set Cursor at [DX]
    POP   DX
    POP   AX

```



```

        JMP     VIDEO_NOT_FINISHED      ;Will ignore DX for now
SCROLL_DOWN_0:
        CMP     AL,0                    ;AL has number of lines to scroll
        JNZ     SCROLL_DOWN_1
        MOV     AL,40                   ;0 for current 40 line CRT
SCROLL_DOWN_1:
        PUSH    AX
        MOV     AH,ESC
        CALL    FAST_CONOUT
        MOV     AH,'M'
        CALL    FAST_CONOUT
        POP     AX
        DEC     AL
        JNZ     SCROLL_DOWN_1
        JMP     VIDEO_RETURN

LAVA_SCROLL_DOWN:
        OR      CX,CX                  ;Start 0,0?, (CH,CL = row,column start, DH,DL = row,column end)
        JZ      SCROLL_DOWN_L0
        PUSH    AX
        PUSH    DX
        MOV     DX,CX                  ;At least we will reposition cursor
        CALL    L_SET_CURSOR           ;Set Cursor at [DX]
        POP     DX
        POP     AX
        JMP     VIDEO_NOT_FINISHED     ;Will ignore DX for now
SCROLL_DOWN_L0:
        CMP     AL,0                    ;AL has number of lines to scroll
        JNZ     SCROLL_DOWN_L1
        CALL    L_CLEAR_SCREEN         ;AL=0 then clear whole screen
        JMP     VIDEO_RETURN
SCROLL_DOWN_L1:
        JMP     VIDEO_NOT_FINISHED     ;<<<< Will ignore DX for now
        PUSH    AX
;       CALL    L_SCROLL_DOWN          ;<<<<< Not Done Yet
        POP     AX
        DEC     AL
        JNZ     SCROLL_DOWN_L1
        JMP     VIDEO_RETURN

;-----
;AH = 08h      VIDEO - READ CHARACTER AND ATTRIBUTE AT CURSOR POSITION
READ_CHAR_ATT:
;AL = character to display
        CMP     word [CONSOL_FLAG],0   ;Send output to Propeller board (0), Video board (1), or LAVA Board (2)
        JZ      PROPELLER_READ_CHAR_ATT
        CMP     word [CONSOL_FLAG],2
        JZ      LAVA_READ_CHAR_ATT
        JMP     VGA_READ_AC_CURRENT
PROPELLER_READ_CHAR_ATT:
;AL = character to display
        OR      BH,BH                  ;BH = page number (00h to number of pages - 1)
        JNZ     VIDEO_NOT_FINISHED     ;BL = attribute (text mode) or color (graphics mode)

        MOV     AH,07                  ;Return: AH = character's attribute (text mode only)
        MOV     AL,0                    ;      AL = character (Not implemented)
        JMP     VIDEO_RETURN

```

```

LAVA_READ_CHAR_ATT:           ;AL = character to display
    OR     BH,BH               ;BH = page number (00h to number of pages - 1)
    JNZ   VIDEO_NOT_FINISHED ;BL = attribute (text mode) or color (graphics mode)
    MOV   AH,07                ;Return: AH = character's attribute (text mode only)
    MOV   AL,0                 ;      AL = character (Not implemented)
    JMP   VIDEO_RETURN

;-----
WRITE_AT_CURSOR_ATT:         ;AH = 09h      VIDEO - WRITE CHARACTER AND ATTRIBUTE AT CURSOR POSITION
    ;AL = character to display
    CMP   word [CONSOL_FLAG],0 ;Send output to Propeller board (0), Video board (1), or LAVA Board (2)
    JZ    PROPELLER_WRITE_AT_CURSOR_ATT
    CMP   word [CONSOL_FLAG],2
    JZ    LAVA_WRITE_AT_CURSOR_ATT
    JMP   VGA_WRITE_AC_CURRENT ;Send to display on CGA/VGA Board
PROPELLER_WRITE_AT_CURSOR_ATT:
    OR     BH,BH               ;BH = page number (00h to number of pages - 1)
    JNZ   VIDEO_NOT_FINISHED ;BL = attribute (text mode) or color (graphics mode)
    MOV   AH,AL               ;CX = number of times to write character
AT_CURSOR1:
    CALL  FAST_CONOUT         ;Fast direct output to Propeller board
    LOOP AT_CURSOR1          ;Repeat CX times
    JMP   VIDEO_RETURN
LAVA_WRITE_AT_CURSOR_ATT:
    OR     BH,BH               ;BH = page number (00h to number of pages - 1)
    JNZ   VIDEO_NOT_FINISHED ;BL = attribute (text mode) or color (graphics mode)
    MOV   AH,AL               ;CX = number of times to write character
L_AT_CURSOR:
    CALL  L_TTY_OUT           ;Fast direct output to LAVA board (Character in AH)
    LOOP L_AT_CURSOR         ;Repeat CX times
    JMP   VIDEO_RETURN

;-----
WRITE_AT_CURSOR:            ;AH = 0Ah      VIDEO - WRITE CHARACTER ONLY AT CURSOR POSITION
    ;AL = character to display
    CMP   word [CONSOL_FLAG],0 ;Send output to Propeller board (0), Video board (1), or LAVA Board (2)
    JZ    PROPELLER_WRITE_AT_CURSOR
    CMP   word [CONSOL_FLAG],2
    JZ    PROPELLER_WRITE_AT_CURSOR
    JMP   VGA_WRITE_C_CURRENT ;Send to display on CGA/VGA Board
PROPELLER_WRITE_AT_CURSOR:
    OR     BH,BH               ;BH = page number (00h to number of pages - 1)
    JNZ   VIDEO_NOT_FINISHED ;BL = attribute (text mode) or color (graphics mode)
    MOV   AH,AL               ;CX = number of times to write character
AT_CURSOR2:
    CALL  FAST_CONOUT         ;Fast direct output to Propeller board
    LOOP AT_CURSOR2          ;Repeat CX times
    JMP   VIDEO_RETURN
LAVA_WRITE_AT_CURSOR:
    OR     BH,BH               ;BH = page number (00h to number of pages - 1)
    JNZ   VIDEO_NOT_FINISHED ;BL = attribute (text mode) or color (graphics mode)
    MOV   AH,AL               ;CX = number of times to write character

```

```

AT_CURSOR2L:
    CALL    L_TTY_OUT          ;Fast direct output to LAVA board  (Character in AH)
    LOOP   AT_CURSOR2L       ;Repeat CX times
    JMP    VIDEO_RETURN

;-----
VIDEO_TTY:
    ;AH = 0EH      ***** Simple TTY Output mode *****
    ;AL = character, BL Background (1= green), BH = page
    TEST   byte[KB_FLAG_1],HOLD_STATE    ;Is Pause flag set
    JNZ    VIDEO_TTY

    CMP    word [CONSOL_FLAG],0    ;Send output to Propeller board (0), Video board (1), or LAVA Board (2)

    JZ     PROPELLER_VIDEO_TTY
    CMP    word [CONSOL_FLAG],2
    JZ     LAVA_VIDEO_TTY
    JMP    VGA_WRITE_TTY
PROPELLER_VIDEO_TTY:
    IN     AL,KEYSTAT              ;Default Propeller or SD SYSTEMS VIDIO BOARD PORT
    AND    AL,4H                  ;Is board ready for character
    JZ     VIDEO_TTY
    POP    AX                      ;<-- Get character from AX on stack above
    OUT    KEYOUT,AL
    JMP    VIDEO_RETURN1          ;Note the normal extra AX was removed from stack above
LAVA_VIDEO_TTY:
    MOV    AH,AL
    CALL   L_TTY_OUT              ;Fast direct output to LAVA board  (Character in AH)
    JMP    VIDEO_RETURN

;-----
GET_VIDEO_PARMS:
    ;AH = 0Fh      VIDEO - GET VIDEO PARAMATERS
    ;AH = Number of CRT Columns, AL = Display Mode
    CMP    word [CONSOL_FLAG],0    ;Send output to Propeller board (0) or Video board (1), or LAVA Board (2)
    JZ     PROPELLER_GET_VIDEO_STATE
    CMP    word [CONSOL_FLAG],2
    JZ     LAVA_GET_VIDEO_STATE
    JMP    VGA_GET_VIDEO_STATE
PROPELLER_GET_VIDEO_STATE:
    MOV    AX,5003H
    MOV    BX,0                    ;BH = Current page
    JMP    VIDEO_RETURN
LAVA_GET_VIDEO_STATE:
    MOV    AX,6303H                ;99 Characters/line
    MOV    BX,0                    ;BH = Current page
    JMP    VIDEO_RETURN

;-----
VIDEO_VGA:
    ;AH = 12H      VIDEO - ALTERNATE FUNCTION SELECT (VGA, MCGA) - VIDEO ADDRESSING
    ;BL = 32, return AL = new state. 0 = enabled, 1 = disable
    ;Use for Cirrus VGA Board initialization (only)
    CMP    BL,32H
    JNZ    VIDEO_TBD
    MOV    AL,12H                  ;Return AL = 12h if function is supported
    JMP    VIDEO_RETURN

```

```

;-----
WRITE_STRING:                ;AH = 13H      VIDEO - WRITE CHARACTER AND ATTRIBUTE AT CURSOR POSITION
                             ;ES:BP = string pointer
MOV     ES,[ES_STORE]        ;Saved at the start
CMP     word [CONSOL_FLAG],0 ;Send output to Propeller board (0), Video board (1), or LAVA Board (2)
JZ      PROPELLER_WRITE_STRING ;CX = string length
CMP     word [CONSOL_FLAG],2
JZ      LAVA_WRITE_STRING    ;CX = string length
JMP     VGA_WRITE_STRING     ;DX = cursor position

PROPELLER_WRITE_STRING:
OR      BH,BH                ;Can do only page 0
JNZ     VIDEO_NOT_FINISHED  ;BH = page number (00h to number of pages - 1)
OR      CX,CX                ;For zero length string, just return (as IBM does)
JZ      PrW2
OR      AL,AL                ;AL = 0, do not move cursor, AL = 1, update cursor. AL=3 or 4 add attriute also
JZ      PrW1                ;Currently only AL=0 & 1 mode implemented
CALL    PROPELLER_SET_CURSOR ;Set Cursor at [DX]
PrW1:  MOV     AH,[ES:BP]     ;Send string to console
CALL    FAST_CONOUT
INC     BP                    ;No need to save BP
LOOP   PrW1
PrW2:  JMP     VIDEO_RETURN

LAVA_WRITE_STRING:
OR      BH,BH                ;Can do only page 0
JNZ     VIDEO_NOT_FINISHED  ;BH = page number (00h to number of pages - 1)
OR      CX,CX                ;For zero length string, just return (as IBM does)
JZ      LPrW2
PUSH   AX                    ;Save Cursor update info
OR      AL,AL                ;AL = 0, do not move cursor, AL = 1, update cursor. AL=3 or 4 add attriute also
JZ      LPrW1
CALL    L_HIDE_CURSOR
LPrW1: MOV     AH,[ES:BP]     ;Send string to console
CALL    L_TTY_OUT_NO_UPDATE
INC     BP                    ;No need to save BP
LOOP   LPrW1

POP     AX
OR      AL,AL                ;AL = 0, do not move cursor, AL = 1, update cursor. AL=3 or 4 add attriute also
JZ      LPrW2
CALL    L_NEXT_POSITION     ;Advance the cursor one position, next line if at EOL, Scroll up if at bottom of screen
CALL    L_SHOW_CURSOR       ;Show new cursor position
LPrW2: JMP     VIDEO_RETURN

;----- CGA/VGA Video board routines -----
;
; Note all INT 10H generated Console outputs will come here if [CONSOLE_FLAG] = 1
;
VGA_SET_MODE:
CALL    VGA_INIT            ;Want this callable because it is used at Initalization
JMP     VIDEO_RETURN

```

```

;Arrive here with ES: set to Video RAM area, DS:=0, AL=Mode
VGA_INIT: ;Initilize the S-100 Lomas CGA video board (or compatible board)
    mov     dx,c6845port+4 ;address of colour card
    mov     bl,0           ;mode set for colour
    cmp     di,30h
    jne     m8
    mov     al,7
    mov     dx,bw6845port+4 ;address of b/w card
    inc     bl           ;mode set for bw card

m8:     mov     ah,al       ;save mode in ah
    mov     [CRT_MODE],al  ;store it
    mov     [ADDR_6845],dx ;also chip ports

    PUSH   DS             ;Stuff in capitals below are mods in the AT-BIOS ROM
    push  ax
    push  dx             ;save 6845 base reg

    add   dx,4           ;point to control reg = 3d8h
    mov   al,bl         ;get mode
    out  dx,al         ;setup chip for new mode

    pop   dx             ;back to base 6845 reg
    sub  ax,ax
    mov  ds,ax         ;DS: to 0

    LDS  bx,[VID_PARM_PTR] ;DS=0, BX=VID_PARM_PTR, will set DS=CS (here), BX to VID_PARM_TABLES
    pop  ax             ;get back parameters

    mov  cx,Index_Reg_Count ;length of row table
    cmp  ah,2           ;Need to figure out which patamater table to use
    jc   m9            ;mode 0 or 1 (40X25)
    add  bx,cx         ;go to next row of int table, ie 16 bytes higher
    cmp  ah,4
    jc   m9            ;mode 2 or 3 (80X25)
    add  bx,cx
    cmp  ah,7
    jc   m9            ;mode is 4,5 or 6 (graphics mode)
    add  bx,cx         ;else BW Card paramaters

m9:     push  ax         ;BX points to correct row of init Table
    PUSH  ES
    XOR  AX,AX         ;Not clear why AT BIOS has this stuff
    MOV  ES,AX        ;ES:-> 0
    MOV  AX,[BX+10]   ;Uses DS:=0
    XCHG AH,AL
    MOV  [ES:CURSOR_MODE],AX
    POP  ES

    xor  ah,ah

m10:    mov  al,ah     ;Block output iniation parms to chip.
    out  dx,al

    inc  dx           ;next port
    inc  ah           ;next value

```

```

mov     al,[bx]           ;Note this will use [DS:BX] from the above LDS
out     dx,al

inc     bx
dec     dx               ;back to pointer reg
loop   m10

pop     ax
POP     DS

xor     di,di           ;fill video with blanks
mov     [CRT_START],di  ;start address
mov     byte[ACTIVE_PAGE],0
mov     cx,8192         ;number of words in colour card
cmp     ah,4           ;Test for colour card
jc     m12
cmp     ah,7
je     m11
xor     ax,ax           ;fill for graphics mode
jmp     short m13
m11:   mov     CH,08H    ;buffer size for b/w card
m12:   mov     ax,' '+ (02H*256) ;<<<<NOTE IBM USES WHITE ON BLACK (07), we use 02,Green
m13:   rep     stosw     ;AX -> [ES:DI] (Normally B800:0 upwards)

mov     al,[CRT_MODE]   ;;;get the mode ->AL
xor     ah,ah           ;AH to 0
mov     si,ax
mov     dx,[ADDR_6845]
add     dx,4

mov     al,[CS:si+m7]   ;Make sure we use the CS: override (DS:=0)

out     dx,al
mov     [CRT_MODE_SET],al ;save that value

mov     al,[CS:si+m6]
xor     ah,ah
mov     [CRT_COLS],ax

and     si,0eh          ;word offset into clear length table
mov     cx,[CS:si+m5]  ;Make sure we use teh CS: override (DS:=0)
mov     [CRT_LEN],cx  ;save length of crt
mov     cx,2           ;clear all cursor positions (we have space for only 2)
mov     di,[CURSOR_POSN]
push   ds              ;DS=0
pop     es              ;ES=0
xor     ax,ax          ;AX=0 -> [ES:DI]
rep     stosw          ;Repeat 2 times

inc     dx              ;Set overscan port to a default
mov     al,30h
cmp     byte[CRT_MODE],6
jnz    m14
mov     al,3fh         ;640 x 200 is special case
m14:   out     dx,al
mov     [CRT_PALLETTE],al ;store value

```



```

;      READ CURSOR POSITION
;      BH = PAGE OF CURSOR
;output:-
;      DX = ROW,COLUMN OF THE CURSOR POSITION
;      CX = CURRENT CURSOR MODE

VGA_GET_CURSOR_POS:          ;AH = 03h      VIDEO - GET CURSOR POSITION AND SIZE
    mov     bl,bh
    xor     bh,bh
    sal     bx,1
    mov     dx,[bx+CURSOR_POSN]
    mov     cx,[CURSOR_MODE]
    POP     AX                ;Remove the "extra AX"
    POP     BP                ;New for AT-BIOS
    POP     DI
    POP     SI
    POP     BX
    POP     AX                ;Discard old CX & DX
    POP     AX
    POP     DS
    POP     ES
    IRET

;      SET THE ACTIVE DISPLAY PAGE
;      AL = NEW DISPLAY PAGE

VGA_SET_PAGE:                ;AH = 5
    mov     [ACTIVE_PAGE],al
    mov     cx,[CRT_LEN]
    cbw
    push    ax
    mul     cx
    mov     [CRT_START],ax

    mov     cx,ax
    sar     cx,1
    mov     ah,12
    call    m16
    pop     bx
    sal     bx,1
    mov     ax,[bx+CURSOR_POSN]
    call    m18
    JMP     VIDEO_RETURN

;      SET BACKGROUND COLOUR,OVERSCAN COLOUR, AND FORGROUND COLOUR FOR MEDIUM RESOLUTION GRAPHICS
;      BH = 0 THEN BACKGROUND SET FROM LOW BITS OF BL (0-31)
;      BH = 1 THE PALLET SELECTION IS MADE BASED ON LOW BITS OF BL:-
;              0 = GREEN, RED,YELLOW FOR COLOURS 1,2,3
;              1 = BLUE,CYAN,MAGENTA FOR COLOURS 1,2,3
;      BL = COLOUR VALUE TO BE USED

```



```

VGA_SET_COLOR:                ;AH = 0BH
    mov     dx,[ADDR_6845]
    add     dx,5
    mov     al,[CRT_PALLETTE]
    or     bh,bh
    jnz    m20

    and     al,0e0h            ;handle for colour 0
    and     bl,1fh
    or     al,bl

m19:    out     dx,al
    mov     [CRT_PALLETTE],al
    JMP    VIDEO_RETURN

m20:    and     al,0dfh        ;handel colour 1
    shr     bl,1
    jnc    m19
    or     al,20h
    jmp    m19

;     GET CURRENT VIDIO STATE
;     AL = CURRENT VIDIO MODE
;     BH = CURRENT ACTIVE PAGE

VGA_GET_VIDEO_STATE:         ;AH = 0FH
    mov     ah,[CRT_COLS]
    mov     al,[CRT_MODE]
    mov     bh,[ACTIVE_PAGE]
    POP    DI                ;Remove the "extra AX"
    POP    BP                ;New for AT-BIOS
    POP    DI
    POP    SI
    POP    CX                ;Discard saved BX
    JMP    M15              ;Jump to remainder on VIDEO_RETURN

;     Scroll up text on screen
;     AL     =     NUMBER OF ROOLS TO SCROOL
;     CX     =     ROW/COL UPPER LEFT
;     DX     =     ROW/COL LOWER RIGHT
;     BH     =     ATTRIBUTE
;     DS     =     DATA SEGMENT
;     ES     =     VIDEO BUFFER

VGA_SCROLL_UP:              ;AH = 6
    CALL   TEST_LINE_COUNT   ;New in AT-BIOS
    cmp    ah,4
    jc     n1
    cmp    ah,7
    je     n1
    jmp    graphics_up

```

```

n1:  push  bx
      mov  ax,cx
      call scrool_position
      jz   n7
      add  si,ax
      mov  ah,dh
      sub  ah,bl

n2:  call  n10
      add  si,bp
      add  di,bp
      dec  ah
      jnz  n2

n3:  pop   ax
      mov  al,' '           ;fill with blanks

n4:  call  n11
      add  di,bp
      dec  bl
      jnz  n4

n5:  xor   ax,ax
      mov  ds,ax
      cmp  byte [CRT_MODE],7
      je   n6
      mov  al,[CRT_MODE_SET]
      mov  dx,3d8h         ;set colour port
      out  dx,al

n6:  JMP   VIDEO_RETURN

n7:  mov   bl,dh
      jmp  n3

scrool_position:
      ;the lomas board does not need video off here
      ;also no need to wait for retrace
      cmp  byte [CRT_MODE],2
      jb  n9
      cmp  byte [CRT_MODE],3
      ja  n9

      push dx
      mov  dx,3dah         ;must be 80x25 colour scroll
      push ax

n8:  in   al,dx
      test al,8           ;wait for vertical retrace
      jz  n8
      mov  al,25h
      mov  dx,3d8h
      out  dx,al         ;turn off vidio
      pop  ax           ;during retrace
      pop  dx

```

```

n9:   call    POSITION
      add    ax,[CRT_START]
      mov    di,ax
      mov    si,ax
      sub    dx,cx
      inc    dh
      inc    dl
      xor    ch,ch
      mov    bp,[CRT_COLS]
      add    bp,bp
      mov    al,bl
      mul   byte [CRT_COLS]
      add    ax,ax
      push   es
      pop    ds
      cmp    bl,0
      ret

n10:  mov    cl,dl                ;no of columns to move
      push   si
      push   di
      rep   movsw
      pop    di
      pop    si
      ret

n11:  mov    cl,dl                ;no of columns to clear
      push   di
      rep   stosw
      pop    di
      ret

;     Scroll down text on screen
;     Ah     =     CURRENT CRT MODE
;     AL     =     NUMBER OF ROOLS TO SCROOL
;     CX     =     ROW/COL UPPER LEFT
;     DX     =     ROW/COL LOWER RIGHT
;     BH     =     ATTRIBUTE
;     DS     =     DATA SEGMENT
;     ES     =     VIDEO BUFFER
;

VGA_SCROLL_DOWN:                ;AH = 7
      std
      CALL  TEST_LINE_COUNT      ;New in AT-BIOS
      cmp  ah,4
      jc   n12
      cmp  ah,7
      je   n12
      jmp  graphics_down

n12:  push  bx
      mov  ax,dx

```

```

        call    scrool_position
        jz     n16
        sub    si,ax
        mov    ah,dh
        sub    ah,bl

n13:    call    n10
        sub    si,bp
        sub    di,bp
        dec    ah
        jnz    n13

n14:    pop    ax
        mov    al,' '

n15:    call    n11
        sub    di,bp
        dec    bl
        jnz    n15
        jmp    n5

n16:    mov    bl,dh
        jmp    n14

TEST_LINE_COUNT:    ;New in AT-BIOS
                    ;If lines to be scrolled = lines in window, adjust AL else return
        MOV     BL,AL
        OR     AL,AL
        JZ     BL_SET
        PUSH  AX
        MOV    AL,DH
        SUB    AL,CH
        INC    AL
        CMP    AL,BL
        POP    AX
        JNE    BL_SET
        SUB    BL,BL
BL_SET  RET

;      READ CURRENT CHARACTER AND ATTRIBUTE
;      AH = CURRENT CRT MODE
;      BH = DISPLAY PAGE
;      DS = DATA SEGMENT
;      ES = REGEN SEGMENT
;output:-
;      AH = ATTRIBUTE READ
;      AL = CHAR READ
;
VGA_READ_AC_CURRENT:    ;AH = 08H
        cmp    ah,4
        jc    p1
        cmp    ah,7
        je    p1
        jmp    graphics_read

p1:    call    find_position

```

```

        mov     si,bx

        mov     dx,[ADDR_6845]      ;wait for retreace
        add     dx,6
        push    es
        pop     ds

p2:     in      al,dx
        test    al,1
        jnz    p2
        cli                                ;no more ints

p3:     in      al,dx
        test    al,1
        jz     p3
        lodsw
        JMP    VIDEO_RETURN

find_position:
        mov     cl,bh
        xor     ch,ch
        mov     si,cx
        sal     si,1
        mov     ax,[si+CORSOR_POSN]
        xor     bx,bx
        jcxz    p5

p4:     add     bx,[CRT_LEN]
        loop   p4

p5:     call    POSITION
        add     bx,ax
        ret

;       WRITE CHAR AND ATTRIBUATE AT CURRENT CURSOR POSITION
;       AH = CURRENT CRT MODE
;       BH = DISPLAY PAGE
;       CX = COUNT OF CHARACTERS TO WRITE
;       AL = CHAR TO WRITE
;       BL = ATTRIBUATE OF CHAR TO WRITE
;       DS = DATA SEGMENT
;       ES = REGEN SEGMENT

VGA_WRITE_AC_CURRENT:                ;AH = 9
        cmp     ah,4
        jc     p6
        cmp     ah,7
        je     p6
        jmp    graphics_write

p6:     mov     ah,b1
        push    ax
        push    cx
        call   find_position

```

```

        mov     di,bx
        pop     cx
        pop     bx

p7:     mov     dx,[ADDR_6845]
        add     dx,6

p8:     in      al,dx
        test    al,1
        jnz    p8
        cli

p9:     in      al,dx
        test    al,1
        jz     p9
        mov     ax,bx
        stosw
        sti
        loop   p7
        JMP    VIDEO_RETURN

```

```

;       WRITE CHAR AT CURSOR POSITION DO NOT CHANGE ATTRIBUATE
;       BH = DISPLAY PAGE
;       CX = COUNT OF CHARACTERS TO WRITE
;       AL = CHAR TO WRITE
;       DS = DATA SEGMENT
;       ES = REGEN SEGMENT

```

```

VGA_WRITE_C_CURRENT:           ;AH = 0AH
        cmp     ah,4
        jc     p10
        cmp     ah,7
        je     p10
        jmp    graphics_write

p10:    push    ax
        push    cx
        call   find_position
        mov     di,bx
        pop     cx
        pop     bx

p11:    mov     dx,[ADDR_6845]
        add     dx,6

p12:    in      al,dx
        test    al,1
        jnz    p12
        cli

p13:    in      al,dx
        test    al,1
        jz     p13

```

```

mov     al,bl
stosb
sti
inc     di                ;go past attribute
loop   p11
JMP    VIDEO_RETURN

;AH = 13H      VIDEO - WRITE CHARACTER AND ATTRIBUTE AT CURSOR POSITION
;ES:BP = string pointer (Note: New in AT-BIOS)
;Test for invalid request
VGA_WRITE_STRING:
    CMP     AL,04
    JB      W0
    JMP     DONE
W0:    OR     CX,CX        ;Return if zero length
    JNZ     W1
    JMP     DONE
W1:    PUSH  BX
    MOV     BL,BH        ;get current cursor position for that page
    XOR     BH,BH
    SAL     BX,1         ;X2
    MOV     SI,[BX+CURSOR_POSN] ;0,1,2,..UP TO 8 PAGES
    POP     BX
    PUSH   SI           ;save current cursor position

    PUSH   AX           ;save write string option
    MOV     AX,0200H
    INT     10H        ;set new cursor position
    POP     AX

WRITE_CHAR:
    PUSH   CX
    PUSH   BX
    PUSH   AX
    PUSH   ES

    XCHG   AH,AL
    MOV     AL,[ES:BP]
    INC     BP

    CMP     AL,08H      ;special cases, BS
    JE      DD_TTY
    CMP     AL,0DH
    JE      DD_TTY
    CMP     AL,0AH
    JE      DD_TTY
    CMP     AL,07H
    JNE     GET_ATTRIBUTE

DD_TTY: MOV     AH,0EH        ;write to tty
    INT     10H
    MOV     BL,BH
    SAL     BH,1           ;X2
    MOV     DX,[BX+CURSOR_POSN]
    POP     ES

```

```

        POP     AX
        POP     BX
        POP     CX
        JMP     ROWS_SET

GET_ATTRIBUTE:
        MOV     CX,1
        CMP     AH,2           ;If AL is 1 or 2 them AL has ASCII character, BL has the Attribute
        JB     GOT_IT        ;If 3 or 4 then attrib, char, attrtrib, char.....
        MOV     BL,[ES:BP]
        INC     BP

GOT_IT: MOV     BH,0
        MOV     CX,1
        MOV     AH,09H       ;write char & attribute on crt
        INT     10H
        POP     ES
        POP     AX
        POP     BX
        POP     CX

        INC     DL           ;inc column count
        CMP     DL,[CRT_COLS]

        JB     COLUMNS_SET
        INC     DH
        SUB     DL,DH
        CMP     DH,25       ;bottom of page
        JB     ROWS_SET

        PUSH    ES
        PUSH    AX
        MOV     AX,0E0AH    ;scroll down one line
        INT     10H
        DEC     DH
        POP     AX
        POP     ES

ROWS_SET:
COLUMNS_SET:
        PUSH    AX
        MOV     AX,0200H    ;set cursor position
        INT     10H
        POP     AX
        LOOP   WRITE_CHAR

        POP     DX
        CMP     AL,1
        JE     DONE
        CMP     AL,3
        JE     DONE
        MOV     AX,0200H    ;set cursor position
DONE:   JMP     VIDEO_RETURN

```



```

;      READ OR WRITE A DOT AT INDICATED POSITION
;      DX = ROW (0-199)
;      CX = COLUMN (0-639)
;      AL = DOT VALUE (see text)
;      DS = DATA SEGMENT
;      ES = REGEN SEGMENT
;output:-
;      AL = DOT VALUE READ, RIGHT JUSTIFIED

VGA_READ_DOT:                ;AH = 0DH
    call    RX3
    mov     al,[es:si]
    and     al,ah
    shl     al,cl
    mov     cl,dh
    rol     al,cl
    JMP     VIDEO_RETURN

VGA_WRITE_DOT:              ;AH = 0CH
    push    ax
    push    ax
    call    RX3
    shr     al,cl
    and     al,ah
    mov     cl,[es:si]
    pop     bx
    test    bl,80h
    jnz     rx2
    not     ah
    and     cl,ah
    or      al,cl

rx1:   mov     [es:si],al
    pop     ax
    JMP     VIDEO_RETURN

rx2:   xor     al,cl
    jmp     rx1

;
;      THIS ROUTINE DETERMINES THE RAM LOCATION OF COL/ROW
;input:-
;      DX = ROW (0-199)
;      CX = COLUMN (0-639)
;output:-
;      SI = OFFSET INTO RAM
;      AH = MASK TO STRIP OF BITS OF INTREST
;      CL = BITS TO SHIFT TO RIGHT JUSTIFY MASK IN AH
;      DH = NO OF BITS IN RESULT
;
RX3:   push    bx
    push    ax

    mov     al,40h

```

```

    push    dx
    and     dl,0FEH
    mul     dl

    pop     dx
    test    dl,1
    jz      rx4
    add     ax,2000H

rx4:   mov     si,ax
    pop     ax
    mov     dx,cx

    mov     bx,2C0H           ;determine graphics mode currently in effect
    mov     cx,302h
    cmp     byte [CRT_MODE],6
    jc      rx5
    mov     bx,180h
    mov     cx,703h

rx5:   and     ch,dl

    shr     dx,cl
    add     si,dx
    mov     dh,bh

rx6:   sub     cl,cl
    ror     al,1

    add     cl,ch
    dec     bh
    jnz     rx6

    mov     ah,bl
    shr     ah,cl
    pop     bx
    ret

;     GRAPHICS SCROOL UP
;     CH,CL = UPPER LEFT HAND CORNER OF SCREEN
;     DH,DL = LOWER RIGHT HAND CORNER OF SCREEN
;     BH = FILL CHAR FOR BLANK LINES
;     DS = DATA SEGMENT
;     ES = REGEN SEGMENT

graphics_up:
    mov     bl,al           ;save line count
    mov     ax,cx

    call    graph_posn
    mov     di,ax

    sub     dx,cx
    add     dx,101h

```

```

    sal    dh,1
    sal    dh,1
    cmp    byte [CRT_MODE],6
    jnc    rx7
    sal    dl,1
    sal    dl,1
rx7:  push   es
      pop    ds
      sub    ch,ch
      sal    bl,1
      sal    bl,1
      jz     rx11
      mov    al,bl
      mov    ah,80
      mul   ah
      mov    si,di
      add    si,ax
      mov    ah,dh
      sub    ah,bl
rx8:  call   rx17
      sub    si,2000h-80      ;next row
      sub    di,2000h-80
      dec    ah
      jnz   rx8
rx9:  mov    al,bh            ;fill in vacent lines
rx10: call   RX18
      sub    di,2000h-80
      dec    bl
      jnz   rx10
      JMP   VIDEO_RETURN
rx11: mov    bl,dh
      jmp   rx9

```

```

;     GRAPHICS SCROOL DOWN
;     CH,CL = UPPER LEFT HAND CORNER OF SCREEN
;     DH,DL = LOWER RIGHT HAND CORNER OF SCREEN
;     BH = FILL CHAR FOR BLANK LINES
;     DS = DATA SEGMENT
;     ES = REGEN SEGMENT

```

```

graphics_down:
    std
    mov    bl,al
    mov    ax,dx
    call   graph_posn
    mov    di,ax

```

```

sub    dx,cx
add    dx,101h
sal    dh,1
sal    dh,1

cmp    byte [CRT_MODE],6
jnc    rx12

sal    dl,1
sal    di,1
inc    di

rx12:  push  es
pop    ds
sub    ch,ch
add    di,240
sal    bl,1
sal    bl,1
jz     rx16
mov    al,bl
mov    ah,80
mul    ah
mov    si,di
sub    si,ax
mov    ah,dh
sub    ah,bl

rx13:  call  rx17
sub    si,2000h+80
sub    di,2000h+80
dec    ah
jnz    rx13

rx14:  mov   al,bh

rx15:  call  RX18
sub    di,2000h+80
dec    bl
jnz    rx15
cld
JMP    VIDEO_RETURN

rx16:  mov   bl,dh
jmp    rx14

rx17:  mov   cl,dl
push  si
push  di
rep   movsb

pop    di
pop    si
add   si,2000h
add   di,2000h
push  si

```



```

    sal    ax,1
    sal    ax,1
    add    si,ax
    cmp    byte [CRT_MODE],6
    pop    ds
    jc     s7

s3:   push  di
      push  si
      mov   dh,4

s4:   lodsb
      test  bl,80h
      jnz  s6
      stosb
      lodsb

s5:   mov   [es:di+1ffffh],al
      add  di,79
      dec  dh
      jnz  s4
      pop  si
      pop  di
      inc  di
      loop s3
      JMP  VIDEO_RETURN

s6:   xor   al,[es:di]
      stosb
      lodsb
      xor  al,[es:di+1ffffh]
      jmp  s5

s7:   mov  dl,b1                ;high res write
      sal  di,1
      call s19

s8:   push  di
      push  si
      mov   dh,4

s9:   lodsb
      call  s21
      and  ax,bx

      test  dl,80h
      jz   s10
      xor  ah,[es:di]
      xor  al,[es:di+1]

s10:  mov  [es:di],ah
      mov  [es:di+1],al
      lodsb
      call  s21
      and  ax,bx

```

```

        test    dl,80h
        jz     s11
        xor    ah,[es:di+2000h]
        xor    al,[es:di+2001h]
s11:    mov     [es:di+2000h],ah
        mov     [es:di+2001h],al
        add    di,80
        dec    dh
        jnz    s9
        pop    si
        pop    di
        inc    di
        inc    di
        loop   s8
        JMP    VIDEO_RETURN

```

```

;       GRAPHICS READ
;       NONE (0 IS ASSUMED FOR BACKGROUND COLOUR)
;output:-
;       AL = CHAR (0 IF NONE THERE)

```

```

graphics_read:
        call   s26
        mov    si,ax
        sub    sp,8
        mov    bp,sp

        cmp    byte [CRT_MODE],6
        push  es
        pop    ds
        jc    s13

        mov    dh,4
s12:    mov    al,[si]
        mov    [bp],al
        inc    bp
        mov    al,[si+2000h]
        mov    [bp],al
        inc    bp
        add    si,80
        dec    dh
        jnz    s12
        jmp    s15
s13:    sal    si,1
        mov    dh,4
s14:    call   s23
        add    si,2000h
        call  s23
        sub    si,2000h-80
        dec    dh

```

```

jnz     s14

s15:    mov     di,CRT_CHAR_GEN           ;char gen in IBM Rom
        push   cs                       ;<<<< NOTE FOR 27128K EPROM OR 8088 BOARD I HAVE REMOVED THIS CHARACTER TABLE
        pop    es                       ;THERE IS NOT ENOUGH ROOM IN  ROM. SELDOM USED ANYWAY>>>>
        sub    bp,8
        mov    si,bp
        cld
        mov    al,0

s16:    push   ss
        pop    ds
        mov    dx,128

s17:    push   si
        push   di
        mov    cx,8
        repe  cmpsb

        pop    di
        pop    si
        jz     s18
        inc    al
        add    di,8
        dec    dx
        jnz   s17

        cmp    al,0
        je     s18
        sub    ax,ax
        mov    ds,ax           ;set ds to 0

        les    di,[EXT_CHAR_PTR]
        mov    ax,es
        or     ax,di
        jz     s18
        mov    al,128
        jmp    s16

s18:    add    sp,8
        JMP    VIDEO_RETURN       ;<<<<<<<< Check!

s19:    and    bl,3
        mov    al,bl
        push  cx
        mov    cx,3

s20:    sal    al,1
        sal    al,1
        or     bl,al
        loop  s20
        mov    bh,bl
        pop    cx
        ret

```



```

s21:  push  dx
      push  cx
      push  bx
      sub   DX,DX
      mov   cx,1

s22:  mov   bx,ax
      and  bx,cx
      or   dx,bx
      shl  ax,1
      shl  cx,1
      mov  bx,ax
      and  bx,cx
      or   dx,bx
      shl  cx,1

      jnc  s22
      mov  ax,dx
      pop  bx
      pop  cx
      pop  dx
      ret

s23:  mov   ah,[si]
      mov  al,[si+1]
      mov  cx,0c000h
      mov  dl,0

s24:  test  ax,cx
      clc
      jz   s25
      stc

s25:  rcl  dl,1
      shr  cx,1
      shr  cx,1
      jnc  s24
      mov  [bp],dl
      inc  bp
      ret

s26:  mov   ax,[CURSOR_POSN]

graph_posn:
      push bx
      mov  bx,ax
      mov  al,ah
      mul  byte [CRT_COLS]
      shl  ax,1
      shl  ax,1
      sub  bh,bh
      add  ax,bx
      pop  bx
      ret

```

```

; WRITE_TTY          <<<< MAIN VIDEO BOARD CHARACTER OUTPUT ROUTINE >>>>>
; AL = CHARACTER
; BL = BACKGROUND CHAR IF IN GRAPHICS MODE

VGA_WRITE_TTY:      ;AH = 0EH
    push    ax
    push    ax
    mov     ah,3
    MOV     BH,[ACTIVE_PAGE]
    int     10h      ;DX now has current Cursor position
    pop     ax      ;Get character

    cmp     al,8     ;is it BS
    je      u8
    cmp     al,0dh   ;Is it CR
    je      u9
    cmp     al,0ah   ;Is it LF
    je      u10
    cmp     al,07    ;Is it BELL
    je      u11

    mov     ah,10    ;Write char on screen
    mov     cx,1     ;1X
    int     10h

    inc     dl
    cmp     dl,byte [CRT_COLS]
    jnz     u7
    mov     dl,0
    cmp     dh,24
    jnz     u6

u1:    mov     ah,2     ;Set Cursor
    int     10h      ;;Difference on AT-BIOS (PC has BH=0)

    mov     al,[CRT_MODE]
    cmp     al,4
    jc      u2
    cmp     al,7
    mov     bh,0
    jne     u3

u2:    mov     ah,8     ;Read cursor
    int     10h
    mov     bh,ah

u3:    mov     ax,601h   ;Scroll up one line
    sub     cx,cx
    mov     dh,24
    mov     dl,byte [CRT_COLS]
    dec     dl

u4:    int     10h

u5:    pop     ax
    JMP     VIDEO_RETURN

```

```

u6:   inc    dh

u7:   mov    ah,2
      jmp    u4

u8:   cmp    dl,0
      je     u7
      dec    dl
      jmp    u7

u9:   mov    dl,0
      jmp    u7

u10:  cmp    dh,24
      jne    u6
      jmp    u1

u11:  mov    bl,2
      call   BELL1          ;send hardware bell
      jmp    u5

;----- VIDEO SUPPORT ROUTINES -----

VIDEO_RETURN:          ;Most (but not all) routines finish up here
      POP    DI            ;Remove the "extra AX on stack"
VIDEO_RETURN1:
      POP    BP
      POP    DI
      POP    SI
      POP    BX
M15:  POP    CX
      POP    DX
      POP    DS
      POP    ES
      IRET                ;Note IRET

FAST_CONOUT:          ;Fast send Character (in AH) to Propeller board
      IN     AL,KEYSTAT    ;Propeller or SD SYSTEMS VIDIO BOARD PORT
      AND    AL,4H        ;Is board ready for character
      JZ     FAST_CONOUT
      MOV    AL,AH
      OUT    KEYOUT,AL
      RET

PROPELLER_SET_CURSOR: ;Set cursor location to DH & DL
      MOV    AH,ESC
      CALL   FAST_CONOUT  ;Send is VT100 Format "ESC [ row ; column H"
      MOV    AH,'['
      CALL   FAST_CONOUT

      MOV    AL,DH        ;DH = row (00h is top)
      CALL   HEX_TO_BCD   ;(DX unaltered for below)
      PUSH   AX

```

```

MOV     AH,AL
ROR     AH,1
ROR     AH,1
ROR     AH,1
ROR     AH,1
AND     AH,0FH
ADD     AH,30H           ;Convert to ASCII
CALL    FAST_CONOUT     ;Send ROW 10's digit
POP     AX
MOV     AH,AL
AND     AH,0FH           ;Low nibble
ADD     AH,30H           ;Convert to ASCII
CALL    FAST_CONOUT     ;Send ROW 1's digit

MOV     AH,','
CALL    FAST_CONOUT

MOV     AL,DL           ;DL = Column (00h is left)
CALL    HEX_TO_BCD

PUSH    AX
MOV     AH,AL
ROR     AH,1
ROR     AH,1
ROR     AH,1
ROR     AH,1
AND     AH,0FH
ADD     AH,30H           ;Convert to ASCII
CALL    FAST_CONOUT     ;Send ROW 10's digit
POP     AX
MOV     AH,AL
AND     AH,0FH           ;Low nibble
ADD     AH,30H           ;Convert to ASCII
CALL    FAST_CONOUT     ;Send ROW 1's digit
MOV     AL,AH

MOV     AH,'H'
CALL    FAST_CONOUT
RET

```

```

;Calculate th Video RAM address from row/column
;ax = row,column
;calculates ram address
POSITION:
push    bx
mov     bx,ax
mov     al,ah
mul     byte [CRT_COLS]
xor     bh,bh
add     ax,bx
sal     ax,1
pop     bx
ret

```

```

VIDEO_NOT_FINISHED:
PUSH    BX
MOV     BX,VID_PARM_TBD1_MSG ;"Int 10H Video paramater routine not fully implemented"

```

```

        JMP     VIDEO_TBD1

VIDEO_TBD:
    PUSH     BX
    MOV     BX,VID_PARM_TBD_MSG    ;"Int 10H Video paramater not yet implemented"
VIDEO_TBD1:
    CALL    SERIAL_PRINT_STRING
    POP     BX
    POP     AX                    ;Recover that extra AX on stack
    CALL    SERIAL_DISPLAY_REGISTERS ;Display Registers on serial port display (All registers retained)
    JMP     VIDEO_RETURN1        ;Remember we have removed that one extra AX on stack

; Input: AL = input number   Output: AL = BCD
HEX_TO_BCD:
    pushf                    ; Save flags register
    push cx                  ; Save general-purpose regs
    push dx
    push ax

    sub ah, ah              ; We don't want a high-order byte so we don't have a divide overflow
    mov dl, 0Ah            ; Divide by 10
    div dl                  ; Unsigned divide. Quotient in al,remainder in ah.
    mov dl, ah              ; Save remainder
    mov ah, al              ; Move quotient (multiple of 10)
    mov cl, 4               ; and shift into high nibble of al
    shr ax, cl              ; (8086 imposes stupid restrictions on shr operands)
    or al, dl               ; Set low nibble of al to remainder
    pop dx                  ; Recover ah (pulling its value into dx first)
    mov ah,dh              ; restore cx, dx and flags
    pop dx
    pop cx
    popf
    ret                    ; All done.

;----- BASIC LAVA-10 CRT TREMINAL COMMANDS -----
;          Only AL register changed unless stated otherwise

INITILIZE_LAVA:                ;Clear Screen, Green/Black Cursor 0,0
    MOV     AL,00000000B        ;Set to WRITE mode, no strobes etc
    OUT     LavaStatus,AL      ;Send to lava status port (91H)
    CALL    L_CLEAR_BUFFER     ;Clear a buffer LAVA RAM area for Clear line etc
    CALL    L_CLEAR_SCREEN
    CALL    L_HOME              ;Set cursor X,Y to 0,0
    MOV     BX,L_GREEN_COLOR
    CALL    L_SET_COLOR
    CALL    L_SHOW_CURSOR
    RET

L_TTY_OUT:                      ;<< CORE FUNCTION >>Write 1 character (in [AH]) to current cursor X,Y position. Update cursor
    CMP     AH,SPACE          ;Special treatment for control characters.
    JGE     L_NOT_SEPCIAL

    CMP     AH,CR              ;First treat the special case sitations

```

```

        JNZ     L_NOT_CR
        CALL   L_DO_CR
        RET
L_NOT_CR:
        CMP    AH,LF
        JNZ    L_NOT_LF
        CALL   L_DO_LF
        RET
L_NOT_LF:
        CMP    AH,BS
        JNZ    L_NOT_BS
        CALL   L_BACK_SPACE
        RET
L_NOT_BS:
        CMP    AH,SCROLL           ;Scroll up one line with 01H
        JNZ    L_NOT_SCROLL
        CALL   L_SCROLL_UP_1
        RET
L_NOT_SCROLL:
        CMP    AH,CLEAR
        JNZ    L_NOT_CLEAR
        CALL   L_CLEAR_SCREEN
        RET
L_NOT_CLEAR:
        CMP    AH,BELL
        JNZ    L_NOT_BELL
        CALL   BELL1               ;Send Bell to Propeller Board
        RET
L_NOT_BELL:
L_NOT_SPECIAL:                    ;We need to also take care of DEL (7FH)
        CMP    AH,DELETE
        JNZ    L_NOT_DEL
        CALL   L_DEL_SPACE
        RET
L_NOT_DEL:                         ;Else do "regular" ASCII characters
        CALL   L_HIDE_CURSOR

        MOV    AL,DRAW$TEXT        ;Send Draw Text Command
        CALL   L_PULSE$WR
        MOV    AL,1                 ;Send 1 character only
        CALL   L_PULSE$WR
        MOV    AL,AH
        CALL   L_PULSE$WR          ;Send Ascii
        MOV    AL,0
        CALL   L_PULSE$WR          ;send Ascii X2 (So we have an even number of bytes sent)
L_TTY_DONE:
        CALL   L_NEXT_POSITION      ;Advance the cursor one position, next line if at EOL, Scroll up if at bottom of screen
        CALL   L_SHOW_CURSOR        ;Show new cursor position
        RET

L_TTY_OUT_NO_UPDATE:              ;<< CORE FUNCTION >>Write 1 character (in [AH]) to current cursor X,Y position. NO Update cursor
        MOV    AL,DRAW$TEXT        ;Send Draw Text Command
        CALL   L_PULSE$WR

```

```

MOV     AL,1                ;Send 1 character only
CALL   L_PULSE$WR
MOV     AL,AH
CALL   L_PULSE$WR          ;Send Ascii
MOV     AL,0
CALL   L_PULSE$WR          ;send Ascii X2 (So we have an even number of bytes sent)
RET

```

```

L_HOME:                    ;Cursor to Top left of screen

```

```

PUSH   BX
CALL   L_HIDE_CURSOR
XOR    BX,BX
CALL   L_SET_X
CALL   L_SET_Y
CALL   L_SHOW_CURSOR
POP    BX
RET

```

```

L_SET_CURSOR:              ;AH = 02h      VIDEO - SET CURSOR POSITION
                             ;DH = row (00h is top), DL = column (00h is left)

```

```

PUSH   BX
XOR    BX,BX
MOV    BL,DL
SHL    BX,1                ;X2
SHL    BX,1                ;X4
SHL    BX,1                ;X8      (8 Pixels/character)
CALL   L_SET_X
XOR    BX,BX
MOV    BL,DH
SHL    BX,1                ;X2
SHL    BX,1                ;X4
SHL    BX,1                ;X8
SHL    BX,1                ;X16     (16 Pixels/character)
CALL   L_SET_Y
POP    BX
RET

```

```

L_GET_CURSOR:              ;AH = 03h      VIDEO - GET CURSOR POSITION AND SIZE
                             ;DH = row (00h is top), DL = column (00h is left)

```

```

PUSH   BX
CALL   L_GET_X
SHR    BX,1                ;/2
SHR    BX,1                ;/4
SHR    BX,1                ;/8      (8 Pixels/character)
MOV    DL,BL
CALL   L_GET_Y
SHR    BX,1                ;/2
SHR    BX,1                ;/4
SHR    BX,1                ;/8
SHR    BX,1                ;/16     (16 Pixels/character)
MOV    DH,BL
POP    BX
RET

```

```

L_SHOW_CURSOR:                ;Show cursor at current position
    MOV     AL, DRAW$TEXT      ;Send Draw Text Command
    CALL   L_PULSE$WR
    MOV     AL, 1              ;Send 1 character only
    CALL   L_PULSE$WR
    MOV     AL, '_'           ;
    CALL   L_PULSE$WR        ;Send Ascii
    MOV     AL, 0
    CALL   L_PULSE$WR        ;Send Ascii X2 (So we have an even number of bytes sent)
    RET

```

```

L_HIDE_CURSOR:                ;Hide cursor at current position
    PUSH   BX
    CALL   L_GET_COLOR        ;Normally white on black
    PUSH   BX                ;Save For below
    MOV    BX, L_BLACK_COLOR
    CALL   L_SET_COLOR
    MOV    AL, DRAW$TEXT     ;Send Draw Text Command
    CALL   L_PULSE$WR
    MOV    AL, 1            ;Send 1 character only
    CALL   L_PULSE$WR
    MOV    AL, '_'         ;
    CALL   L_PULSE$WR        ;Send Ascii
    MOV    AL, 0
    CALL   L_PULSE$WR        ;Send Ascii X2 (So we have an even number of bytes sent)
    POP    BX                ;Get Back original color
    CALL   L_SET_COLOR
    POP    BX
    RET

```

```

L_DO_CR:
    PUSH   BX                ;Move cursor to start of line
    CALL   L_HIDE_CURSOR
    XOR    BX, BX
    CALL   L_SET_X
    CALL   L_SHOW_CURSOR
    POP    BX
    RET

```

```

L_DO_LF:
    PUSH   BX                ;Move cursor down vertically one line
    CALL   L_HIDE_CURSOR
    CALL   L_GET_Y
    CMP    BX, (L_SCREEN_LINES * L_CHAR_HEIGHT) - L_CHAR_HEIGHT
    JL     L_DO_LF1
    CALL   L_SCROLL_UP_1     ;Scroll up 1 line
    JMP    L_DO_LF2

```

```

L_DO_LF1:

```



```

        ADD     BX,L_CHAR_HEIGHT
        CALL   L_SET_Y
L_DO_LF2:
        CALL   L_SHOW_CURSOR
        POP    BX
        RET

L_GET_COLOR:                                ;READ Register command, Get Text Color. Data in BX
        MOV    AL,READ$CSR
        CALL   L_PULSE$WR                    ;Send
        MOV    AL,0
        CALL   L_PULSE$WR
        MOV    AL,0
        CALL   L_PULSE$WR
        MOV    AL,0H                          ;Point to CSR_COLOR
        CALL   L_PULSE$WR
        CALL   L_PULSE$2RD                    ;<<< Read 2 byte into [BX]
        RET

L_SET_COLOR:                                ;WRITE Register command, Set Text Color. Data in BX
        MOV    AL,WRITE$CSR
        CALL   L_PULSE$WR                    ;Send
        MOV    AL,0
        CALL   L_PULSE$WR
        MOV    AL,0
        CALL   L_PULSE$WR
        MOV    AL,0H                          ;Point to CSR_COLOR
        CALL   L_PULSE$WR
        MOV    AL,BH
        CALL   L_PULSE$WR
        MOV    AL,BL
        CALL   L_PULSE$WR
        RET

L_NEXT_POSITION:                            ;Advance LAVA cursor to next position (Cursor is not displayed here)
        PUSH   BX
        CALL   L_GET_X                        ;Get X position in BX
        CMP    BX,(L_CHARS_PER_LINE * L_CHAR_WIDTH) - L_CHAR_WIDTH
        JL     L_SAME_LINE                    ;On Same line just update
        CALL   L_DO_LF
        CALL   L_HIDE_CURSOR
        XOR    BX,BX                          ;X=0 always to start of next line
        CALL   L_SET_X
        POP    BX
        RET

L_SAME_LINE:                                ;This is the normal situation
        ADD    BX,8
        CALL   L_SET_X
        POP    BX
        RET

L_CLEAR_CURRENT_LINE:                        ;Clear a whole line at current cursor Y position (Any X position on that lne)

```

```

PUSH  BX
PUSH  CX                ;No need to hide cursor
PUSH  SI
CALL  L_GET_X
PUSH  BX                ;Store it for when we return below

CALL  L_GET_Y
MOV   SI,BX
CALL  L_CLEAR_LINE

POP   BX                ;Get Back original Cursor position
CALL  L_SET_X
POP   SI
POP   CX
POP   BX
RET

```

```

L_CLEAR_SCREEN:                ;Clear the whole screen. Cursor to 0,0

```

```

PUSH  BX
PUSH  CX
PUSH  SI
MOV   SI,0
MOV   CX,L_SCREEN_LINES+1    ;Count of total lines on screen

```

```

L_CLEAR1:
PUSH  CX
PUSH  SI
CALL  L_CLEAR_LINE
POP   SI
POP   CX
ADD   SI,L_CHAR_HEIGHT
LOOP  L_CLEAR1
XOR   BX,BX                ;Set cursor position 0,0
CALL  L_SET_X
CALL  L_SET_Y
POP   SI
POP   CX
POP   BX
RET

```

```

L_CLEAR_LINE:                ;Clear line at [SI]. Note BX & DX changed

```

```

MOV   CX,0                ;Count for lines below

```

```

L_CLEAR_LINE1:
MOV   BX,L_BELOW_SCREEN    ;SOURCE: Below bottom of screen (will display as background, see L_CLEAR_BUFFER)
ADD   BX,CX

```

```

MOV   DX,0                ;X position is 0
CALL  L_MAKE_24_ADDRESS    ;Generate LAVA 24 bit address DX+BX -> DX+BH

```

```

MOV   AL,COPY$MEMORY      ;Sent COPY MEMORY command

```

```

CALL  L_PULSE$WR

```

```

MOV   AL,BH

```

```

CALL  L_PULSE$WR          ;Source Address 23:16

```

```

MOV   AL,DH

```

```

CALL  L_PULSE$WR          ;Source Address 15:8

```

```

MOV   AL,DL

```

```

CALL    L_PULSE$WR          ;Source Address 7:0

MOV     AL,03H
CALL    L_PULSE$WR          ;Next two size bytes
MOV     AL,0FFH
CALL    L_PULSE$WR

MOV     AX,0
CALL    L_PULSE$WR          ;Filler byte

MOV     BX,SI                ;DESTINATION:  Get Y position
ADD     BX,CX
MOV     DX,0                 ;X position is 0
CALL    L_MAKE_24_ADDRESS    ;Generate LAVA 24 bit address DX+BX -> DX+BH
MOV     AL,BH
CALL    L_PULSE$WR          ;Send Address 23:16
MOV     AL,DH
CALL    L_PULSE$WR          ;Send Address 15:8
MOV     AL,DL
CALL    L_PULSE$WR          ;Send Address 7:0
INC     CX
CMP     CX,L_CHAR_HEIGHT
JNZ    L_CLEAR_LINE1
RET

L_CLEAR_EOL:                ;Clear to EOL (Any X position to end of that line)
PUSH    BX
PUSH    CX
PUSH    DX
PUSH    SI
PUSH    DI
CALL    L_HIDE_CURSOR
CALL    L_GET_X              ;GET X POSITION OF CURSOR IN BX (Number of character positions)
PUSH    BX                  ;Save Cursor for when done

MOV     SI,BX                ;>>> X Position in SI <<<
MOV     DX,L_CRT_WIDTH
SUB     DX,BX                ;>>> Length in DX <<<< of line in delete area left to EOL

CALL    L_GET_Y              ;GET Y POSITION OF CURSOR IN BX (Number of character positions)
MOV     DI,BX                ;>>> Y Position in DI <<<

MOV     CX,0                 ;Count for lines for below
EOL_LINE1:                  ;Will move a clear memory block into the area
PUSH    DX                  ;Save data
MOV     BX,L_BELOW_SCREEN    ;SOURCE: Below bottom of screen (will display as background, see L_CLEAR_BUFFER)
ADD     BX,CX
MOV     DX,SI
CALL    L_MAKE_24_ADDRESS    ;Generate LAVA 24 bit address DX+BX -> DX+BH

MOV     AL,COPY$MEMORY       ;Sent COPY MEMORY command
CALL    L_PULSE$WR
MOV     AL,BH
CALL    L_PULSE$WR          ;Source Address 23:16
MOV     AL,DH

```

```

CALL  L_PULSE$WR      ;Source Address 15:8
MOV   AL,DL
CALL  L_PULSE$WR      ;Source Address 7:0

POP   DX              ;Get back saved length
MOV   AL,DH
CALL  L_PULSE$WR      ;Next two size bytes
MOV   AL,DL
CALL  L_PULSE$WR
PUSH  DX              ;Save length again

MOV   AX,0
CALL  L_PULSE$WR      ;Filler byte

MOV   BX,DI           ;DESTINATION:  Get Y position
ADD   BX,CX
MOV   DX,SI           ;X position is 0
CALL  L_MAKE_24_ADDRESS ;Generate LAVA 24 bit address DX+BX -> DX+BH
MOV   AL,BH
CALL  L_PULSE$WR      ;Send Address 23:16
MOV   AL,DH
CALL  L_PULSE$WR      ;Send Address 15:8
MOV   AL,DL
CALL  L_PULSE$WR      ;Send Address 7:0

POP   DX              ;balance up stack
INC   CX
CMP   CX,L_CHAR_HEIGHT
JNZ   EOL_LINE1

POP   BX              ;Get Back original Cursor position
CALL  L_SET_X
CALL  L_SHOW_CURSOR
POP   DI
POP   SI
POP   DX
POP   CX
POP   BX
RET

```

```

L_SCROLL_UP_1:      ;Move the whole screen up one line (quickly)
PUSH  BX
PUSH  CX
PUSH  SI
PUSH  DI
CALL  L_GET_Y
PUSH  BX              ;Store it for when we return below
CALL  L_HIDE_CURSOR

MOV   CX,(L_CHAR_HEIGHT * L_SCREEN_LINES) - L_CHAR_HEIGHT ;(Count for screen scan lines below)
MOV   SI,L_CHAR_HEIGHT ;Source, one line down
MOV   DI,0            ;Destination, top of screen

UP1:  MOV   BX,SI      ;SOURCE

```

```

MOV     DX,0                ;X position is 0
CALL    L_MAKE_24_ADDRESS   ;Generate LAVA 24 bit address DX+BX -> DX+BH

MOV     AL,COPY$MEMORY      ;Sent COPY MEMORY command
CALL    L_PULSE$WR
MOV     AL,BH
CALL    L_PULSE$WR         ;Source Address 23:16
MOV     AL,DH
CALL    L_PULSE$WR         ;Source Address 15:8
MOV     AL,DL
CALL    L_PULSE$WR         ;Source Address 7:0

MOV     AL,03H
CALL    L_PULSE$WR         ;Next two size bytes
MOV     AL,0FFH
CALL    L_PULSE$WR

MOV     AX,0
CALL    L_PULSE$WR         ;Filler byte

MOV     BX,DI               ;DESTINATION
MOV     DX,0                ;X position is 0
CALL    L_MAKE_24_ADDRESS   ;Generate LAVA 24 bit address DX+BX -> DX+BH
MOV     AL,BH
CALL    L_PULSE$WR         ;Send Address 23:16
MOV     AL,DH
CALL    L_PULSE$WR         ;Send Address 15:8
MOV     AL,DL
CALL    L_PULSE$WR         ;Send Address 7:0

INC     SI                  ;Next scan line
INC     DI
LOOP    UP1

MOV     SI,(L_CHAR_HEIGHT * L_SCREEN_LINES)
CALL    L_CLEAR_CURRENT_LINE

POP     BX                  ;Get Back original Y Cursor position
CALL    L_SHOW_CURSOR
POP     DI
POP     SI
POP     CX
POP     BX
RET

L_DEL_SPACE:                ;DEL requires special treatment because LAVA does not
PUSH    BX                  ;Overwrite characters. ie a space will not delete a character if overwritten
PUSH    CX
PUSH    DX
CALL    L_HIDE_CURSOR
CALL    L_GET_X
JMP     L_PUT_SPACE

L_BACK_SPACE:                ;Back space requires special treatment because LAVA does not
PUSH    BX                  ;Overwrite characters. ie a space will not delete a character if overwritten

```

```

        PUSH    CX
        PUSH    DX
        CALL   L_HIDE_CURSOR
        CALL   L_GET_X
        CMP    BX,8
        JL    L_PUT_SPACE
        SUB    BX,8
        CALL   L_SET_X                ;Back space one character
L_PUT_SPACE:                          ;Print a space on Screen at current X,Y position
        CALL   L_GET_COLOR
        PUSH   BX                    ;Save for below
        MOV    BX,L_BLACK_COLOR      ;The trick is to overlay with two ASCII characters that fill the complete
        CALL   L_SET_COLOR           ;8X16 pixel area in black (If a different background color, then change)

        MOV    AL,DRAW$TEXT          ;Send Draw Text Command
        CALL   L_PULSE$WR
        MOV    AL,1                  ;Send 1 character only
        CALL   L_PULSE$WR
        MOV    AL,03H
        CALL   L_PULSE$WR           ;Send Ascii 'Heart figure"
        MOV    AL,0
        CALL   L_PULSE$WR          ;send Ascii X2 (So we have an even number of bytes sent)

        MOV    AL,DRAW$TEXT          ;Send Draw Text Command
        CALL   L_PULSE$WR
        MOV    AL,1                  ;Send 1 character only
        CALL   L_PULSE$WR
        MOV    AL,08H
        CALL   L_PULSE$WR           ;Overlay with ASCII "Circle figure"
        MOV    AL,0
        CALL   L_PULSE$WR          ;send Ascii X2 (So we have an even number of bytes sent)

        POP    BX                    ;Get back color
        CALL   L_SET_COLOR
        CALL   L_SHOW_CURSOR
        POP    DX
        POP    CX
        POP    BX
        MOV    AL,BS                 ;Return with space in AL
        RET

L_MAKE_24_ADDRESS:                    ;Generate LAVA 24 bit memory address from X in DX, and Y in BX
        MOV    AX,DX                 ;Get X address, isolate bits 8 & 9
        AND    AH,03H
        SHL    BX,1                  ;Shift over Y by 2 bits
        SHL    BX,1
        OR     AH,BL                 ;Combine in lower 6 bits of Y coordinate
        MOV    DH,AH
        RET                          ;Return Address 7:0 in DL, 15:8 in DH, and 23:16 in BH

L_GET_X:
        MOV    AL,READ$CSR           ;READ Register command for X Position into BX
        CALL   L_PULSE$WR           ;Send
        MOV    AL,0

```

```

CALL    L_PULSE$WR
MOV     AL,0
CALL    L_PULSE$WR
MOV     AL,01H                ;Point to CSR_FONT_X
CALL    L_PULSE$WR
CALL    L_PULSE$2RD          ;<<< Read 2 byte into [BX]
RET

```

```

L_GET_Y:
MOV     AL,READ$CSR          ;READ Register command for Y Position into BX
CALL    L_PULSE$WR          ;Send
MOV     AL,0
CALL    L_PULSE$WR
MOV     AL,0
CALL    L_PULSE$WR
MOV     AL,02H              ;Point to CSR_FONT_Y
CALL    L_PULSE$WR
CALL    L_PULSE$2RD          ;<<< Read 2 byte into [BX]
RET

```

```

L_SET_X:
MOV     AL,WRITE$CSR         ;WRITE Register command, X Position, data in BX
CALL    L_PULSE$WR          ;Send
MOV     AL,0
CALL    L_PULSE$WR
MOV     AL,0
CALL    L_PULSE$WR
MOV     AL,01H              ;Point to CSR_FONT_X
CALL    L_PULSE$WR
MOV     AL,BH
CALL    L_PULSE$WR
MOV     AL,BL
CALL    L_PULSE$WR
RET

```

```

L_SET_Y:
MOV     AL,WRITE$CSR         ;WRITE Register command, Y Position, data in BX
CALL    L_PULSE$WR          ;Send
MOV     AL,0
CALL    L_PULSE$WR
MOV     AL,0
CALL    L_PULSE$WR
MOV     AL,02H              ;Point to CSR_FONT_Y
CALL    L_PULSE$WR
MOV     AL,BH
CALL    L_PULSE$WR
MOV     AL,BL
CALL    L_PULSE$WR
RET

```

```

;Clear an area of the LAVA screen RAM for use with Clear Line, EOL etc.

```

```

L_CLEAR_BUFFER:                                ;We will us this for fast LAVA block moves etc.
MOV      BX,L_BELOW_SCREEN                    ;Y position of RAM below bottom of visible screen
CLEARB2:MOV  DX,0                             ;X position is 0
CLEARB1:PUSH BX
        PUSH  DX
CALL     L_MAKE_24_ADDRESS                    ;Generate LAVA 24 bit address DX+BX -> DX+BH
MOV      AL,WRITE$MEMORY                     ;Sent COPY MEMORY command
CALL     L_PULSE$WR
MOV      AL,BH                               ;Address 23:16
CALL     L_PULSE$WR
MOV      AL,DH                               ;Address 15:8
CALL     L_PULSE$WR
MOV      AL,DL                               ;Address 7:0
CALL     L_PULSE$WR
MOV      AL,L_BLACK_COLOR                   ;BLACK (0FH = Blue for testing)
CALL     L_PULSE$WR
MOV      AL,L_BLACK_COLOR                   ;BLACK
CALL     L_PULSE$WR
POP      DX
POP      BX
INC      DX                                  ;Are we at end of line
CMP      DX,L_CRT_WIDTH+10
JLE     CLEARB1
INC      BX                                  ;Go to next scan line
CMP      BX,L_BELOW_SCREEN+L_CHAR_HEIGHT    ;16 scan lines total
JLE     CLEARB2
RET

;----- LAVA CORE WRITE ROUTINE -----

L_PULSE$WR:                                    ;Note only [AL] altered
;>>>> WRITE ONE BYTE OF DATA TO LAVA CHIP, Data in [AL] <<<<<
OUT      LavaData,AL                         ;Send [AL] to Lava data port (91H)
MOV      AL,00000001B                       ;Output enable U10 to LAVA data bus, and set LAVA to WRITE mode
OUT      LavaStatus,AL                      ;Send to lava status port (90H)
MOV      AL,10000001B                       ;Then pulse status port strobe bit LOW (Bit 7 high, pulsed strobe low)
OUT      LavaStatus,AL                      ;Send to lava status port (90H)

L_WR$NOT$RDY:
IN       AL,LavaStatus                      ;Wait until LAVA "Done" signal clears U12A. Then we are done
AND      AL,80H                             ;This will set strobe bit back HIGH. Note still in WRITE LAVA mode
JZ       L_WR$NOT$RDY
RET

;----- LAVA CORE READ ROUTINE -----

L_PULSE$2RD:                                  ;Note only [AL] & [BX] altered
;>>>> READ TWO BYTES OF DATA FROM LAVA CHIP, Data in [BX] <<<<<
MOV      AL,00001000B                       ;Set to LAVA READ MODE, Disable U10 to LAVA data bus
OUT      LavaStatus,AL                      ;Send to lava status port (91H)
MOV      AL,10001000B                       ;Then pulse strobe bit LOW
OUT      LavaStatus,AL                      ;Send to lava status port (91H)

L_RD$NOT$RDY:
IN       AL,LavaStatus                      ;Wait until JAVA "Done" signal clears U12A. Then we are done
AND      AL,80H                             ;This will set strobe bit back HIGH. Note still in READ LAVA mode
JZ       L_RD$NOT$RDY

```



```

    IN     AL,LavaData           ;Data [15:8] from port (90H)
    MOV    BH,AL                ;Save in BH

    MOV    AL,10001000B         ;Pulse strobe bit LOW
    OUT    LavaStatus,AL        ;Send to lava status port (91H)
L_RD$NOT$RDY1:
    IN     AL,LavaStatus         ;Wait until JAVA "Done" signal clears U12A. Then we are done
    AND    AL,80H               ;This will set strobe bit back HIGH. Note still in READ LAVA mode
    JZ     L_RD$NOT$RDY1

                                ;Now Second Byte
    IN     AL,LavaData           ;Data [7:0] from port (90H)
    MOV    BL,AL
    RET                          ;Return with data in [BX]

;*****
;
;   Console Input Handler   (Software Interrupt 16H)
;   Return with keyboard buffer character in AL
;
;Input: AH = 00h           KEYBOARD - GET KEYSTROKE
;
;Return:AH = BIOS scan code
;       AL = ASCII character
;
;       Note:   On extended keyboards, this function discards any extended keystrokes,
;               returning only when a non-extended keystroke is available. The BIOS
;               scan code is usually, but not always, the same as the hardware scan
;               code processed by INT 09. It is the same for ASCII keystrokes and most
;               unshifted special keys (F-keys, arrow keys, etc.), but differs for shifted
;               special keys. Some (older) clone BIOSes do not discard extended keystrokes
;               and manage function AH=00h and AH=10h the same.
;
;Input: AH = 01h           KEYBOARD - CHECK FOR KEYSTROKE
;
;Return:ZF set if no keystroke available
;       ZF clear if keystroke available
;       AH = BIOS scan code
;       AL = ASCII character
;
;       Note: If a keystroke is present, it is not removed from the keyboard buffer;
;               however, any extended keystrokes which are not compatible with 83/84- key keyboards
;               are removed by IBM and most fully-compatible BIOSes in the process of checking
;               whether a non-extended keystroke is available. Some (older) clone BIOSes do not
;               discard extended keystrokes and manage function AH=00h and AH=10h the same.
;
;Input: AH = 02h           KEYBOARD - GET SHIFT FLAGS
;
;Return:AL = shift flags (see below)
;       AH destroyed by many BIOSes
;
;       Bitfields for keyboard shift flags:-
;       7   Insert active
;       6   CapsLock active
;       5   NumLock active
;       4   ScrollLock active

```

```

;           3      Alt key pressed (either Alt on 101/102-key keyboards)
;           2      Ctrl key pressed (either Ctrl on 101/102-key keyboards)
;           1      left shift key pressed
;           0      right shift key pressed

;*****

CONIN:  sti
        push    ds
        push    bx
        XOR    BX,BX                ;Set DS to data area for ROM usage in low RAM @ 400H....)
        MOV    DS,BX

Xconio: or     ah,ah                ;read keyboard?
        jnz    con1                ;skip if not

conio:  TEST   byte[KB_FLAG_1],HOLD_STATE    ;Is Pause flag set
        JNZ   conio
        mov   al,[chrcnt]                ;any data in buffer?
        test  al,al
        je    conio                    ;wait for a key
        mov   bx,[bufhd]                ;get buffer address
        mov   al,[bx]                   ;character to al
        mov   ah,0                      ;scan code always zero
        inc   bx
        cmp   bx,keybuff+32             ;at end of buffer?
        jl   conio0
        mov   bx,keybuff                ;reset buffer address if so
conio0: mov   [bufhd],bx
        cli                               ;turn off interrupts
        dec   byte [chrcnt]             ;while we adjust count
        sti
        pop   bx
        pop   ds
        iret                            ;return char in AL, AH=0

con1:   cmp   ah,1                    ;read status?
        jne   con2                    ;skip if not
        mov   al,[chrcnt]              ;get character count
        test  al,al                    ;Z-flag = availability
        mov   bx,[bufhd]
        mov   al,[bx]                  ;character to al
        mov   ah,0                      ;scan code = 0
conirt: pop   bx
        pop   ds
        retf   2                       ;throw away flags

con2:   cmp   ah,3                    ;read shift status
        jne   con3
        mov   al,0                      ;set status to zero
con3:   pop   bx
        pop   ds
        iret

```

```

;*****
;
;       Printer Output Handler       (Software Interrupt 17H)
;
;Input: AH = 00h       PRINTER - WRITE CHARACTER
;       AL = character to write
;       DX = printer number (00h-02h)
;
;Return:AH = printer status
;       Bitfields set for printer status:
;       7       not busy
;       6       acknowledge
;       5       out of paper
;       4       selected
;       3       I/O error
;       2-1     unused
;       0       timeout
;
;Input: AH = 01h       PRINTER - INITIALIZE PORT
;       DX = printer number (00h-02h)
;
;Return:AH = printer status (same as above)
;
;Input: AH = 02h       PRINTER - GET STATUS
;       DX = printer number (00h-02h)
;
;Return:AH = printer status (see above)
;
;*****

LST_OUT: PUSH  AX                ;Note we will assume only one printer
        PUSH  BX
        PUSH  CX
        CMP   AH,0              ;AH=0 Print Character
        JZ   PRN_CHAR
        CMP   AH,1
        JZ   INIT_PRN          ;AH=1 Initilize Printer (Set Font etc)
        JMP  STATUS_PRN       ;AH=2 Get status

PRN_CHAR:
        CALL  LIST_OUT1        ;AH = 0; Print a character (in AL) on printer
LDONE:  POP   CX
        POP   BX
        POP   AX
        XOR   AH,AH           ;Retur Z set (and AH = 0 ) if all OK
        IRET                  ;<- Note IRET

STATUS_PRN:
        CALL  LIST_STATUS      ;Get List Status
        JZ   LDONE            ;Must be initilize or a status check. Same ending
        ;If it matches xxxx0110B we are OK
PSTAT:  TEST  AL,00001000B     ;Test for paper out
        JNZ  PAPER_OUT
        POP   CX              ;Else just return busy signal
        POP   BX
        POP   AX              ;Just in case return with character in AL

```

```

        MOV     AH,00000001B           ;return with timeout bit set
        IRET
PAPER_OUT:
        POP     CX
        POP     BX
        POP     AX                     ;Just in case return with character in AL
        MOV     AH,00100000B         ;Flag for paper out
        IRET

INIT_PRN:
        MOV     BX,PRN_INIT_STR       ;Set Font etc.
INIT_PRN1:
        MOV     CL,[CS:BX]
        INC     BX
        OR      CL,CL
        JZ      LDONE
        CALL   LIST_OUT
        JMP     INIT_PRN1

LIST_OUT1:
        MOV     CL,AL                 ;Remember can be called by IBM BIOS section or the monitor section
        ;For BIOS interrupt printing character is in AL
LIST_OUT:
        ;Within this monitor character is in CL
        MOV     CH,0FFH               ;Check status up to 255 times
LO2:    CALL   LIST_STATUS            ;XXXX0110 if ready
        JZ      LIST_OK
        DEC     CH
        JNZ    LO2
LIST_OK:MOV     AL,0FFH                ;Setup strobe high to low then high
        OUT    PRINTER_STROBE,AL
        MOV    AL,CL
        OUT    PRINTER_OUT,AL        ;Now Data
        MOV    AL,0FEH                ;Bit 0, STROBE FOR CENTRONICS
        OUT    PRINTER_STROBE,AL
        MOV    AL,0FFH                ;Raise strobe again
        OUT    PRINTER_STROBE,AL
        RET

LIST_STATUS:
        ;Remember can be called by IBM BIOS section or the monitor section
        IN     AL,PRINTER_STATUS
CENSTAT:AND    AL,00001111B           ;XXXX0110 IS READY (BIT 3=PAPER BIT 2=FAULT
        CMP    AL,00000110B         ;BIT 1=SELECT BIT 0=BUSY
        RET

;*****
;
;     BASIC Handler      (Software Interrupt 18h)
;
;*****

basic:  PUSH   AX
        PUSH   BX
        PUSH   CX
        MOV    BX,NO_BASIC_MSG       ;Announce we got an BASIC Interrupt

```

```

NO_INT_SUPPORT:                ;Common for warning about un-implemented int
    CALL    PRINT_STRING      ;Send msg pointed to by CS:BX
    POP     CX                ;Note this routine is also used by the MS-DOS BIOS section
    POP     BX
    POP     AX
    ired                    ;Remember IRET collects the saved Flags

;*****
;
;    Equipment Check Handler          (Software Interrupt 11H)
;
;*****

equip:  push    ds                ;save data segment
        XOR     AX,AX            ;Set DS to data area for ROM usage in low RAM @ 400H....)
        MOV     DS,AX
        mov     ax,[EQFLAG]
        pop     ds
        ired

;*****
;
;    Memory Size Handler          (Software Interrupt 12H)
;    BIOS - GET MEMORY SIZE
;    Return:AX = kilobytes of contiguous memory starting at absolute address 00000h
;
;    Note: This call returns the contents of the word at 0040h:0013h;
;    in PC and XT, this value is set from the switches on the motherboard
;*****

memsiz: push    ds
        XOR     AX,AX            ;Set DS to data area for ROM usage in low RAM @ 400H....)
        MOV     DS,AX
        mov     ax,[memrsz]
        pop     ds
        ired

;*****
;
;    Interrupt 1Bh Keyboard Break
;
;*****

kbd_break:
    PUSH    AX
    PUSH    BX
    PUSH    CX
    MOV     BX,NO_BREAK_MSG      ;Announce we got an BREAK Interrupt
    jmp     NO_INT_SUPPORT

```

```

;*****
;
;       Interrupt 1Ch (28 Decimal)  User Timer Tic
;
;*****

user_timer:
        IRET                                ;Just return

;*****
;
;       Comm I/O Handler              (Software Interrupt 14H)
;
;       Note: We will leave it at 19,200 Baud (faster than on original PC)
;
;Input: AH = 00h      SERIAL - INITIALIZE PORT
;       AL = port parameters
;           Paramater Bit Description
;           7-5      data rate (110,150,300,600,1200,2400,4800,9600 bps)
;           4-3      parity (00 or 10 = none, 01 = odd, 11 = even)
;           2        stop bits (set = 2, clear = 1)
;           1-0      data bits (00 = 5, 01 = 6, 10 = 7, 11 = 8)
;       DX = port number (00h-03h)
;Return:AH = line status
;           Bit(s)  Description
;           7       carrier detect
;           6       ring indicator
;           5       data set ready
;           4       clear to send
;           3       delta carrier detect
;           2       trailing edge of ring indicator
;           1       delta data set ready
;           0       delta clear to send
;
;Input: AH = 01h      SERIAL - WRITE CHARACTER TO PORT
;       AL = character to write
;       DX = port number (00h-03h)
;Return:AH bit 7 clear if successful
;       AH bit 7 set on error
;       AH bits 6-0 = port status
;
;Input: AH = 02h      SERIAL - READ CHARACTER FROM PORT
;       AL = 00h (ArtiCom)
;       DX = port number (00h-03h)
;       Return:AH = line status
;       AL = received character if AH bit 7 clear

;S100Computers Serial I/O Board Initalization
;Note only SSC A of the Zilog SCC serial ports will be set used (and set to 38,400 Baud initially).
;Will leave SSC B at 38,400 for speech synthizer (untouched). So DX will be ignored

commio: PUSH    AX                        ;Note we will assume only two serial ports

```



```

        OUT     ACTL,AL
SIO_DONE:
        POP     CX                ;We will assume no problem, always!
        POP     BX
        POP     AX
        XOR     AH,AH
        IRET                    ;Note IRET not RET

WR_SIO:                                ;Write a character to SSC Channel A
        MOV     AH,AL            ;Store char in AH
        MOV     CX,256          ;Will try 256 times, then timeout
WR_SIO1:IN  AL,ACTL            ;(A0), Is SCC TX Buffer empty
        AND     AL,04H
        JNZ    SENDSER        ;NZ if ready to recieve character
        LOOP   WR_SIO1
BAD_SER:POP  CX
        POP     BX
        POP     AX
        XOR     AH,AH
        OR     AH,80H          ;Flag we have a problem
        IRET                    ;Note IRET not RET

SENDSER:MOV  AL,AH
        OUT    ADTA,AL        ;(A2), Send it
        JMP    SIO_DONE

RD_SIO:                                ;Read a character from SSC Channel A
        MOV     CX,256          ;Will try 256 times, then timeout
RD_SIO1:IN  AL,ACTL            ;(A0), Is SCC TX Buffer empty
        AND     AL,01H
        JNZ    GETSER        ;NZ if something there
        LOOP   RD_SIO1
        JMP    BAD_SER
GETSER:POP  CX                ;Get back everything
        POP     BX
        POP     AX
        XOR     AH,AH
        IN     AL,ADTA        ;(A2), return with data
        IRET                    ;Note IRET not RET

SERIAL_OUT:                            ;Simple write a character to SSC Channel#1 on S100Computers Serial IO Board
        MOV     AH,CL            ;Store char in AH
        PUSH   CX
        MOV     CX,256          ;Will try 256 times, then timeout
SERIAL_OUT1:
        IN     AL,ACTL            ;(A0), Is SCC TX Buffer empty
        AND     AL,04H
        JNZ    SERIAL_OUT2      ;NZ if ready to recieve character
        LOOP   SERIAL_OUT1
        POP     CX
        XOR     AH,AH
        OR     AH,80H          ;Flag we have a problem
        RET                    ;Note RET not IRET
SERIAL_OUT2:

```



```

MOV     AL,AH
OUT     ADTA,AL           ;(A2), Send it
POP     CX                ;We will assume no problem, always!
XOR     AH,AH            ;Z for no problem
RET                                           ;Note RET not IRET

```

```

;*****
;

```

```

;   Old Cassette Handler      (Software Interrupt 15H)
;   We will use this as a staging point for a far Jump if an extra
;   ROM is discovered during the BIOS initialization sequence
;   Things like SCSI adaptors etc.
;

```

```

;*****

```

```

CASSETTE:
    push    DS

    PUSH   AX

    XOR    AX,AX           ;Set DS to data area for ROM usage in low RAM @ 400H....)
    MOV    DS,AX
    CMP    byte [DEBUG_FLAG],0 ;Is Debug mode on
    JNZ    CASSETTE_DEBUG ;If not 0 then send debug data

    PUSH   AX
    IN     AL,IOBYTE      ;If bit 3 of Port EFH is 0, Then force Debug Display
    AND    AL,08H
    POP    AX
    JNZ    Cassette1     ;If not 0, skip

```

```

CASSETTE_DEBUG:
    PUSH   AX
    PUSH   BX
    MOV    BX,INT_15H_MSG ;"Int 15H (Cassette) AX="
    CALL   SERIAL_PRINT_STRING
    POP    BX
    POP    AX
    CALL   SERIAL_DISPLAY_REGISTERS ;Display Registers on serial port display (All registers retained)

```

```

Cassette1:
    POP    AX
    POP    DS

    CMP    AH,44H         ;Cirrus Logic VGA board used this to check BIOS is capable
    JNZ    Cassette2
    MOV    BX,VGA_OK_MSG ;Announce we can handle Cirrus Logic VGA Board
    CALL   PRINT_STRING  ;Send msg pointed to by CS:BX
    XOR    AX,AX
    CLC
    retf   2              ;Clear carry (required)
                                ;Remove the original status flags on return

```

```

Cassette2:
    CMP    AH,41H         ;Extenal Wait event (Unused)

```

```

JZ     EXT_WAIT

CMP    AH,0C0H
JZ     GET_DESCRIPTION_TABLE

CMP    AH,0C1H           ;RETURN EXTENDED-BIOS DATA-AREA SEGMENT ADDRESS (PS)
JZ     EXT_BIOS_DATA

CMP    AH,88H
JZ     HIGH_RAM_CHECK

PUSH   AX
PUSH   BX
PUSH   CX
PUSH   AX
MOV    BX,CASSETTE_MSG           ;Announce we got an EXTRA Interrupt
CALL  PRINT_STRING             ;Send msg pointed to by CS:BX
POP    AX
MOV    AL,AH
CALL  AL_HEXOUT
MOV    BX,H_MSG_CRLF           ;"H",CR,LF
CALL  PRINT_STRING             ;Send msg pointed to by CS:BX

POP    CX
POP    BX
POP    AX
STC                                     ;Set carry to indicate INT is not supported
retf  2                               ;Remove the original status flags on return (remember we got here via an INT)

GET_DESCRIPTION_TABLE:                ;AH=C0H
MOV    AX,CS                       ;Return pointer with ES:BX
MOV    ES,AX
MOV    BX,SYS_TABLE
XOR    AX,AX
CLC                                     ;Clear carry
retf  2                               ;Remove the original status flags on return

HIGH_RAM_CHECK:                       ;AH=88H
MOV    AX,0h                       ;Using 8086, so 0H RAM above 1M
CLC                                     ;Set carry
retf  2                               ;Remove the original status flags on return

EXT_WAIT:                             ;AH=41H
STC                                     ;Set carry
retf  2                               ;Remove the original status flags on return

EXT_BIOS_DATA:                       ;AH= C1H, Extended BIOS Data Area Segment in ES
STC                                     ;Set carry (Used on PS/2, not needed here)
retf  2                               ;Remove the original status flags on return

;----- SUPPORT ROUTINES FOR IBM-PC BIOS -----

dumpreg:                              ;Dump all 8086 registers to screen
CALL  PRINT_8086_REGISTERS

```

```
CALL PRINT_SEG_REGISTERS
RET
```

```
SERIAL_DISPLAY_REGISTERS:      ;For Debugging only, Send to serial port Register values of registers with INTs
PUSH AX                      ;Save everything
PUSH BX
PUSH CX
PUSH DX

PUSH DX                      ;we will display in this order
PUSH CX
PUSH BX
PUSH AX

MOV BX,INT_AX_MSG            ;"AX="
CALL SERIAL_PRINT_STRING
POP AX
CALL SERIAL_AX_HEXOUT        ;Get AX

MOV BX,INT_BX_MSG            ;"H BX="
CALL SERIAL_PRINT_STRING
POP AX                      ;Get BX
CALL SERIAL_AX_HEXOUT

MOV BX,INT_CX_MSG            ;"H CX="
CALL SERIAL_PRINT_STRING
POP AX                      ;Get CX
CALL SERIAL_AX_HEXOUT

MOV BX,INT_DX_MSG            ;"H DX="
CALL SERIAL_PRINT_STRING
POP AX                      ;Get DX
CALL SERIAL_AX_HEXOUT

MOV BX,H_Msg                 ;"H"
CALL SERIAL_PRINT_STRING

POP DX                      ;Restore everything
POP CX
POP BX
POP AX
RET
```

```
;=====CORE SUPPORT ROUTINES =====
```

```
; Calculate length difference between DS:SI(end) and ES:DI(start)
```

```
CLENGTH:
MOV AX,DS                    ;DS has segment of final value
MOV CX,ES                    ;ES has segment of start value
SUB AX,CX                    ;Check if finish is the next segment up
JZ SAME_SEGMENT
CMP AX,1000H                 ;Max length must be < 64K
JG BAD_RANGE
```

```

MOV     AX,0FFFFH
SUB     AX,DI           ;Calculate start up to end of segment
ADD     AX,SI           ;Add in the part from the next segment up.
INC     AX              ;Count = difference +1
MOV     CX,AX          ;Return value in CX
RET

SAME_SEGMENT:
MOV     CX,SI
sub     CX,DI
CMP     CX,0FFFEH
JZ     BAD_RANGE
inc     cx              ;count = difference +1
ret

BAD_RANGE:
PUSH    BX
PUSH    CX
MOV     BX,RangeErrMsg ;Range error
CALL   PRINT_STRING
jmp    ToMonitor       ;Note this will clean up the stack

; Send to console the address ES+DI ;CX Unchanged

SHOW_ADDRESS_ES:
push   cx
mov    ax,es
mov    cl,12
shr    ax,cl           ;Get high nibble down to AL
call   hexdigout
MOV    BX,DI
call   BX_HEXOUT      ;Then next 4 digits in BX
call   BLANK
pop    cx
ret

SHOW_ADDRESS_ES_NOSPACE:           ;Same but no trailing blank
push   cx
mov    ax,es
mov    cl,12
shr    ax,cl           ;Get high nibble down to AL
call   hexdigout
MOV    BX,DI
call   BX_HEXOUT      ;Then next 4 digits in BX
pop    cx
ret

; BINARY OUTPUT           ;Send what is in [al] in bits
AL_BINOUT:                 ;No registers altered (except AL)
push   cx
mov    cx,8

```

```

binout1: push  cx
          shl  al,1
          jb   bout1
          mov  cl,'0'
          push ax
          call CO
          pop  ax
          jmp  binend
bout1:   mov  cl,'1'
          push ax
          call CO
          pop  ax
binend:  pop  cx
          loop binout1
          pop  cx
          ret

```

```

;      HEXCHK                ;check for a valid HEX DIGIT
HEX_check:
sub     al,'0'                ;convert to binary if ok set carry if problem
jb     hret
cmp     al,0ah
cmc
jnb    hret
sub     al,7
cmp     al,10
jb     hret
cmp     al,16
cmc
hret:   ret

```

```

; Send to console the address DS+SI ;CX Unchanged

```

```

SHOW_ADDRESS_DS:
push   cx                    ;Same but send upper nibble of ds reg
mov    ax,ds
mov    cl,12
shr    ax,cl                  ;Get high nibble down to AL
call   hexdigout
MOV    BX,SI
call   BX_HEXOUT              ;Then next 4 digits in BX
call   BLANK
pop    cx
ret

```

```

; Send to console the address SS+SI ;Used (Only) by sector display routine. CX Unchanged

```

```

SHOW_ADDRESS_SS:
push   cx                    ;Same but send upper nibble of ds reg
mov    ax,ss
mov    cl,12
shr    ax,cl                  ;Get high nibble down to AL

```

```

    call    hexdigout
    MOV     BX,SI
    call    BX_HEXOUT           ;Then next 4 digits in BX
    call    BLANK
    pop     cx
    ret

;      Get 8 bit value (2 digits) to AL. (BX, CX & DX Unchanged), terminator in AH - normally 0

GET2DIGITS:
    PUSH   BX
    PUSH   CX
    mov    bx,0                ;Default to 0H

    call   CICO                ;1st Console input digit to AL
    cmp   al,'0'              ;alphanumeric?
    jb    bexit2
    call  HEX_check           ;convert to binary and check it
    jb    err2
    add   bl,al               ;Move into BX
    mov   cl,4
    shl  bx,cl               ;shift in last addition to high nibble on BL

    push  BX                  ;Just in case
    call  CICO                ;2nd Console input digit to AL
    pop   BX

    cmp   al,'0'              ;alphanumeric?
    jb    bexit2
    call  HEX_check           ;convert to binary and check it
    jb    err2
    add   bl,al               ;Move into BX
    MOV   AL,BL
    MOV   AH,0                ;Ret 0 in AH if all OK
    POP   CX
    POP   BX
    ret

err2:   POP   CX              ;Cleanup stack
        POP   BX
        JMP   ERR            ;Then normal error exit

bexit2: cmp   al,' '          ;save terminator, if SP,CR accept only 1 digit
        je    bgood2
        cmp   al','
        je    bgood2
        cmp   al,CR
        je    bgood2
        cmp   al,ESC
        je    bgood2
        POP   CX              ;Cleanup stack
        POP   BX
        JMP   ERR            ;Then normal error exit

bgood2: mov   ah,al           ;Save SP,', ' or CR in AH
        MOV   BH,0

```

```

mov     cl,4
shr     bx,cl           ;shift down last addition to low nibble on BL
MOV     AL,BL
POP     CX
POP     BX
ret

```

```

;      Get (up to) 16 bit value (4 digits) to DI. Termination byte in AH

```

```

GET4DIGITS:
    PUSH    BX
    PUSH    CX
    MOV     CX,5         ;4 characters maximum + CR
    mov     bx,0
loop4b: call    CICO      ;Console input to AL
    cmp     al,'0'      ;alphanumeric?
    jb     bexit
    push   cx
    mov     cl,4
    shl     bx,cl       ;shift in last addition
    pop     cx
    call    HEX_check   ;convert [AL] to binary and check it
    jb     AddressError
    add     bl,al
    loop   loop4b
    MOV     DI,BX
    POP     CX
    POP     BX
    ret                    ;Will return BX = xxxxH

```

```

;      Get (up to) 20 bit parameter. 16 bit value (4 digits) to DI.
;      If 5 digits, first digit entered to ES (BX,CX, DX unaltered)

```

```

GET5DIGITS:                    ;Will return ES=000xH, DI = xxxxH
    PUSH    BX
    PUSH    CX
    mov     cx,6         ;Max count of 5 characters + CR
    mov     bx,0         ;So initially ES=0, see below
loopb:  call    CICO      ;Console input to AL
    cmp     al,'0'      ;alphanumeric?
    jb     bexit

    push   cx           ;Save character count
    push   bx           ;force the highest nibble to ds:
    and    bx,0f000h
    mov     es,bx
    pop     bx
    mov     cl,4
    shl     bx,cl       ;shift in last addition
    pop     cx
    call    HEX_check   ;convert to binary and check it
    jb     AddressError
    add     bl,al
    loop   loopb       ;Do up to 5 characters

```

```

bexit: MOV     DI,BX           ;Move data to DI
      cmp     al,' '         ;Terminate with a SP, ",", or CR only
      je      bgood
      cmp     al,', '
      je      bgood
      cmp     al,CR
      je      bgood
      jmp     ERR
bgood: mov     ah,al         ;Save terminator
      POP     CX             ;Balance up stack
      POP     BX
      ret

AddressError:
      MOV     BX,AddressErrMsg ;Range error
      CALL    PRINT_STRING
      jmp     ToMonitor      ;Note this will clean up the stack

;      For debugging display

DEBUG_AX:
      PUSH    AX
      PUSH    BX
      PUSH    CX
      CALL    AX_HEXOUT
      POP     CX
      POP     BX
      POP     AX
      RET

;      Display ALL 8086 registers

PRINT_8086_REGISTERS:          ;Print AX,BX,CX,DX,SI & DI Registers
      PUSHF                    ;Will print all on CRT on one line followed by a CRLF
      PUSH    AX
      PUSH    BX
      PUSH    CX
      PUSH    SI                ;Will pop from stack from here
      PUSH    DI
      PUSH    DX
      PUSH    CX
      PUSH    BX
      PUSH    AX

      MOV     BX,AXMSG          ;[AX]=
      CALL    PRINT_STRING
      POP     AX
      CALL    AX_HEXOUT

      MOV     BX,BXMSG          ;[BX]=
      CALL    PRINT_STRING
      POP     AX

```



```

CALL    AX_HEXOUT

MOV     BX,CXMSG           ;[CX]=
CALL   PRINT_STRING
POP     AX
CALL   AX_HEXOUT

MOV     BX,DXMSG           ;[DX]=
CALL   PRINT_STRING
POP     AX
CALL   AX_HEXOUT

MOV     BX,DIMSG           ;[DI]=
CALL   PRINT_STRING
POP     AX
CALL   AX_HEXOUT

MOV     BX,SIMSG           ;[SI]=
CALL   PRINT_STRING
POP     AX
CALL   AX_HEXOUT

MOV     BX,H_MSG           ;Final H
CALL   PRINT_STRING
POP     CX
POP     BX
POP     AX
POPF
RET

```

```
; Display 8086 Segment registers
```

```

PRINT_SEG_REGISTERS:           ;Print current RAM loction of the stack
    PUSHF                     ;Will print all on CRT on one line followed by a CRLF
    PUSH    AX
    PUSH    BX
    PUSH    CX
    MOV     BX,SSMSG           ;[SS]=
    CALL   PRINT_STRING
    MOV     AX,SS
    CALL   AX_HEXOUT

    MOV     BX,SPMSG           ;[SP]=
    CALL   PRINT_STRING
    MOV     AX,SP
    SUB     AX,10               ;Adjust because we saved stuff first
    CALL   AX_HEXOUT

    MOV     BX,CSMSG           ;[CS]=
    CALL   PRINT_STRING
    MOV     AX,CS
    CALL   AX_HEXOUT

    MOV     BX,DSMSG           ;[DS]=

```

```

CALL PRINT_STRING
MOV AX,DS
CALL AX_HEXOUT

MOV BX,ESMSG ;[ES]=
CALL PRINT_STRING
MOV AX,ES
CALL AX_HEXOUT

MOV BX,BPMSG ;[BP]=
CALL PRINT_STRING
MOV AX,BP
CALL AX_HEXOUT

MOV BX,H_MSG ;Final H
CALL PRINT_STRING
POP CX
POP BX
POP AX
POPF
RET

; CHECK FOR ^S or ESC AT CONSOL
CTRL_CHECK:
call CSTS
cmp al,0
jz ctlexit
call CICO
cmp al,'S'-40h ;^S will pause
jnz ctlcchek ;possibly ^C
xwait: call CSTS
cmp al,0
jz xwait
ret
ctlcchek:
cmp al,ESC ;ESC will abort
jz ERR
ctlexit:ret

; SEND CRLF with an ESC at keyboard check
CRLF_CHECK:
push cx
push bx
call CTRL_CHECK ;Will jump to err if ESC
mov cl,CR
call CO
mov cl,LF
call CO
pop bx
pop cx
ret

; SIMPLE SEND CRLF

```

```

CRLF:  push    cx
       push    bx
       mov     cl,CR
       call   CO
       mov     cl,LF
       call   CO
       pop     bx
       pop     cx
       ret

```

```

;      PRINT A BLANK SPACE
BLANK: push    cx
       mov     cx,1
       call   TABS
       pop     cx
       ret

```

```

;      TABS                               ;[cx] = number of spaces
TABS:  push    cx
       mov     cl,' '
       call   CO
       pop     cx
       loop   TABS
       ret

```

```

;      ERROR ABORT ROUTINE
ERR:   MOV     BX,ERR_MSG                 ;Invalid Command (or code not yet done)
       CALL   PRINT_STRING
       jmp    ToMonitor

```

```

;      BX_HEXOUT                           ;bx output as 4 hex digits
BX_HEXOUT:                               ;No registers altered
       push   ax
       mov    al,bh
       call  AL_HEXOUT
       mov    al,bl
       call  AL_HEXOUT
       pop   ax
       ret

```

```

;      AX_HEXOUT                           ;output the 4 hex digits in [AX]
AX_HEXOUT:                               ;No registers altered
       PUSH  AX
       MOV   AL,AH
       CALL  AL_HEXOUT
       POP   AX
       CALL  AL_HEXOUT
       RET

```

```

;      AL_HEXOUT          ;output the 2 hex digits in [AL]
AL_HEXOUT:              ;No registers altered (except AL)
    push    cx
    push    ax
    mov     cl,4          ;first isolate low nibble
    shr     al,cl
    call    hexdigout
    pop     ax
    call    hexdigout     ;get upper nibble
    pop     cx
    ret

hexdigout:
    and     al,0fh        ;convert nibble to ascii
    add     al,90h
    daa
    adc     al,40h
    daa
    mov     cl,al
    call    CO
    ret

;   ROUTINE TO PRINT A STRING   CS:BX = START OF STRING  $ or 0 = FINISH

PRINT_STRING:
    push    cx
print1: mov     al,[CS:bx]    ;Note this routine does NOT assume DS = CS here.
    inc     bx              ;By using the CS over-ride we will always have
    cmp     al,'$'         ;a valid pointer to messages at the end of this monitor
    jz     print2
    cmp     AL,0           ;Also terminate with 0's
    JZ     print2
    mov     cl,al
    call    CO
    jmp     print1
print2: pop     cx
    ret

;   ROUTINE TO PRINT A STRING TO S100Computers Serial Port #1  BX = START OF STRING  $ or 0 = FINISH
;   This routine is used mainly for Debugging the IBM BIOS section. No registers altered

SERIAL_PRINT_STRING:
    push    AX
    push    cx
sprint1:mov     al,[CS:bx]    ;Note this routine does NOT assume DS = CS here.
    inc     bx              ;By using the CS over-ride we will always have
    cmp     al,'$'         ;a valid pointer to messages at the end of this monitor
    jz     sprint2
    cmp     AL,0
    JZ     sprint2
    mov     cl,al
    call    SERIAL_OUT     ;Send to serial port #1
    jmp     sprint1
sprint2:pop     cx

```



```

JZ     CIC1
CMP    AL,LF
JZ     CIC1
CMP    AL,SPACE
JZ     CIC1
CMP    AL,ESC           ;Also ESC
JZ     CIC1

CMP    AL,'0'
JB     BAD_CHAR
CMP    AL,':'           ;Allow 0-9
JB     CIC1
CMP    AL,'A'
JB     BAD_CHAR       ;do not allow : to @
CMP    AL,'['         ;Is upper case A to Z
JB     CIC1
CMP    AL,'a'
JB     BAD_CHAR
CMP    AL,'{'
JB     UPPER_CASE
JMP    BAD_CHAR

UPPER_CASE:
AND    AL,5FH           ;THIS CONVERTS ALL LC->UC
CIC1:  PUSH  AX
      PUSH  CX
      MOV   CL,AL
      CALL  CO           ;DISPLAY ON CONSOLE
      POP   CX
      POP   AX
      RET

;
BAD_CHAR:
MOV    AL,BELL         ;SEND BELL TO INDICATE BAD DATA
CALL  CIC1
MOV    AL,'?'         ;SEND ? TO INDICATE BAD DATA
JMP   CIC1

SPEAKOUT:
MOV    AL,0H           ;Will try 256 times, then timeout
SOUT1: PUSH  AX
      IN   AL,BCTL     ;Are we ready for a character
      AND  AL,04H
      JNZ  SENDS
      POP  AX
      DEC  AL
      JNZ  SOUT1
      RET

SENDS: POP   AX
      MOV  AL,CL
      OUT  BDTA,AL     ;Send it
      RET

```

```
;SPEAKTOMM THIS IS A ROUTINE TO SEND A STRING TO TALKER [BX] AT STRING
```

```

SPEAK_STRING:
    MOV     AL,[CS:BX]
    CMP     AL,'$'           ;Terminate with "$" or 0
    JZ      STOMM1
    OR      AL,AL
    JZ      STOMM1
    MOV     CL,AL
    CALL    SPEAKOUT
    INC     BX
    JMP     SPEAK_STRING
STOMM1: MOV     CL,CR           ;MUST END WITH A CR
    JMP     SPEAKOUT

POO:  RET
RI:   MOV     AL,1AH           ;NO PUNCH OUTPUT AT THE MOMENT
    RET           ;NO READER AT THE MOMENT

NOT_DONE_WARNING:
    mov     bx,TO_BE_DONE     ;Signon notice
    call    PRINT_STRING
    RET

;End of the bios code

;+++++
;      Data contained in BIOS (Does not get modified, rommable)

;***** DATA SECTION *****
;
;
;      Interrupt vector table for 8259A

vec_tbl_8259A:
;Pointer to 8259A Hardware interrupts used here
    dw     timer           ;Interrupt Base + 0 ;Will use timer
    dw     keyhnd         ;Interrupt Base + 1 ;Will use for keyboard press
    dw     Send_EOI       ;Interrupt Base + 2
    dw     Send_EOI       ;Interrupt Base + 3
    dw     Send_EOI       ;Interrupt Base + 4
    dw     Send_EOI       ;Interrupt Base + 5
    dw     Send_EOI       ;Interrupt Base + 6
    dw     Send_EOI       ;Interrupt Base + 7

vec_tbl_soft_ints:
;Pointer to software interrupts used here
    dw     CONOUT         ;interrupt 10
    dw     equip          ;interrupt 11
    dw     memsiz         ;interrupt 12
    dw     DISKIO         ;interrupt 13
    dw     commio         ;interrupt 14
    dw     CASSETTE       ;interrupt 15
    dw     CONIN          ;interrupt 16
    dw     LST_OUT        ;interrupt 17
    dw     basic          ;interrupt 18

```



```

dw      BOOT_DOS_INT      ;interrupt 19
dw      time_of_day       ;interrupt 1A
dw      kbd_break         ;interrupt 1B
dw      user_timer        ;interrupt 1C
dw      VID_PARM_TABLES   ;interrupt 1D
dw      FDISK_3PARM_TBL   ;interrupt 1E      ;Default to 3" 1.44M Floppy Disk
dw      0                  ;interrupt 1F

INITIAL_VGA_VALUES:
DB      03H
DW      0050H
DW      1000H
DW      0000H
DW      0000H,0000H,0000H,0000H
DW      0000H,0000H,0000H,0000H
DW      0607H
DB      0H
DW      3D4H
DB      29H
DB      30H
EQU     $-INITIAL_VGA_VALUES

;Paramaters that MUST be in low RAM for the Lomas CGA board
;to initilize properly with MS-DOS. (Starting at 0:449H...)
;CRT_MODE
;CRT_COLS
;CRT_LEN
;CRT_START
;CURSOR_POSN (8 Total) (Must be 0000 for first one at initialization!)
;CURSOR_MODE
;ACTIVE_PAGE
;ADDR_6845
;CRT_MODE_SET
;CRT_PALLETTE

VID_PARM_TABLES      db      38h,28h,2dh,0ah,1fh,6,19h      ;for 40 x 25
db      1ch,2,7,6,7
db      0,0,0,0
db      71h,50h,5ah,0ah,1fh,6,19h      ;for 80 x 25
db      1ch,2,7,6,7
db      0,0,0,0
db      38h,28h,2dh,0ah,7fh,6,64h      ;for graphics
db      70h,2,1,6,7
db      0,0,0,0
db      61h,50h,52h,0fh,19h,6,19h      ;for 80 x 25 on b/w card
db      19h,2,0dh,0bh,0ch
db      0,0,0,0
m5      dw      2048      ;40 x 25 length
dw      4096      ;80 x 25
dw      16384      ;graphics
dw      16384
m6      db      40,40,80,80,40,40,80,80      ;columns
m7      db      2ch,28h,2dh,29h,2ah,2eh,1eh,29h      ;table of Video board mode sets
DB      '<-JMP to VIDIO PARMS TABLE '

;<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<<
;
;      Default Floppy Disk Parameters Tables
;      Most are unique to the NEC 765 controller used in the IBM-PC.
;      I do not use them in this BIOS

```

```

FDISK_5PARAM_TBL db      0DFH      ;For 5" 360K Disks
                  db      2
                  db      25      ;Time delay for motor
                  db      2        ;512 byte sectors
                  db      09H      ;sectors per track!
                  db      02ah     ;GAP length
                  db      0ffh     ;DTL
                  db      050h     ;GAP length for format
                  db      0f6h     ;Fill byte for format
                  db      25      ;Head settle time
                  db      4        ;Motor stat time
                  db      11      ;length of Table

FDISK_3PARAM_TBL db      0AFH      ;For 3" 1.44M Disks
                  db      2
                  db      25      ;Time delay for motor
                  db      2        ;512 byte sectors
                  db      12H      ;18 sectors per track
                  db      1BH      ;GAP length
                  db      0FFH     ;DTL
                  db      6CH      ;GAP length for format
                  db      0F6H     ;Fill byte for format
                  db      0FH      ;Head settle time
                  db      8        ;Motor stat time
                  db      11      ;length of Table

;      Default Hard Disk Parameters Table:-
;      Custom HDISK: 1024 Cylinders, 15 heads, 63 sectors, 512MB Total

HDISK_PARAM_TBL DW      DOS_MAXCYL ;0, Max Cylinders
                 DB      DOS_MAXHEADS ;2, Max heads (15)
                 DW      0000H      ;3, Not used on AT
                 DW      0FFFFH     ;5, Start Write Precomp (not used)
                 DB      0H         ;7, ECC burst length (not used)
                 DB      08H        ;8, "Control Byte" (Bit 7 = disable retries)
                 DB      0H,0H,0H   ;9, Timeouts no used on AT
                 DW      0400H      ;A, Landing zone
                 DB      DOS_MAXSEC ;B, Sec/track
                 DB      0H,0H,0H   ;C, Reserved

SYS_TABLE      DW      8H          ;Called by INT 15H, AH=C0H called by MSDOS V3+
                 DB      0FCH      ;Machine ID Byte
                 DB      0         ;Sub model
                 DB      0         ;BIOS version
                 DB      10H       ;Keyboard Int
                 DB      0,0,0

;      Interrupt messages for checkout
;
msg10 db      13,10,'Int 10h',0
msg11 db      13,10,'Int 11h',0

```

```

msg12 db 13,10,'Int 12h',0
msg13 db 13,10,'Int 13h',0
msg14 db 13,10,'Int 14h',0
msg15 db 13,10,'Int 15h',0
msg16 db 13,10,'Int 16h',0
msg17 db 13,10,'Int 17h',0
msg18 db 13,10,'Int 18h',0
msg19 db 13,10,'Int 19h',0
msg1a db 13,10,'Int 1Ah',0
msg1b db 13,10,'Int 1Bh',0
msg1c db 13,10,'Int 1Ch',0
msg1d db 13,10,'Int 1Dh',0
msg1e db 13,10,'Int 1Eh',0
msg1f db 13,10,'Int 1Fh',0
;
xtmsg db 13,10,' Exit',0

```

```

;MAIN MENU COMMAND BRANCH TABLE

```

```

ctable dw MAP ;A ;Display Memory Map
dw SET_CO_FLAG ;B ;Set Console output to Propeller or CGA/VGA Video board
DW MMENU_FBOOT_DOS ;C ;LOAD MS-DOS from 5" Floppy (No debugging)
dw DISPLAY_RAM_BYTES ;D ;Display Memory contents (Read RAM in Bytes)
dw SET_TIME_DATE ;E ;Display/Set Time & Date
dw FILL ;F ;Fill memory contents
dw GOTO ;G ;Jump to a SEG:ADDRESS location
dw HEXMATH ;H ;Add & Subtract two Hex numbers
dw SOFT_INTS ;I ;Test Software interrupts
dw TEST_RAM ;J ;Test RAM
dw KCMD ;K ;Display this menu
dw TEST_8259 ;L ;Test 8259A hardware
dw MOVE ;M ;Move memory
dw MYIDE ;N ;Sub-menu to test/diagnose IDE Board
dw ERR ;O ;
dw MMENU_HBOOT_DOS ;P ;LOAD MS-DOS from HDISK (No debugging)
dw QUERY ;Q ;Query In or Out to a port
dw REGISTERS ;R ;Display the 8086 registers in RM
dw SUBSTITUTE ;S ;Substitute byte values in RAM
dw DISPLAY_RAM_WORDS ;T ;Display Memory contents (Read RAM in Words)
dw INPORTS ;U ;Display all active 8086 INPUT ports
dw VERIFY ;V ;Verify two memory regions are the same
dw XMODEM_LOAD ;W ;Load code to RAM from Modem/Serial port
dw IBM_BIOS ;X ;IBM-PC Sub menu
DW ERR ;Y ;
dw Z80 ;Z ;Return back to Z80 master

```

```

;IDE COMMAND BRANCH TABLE

```

```

IDE_TABLE DW SET_DRIVE_A ; "A" Select Drive A
DW SET_DRIVE_B ; "B" Select Drive B
DW ERR ; "C" LOAD CPM (If present)
DW DISPLAY ; "D" Sector contents display:- ON/OFF
DW RAMCLEAR ; "E" Clear RAM buffer
DW FORMAT ; "F" Format current disk
DW ERR ; "G" Restore backup

```

```

DW ERR ; "H" Backup partition
DW NEXT_SECT ; "I" Next Sector
DW PREV_SECT ; "J" Previous sector
DW IDE_LOOP ; "K"
DW SET_LBA ; "L" Set LBA value (Set Track,sector)
DW ERR ; "M"
DW SPINDOWN ; "N" Power down hard disk command
DW DRIVE_ID ; "O" Show current Drive ID
DW ERR ; "P"
DW LBA_DISPLAY_TEST ; "Q" Check the LBA mode HEX display on the IDE board is working correctly
DW READ_SEC ; "R" Read sector to data buffer
DW SEQ_SEC_RD ; "S" Sequential sec read and display contents
DW ERR ; "T"
DW SPINUP ; "U" Power up hard disk command
DW N_RD_SEC ; "V" Read N sectors
DW WRITE_SEC ; "W" Write data buffer to current sector
DW N_WR_SEC ; "X" Write N sectors
DW COPY_AB ; "Y" Copy Drive A to Drive B
DW VERIFY_AB ; "Z" Verify Drive A:= Drive B:

```

```

;IBM_BIOS COMMAND BRANCH TABLE

```

```

IBM_TABLE dw MENU_TIMER_TEST ;A
dw SET_CO_FLAG ;B Set Console output to Propeller or CGA/VGA Video board
dw MENU_FBOOT_DOS ;C Boot MS-DOS from 5" floppy (Allow Debugging)
dw DEBUG_ON_OFF ;D
dw MENU_KEY_TEST ;E
dw MENU_CO_TEST ;F
dw MENU_BUFF_IO ;G
dw XY_VIDEO ;H
dw PrintScrTest ;I Print Screen test
dw READ_BYTE_TEST ;J Tests to test/see hardware RAM RD/WR signals
dw READ_WORD_TEST ;K
dw WRITE_BYTE_TEST ;L
dw WRITE_WORD_TEST ;M
dw ERR ;N
dw MENU_SIO_TEST ;O
dw MENU_HBOOT_DOS ;P Boot MS-DOS from HDISK (Allow Debugging)
dw CHS_DISPLAY_TEST ;"Q" Check the CHS mode HEX display on the IDE board is working correctly
dw ERR ;R
dw FSEQ_5RD_TEST ;S
dw FSEQ_3RD_TEST ;T
dw HSEQ_RD_TEST ;U
dw ERR ;V
dw HSEC_RW_TEST ;W Hard Disk Sector Read/Write test using INT 13H
dw ERR ;X
dw DUMP_B_SEC ;Y Display Floppy Boot sector info
dw DUMP_MBR ;Z Display the Hard Disk MBR information

```

```

;Initilization table for ZILOG SCC registers (For XMODEM Input)
SCCINIT DB 04H ;1, Point to WR4
DB 44H ;2, X16 clock,1 Stop,NP
;
DB 03H ;3, Point to WR3
DB 0C1H ;4, Enable reciever, No Auto Enable (Hardware CTS), Recieve 8 bits

```



```

TO_BE_DONE      DB      CR,LF,'Code not done yet!',CR,LF,'$'
AXMSG           DB      'AX=$'
BXMSG           DB      'H BX=$'
CXMSG           DB      'H CX=$'
DXMSG           DB      'H DX=$'
DIMSG           DB      'H DI=$'
SIMSG           DB      'H SI=$'
CSMSG           DB      'CS=$'
SPMSG           DB      'H SP=$'
SSMSG           DB      'H SS=$'
DSMSG           DB      'H DS=$'
ESMSG           DB      'H ES=$'
BPMSG           DB      'H BP=$'
H_MSG           DB      'H$'
INT_FLAGS_MSG  DB      'H Flags=$'
AddressErrMsg   DB      CR,LF,'Address paramater error.$'
RangeErrMsg     DB      CR,LF,'Paramater range error.$'

MAIN_MENU       DB      CR,LF
                DB      'A=Memmap   B=Video   C=DOS(F)   D=Disp RAM   E=Time & Date',CR,LF
                DB      'F=Fill RAM  G=Goto    H=Math      I=Interrupts J=Test RAM',CR,LF
                DB      'K=Menu     L=8259A  M=Move RAM  N=IDE Menu   O=',CR,LF
                DB      'P=DOS(H)  Q=Ports  R=Registers S=Subs    T=Disp RAM (Words)',CR,LF
                DB      'U=All Ports V=Verify  W=XModem   X=PC-BIOS   Z=Z80',CR,LF,'$'

DIFF_Header_Msg DB      CR,LF,'First RAM  HEX Binary      Second RAM  HEX Binary$'
MATCHES_OK      DB      CR,LF,'Both RAM locations match$'
PORTS_IN_MSG    DB      CR,LF,'Input Ports, 0-0FFFFH Ports. (16 Bit Port DX->AX and DX->AL)',CR,LF,LF,'$'
MORE_MSG        DB      CR,LF,'Continue ? (Y/N) $'
MSG30           DB      CR,LF,'Adj :- $'
MSG12T          DB      ' $'
MSG16T          DB      '/20$'
JMSG            DB      CR,LF,LF,'Continous RAM hardware test.',CR,LF,'Please enter start , ending address (+CR).',CR,LF,'$'
STARTJMSG       DB      CR,LF,'Starting RAM test. Hit ESC any time to abort',CR,LF,'$'
RAM_Test_Count  DB      CR,'RAM test loop count = $'
TMMSG           DB      CR,LF,'Time:- $'
GET_SEG_MSG     DB      CR,LF,'Enter Segment (xxxxH)->$'
GET_OFFS_MSG    DB      CR,LF,'Enter Offset (xxxxH)->$'
MATH_MSG        DB      CR,LF,LF,'Hex Math. Enter xxxxH,xxxxH:- $'
MATH_HEADER1    DB      CR,LF,'Sum = $'
MATH_HEADER2    DB      'H. Difference = $'
PIC_SIGNON      DB      CR,LF,LF,'Test of Interrupts on the MSDOS Support Board',CR,LF
                DB      'Any keyboard key should flash the "D1" LED.',CR,LF
                DB      'If CPU returned sINTA, "D2" LED should flash.',CR,LF,LF,'$'
CRLFMSG         DB      CR,LF,'$'
TrapIntMSG      DB      'Trap int. detected at a non-assigned location.$'
TrapFFIntMSG    DB      'Trap int. detected at 0FFH in RAM.$'
DebugTrapMSG    DB      'Trap int. detected Software Debug INT at 0CH in RAM.$'
Int0MSG         DB      'V0 $'
Int1MSG         DB      'V1 $'
Int2MSG         DB      'V2 $'
Int3MSG         DB      'V3 $'
Int4MSG         DB      'V4 $'
Int5MSG         DB      'V5 $'
Int6MSG         DB      'V6 $'
Int7MSG         DB      'V7 $'

```

```

DIVIDE_MSG          DB      CR,LF,'Int #0 (Invalid Divide), FAULT',CR,LF,'$'
PM_DIVIDE_MSG      DB      'PM Int 0 Divide, FAULT',CR,LF,'$'
DEBUG_MSG          DB      'Int 1 Debug Exception, TRAP',CR,LF,LF,'$'
BREAKPOINT_MSG    DB      'Int 3 Breakpoint, TRAP',CR,LF,LF,'$'
NMI_FAULT_MSG     DB      CR,LF,'Int #2 (NMI Interrupt), TRAP',CR,LF,'$'
OVERFLOW_ERR_MSG  DB      CR,LF,'Int #4 (Overflow), TRAP',CR,LF,'$'
BOUNDS_ERR_MSG    DB      CR,LF,'Int #5 (Bounds Check), FAULT',CR,LF,'$'
INVALID_ERR_MSG   DB      CR,LF,'Int #6 (Invalid Opcode), FAULT',CR,LF,'$'
DEVICE_ERR_MSG    DB      CR,LF,'Int #7 (No Coprocessor), FAULT',CR,LF,'$'
DOUBLE_ERR_MSG    DB      CR,LF,'Int #8 (Double Fault), ABORT',CR,LF,'$'
COPROCESSOR_SEG_ERR_MSG DB  CR,LF,'Int #9 Co-processor Segment Overrun, ABORT',CR,LF,'$'
INVALID_TSS_ERR_MSG DB  CR,LF,'Int #10 Invalid TSS, FAULT, $'
INT_ERR_NUM_MSG   DB      'Error Number = $'
SEGMENT_ERR_MSG   DB      CR,LF,'Int #11 Segment not present, FAULT, $'
STACK_ERR_MSG     DB      CR,LF,'Int #12, Stack exception, FAULT $'
GENERAL_ERR_MSG   DB      CR,LF,'Int #13 General protection error, FAULT $'
PAGE_ERR_MSG      DB      CR,LF,'Int #14 Page Fault, FAULT',CR,LF,'$'
RESERVED_ERR_MSG  DB      CR,LF,'INT #15 Intel Reserved Int, TRAP',CR,LF,'$'
COPROCESSOR_ERR_MSG DB  CR,LF,'Int #16 Co-processor error, FAULT',CR,LF,'$'
CPU_HALTED_MSG    DB      'The CPU is Halted. Press Reset to restart.',CR,LF,'$'

INT_SIGNON        DB      CR,LF,LF,'Test of CPU FAULT & TRAP Interrupts.'
                  DB      CR,LF,'Note. The CPU will HALT upon accepting FAULTS!'
                  DB      CR,LF,LF,'CPU Interrupt Testing Menu',CR,LF
                  DB      '00 = Divide by Zero FAULT test',CR,LF
                  DB      '04 = Overflow TRAP test',CR,LF
                  DB      '06 = Invalid Opcode FAULT test',CR,LF
                  DB      '0D = General Protection Fault, FAULT test',CR,LF
                  DB      '40 = Software Int 40H test',CR,LF
                  DB      'F0 = Software Int F0H test',CR,LF,LF

INT_RANGE_MSG     DB      CR,LF,BELL,'Only CPU ints 00, 04, 06, 0D, 40 or F0 for this test.',CR,LF,'$'

MODEM_SIGNON:    DB      'Load a File from a PC into RAM using the S100Computers IO Board',CR,LF
                  DB      'Zilog SCC Ports A1H & A3H. Requires RTS & CTS, 38,400 Baud.',CR,LF,'$'
SSC_MSG_INIT     DB      'SCC Port A initialized to 38,400 Baud.',CR,LF,LF,'$'
RAM_DESTINATION  DB      CR,LF,'Enter destination in RAM for data (up to 5 digits): $'
P_RAM_DESTINATION DB  CR,LF,'Enter destination in RAM for data (up to 8 digits): $'
DOWNLOAD_MSG     DB      'Downloading file Started.$'
SPEED_MSG        DB      'Serial Port is set to 38,400 Baud.$'
RMSG             DB      CR,LF,'WAITING FOR SECTOR # $'
ERRSOH          DB      'H Received',CR,LF,'Did not get Correct SOH',CR,LF,'$'
MODEM_ERR2      DB      CR,LF,'Bad Sector # in Header',CR,LF,'$'
MODEM_ERR3      DB      CR,LF,'Bad Checksum for Sector',CR,LF,'$'
TOUTM           DB      CR,LF,'Timeout! $'
QUITM           DB      CR,LF,'+++ MULTIPLE ERRORS ENCOUNTERED +++'
                  DB      CR,LF,'Type Q To Quit, R To Retry:$'
RAM_MSG         DB      'H. If OK will write to RAM location $'
FINISH_MSG      DB      'Down loading of file complete. No Errors$'
TRANS_DONE      DB      CR,LF,LF,'Data Transfer Is Complete',CR,LF,LF,'$'
BAD_HEADER      DB      CR,LF,'Unable to get a valid file header!',CR,LF,'$'
ENTER_RAM_LOC   DB      CR,LF,'Enter start RAM destination (1000H - FF000H) (xx000H): $'
START_POINTER   DB      CR,LF,'Will load data starting at RAM location $'
ABORT_MSG       DB      CR,LF,LF,'Invalid Character or Program Aborted',CR,LF,'$'

```

```

IDE_SIGNON0  DB      CR,LF,LF,'IDE HDisk Test Menu Routines.  $'
IDE_SIGNON4  DB      'A=Select Drive A  B=Select Drive B  C=Boot CPM  D=Set Sec Display $'
IDE_SIGNON1  DB      'On',CR,LF,'$'
IDE_SIGNON2  DB      'Off',CR,LF,'$'

IDE_SIGNON3  DB      'E=Clear Sec Buff  F=Format Disk      I=Next Sec      J=Previous Sec',CR,LF
DB      'L=Set LBA Value  N=Power Down      O=Disk ID      Q=LBA Display Test',CR,LF
DB      'R=Read Sector      S=Seq Sec Rd      U=Power Up      V=Read N Sectors',CR,LF
DB      'W=Write Sector      X=Write N Sectors Y=Copy A->B  Z=Verify A=B',CR,LF
DB      '(ESC) Back to Main Menu',CR,LF
DB      LF,'Current settings:- $'

IDE_MENU     DB      'Enter a Command:- $'
IDE_HARDWARE DB      CR,LF,'Initilizing IDE Board, one moment please...',CR,LF,'$'

INIT_1_ERROR: DB      CR,LF,'Initilizing of First Drive failed. Aborting Command.',BELL,CR,LF,LF,'$'
INIT_2_ERROR  DB      CR,LF,'Initilizing of Second Drive failed. (Possibly not present).',BELL,CR,LF,LF,'$'
BAD_DRIVE:    DB      CR,LF,'First Drive ID Information appears invalid. '
DB      '(Drive possibly not present).',CR,LF
DB      'Aborting Command.',BELL,CR,LF,LF,'$'

msgmdl       DB      CR,LF,'Drive/CF Card Information:-',CR,LF
DB      'Model: $'
msgsn        DB      'S/N:  $'
msgrev       DB      'Rev:  $'
msgscy       DB      'Cylinders: $'
msgghd       DB      ', Heads: $'
msgsc        DB      ', Sectors: $'
msgCPMTRK    DB      'CPM TRK = $'
msgCPMSEC    DB      ' CPM SEC = $'
msgLBA       DB      ' (LBA = 00$'
MSGBracket   DB      ')$'
H_Msg        DB      'H$'
H_MSG_CRLF   DB      'H',CR,LF,'$'
NotDoneYet   DB      CR,LF,'Command Not Done Yet$'
CONFIRM_WR_MSG DB      CR,LF,LF,BELL,'Will erase data on the current drive, '
DB      'are you sure? (Y/N)...$'
msgrd        DB      'Sector Read OK',CR,LF,'$'
msgwr        DB      'Sector Write OK',CR,LF,'$'
SET_LBA_MSG  DB      'Enter CPM style TRK & SEC values (in hex).',CR,LF,'$'
SEC_RW_ERROR DB      'Drive Error, Status Register = $'
ERR_REG_DATA DB      'Drive Error, Error Register = $'
ENTERRAM_SECL DB      'Starting sector number, (xxH) = $'
ENTERRAM_HEAD DB      'Starting HEAD number, (xxH) = $'
ENTERRAM_FTRKL DB      'Enter Starting Track number, (xxH) = $'
ENTERRAM_TRKL DB      'Track number (LOW byte, xxH) = $'
ENTERRAM_TRKH DB      'Track number (HIGH byte, xxH) = $'
ENTER_HEAD   DB      'Head number (01-0f) = $'
ENTER_COUNT  DB      'Number of sectors to R/W (xxH) = $'
ENTERRAM_DMA DB      'Enter DMA Adress (Up to 5 digits, xxxxxH) = $'
OVER_COUNT_10 DB      CR,LF,'1 & 9 sectors. Only!',CR,LF,'$'
OVER_COUNT_19 DB      CR,LF,'1 & 18 sectors. Only!',CR,LF,'$'
DRIVE_BUSY   DB      'Drive Busy (bit 7) stuck high.  Status = $'
DRIVE_NOT_READY DB      'Drive Ready (bit 6) stuck low.  Status = $'
DRIVE_WR_FAULT DB      'Drive write fault.  Status = $'

```



```

UNKNOWN_ERROR DB 'Unknown error in status register. Status = $'
BAD_BLOCK DB 'Bad Sector ID. Error Register = $'
UNRECOVER_ERR DB 'Uncorrectable data error. Error Register = $'
READ_ID_ERROR DB 'Error setting up to read Drive ID',CR,LF,$'
SEC_NOT_FOUND DB 'Sector not found. Error Register = $'
INVALID_CMD DB 'Invalid Command. Error Register = $'
TRKO_ERR DB 'Track Zero not found. Error Register = $'
UNKNOWN_ERROR1 DB 'Unknown Error. Error Register = $'
CONTINUE_MSG DB CR,LF,'To Abort enter ESC. Any other key to continue. $'
FORMAT_MSG_A DB 'Fill disk sectors of Disk [A] with 0E5H$'
FORMAT_MSG_B DB 'Fill disk sectors of Disk [B] with 0E5H$'
ATHOME_MSG DB CR,LF,BELL,'Already on Track 0, Sector 0$'
AT_START_MSG DB CR,LF,BELL,'Already at start of disk!$'
AT_END_MSG DB CR,LF,BELL,'At end of Disk!$'
FILL_MSG DB CR,LF,'Sector buffer area cleared to 0000...$'
READN_MSG DB CR,LF,'Read multiple sectors from current disk/CF card to RAM buffer.'
DB CR,LF,'How many 512 byte sectores (xx HEX):$'
WRITEN_MSG DB CR,LF,'Write multiple sectors RAM buffer CURRENT disk/CF card.'
DB CR,LF,'How many 512 byte sectores (xx HEX):$'
READN_S_MSG DB CR,LF,'Read Sector to RAM buffer. $'
WRITEN_S_MSG DB CR,LF,'Write Sector from RAM buffer. $'

DiskCopyMsg DB CR,LF,'Copy CPM Partition on Drive A to Drive B (Y/N)? $'
DiskVerifyMsg DB CR,LF,'Will verify CPM Partition on Drive A to Drive B.$'
CopyDone DB CR,LF,'Disk Copy Done.$'
VERIFY_ERR DB CR,LF,BELL,'Verify Error. $'
VerifyDone DB CR,LF,'Disk Verify Done.$'
CR_To_Continue DB CR,LF,'Hit any key to continue.$'
OK_CR_MSG DB ' OK',CR,LF,$'
COPY_ERR DB CR,LF,BELL,'Sector Copy Error.$'
CURRENT_MSG_A DB ' <<<<< Current Drive = [A] >>>>>',CR,LF,LF,$'
CURRENT_MSG_B DB ' <<<<< Current Drive = [B] >>>>>',CR,LF,LF,$'
FORMAT_ERR DB CR,LF,BELL,'Sector Format Error$'
ERR_MSG DB CR,LF,BELL,'Invalid Command (or code not yet done)',CR,LF,$'

IBM_SIGNON_MSG DB CR,LF,LF,'IBM PC BIOS Initalizing$'
IBM_MENU1 DB CR,LF,LF,'IBM-PC BIOS Test Menu. (Debug Flag = $'
IBM_MENU_ON DB 'ON)',CR,LF,$'
IBM_MENU_OFF DB 'OFF)',CR,LF,$'
IBM_MENU2 DB 'A=Timer Test B=Propeller/LAVA/VGA C=MS-DOS Boot (Floppy)',CR,LF
DB 'D=Toggle Debug Flag E=Key Press Test F=Consol Out Test',CR,LF
DB 'G=Keyboard Buffer Test H=INT 10H CMDs I=Print Screen Test',CR,LF
DB 'J=RAM Byte READ Test K=RAM Word READ Test L=RAM Byte WRITE Test',CR,LF
DB 'M=RAM Word WRITE Test O=Out to Serial Port P=MS-DOS Boot (HDISK)',CR,LF
DB 'Q=CHS Hex Display Test S=5" Floppy Sec RD Test T=3" Floppy Sec RD Test',CR,LF
DB 'U=HDisk Sec RD Test W=HDisk Sector R/W Test Y=Floppy Boot Sec Info',CR,LF
DB 'Z=Hard Disk MBR Info (ESC) Back to Main Menu',CR,LF,LF,'>$'

NMI_MSG DB CR,LF,BELL,'Recieved an NMI Interrupt.',CR,LF,$'
ZFDC_FAIL_MSG DB CR,LF,BELL,'ZFDC Board failed to initalize',CR,LF,$'
ZFDC_OK_MSG DB CR,LF,'ZFDC Board Initalize OK',CR,LF,$'
PIC_INIT_MSG DB CR,LF,'Initalizing 8259A PIC (Port 20H, Ints 0 & 1 only)$'
RESET_FAIL_MSG DB CR,LF,BELL,'Reset of floppy drive failed.',CR,LF,$'
HRESET_FAIL_MSG DB CR,LF,BELL,'Reset of Hard Disk drive failed.',CR,LF,$'
BOOT_FAIL_MSG DB CR,LF,BELL,'Boot sector read on floppy drive failed.',CR,LF,$'

```

```

BOOT_OK_MSG      DB      CR,LF,'Boot Sector Loader Signature Valid (AA55H).',CR,LF,'Now Booting MS-DOS.....',CR,LF,LF,'$'
READ_ERR_MSG     DB      CR,LF,BELL,'Floppy Sector Read Error. Error returned = $'
WRITE_ERR_MSG    DB      CR,LF,BELL,'Floppy Sector Write Error. Error returned = $'
HREAD_ERR_MSG    DB      CR,LF,BELL,'HDisk Multi-Sector Read Error.$'
HWRITE_ERR_MSG   DB      CR,LF,BELL,'HDisk Multi-Sector Write Error.$'
HOME_ERR_MSG     DB      CR,LF,BELL,'Disk reset error.',CR,LF,'$'
NO_BASIC_MSG     DB      CR,LF,BELL,'BASIC Handler error.',CR,LF,'$'
NO_BREAK_MSG     DB      CR,LF,BELL,'Keyboard Break Handler error.',CR,LF,'$'
NO_COMM_MSG      DB      CR,LF,BELL,'Serial Communications Handler error.',CR,LF,'$'
CASSETTE_MSG     DB      CR,LF,BELL,'Cassette Handler error. AH=$'
FBOOT_DOS_MSG    DB      CR,LF,'Booting MS-DOS from 5" Floppy Disk$'
HBOOT_DOS_MSG    DB      CR,LF,'Booting MS-DOS from HARD Disk$'
KEY_TEST_MSG     DB      CR,LF,'Software Interrupt driven Keyboard Input test (ESC to Abort)',CR,LF,'$'
IN_CHAR_MSG      DB      CR,LF,'Type one character',CR,LF,'$'
GOT_CHAR_MSG     DB      'H <--- Hex value of character recieved via software Int 16H.',CR,LF,'$'
CO_TEST_MSG      DB      CR,LF,'Software Interrupt driven Console/Video out test',CR,LF,'$'
OUT_CHAR_MSG     DB      '<--- Character Recieved$'
TIMER_TEST_MSG   DB      CR,LF,'8259A Interrupt driven Timer Test$'
TIMER_DATA_MSG   DB      CR,LF,'Enter any key to read timer data. (ESC to Abort)$'
TIMER_LOW_MSG    DB      CR,LF,'Timer Low Value = $'
TIMER_HIGH_MSG   DB      'H',CR,LF,'Timer High Value = $'
TIMER_OFLOW_MSG  DB      'H',CR,LF,'Timer Overflow Value = $'
BUFF_TEST_MSG    DB      CR,LF,'Type keyboard characters as fast as you can!',CR,LF,'$'
SQRDHFAILMSG     DB      CR,LF,BELL,'Error reading sectors from HARD disk',CR,LF,'$'
SQRD5FAILMSG     DB      CR,LF,BELL,'Error reading sectors from 5" Floppy',CR,LF,'$'
SQRD3FAILMSG     DB      CR,LF,BELL,'Error reading sectors from 3" Floppy',CR,LF,'$'
SQRDHOKMSG       DB      CR,LF,'Read sectors from HARD disk OK!',CR,LF,'$'
SQRD5OKMSG       DB      CR,LF,'Read sectors from 5" 360K Floppy disk OK!$'
SQRD3OKMSG       DB      CR,LF,'Read sectors from 3" 1.44M Floppy disk OK!',CR,LF,'$'
DEBUG_SET_MSG    DB      CR,LF,'Set Debug level (0 = OFF, 1 = INTs only, 2 = +HDisk Info, 3 = +Floppy Info) $'
DUMP_ON1_MSG     DB      CR,LF,'Debug flag ON (Level 1)',CR,LF,'$'
DUMP_ON2_MSG     DB      CR,LF,'Debug flag ON (Level 2)',CR,LF,'$'
DUMP_ON3_MSG     DB      CR,LF,'Debug flag ON (Level 3)',CR,LF,'$'
DUMP_OFF_MSG     DB      CR,LF,'Debug flag OFF',CR,LF,'$'
SEC_5RD_MSG      DB      CR,LF,'Sequentially read sectors from 5" Floppy disk',CR,LF,'$'
SEC_3RD_MSG      DB      CR,LF,'Sequentially read sectors from 3" Floppy disk',CR,LF,'$'
SEC_HDRD_MSG     DB      CR,LF,'Read sector from HARD Disk test using Int 13H',CR,LF,'$'
NOT_DONE_MSG     DB      CR,LF,BELL,'Code Not done yet',CR,LF,'$'
INVALID_AH_FMSG  DB      CR,LF,BELL,'Invalid AH paramater in Floppy Handler. AH=$'
INVALID_AH_HMSG  DB      CR,LF,BELL,'Invalid AH paramater in HDisk Handler. AH=$'
SIO_TEST_MSG     DB      CR,LF,'Serial Port (A3H) Test.'
SIO_TEST_MSG     DB      CR,LF,'Enter any text. (ESC to stop).',CR,LF,'>','$'
SIO_INIT_ERR     DB      CR,LF,'Serial Port Initalization Error. AH=$'
SIO_ERR          DB      CR,LF,'Error sending character to Serial Port. AH=$'
INT_13F_MSG      DB      CR,LF,'Int 13H (Floppy)$'
INT_40F_MSG      DB      CR,LF,'Int 40H (<--Floppy)$'
INT_13H_MSG      DB      CR,LF,'Int 13H (*HDisk*)$'

INT_AX_MSG       DB      CR,LF,'AX=$'
INT_BX_MSG       DB      'H BX=$'
INT_CX_MSG       DB      'H CX=$'
INT_DX_MSG       DB      'H DX=$'
INT_SI_MSG       DB      'H',CR,LF,'SI=$'
INT_DI_MSG       DB      'H DI=$'
INT_BP_MSG       DB      'H BP=$'
INT_SP_MSG       DB      'H SP=$'

```

```

INT_CS_MSG      DB      CR,LF,'CS=$'
INT_DS_MSG      DB      'H DS=$'
INT_ES_MSG      DB      'H ES=$'
INT_SS_MSG      DB      'H SS=$'
INT_FS_MSG      DB      'H FS=$'
INT_GS_MSG      DB      'H GS=$'
IP_ADDRESS_MSG DB      'IP=$'

INT_1AH_MSG     DB      CR,LF,'Int 1AH (Time)$'
INT_10H_MSG     DB      CR,LF,'Int 10H (VIDEO)$'
INT_15H_MSG     DB      CR,LF,'Int 15H (Cassette)$'
SIDE_REQUEST_MSG DB     CR,LF,'Read from Side A or Side B (A/B) $'
SIDE_A_SET_MSG  DB     CR,LF,'Will read from Side A',CR,LF,'$'
SIDE_B_SET_MSG  DB     CR,LF,'Will read from Side B',CR,LF,'$'
FORMAT_ERR_MSG DB     CR,LF,'ZFDC Track Format error $'

CMOS_CLOCK_MSG DB     CR,LF,BELL,'CMOS RTC Error',CR,LF,'$'
CMOS_STUCK_MSG  DB     CR,LF,BELL,'CMOS RTC "Stuck" Error',CR,LF,'$'
CMOS_RANGE_MSG DB     CR,LF,BELL,'CMOS RTC Incorrect BCD values Error',CR,LF,'$'
SECTOR_NUM_MSG DB     CR,LF,'Starting requested Sector = $'
HRESET_OK_MSG  DB     CR,LF,'Reset of Hard Disk drive OK.',CR,LF,'$'
RD_ERR_MSG     DB     CR,LF,BELL,'Sector READ Error Returned.'
               DB     CR,LF,'Head = $'
TRACK_MSG      DB     'H Track = $'
SEC_MSG        DB     'H Sector = $'
WR_ERR_MSG     DB     CR,LF,BELL,'Sector WRITE Error Returned.'
               DB     CR,LF,'Head = $'
ESC_END_MSG    DB     CR,LF,'Press ESC to Abort. Any other key to continue $'
SEQAT500      DB     CR,LF,LF,'Sector(s) loaded @ 0000:500H.'
               DB     CR,LF,'Head = $'
CR_TAB_MSG     DB     CR,LF,'          $'
LBA_TEST_MSG   DB     CR,LF,'Test for LBA on IDE drive #2 (using LBA mode)$'
CHS_TEST_MSG   DB     CR,LF,'Test for CHS on IDE drive #2 (using non-LBA mode)$'

TRKL_NUM       DB     CR,LF,'Enter TRACK/Cylinder number (LOW byte, xxH) = $'
TRKH_NUM       DB     CR,LF,'Enter TRACK/Cylinder number (HIGH byte, xxH) = $'
HEAD_NUM       DB     CR,LF,'Enter HEAD number, (0-FH, 0xH) = $'
SECTOR_NUM     DB     CR,LF,'Enter SECTOR number (xxH) = $'
CHECK_DISPLAY_MSG DB   CR,LF,'Check the IDE Board HEX display.$'
BOOT_3RD_MSG   DB     CR,LF,'Display Floppy Boot Sector Information.',CR,LF,'$'
DRIVE_SELECT_MSG DB   CR,LF,'Please select floppy disk (A or B) $'
BOOT_INFO_FAIL_MSG DB  CR,LF,'Error reading Boot disk sector.$',CR,LF
BOOT_INFOOKMSG DB     CR,LF,'Floppy Boot Sector Information:-',CR,LF,LF,'$'

JMP_MSG        DB     ' Boot JMP Vector',CR,LF,'$'
NAME_MSG       DB     ' OEM Name',CR,LF,'$'
BYTES_MSG      DB     ' Bytes/Sec',CR,LF,'$'
CLUSTER_MSG    DB     ' Sec/Cluster',CR,LF,'$'
RES_MSG        DB     ' Reserved Sectors',CR,LF,'$'
FATS_MSG       DB     ' FATS',CR,LF,'$'
ROOT_MSG       DB     ' Root Dir Entries',CR,LF,'$'
SECTORS_MSG    DB     ' Sectors',CR,LF,'$'
MEDIA_MSG      DB     ' Media Byte',CR,LF,'$'
FAT_SEC_MSG    DB     ' FAT Sectors',CR,LF,'$'
SEC_TRK_MSG    DB     ' Sectors/Track',CR,LF,'$'
HEADS_MSG      DB     ' Heads',CR,LF,'$'

```

```

HIDDEN_MSG      DB      '   Hidden Sectors',CR,LF,'$'
HUGE_MSG        DB      '   Huge Sectors',CR,LF,'$'
DRIVE_NO_MSG    DB      '       Drive #',CR,LF,'$'
RESERVED_MSG    DB      '       Reserved',CR,LF,'$'
BOOT_SIG_MSG    DB      '       Boot Signature',CR,LF,'$'
VOL_ID_MSG      DB      '       Volume ID',CR,LF,'$'
VOLUME_MSG     DB      '       Volume Label',CR,LF,'$'
SYS_TYPE_MSG    DB      '   File Sys Type',CR,LF,LF,'$'
NO_MBL_MSG      DB      CR,LF,BELL,'Invalid Floppy Boot Loader Signature detected',CR,LF,'$'
BOOT_MBR_MSG    DB      CR,LF,'Reading Hard Disk MBR sector, (C=0, H=0, S=1)',CR,LF,'$'
BOOT_MBR_FAIL_MSG DB    CR,LF,BELL,'Error reading Hard Disk MBR sector',CR,LF,'0'
MBR_INFOOKMSG   DB      'Hard Disk Master Boot Record:',CR,LF,'$'

DISK_SIG_MSG    DB      '   Hard Disk Signature',CR,LF,'$'
NULS_MSG        DB      '       Usually Nulls (Optional)',CR,LF,LF,'$'
PT1_MSG         DB      '   First Partition Table',CR,LF,'$'
PT2_MSG         DB      '   Second Partition Table',CR,LF,'$'
PT3_MSG         DB      '   Third Partition Table',CR,LF,'$'
PT4_MSG         DB      '   Forth Partition Table',CR,LF,'$'
SIGNATURE_MSG   DB      '       LBR Signature Word',CR,LF,'$'
STATUS_MSG      DB      '   Status Byte, $'
STLBA_MSG       DB      '   Start CHS Address, $'
PAR_TYPE_MSG    DB      '   Partition Type, $'
ECHS_MSG        DB      '   End CHS Address',CR,LF,'$'
SLB_MSG         DB      '   Start LBA Address, $'
ELBA_MSG        DB      '   End LBA Address',CR,LF,LF,'$'
CYL_MSG         DB      'H Cyl=$'
HD_MSG          DB      '   Head=$'
BRAC1_MSG       DB      'H ($'
OF_MSG          DB      'H of $'
BRAC2_MSG       DB      'H)',CR,LF,'$'
DRIVE1_MSG      DB      '   on Drive A',CR,LF,'$'
DRIVE2_MSG      DB      '   on Drive B',CR,LF,'$'
HRW_TEST_MSG    DB      CR,LF,'Hard Disk Sector R/W test using INT 13H',CR,LF
DB              CR,LF,'>>> WARNING <<< Data on Disk will be overwritten. Continue...(Y/N) $'
ONE_MOMENT_MSG  DB      CR,LF,'One moment while IDE Drive is being initalized',CR,LF,'$'
ASK_WR_MSG      DB      CR,LF,'Write data back to Hard Disk...(Y/N)$'
START_DATA_MSG  DB      'H Start of Data =',CR,LF,'$'
SEC_READ_OK     DB      CR,LF,'Sector(s) read OK',CR,LF,'$'
SEC_BACK_OK     DB      CR,LF,'Sector(s) written back OK',CR,LF,'$'
LOOP_ESC_MSG    DB      CR,LF,'Will R/W sectors until ESC is entered. CR to start',CR,LF,'$'

VIDIO_TEST_MSG  DB      CR,LF,'Int 10H tests for control of Video Board I/O',CR,LF
DB              CR,LF,'Enter value of [AX], (xxxxH) $'
ENTER_BX_MSG    DB      CR,LF,'Enter value of [BX], (xxxxH) $'
ENTER_CX_MSG    DB      CR,LF,'Enter value of [CX], (xxxxH) $'
ENTER_DX_MSG    DB      CR,LF,'Enter value of [DX], (xxxxH) $'
ACTIVATE_INT_MSG DB    CR,LF,'Enter CR to implement the INT 10H interrupt, (ESC to Abort) $'

VID_PARM_TBD_MSG DB    CR,LF,'Int 10H Video paramater not yet implemented'
DB              CR,LF,'      ','$'
VID_PARM_TBD1_MSG DB    CR,LF,'Int 10H Video paramater not fully completed'
DB              CR,LF,'      ','$'
VID_PARM_MSG     DB      CR,LF,'Invalid Int 10H Video paramater',CR,LF,'$'
VIDIO_OUTPUT_MSG DB    CR,LF,'   Set MSDOS (INT 10H) Console Output Menu'
DB              CR,LF,'   0 = MSDOS output will be to Propeller Board.'

```

```

DB      CR,LF,' 1 = MSDOS Output will be to CGA/VGA Board.'
DB      CR,LF,' 2 = MSDOS Output will be to LAVA Board.'
DB      CR,LF,'Please enter selection. (ESC to abort):$'
VIDIO_LAVA_MSG DB      CR,LF,'MSDOS output will be to LAVA Board',CR,LF,'$'
VIDIO_PROP_SMSG DB      CR,LF,'MSDOS output will be to Propeller Board',CR,LF,'$'
VIDIO_VGA_MSG DB      CR,LF,'MSDOS output will be to CGA/VGA Board',CR,LF,'$'
VIDIO_PROP_MSG DB      'MSDOS output will be to Propeller Board$'
VIDIO_VGA_SMSG DB      'MSDOS output will be to CGA/VGA Board$'
VIDIO_LAVA_SMSG DB      'MSDOS output will be to LAVA Board$'
INT10_ERR_MSG DB      CR,LF,'Sorry invalid selection. Must be 0,1, or 2 $'
PSCR_TEST_MSG DB      CR,LF,'Will Print (CGA/VGA) screen on Printer',CR,LF,'$'

PSCR_TEST_LEN EQU      $-PSCR_TEST_MSG-3
PRN_INIT_STR  DB      0H                                ;<--- I cannot get the PCL-6 Codes below to work with my printer
;            DB      1BH,'E'                            ;PCL-6 reset
;            DB      1BH,'%12345X',0                    ;Universal Exit
;            DB      1BH,'&','l',01H,'O',0              ;Landscape Orientation (Cannot seem to get these to work)

TIME_ERROR_MSG DB      CR,LF,'RTC Error',CR,LF,0
Time_Msg      DB      'Time=',0
GAP_Msg       DB      ' ',0
Date_Msg      DB      'Date=',0
SET_TIME_MSG  DB      'Do you wish to set the time and date (Y/N): $'
Input_Hours_Msg DB      CR,LF,'Please Enter Hours (2 digits, 00-24) ',0
Input_Minutes_Msg DB CR,LF,'Please Enter Minutes (2 digits, 00-60) ',0
Input_Seconds_Msg DB CR,LF,'Please Enter Seconds (2 digits, 00-60) ',0
Input_Year_Msg DB      CR,LF,'Please Enter Year (2 digits, 20xx) 20',0
Input_Month_Msg DB      CR,LF,'Please Enter Month (2 digits, 00-12) ',0
Input_Day_Msg DB      CR,LF,'Please Enter day (2 digits, 01-31) ',0

ROMCHECK_MSG  DB      CR,LF,'Initilizing VGA ROM at C000:0000H',0
ROMCHECK_MSG_OK DB      CR,LF,'VGA ROM Initilized, returned back to BIOS.',CR,LF,0
NO_VGA_MSG    DB      CR,LF,'No VGA ROM at C000:0000H',0
UNASSIGNED_1_INT_MSG DB CR,LF,'Un-assigned Vector Interrupt # $'
VGA_OK_MSG    DB      CR,LF,'Int 15H VGA Initilization Done',CR,LF,0
NO_8259A_MSG  DB      CR,LF,BELL,'8259A PIC Not found. (MS-DOS will not be bootable)',BELL,CR,LF,0
BYTE_RTEST_MSG DB      CR,LF,'Location for RAM byte read test: ',0
WORD_RTEST_MSG DB      CR,LF,'Location for RAM word read test: ',0
BYTE_WTEST_MSG DB      CR,LF,'Location for RAM byte write test: ',0
WORD_WTEST_MSG DB      CR,LF,'Location for RAM word write test: ',0

;*****
; CHARACTER GENERATOR GRAPHICS FOR 320X200 AND 640X200 GRAPHICS
;*****

CRT_CHAR_GEN:

    %if      CPU_80286                                ;<<<< NOTE I HAVE REMOVED THIS CODE FOR 8088/8086 Boards,
    ;      NOT ENOUGH WITH 28C256 EEPROMS. Not normally used anyway.

    %if      MONITOR_ROM
    TIMES 0FAE6H-($-$$) DB 0                          ;Locate exactly where IBM has it
    %endif

    DB      000H,000H,000H,000H,000H,000H,000H,000H ;
    DB      07EH,081H,0A5H,081H,0BDH,099H,081H,07EH ;

```

```

DB      07EH,0FFH,0DBH,0FFH,0C3H,0E7H,0FFH,07EH      ;
DB      06CH,0FEH,0FEH,0FEH,07CH,038H,010H,000H      ;
DB      010H,038H,07CH,0FEH,07CH,038H,010H,000H      ;
DB      038H,07CH,038H,0FEH,0FEH,07CH,038H,07CH      ;
DB      010H,010H,038H,07CH,0FEH,07CH,038H,07CH      ;
DB      000H,000H,018H,03CH,03CH,018H,000H,000H      ;
DB      0FFH,0FFH,0E7H,0C3H,0C3H,0E7H,0FFH,0FFH      ;
DB      000H,03CH,066H,042H,042H,066H,03CH,000H      ;
DB      0FFH,0C3H,099H,0BDH,0BDH,099H,0C3H,0FFH      ;
DB      00FH,007H,00FH,07DH,0CCH,0CCH,0CCH,078H      ;
DB      03CH,066H,066H,066H,03CH,018H,07EH,018H      ;
DB      03FH,033H,03FH,030H,030H,070H,0F0H,0E0H      ;
DB      07FH,063H,07FH,063H,063H,067H,0E6H,0C0H      ;
DB      099H,05AH,03CH,0E7H,0E7H,03CH,05AH,099H      ;
DB      080H,0E0H,0F8H,0FEH,0F8H,0E0H,080H,000H      ;
DB      002H,00EH,03EH,0FEH,03EH,00EH,002H,000H      ;
DB      018H,03CH,07EH,018H,018H,07EH,03CH,018H      ;
DB      066H,066H,066H,066H,066H,000H,066H,000H      ;
DB      07FH,0DBH,0DBH,07BH,01BH,01BH,01BH,000H      ;
DB      03EH,063H,038H,06CH,06CH,038H,0CCH,078H      ;
DB      000H,000H,000H,000H,07EH,07EH,07EH,000H      ;
DB      018H,03CH,07EH,018H,07EH,03CH,018H,0FFH      ;
DB      018H,03CH,07EH,018H,018H,018H,018H,000H      ;
DB      018H,018H,018H,018H,07EH,03CH,018H,000H      ;
DB      000H,018H,00CH,0FEH,00CH,018H,000H,000H      ;
DB      000H,030H,060H,0FEH,060H,030H,000H,000H      ;
DB      000H,000H,0C0H,0C0H,0C0H,0FEH,000H,000H      ;
DB      000H,024H,066H,0FFH,066H,024H,000H,000H      ;
DB      000H,018H,03CH,07EH,0FFH,0FFH,000H,000H      ;
DB      000H,0FFH,0FFH,07EH,03CH,018H,000H,000H      ;
DB      000H,000H,000H,000H,000H,000H,000H,000H      ;
DB      030H,078H,078H,030H,030H,000H,030H,000H      ;
DB      06CH,06CH,06CH,000H,000H,000H,000H,000H      ;
DB      06CH,06CH,0FEH,06CH,0FEH,06CH,06CH,000H      ;
DB      030H,07CH,0C0H,078H,00CH,0F8H,030H,000H      ;
DB      000H,0C6H,0CCH,018H,030H,066H,0C6H,000H      ;
DB      038H,06CH,038H,076H,0DCH,0CCH,076H,000H      ;
DB      060H,060H,0C0H,000H,000H,000H,000H,000H      ;
DB      018H,030H,060H,060H,060H,030H,018H,000H      ;
DB      060H,030H,018H,018H,018H,030H,060H,000H      ;
DB      000H,066H,03CH,0FFH,03CH,066H,000H,000H      ;
DB      000H,030H,030H,0FCH,030H,030H,000H,000H      ;
DB      000H,000H,000H,000H,000H,030H,030H,060H      ;
DB      000H,000H,000H,0FCH,000H,000H,000H,000H      ;
DB      000H,000H,000H,000H,000H,030H,030H,000H      ;
DB      006H,00CH,018H,030H,060H,0C0H,080H,000H      ;

DB      07CH,0C6H,0CEH,0DEH,0F6H,0E6H,07CH,000H      ;0
DB      030H,070H,030H,030H,030H,030H,0FCH,000H      ;1
DB      078H,0CCH,00CH,038H,060H,0CCH,0FCH,000H      ;2
DB      078H,0CCH,00CH,038H,00CH,0CCH,078H,000H      ;3
DB      01CH,03CH,06CH,0CCH,0FEH,00CH,01EH,000H      ;4
DB      0FCH,0C0H,0F8H,00CH,00CH,0CCH,078H,000H      ;5
DB      038H,060H,0C0H,0F8H,0CCH,0CCH,078H,000H      ;6
DB      0FCH,0CCH,00CH,018H,030H,030H,030H,000H      ;7
DB      078H,0CCH,0CCH,078H,0CCH,0CCH,078H,000H      ;8

```

```

DB      078H,0CCH,0CCH,07CH,00CH,018H,070H,000H      ;9
DB      000H,030H,030H,000H,000H,030H,030H,000H      ;
DB      000H,030H,030H,000H,000H,030H,030H,060H      ;
DB      018H,030H,060H,0C0H,060H,030H,018H,000H      ;
DB      000H,000H,0FCH,000H,000H,0FCH,000H,000H      ;
DB      060H,030H,018H,00CH,018H,030H,060H,000H      ;
DB      078H,0CCH,00CH,018H,030H,000H,030H,000H      ;
DB      07CH,0C6H,0DEH,0DEH,0DEH,0C0H,078H,000H      ;
DB      030H,078H,0CCH,0CCH,0FCH,0CCH,0CCH,000H      ;
DB      0FCH,066H,066H,07CH,066H,066H,0FCH,000H      ;
DB      03CH,066H,0C0H,0C0H,0C0H,066H,03CH,000H      ;
DB      0F8H,06CH,066H,066H,066H,06CH,0F8H,000H      ;
DB      0FEH,062H,068H,078H,068H,062H,0FEH,000H      ;
DB      0FEH,062H,068H,078H,068H,060H,0F0H,000H      ;
DB      03CH,066H,0C0H,0C0H,0CEH,066H,03EH,000H      ;
DB      0CCH,0CCH,0CCH,0FCH,0CCH,0CCH,0CCH,000H      ;
DB      078H,030H,030H,030H,030H,030H,078H,000H      ;
DB      01EH,00CH,00CH,00CH,0CCH,0CCH,078H,000H      ;
DB      0E6H,066H,06CH,078H,06CH,066H,0E6H,000H      ;
DB      0F0H,060H,060H,060H,062H,066H,0FEH,000H      ;
DB      0C6H,0EEH,0FEH,0FEH,0D6H,0C6H,0C6H,000H      ;
DB      0C6H,0E6H,0F6H,0DEH,0CEH,0C6H,0C6H,000H      ;
DB      038H,06CH,0C6H,0C6H,0C6H,06CH,038H,000H      ;
DB      0FCH,066H,066H,07CH,060H,060H,0F0H,000H      ;
DB      078H,0CCH,0CCH,0CCH,0DCH,078H,01CH,000H      ;
DB      0FCH,066H,066H,07CH,06CH,066H,0E6H,000H      ;
DB      078H,0CCH,0E0H,070H,01CH,0CCH,078H,000H      ;
DB      0FCH,0B4H,030H,030H,030H,030H,078H,000H      ;
DB      0CCH,0CCH,0CCH,0CCH,0CCH,0CCH,0FCH,000H      ;
DB      0CCH,0CCH,0CCH,0CCH,0CCH,078H,030H,000H      ;
DB      0C6H,0C6H,0C6H,0D6H,0FEH,0EEH,0C6H,000H      ;
DB      0C6H,0C6H,06CH,038H,038H,06CH,0C6H,000H      ;
DB      0CCH,0CCH,0CCH,078H,030H,030H,078H,000H      ;
DB      0FEH,0C6H,08CH,018H,032H,066H,0FEH,000H      ;
DB      078H,060H,060H,060H,060H,060H,078H,000H      ;
DB      0C0H,060H,030H,018H,00CH,006H,002H,000H      ;
DB      078H,018H,018H,018H,018H,018H,078H,000H      ;
DB      010H,038H,06CH,0C6H,000H,000H,000H,000H      ;
DB      000H,000H,000H,000H,000H,000H,000H,0FFH      ;

DB      030H,030H,018H,000H,000H,000H,000H,000H      ;
DB      000H,000H,078H,00CH,07CH,0CCH,076H,000H      ;
DB      0E0H,060H,060H,07CH,066H,066H,0DCH,000H      ;
DB      000H,000H,078H,0CCH,0C0H,0CCH,078H,000H      ;
DB      01CH,00CH,00CH,07CH,0CCH,0CCH,076H,000H      ;
DB      000H,000H,078H,0CCH,0FCH,0C0H,078H,000H      ;
DB      038H,06CH,060H,0F0H,060H,060H,0F0H,000H      ;
DB      000H,000H,076H,0CCH,0CCH,07CH,00CH,0F8H      ;
DB      0E0H,060H,06CH,076H,066H,066H,0E6H,000H      ;
DB      030H,000H,070H,030H,030H,030H,078H,000H      ;
DB      00CH,000H,00CH,00CH,00CH,0CCH,0CCH,078H      ;
DB      0E0H,060H,066H,06CH,078H,06CH,0E6H,000H      ;
DB      070H,030H,030H,030H,030H,030H,078H,000H      ;
DB      000H,000H,0CCH,0FEH,0FEH,0D6H,0C6H,000H      ;
DB      000H,000H,0F8H,0CCH,0CCH,0CCH,0CCH,000H      ;
DB      000H,000H,078H,0CCH,0CCH,0CCH,078H,000H      ;

```

```

DB      000H,000H,0DCH,066H,066H,07CH,060H,0F0H      ;
DB      000H,000H,076H,0CCH,0CCH,07CH,00CH,01EH      ;
DB      000H,000H,0DCH,076H,066H,060H,0F0H,000H      ;
DB      000H,000H,07CH,0C0H,078H,00CH,0F8H,000H      ;
DB      010H,030H,07CH,030H,030H,034H,018H,000H      ;
DB      000H,000H,0CCH,0CCH,0CCH,0CCH,076H,000H      ;
DB      000H,000H,0CCH,0CCH,0CCH,078H,030H,000H      ;
DB      000H,000H,0C6H,0D6H,0FEH,0FEH,06CH,000H      ;
DB      000H,000H,0C6H,06CH,038H,06CH,0C6H,000H      ;
DB      000H,000H,0CCH,0CCH,0CCH,07CH,00CH,0F8H      ;
DB      000H,000H,0FCH,098H,030H,064H,0FCH,000H      ;
DB      01CH,030H,030H,0E0H,030H,030H,01CH,000H      ;
DB      018H,018H,018H,000H,018H,018H,018H,000H      ;
DB      0E0H,030H,030H,01CH,030H,030H,0E0H,000H      ;
DB      076H,0DCH,000H,000H,000H,000H,000H,000H      ;
DB      000H,010H,038H,06CH,0C6H,0C6H,0FEH,000H      ;

```

```
%endif
```

```
DIAG_TEST:
```

```

IN      AL,IOBYTE      ;Start at Reset location, few bytes available to FFFFFH
CMP     AL,03FH        ;If 3F then diagnostic, '?' continously of CRT
JZ      XLOOP
JMP     INIT           ;(Start of this monitor)

```

```
XLOOP: NOP              ;For hardware address lines debug viewing
```

```

XOR     BX,BX
MOV     DS,BX          ;Read even & odd byte from RAM

```

```

MOV     AL,[BX]
MOV     AL,[BX+1]
MOV     AX,word [BX]
MOV     AX,word [BX+1]

```

```

IN      AL,IOBYTE      ;see if we need a different character to output (checks I/O)
OUT     01H,AL
CMP     AL,01FH        ;If 1F within this loop then go to RAM at 500H
JNZ     XLOOP
JMP     word 0H:500H    ;Jump to here in low RAM

```

```
DB      '<--- END OF 8086/8088 Monitor V10.33 (John Monahan, 7/26/2014) '
```

```

%if     MONITOR_ROM
TIMES 0FFF0H-($-$$) DB 0

```

```
JMP     word 0F000H:DIAG_TEST ;Not clear why but need long jump for board hardware
```

```

TIMES 0FFFEH-($-$$) DB 0
DB      0FCH           ;"Model Number" IBM PC/AT (At FFFEh)
DB      0H             ;Skip Checksum

```

```
%endif
```

```
;----- LOW RAM VARIABLES (Used mainly by PC-BIOS section) -----
```



```

        absolute      2H*4
NMIint:      resw     2          ;Non-maskable interrupt location (8H)

        absolute      5H*4
PrintScreen: resw     2          ;Print Screen function

        absolute      8H*4
Start8259A_Ints resw     2          ;Location for our hardware interrupts (20H, Same as IBM-PC hardware)
;      8   Timer Tic          TIMER          \
;      9   Keypressed        KEYHND          \
;      A   Reserved          DUMMY_RETURN   \
;      B   Comm Hardware     DUMMY_RETURN   \Normal location for
;      C   Comm Hardware     DUMMY_RETURN   /IBM hardware interrupts
;      D   Disk Hardware     DUMMY_RETURN   /
;      E   Diskette Hardware DUMMY_RETURN   /
;      F   Printer Hardware  DUMMY_RETURN   /

        absolute      10H*4
CRTINT      resw     2          ;Software interrupt used in this BIOS (and IBM-PC/AT)

        absolute      13H*4
MAIN_DISK_VEC resw     2          ;Disk (Hard & Floppy) software interrupt
        absolute      (13H*4)+2
MAIN_DISK_SEG resw     2          ;Disk software interrupt segment (Normally this CS)

        absolute      1DH*4
VID_PARM_PTR resw     2          ;Pointer to CGA Video Board paramaters table
        absolute      (1DH*4)+2
VID_PARM_PTR_SEG resw  2          ;Video Board Table segment (0 here)

        absolute      1EH*4
FDISK_PARMS resw     2          ;Pointer to Floppy Disk paramaters table
        absolute      (1EH*4)+2
FDISK_PARMS_SEG resw  2          ;On MSDOS Boot, this points to the boot Floppy Disk Variables Table
;                               ;Disk Variables Table segment (Normally this CS)

        absolute      1FH*4
EXT_CHAR_PTR resw     2          ;7CH, For Graphics mode extra characters pointers
        absolute      (1FH*4)+2
EXT_CHAR_PTR_SEG resw  2          ;For Graphics mode extra characters pointers segment (Normally this CS)

        absolute      40H*4
OLD_DISK_VEC resw     2          ;Pointer to the original PC Floppy Disk Int Vector (relocated because of HDISK)
        absolute      (40H*4)+2
OLD_DISK_SEG  resw     2          ;New Floppy Disk software interrupt segment (Normally this CS)

        absolute      41H*4
HDISK_PARMS  resw     2          ;Pointer to HARD DISK #1 paramater table
        absolute      (41H*4)+2
HDISK_PARMS_SEG resw  2          ;HARD DISK paramater table segment (Normally this CS)

        absolute      43H*4
EXT_CHAR_PTR2 resw     2          ;10CH, Pointer to Graphics Character set
        absolute      (43H*4)+2

```

```

EXT_CHAR_PTR2_SEG  resw      2          ;Pointer to Graphics Character Set Segment

        absolute      46H*4
HDISK2_PARMS      resw      2          ;Pointer to HARD DISK #2 paramater table
        absolute      (46H*4)+2
HDISK2_PARMS_SEG  resw      2          ;HARD DISK paramater table segment (Normally this CS)

        absolute      400H          ;Low RAM data area (set the same as for IBM-PC BIOS)

RS232_BASE        resw      4          ;Addresses for RS232 Adaptors (if any)
PRINTER_BASE      resw      4          ;Address of Printers (if any)

EQFLAG           resw      1          ;410H, equipment flag (two bytes)
MFG_TST          resb      1          ;412H, MFG initilization flag (not used)
memrsz           resw      1          ;413H, memory size (kilobytes)
expram           resw      1          ;415H, expansion ram size

KB_FLAG          resb      1          ;417H (Insert, shift etc. flags)
KB_FLAG_1        resb      1          ;418H, Second byte of keyboard status
chrCnt           resb      1          ;419H, characters in buffer (Alt_Keypad on PC)

bufhd            resw      1          ;keyboard buffer head (40:1AH)
buftl            resw      1          ;keyboard buffer tail (40:1CH)
keybuff          resw      16         ;keyboard data buffer (40:1EH)
kband           resw      1          ;end of buffer
chrmax           equ      32          ;buffer length
                ; \
                ; \
                ; Keyboard buffer area
                ; /
                ; /

        absolute      43EH

SEEK_STATUS       resb      1          ;Seek status (40:3EH)
CURRENT_HEAD      resb      1          ;On IBM PC, motor status (40:3FH)
CURRENT_DRIVE     resb      1          ;On IBM PC, motor count (40:40H)

IBM_DISK_STATUS   resb      1          ;Returned disk status (40:41H)
                ;
DMA_OFFSET        resw      1          ;DMA offset address for controller (On PC this area is used by FDC)
DMA_SEGMENT       resw      1          ;DMA segmant address for controller
CURRENT_SECTOR    resb      1
CURRENT_TRACK     resb      1
CURRENT_TRACK_HIGH resb      1

        absolute      449H          ;Video board paramaters

CRT_MODE          resb      1          ;449H, Video Display Mode
                ; 0 = 40 x 25 text (no color)
                ; 1 = 40 x 25 text (16 color)
                ; 2 = 80 x 25 text (no color)
                ; 3 = 80 x 25 text (16 color)

```

```

; 4 = 320 x 200 graphics 4 color
; 5 = 320 x 200 graphics 0 color
; 6 = 640 x 200 graphics 0 color
; 7 = 80 x 25 text (mono card)

CRT_COLS      resw 1
CRT_LEN       resw 1
CRT_START     resw 1
CURSOR_POSN   resw 8      ;IBM has 8

CURSOR_MODE   resw 1      ;446H, Cursor shape
ACTIVE_PAGE   resb 1
ADDR_6845     resw 1
CRT_MODE_SET  resb 1
CRT_PALLETTE  resb 1

IO_ROM_INIT   resw 1      ;467H, Anchor location to implement extra ROMS
IO_ROM_SEG    resw 1      ;469H
INTR_FLAG     resb 1

timlow        resw 1      ;timer low count (40:6CH) for timer
timhi         resw 1      ;timer high count
timofl        resb 1      ;timer overflow flag

BIOS_BREAK    resb 1      ;Bit 7 = 1 if break key pressed (40:71H)
RESET_FLAG    resw 1      ;1234H if KB reset underway (40:72H)

;Additional data stores on IBM-AT
DISK_STATUS1  resb 1      ;474H, Status of last HDisk operation
HF_NUM        resb 1      ;475H, Number of hard disk drives
CONTROL_BYTE  resb 1
PORT_OFF      resb 1

PRINT_TIM_OUT resw 2      ;Printer & RS232 Time-out variables
RS232_TIM_OUT resw 2

BUFFER_START  resw 1      ;Additional Keyboard data area (on IBM-AT)
BUFFER_END    resw 1      ;482H & 483H

;484H-48AH, Video control data area 2
;484H, Number of video rows-1
;485H, Number of scan lines/char
;487H, Video adaptor options
;488H, Video display adaptor switches
;489H, VGA video flags 1
;48AH, VGA video flags 2

absolute     48BH        ;Disk (Floppy & HDisk) data control area
;48B-495H
LAST_RATE     resb 1      ;488H, Additional Floppy data
HF_STATUS     resb 1      ;48CH, Additional HDisk data area
HF_ERROR      resb 1
HF_INT_FLAG   resb 1
HF_CNTRL      resb 1
DSK_STATE     resw 2      ;490H, Additional Diskette Area (must be 0 for MS-DOS 4.01)

```

```

DSK_TRK      resb    3
KB_FLAG_2    resb    1      ;497H, Last keyboard LED/Shift key state (on AT)

;498H, RTC additional data area
USER_FLAG    resw    1      ; offset address of user wait flag
USER_FLAG_SEG resw    1      ; segment " "
RTC_LOW      resw    1      ; user RTC low word
RTC_HIGH     resw    1      ; user RTC high word
RTC_WAIT_FLAG resb    1      ;4A0H, user wait active

      absolute    4A1H      ;4A1H-4A7H Reserved for LAN bytes
      absolute    4A8H      ;4A8H-4ABH, Segment:Offset address of video parameter control block
      absolute    4ACH      ;Reserved
      absolute    4F0H      ;Inter-applications communications area. I will use it for this BIOS

CONSOLE_FLAG resw    1      ;0000 if MSDOS output to Propeller board, 0001 to LAVA board, 0002 to VGA Video board.
ZFDC_ERR_CODE resb    1      ;Error code returned by ZFDC controller in AH for error
DEBUG_FLAG   resb    1      ;If not Zero display track, side, sector etc info during disk R/W
ZFDC_INIT_FLAG resb    1      ;Flag to indicate ZFDC board has been initialised
SECTORS_TO_DO resb    1      ;Number of sectors to transfer in current operation
SECTORS_DONE resb    1      ;Number actually transferred
VERIFY_FLAG  resb    1      ;0 for normal sector reads, NZ, if just sector verifys required
ES_STORE     resw    1      ;Used for INT 10H, String write

      absolute    500H      ;To keep things the same as for the IBM_PC
STATUS_BYTE  resb    1      ;Flag for print screen routine
SINGLE_DRIVE  resb    1      ;

      absolute    510H      ;This area is used by BASIC. However MSDOS will not boot if used

      absolute    522H      ;To keep things the same as for the IBM_PC
DOS_INIT_AREA resb    16      ;IBMBIO.COM buffers the directory of the boot
;device here at load time when locating the guts
;of the operating system (IBMDOS.COM/MSDOS.SYS)

      absolute    530H      ;To keep things the same as for the IBM_PC
DOS_MODE_AREA resb    4
      absolute    534H      ;To keep things the same as for the IBM_PC
MORE_DOS     resb    12

      absolute    0B800H      ;IBM-PC Color Video Board RAM area

Video_Ram    resw    16384 *2 ;Video RAM area (IF, Lomas or other S100 PC Video board is used)
      absolute    7c00h      ;0000:7c00H

DOS_BOOT_LOC: resw    1      ;<---MS-DOS/FreeDOS BOOT LOCATION

      absolute    7c00h+510      ;0000:7dfeH

DOS_BOOT_SIGNATURE: resw    1 ;<---MS-DOS Valid Boot Signature Location (0AA55H)

```

```

;Remember there is a high RAM data area used (only) for the IDE Board
;diagnostic functions. These variables will normally be accessed as SS:[BP]
;This is used by the IDE drive diagnostic commands ONLY. We need an area
;to store buffers in RAM. In a full 1MG system they will at D000:E000H
;Remember also the stack is normally at D000:FFFCH

```

```

absolute      0E000H      ;For SS:BP -> D000:E000H

```

```

RAM_DRIVE_SEC  resw      1      ;This area will be in top of RAM well below stack (used by IDE Board sections)
RAM_DRIVE_TRK  resw      1
RAM_DRIVE_HEAD resw      1
RAM_DRIVE_COUNT resw     1      1
RAM_SEC        resw      1
RAM_TRK        resw      1
DELAYStore    resw      1
RAM_DMA        resw      1
RAM_DMA_STORE  resw      1
SECTOR_COUNT  resw      1
CURRENT_IDE_DRIVE resw    1
DISPLAY_FLAG   resw      1

```

```

absolute      0E100H      ;For SS:BP -> D000:E000H

```

```

IDE_Buffer     resb      200H    ;512 Byte buffer for IDE Sector R/W
IDE_Buffer2    resb      200H    ;512 Byte buffer for IDE Sector Verify

```

```

;End of 8086 Monitor

```