

```

; MASTER.Z80 This is the main monitor program for my system.
; It resided in 1 2732 PROM at F000H (or top half of 28C64)
; Assemble and SLR's Z80ASM Assembler (Can also use Cromemco's Assembler)
; Use:- Z80ASM MASTER FH
;
; Note the monitor is is two sections. The F000H-F7FFH is for typical display
; move memory type functions. The second portion starts at F800H and contains
; a series of CPM BIOS compatible jumps. For compatibility with some of my old
; CPM V1.4 software these locations should not be changed. You can easily build
; around them. The second section (after the above BIOS jumps section) contains
; CPM boot loader code and other more specialized stuff.
;
; To assemble under windows...
; Load Altair.EXE
; do cpm3
; I:
; Submit master
;
; Master.HEX is written back to the same windows folder as altair.exe is in.
;
; Programming an EEPROM for the Z80 Board with the VP-280 Programmer
; Using a MK28C28A EEPROM or uP28C64:-
; For monitor at F000H-FFFFH
; Load Buffer Address - 1000
; From File address F000H
; This will put the code (4K) in the top "half" of the 8K EEPROM. It can be seen/edited at 1000H
;
; Recent History...
;
; 26/2/09 Added ability to switch CO/CI to ACIA serial from PC.
; 5/3/09 Adjust RTS/CTS levels for Modem
; V3.5 6/3/09 Set talker messages for new V-Stamp chip.
; 12/09/09 Add SD Systems IO-8 board Serial ports.
; V3.52 16/9/09 Add SD Systems IO-8 Board clock display on signon
; v3.6 21/9/09 Add display command for greater than 64K RAM, removed
; V4.0 10/26/09 Switched in 8255 driven IDE HD Controller (Removed XComp)
; some old commands to make more room.
; V4.1 11/7/09 Added input ports scan/diagnostic
; V4.2 11/14/09 Remove Date (keep time) from Clock (Chip is messed up by CPM3 routine)
; also modified to switch from the SD System assembler to the SLR one.
; V4.21 11/17/09 Removed 8086 jump far setting code
; V4.3 11/18/09 Implement movement of 8086 Monitor code (EPROM) to correct location in RAM space
; V4.31 11/19/09 Check 8086 Monitor ROM->ROM went OK. Added W command.
; V4.32 12/7/09 Turn off any SD Systems 8024 video screen enhancements (flashing, underline etc).
; V4.33 12/25/09 Correct High/Low byte Sector read for IDE board
; V4.34 2/23/10 "O" command, 8086 Far jump to 500H (IF RAM @ FFFF0H), W command boots 8086 from reset at FFFF0H.
; V4.35 3/25/10 "O" command just puts 8086 Far JMP to 500H (IF RAM @ FFFF0H). Done also at each reset.
; V4.4 7/29/10 Removed all SD Systems IO-8. Added S-100Computers I/O board drivers.
; V4.41 7/29/10 Initalization of V-Stamp chip done. Cleaned up Serial port names etc

```

```

;      V4.42  7/31/10      Switched RTC over to S-100Computers board (Ports A4,A5)
;      V4.50  2/7/11      Added Floppy Boot loader for ZFDC board. Still have the Versafloppy loader but no BIOS functions
;      V4.51  2/13/11     Check IDE if Boot sector is valid
;      V4.52  2/15/11     Pulse CF/IDE cards twice to reset (some) cards properly
;      V4.53  2/16/11     Initalize IDE board with IDE RD/WR lines inactive on power-up.
;      V4.54  2/28/11     Incorporated new fast multi-sector boot for CPM floppy loading with ZFDC board
;      V4.55  2/28/11     "O" command now jumps to SWITCH_8086 (activates 8086) when done
;      V4.55a 3/1/11      "O" cmd will just put 33 on Consol (temporary 8086 board test)
;      V4.56  3/15/11     Re-did IDE drive hardware reset pulse to one (delayed) pulse, then wait for drive ready status.
;      V4.57  6/3/11      Set up an equate for IDE drive reset pulse, Fixed Z command (Last version using MM58167 RTC chip)
;      V4.6   11/27/11    Switched to Dallas Semiconductor/IBM-PC CMOS-RTC chip & MSDOS Support board for time & dates
;      V4.7   3/26/12     Cleaned up IOBYTE options. Added 68000 CPU Slave activate option (B menu command)

SCROLL EQU 01H      ;Set scrool direction UP.
BELL EQU 07H
SPACE EQU 20H
TAB EQU 09H        ;TAB ACROSS (8 SPACES FOR SD-BOARD)
CR EQU 0DH
LF EQU 0AH
FF EQU 0CH
QUIT EQU 11H       ;Turns off any screen enhancements (flashing, underline etc).
NO_ENHANCEMENT EQU 17H ;Turns off whatever is on
FAST EQU 10H       ;High speed scrool
ESC EQU 1BH
DELETE EQU 7FH
BACKS EQU 08H
CLEAR EQU 1AH      ;TO CLEAR SCREEN
RST7 EQU 38H       ;RST 7 (LOCATION FOR TRAP)
IOBYTE EQU 0EFH    ;IOBYTE (SEE BELOW)
NN EQU 0H          ;[I] INITIAL VALUE
;

STARTCPM EQU 100H  ;LOCATION WHERE CPM WILL BE PLACED FOR COLD BOOT
STARTDOS EQU 100H  ;LOCATION WHERE MSDOS WILL BE PLACED FOR COLD BOOT
FFILE_SIZE EQU 9000h/512 ;SIZE OF 5MSDOS20.COM IN 512 BYTE SECTORS
;
;
;IOBYTE = SENSE SWITCHES AT PORT 0EFH
;
; BIT MAP OF PORT 0EFH:----- X X X X X X X X (11111111=NORMAL CONFIG)
;      | | | | | | | | ..For Z80 Monitor,      0=CONSOLE DATA TO PRINTER ALSO
;      | | | | | | | | .....For 8086 Monitor, 0=Force Consol output to CGA/VGA Board
;      | | | | | | | | .....For 8086 Monitor, 0=Do not initalize extra ROMS
;      | | | | | | | | .....Unused
;      | | | | | | | | .....For CPM3,          0=Prevents LF's in CPM3
;      | | | | | | | | .....For Z80 Monitor,   0=Consol I/O via ACIA Serial port
;      | | | | | | | | .....For CPM3,         0=Force format of Mdisk ith CPM3
;      | | | | | | | | .....For CPM3,         0=R/W protect Mdisk
;      | | | | | | | | .....For 8086 Monitor, 0=Prevent doing a JMPF to 0000:0500H after 8086 reset
;

```

```

;
;----- SD SYSTEMS VIDIO BOARD FOR CONSOLE INPUT & OUTPUT
CONSOL_STATUS EQU    0H
CONSOL_IN      EQU    01H
CONSOL_OUT     EQU    01H

;----- THIS IS MY PORT TO OUTPUT DATA TO HP 4050T LASAR PRINTER (IMSAI 8PIO Board)
PRINTER_STATUS EQU    5          ;IN, HP PARRELL PORT
PRINTER_OUT    EQU    5          ;OUT
PRINTER_STROBE EQU    4          ;OUT
DIAG_LEDS      EQU    5          ;OUT (Will use this port initially for diagnostic LED display)

;----- S100Computers I/O BOARD PORT ASSIGNMENTS (A0-AC)
BCTL          EQU    0A0H        ;CHANNEL B CONTROL PORT ASSIGNMENTS OF THE ZILOG SCC CHIP      ;<--- Adjust as necessary,
ACTL          EQU    0A1H        ;CHANNEL A CONTROL
BDTA          EQU    0A2H        ;CHANNEL B DATA
ADTA          EQU    0A3H        ;CHANNEL A DATA

PortA_8255    EQU    0A8H        ;A port of 8255 ;<--- Adjust as necessary
PortB_8255    EQU    0A9H        ;B port of 8255
PortC_8255    EQU    0AAH        ;C Port of 8255
PortCtrl_8255 EQU    0ABH        ;8255 configuration port
AinBout8255cfg EQU    10011000b  ;Set 8255 ports:- A input, B output,

USB_DATA      EQU    0ACH        ;PORT ASSIGNMENT FOR DLP-USB Controller chip
USB_STATUS    EQU    0AAH        ;Status port for USB port (Port C of 8255, bits 6,7)
USB_RXE       EQU    80H         ;If Bit 7 = 0, data available to recieve by S-100 Computer
USB_TXE       EQU    40H         ;If Bit 6 = 0 data CAN be written for transmission to PC

;----- S100Computers MSDOS Support Board PORT ASSIGNMENTS
CMOS_PORT     EQU    70H         ;Base Port for CMOS Chip on MSDOS Support Board
MASTER_PIC_PORT EQU    20h       ;Hardware port the 8259A (two ports 20H & 21H)

MasterICW1    equ    00010111B   ;EDGE triggered, 4 bytes, single Master,ICW4 needed
MasterICW2    equ    8H          ;Base address for 8259A Int Table (IBM-PC uses 8X4 = 20H)
MasterICW3    equ    0H          ;No slave
MasterICW4    equ    00000011B   ;No special mode, non buffer, Auto EOI, 8086. ;<<<<,

;----- PORTS FOR FOR Z80/WD2793 FDC Board
S100_DATA_A   EQU    10H        ;IN, S100 Data port to GET data to from FDC Board
S100_DATA_B   EQU    10H        ;OUT, S100 Data port to SEND data to FDC Board
S100_STATUS_A EQU    11H        ;Status port for A
S100_STATUS_B EQU    11H        ;Status port for B
RESET_ZFDC_PORT EQU    13H      ;Port to reset ZFDC Z80 CPU.

```

```

STATUS_DELAY EQU    5           ;Time-out for waiting for ZFDC Board handshake signal (~0.5 seconds @ 10MHz)
DIRECTION_BIT EQU    7           ;Bits for the ZFDC flags 0 = IN, 1 = OUT
DATA_IN_RDY EQU    0           ;Bit for data available from ZFDC board
DATA_OUT_RDY EQU    1           ;Bit for data can be sent to ZFDC board
STD8IBM EQU        EQU    1           ;IBM 8" SDSS Diak
NO_ERRORS_FLAG EQU    0           ;No Errors flag for previous cmd, sent back to S-100 BIOS

```

;Commands to the ZFDC Board:-

```

CMD_RESET_ZFDC EQU    3H           ;Reset the WD2793 chip and Board software
CMD_SET_FORMAT EQU    4H           ;This will select a specified drive and assign a disk format table to that drive
CMD_SET_DRIVE EQU    5H           ;This will select a specified drive (0,1,2,3)
CMD_SET_TRACK EQU    7H           ;This will set head request to a specified track
CMD_SET_SIDE EQU    8H           ;This will set side request to a specified side
CMD_SET_SECTOR EQU    9H           ;This will set sector request to a specified sector
CMD_SET_HOME EQU    0AH           ;This will set head request to Track 0 of CURRENT drive
CMD_STEP_IN EQU    0BH           ;Step head in one track of CURRENT drive
CMD_SEEK_TRACK EQU    0EH           ;Seek to track to (IY+DRIVE_TRACK) with the track verify bit set on CURRENT drive/format
CMD_READ_SECTOR EQU    10H           ;Read data from the CURRENT sector (on current track,side,drive).
CMD_HANDSHAKE EQU    21H           ;Handshake command only sent during board initialization/testing
CMD_RD_MULTI_SECTOR EQU 29H           ;Read data from multiple sectors starting at the CURRENT sector (on current track,side,drive).

```

;----- PORT(S) TO SWITCH MASTER/SLAVE(S)

```

Z80PORT EQU    0D0H           ;4 PORTS ON Z80 BOARD FOR MEMORY MANAGEMENT (& INT Controller on IA Z80 CPU Board)
SW86 EQU    0EDH           ;INPUT FROM THIS PORT SWITCHES IN THE 8088,8086, or 80286 board
SW68K EQU    0ECH           ;INPUT FROM THIS PORT SWITCHES IN THE 68000 CPU Board

```

;----- VERSAFLOPPY-II FLOPPY DISK CONTROLLER COMMANDS ETC.

```

X EQU    50H           ;BASE PORT FOR 1791
RSET EQU    X+0           ;CONTROLLER RESET ADDRESS
SELECT EQU    X+3           ;DRIVE SELECT PORT
STATUS EQU    X+4           ;STATUS PORT
TRACK EQU    X+5           ;TRACK PORT
SECTOR EQU    X+6           ;SECTOR PORT
DATA EQU    X+7           ;DATA PORT
CMD EQU    X+4           ;COMMAND PORT

CIOBYTE EQU    03H
CDISK EQU    04H
ZERO_L EQU    08H           ;Some of my CPM Loader's needs these to be zero!
ZERO_H EQU    09H           ;(The Non Banked version of CPM3). Need to later see why
@TADDR EQU    40H
@UNIT EQU    42H           ;NEW @UNIT BYTE
@SCTR EQU    43H           ;SECTOR (compatible with my old CPM2.2 Versafloppy BIOS)
@TRK EQU    44H           ;TRACK
@NREC EQU    45H           ;# OF SECTORS

```

```

@ERMASK      EQU    46H          ;ERROR MASK
@ERSTAT      EQU    47H          ;ERROR FLAG STORE
@IDSV EQU    48H                ;6 BYTES (USED FOR TRACK ID COMMAND)
@CMD SV EQU   4EH                ;COMMAND SAVE
@SPSV EQU    4FH                ;SP SAVE
TEMP2 EQU    51H                ;2 BYTE TEMP RECORD
@SIDE EQU    51H                ;SIDE STORE FOR MSDOS DISK
@COUNT EQU  53H                ;SECTORS/TRACK for BOOT (Currently unused)
@UNITCK      EQU    55H          ;OLD @UNIT BYTE
@RSEEK EQU    56H                ;NBR OF RESEKES
@RTRY EQU    57H                ;NBR OF RTRYS
ADRI VE EQU   58H                ;STORE OF A: DRIVE DENSITY ETC TYPE
BDRI VE EQU   59H                ;STORE OF B: DRIVE TYPE
@FDCTYPE EQU 5BH                ;0FFH = ZFDC FDC Board Boot, else Versafloppy II FDC Boot,
@SEC_SIZE EQU 5CH                ;Byte count of a sector fot loader
@SSTACK      EQU    80H          ;SYSTEM STACK

COLD EQU     80H                ;COLD START ADDRESS FOR CPM FLOPPY (ONLY) BOOT LOADER

RDACMD EQU   0C0H                ;READ ADDRESS CODE
RDCMD EQU    088H                ;READ SECTOR CODE
WRCMD EQU    0A8H                ;WRITE SECTOR CODE
WRTCMD EQU   0F4H                ;WRITE TRACK CODE
RSCMD EQU    008H                ;RESTORE COMMAND (Note 3 Ms seek)
SKNCMD EQU   018H                ;SEEK NO VERIFY
FSKCMD EQU   01CH                ;FLOPPY SEEK COMAND
RSV CMD EQU   00CH                ;RESTORE WITH VERIFY COMMAND
MSKCMD EQU   01FH                ;MINI FLOPPY SEEK COMMAND

SRMASK EQU   0FEH                ;SECTOR READ ERROR BITS MASK

STDSDT EQU   26                  ;STANDARD 8" 26 SECTORS/TRACK
STDDDT EQU   50                  ;STANDARD DD 8" 50 SECTORS/TRACK
NBYTES EQU   128                 ;BYTES/SECTOR
NTRKS EQU    77                  ;TRACKS/DISK

;----- S100Computers IDE HARD DISK CONTROLLER COMMANDS ETC.
IDEAport EQU  030H                ;lower 8 bits of IDE interface
IDEBport EQU  031H                ;upper 8 bits of IDE interface
IDECport EQU  032H                ;control lines for IDE interface
IDECtrl EQU   EQU    033H          ;8255 configuration port
IDEDrivePort EQU 034H            ;To select the 1st or 2nd CF card/drive (Not used with this monitor)

IDE_Reset_Delay EQU 020H          ;Time delay for reset/initilization (~60 uS, with 10MHz Z80, 2 I/O wait states)

CPM_ADDRESS EQU 100H              ;Will place the CPMLDR.COM Loader here with
                                ;CPMLDR.COM will ALWAYS be on TRK 0,SEC2, (LBA Mode)
SEC_COUNT EQU 12                  ;CPMLDR.COM requires (currently) 10, 512 byte sectors
                                ;Add extra just in case
RDcfg8255 EQU 10010010B          ;Set 8255 IDEcport out, IDEAport/B input

```

```

WRcfg8255    EQU    1000000B    ;Set all three 8255 ports output
;
IDEa0line    EQU    01H          ;direct from 8255 to IDE interface
IDEa1line    EQU    02H          ;direct from 8255 to IDE interface
IDEa2line    EQU    04H          ;direct from 8255 to IDE interface
IDEcs0line   EQU    08H          ;inverter between 8255 and IDE interface
IDEcs1line   EQU    10H          ;inverter between 8255 and IDE interface
IDEwrline    EQU    20H          ;inverter between 8255 and IDE interface
IDERdline    EQU    40H          ;inverter between 8255 and IDE interface
IDEReset     EQU    80H          ;inverter between 8255 and IDE interface
;
;Symbolic constants for the IDE Drive registers, which makes the
;code more readable than always specifying the address pins
;
REGdata      EQU    08H          ;IDEcs0line
REGgerr      EQU    09H          ;IDEcs0line + IDEa0line
REGcnt       EQU    0AH          ;IDEcs0line + IDEa1line
REGsector    EQU    0BH          ;IDEcs0line + IDEa1line + IDEa0line
REGcylLSB    EQU    0CH          ;IDEcs0line + IDEa2line
REGcylMSB    EQU    0DH          ;IDEcs0line + IDEa2line + IDEa0line
REGshd       EQU    0EH          ;IDEcs0line + IDEa2line + IDEa1line          ; (0EH)
REGCMD       EQU    0FH          ;IDEcs0line + IDEa2line + IDEa1line + IDEa0line      ; (0FH)
REGstatus    EQU    0FH          ;IDEcs0line + IDEa2line + IDEa1line + IDEa0line
REGcontrol   EQU    16H          ;IDEcs1line + IDEa2line + IDEa1line
REGastatus   EQU    17H          ;IDEcs1line + IDEa2line + IDEa1line + IDEa0line

;IDE CMD Constants.  These should never change.
CMDrecal     EQU    10H
CMDread      EQU    20H
CMDwrite     EQU    30H
CMDdinit     EQU    91H
CMDdid       EQU    0E0H
CMDdownspin  EQU    0E0H
CMDupspin    EQU    0E1H
;
; IDE Status Register:
; bit 7: Busy      1=busy, 0=not busy
; bit 6: Ready 1=ready for CMD, 0=not ready yet
; bit 5: DF 1=fault occurred insIDE drive
; bit 4: DSC 1=seek complete
; bit 3: DRQ 1=data request ready, 0=not ready to xfer yet
; bit 2: CORR 1=correctable error occurred
; bit 1: IDX vendor specific
; bit 0: ERR 1=error occurred
;
;-----
;
;CONNECTIONS TO Z80-MONB.Z80 :-
;
BASE    EQU    0F000H          ;Start or EPROM Location (Assume a 2732 or half of a 278C64)

```

```

      ORG     BASE          ;<-----<<<<<< LOCATION OF START OF MONITOR (First part)
VERSA EQU   BASE+800H     ;<-----<<<<<< LOCATION OF FLOPPY BIOS (For old Software)
                                ;
                                ;           NOTE MUST INSURE NO OVERFLOW OF THE FIRST
                                ;           PART OR THIS MONITOR INTO THIS BIOS AREA

;PROGRAM CODE BEGINS HERE
;FIRST A JUMP TABLE FOR ALL JUMPS INTO THE MONITOR. NOTE THESE CANNOT BE
;CHANGED. WHERE POSSIBLE ZAPPLE FORMAT IS USED.

ZAPPLE:    JP     BEGIN          ;INITIALIZATION
ZCI:       JP     CI              ;CONSOL INPUT
ZRI:       JP     SERIAL_IN      ;READER      INPUT = Modem Input for Now
ZCO:       JP     CO              ;CONSOL OUTPUT
ZPOO:      JP     SERIAL_OUT     ;PUNCH OUTPUT = Modem Output for Now
ZLO:       JP     LO              ;LIST OUTPUT
ZCSTS:     JP     CSTS           ;CONSOL STATUS
ZMEMCK:    JP     MEMSIZ         ;GET HIGHEST RAM RETURNS IT IN [HL]
ZTRAP:     JP     TRAP           ;ERROR TRAP ADDRESS
ZSTART:    JP     START         ;JUMP TO MONITOR DO NOT RESET HARDWARE
ZTALK:     JP     SPEAKOUT       ;SEND AN ASCII CHARACTER TO TALKER (One at a time)
ZTALKS:    JP     SPEAKER_CTS    ;STATUS FOR SPEECH CTS Line (V-Stamp CTS low when ready)
ZDELAY:    JP     DELAY          ;SOFTWARE DELAY LENGTH IN [A]
ZLSTAT:    JP     LSTAT         ;LIST STATUS
ZONLIST:   JP     ONLIST        ;INITILIZE LIST DEVICE
ZOFFLIST:  JP     OFFLIST       ;TURN OFF LIST DEVICE
ZTIME:     JP     PRINT_TIME     ;PUT TIME ON CRT @ CURSOR POSITION
ZDATE:     JP     PRINT_DATE     ;PRINT DATE ON CRT @ CURSOR POSITION
ZSPEAK$:   JP     SPEAK$        ;SEND ASCII STRING TO TALKER [HL] UP TO '$'
ZSERIAL_OUT:
      JP     SERIAL_OUT        ;OUT TO ZILOG SCC SERIAL PORT
ZSERIAL_IN:
      JP     SERIAL_IN         ;INPUT FROM ZILOG SCC SERIAL PORT
ZSERIAL_STAT:
      JP     SERIAL_STAT       ;STATUS FROM ZILOG SCC SERIAL PORT
ZLOADER:   JP     LOADER        ;LOAD IN CPM IMAGE ON TRACKS 0 & 1 (VIA FLOPPY BOOT LOADER ON DISK SECTOR 1)
ZPM$G0:    JP     TOM           ;DISPLAY STRING ON CONSOL [HL]=START ADD. [B]=LENGTH
ZPM$G$:    JP     PRINT_STRING   ;DISPLAY STRING ON CONSOL [HL]=START ADD. '$'=END
ZHLSP:     JP     HLSP          ;DISPLAY [HL] ON CONSOL THEN ONE SPACE
ZBITS:     JP     BITS1         ;DISPLAY 8 BITS OF [A] ON CONSOL
ZLBYTE:    JP     LBYTE         ;DISPLAY [A] ON CONSOL
ZHEXSP:    JP     HEXSP         ;PUT 16 BIT PARAMETERS ON STACK FROM CONSOL, [C]=PARAMETER #
ZCRLF:     JP     CRLF          ;SEND CRLF TO CONSOL
ZHILO:     JP     HILO          ;RANGE CHECK (INC [HL], IF HL=DE THEN SET CARRY)
ZCONV:     JP     CONV          ;CONVERT HEX IN [A] TO ASCII IN [A]
ZDOS:      JP     DOS           ;LOAD MSDOS FROM 5" DRIVE D:
ZPCHK:     JP     PCHK         ;INPUT FROM CONSOL & TEST FOR DELIMITERS RET {Z} IF
                                ;SPACE OR , RET {C} IF A CR ELSE NON ZERO NON CARRY

VFLOPPY    JP     VBOOT         ;BOOT UP CPM-80 FROM VERSAFLOPPY II FDC
ZHARD:     JP     HBOOTCPM      ;BOOT UP CPM-80 FROM HARD DISK

```

```
ZPRDY: JP      PRDY                ;PUNCH READY CHECK
ZRSTAT:      JP      RSTAT          ;READER STATUS
ZCCHK: JP      CCHK                ;CHECK FOR ^S & ESC AT KEYBOARD
ZFLOPPY      JP      ZBOOT          ;BOOT UP CPM-80 FROM ZFDC FDC
```

```
;
;      NOTE TABLE MUST BE WITHIN 0-FFH BOUNDRY
```

```
;
;COMMAND BRANCH TABLE
```

```
TBL:  DW  FLUSH      ; "@" SEND FF to LaserJet printer
      DW  MEMMAP     ; "A" DISPLAY A MAP OF MEMORY
      DW  SWITCH_68K ; "B" SWITCH CONTROL TO 68000 CPU
      DW  ZBOOT      ; "C" BOOT IN CP/M FROM 8" DISK WITH WITH ZFDC FDC
      DW  DISP       ; "D" DISPLAY MEMORY (IN HEX & ASCII)
      DW  ECHO       ; "E" ECHO CHAR IN TO CHAR OUT
      DW  FILL       ; "F" FILL MEMORY WITH A CONSTANT
      DW  GOTO       ; "G" GO TO [ADDRESS]
      DW  SHOW_DATE  ; "H" SHOW CURRENT DATE
      DW  SHOW_TIME  ; "I" SHOW CURRENT TIME
      DW  RAMTEST    ; "J" NON-DESTRUCTIVE MEMORY TEST
      DW  KCMD       ; "K" DISPLAY THE LIST OF MONITOR COMMANDS
      DW  VBOOT      ; "L" BOOT IN CP/M FROM 8" DISK WITH VERSAFLOPPY II FDC
      DW  MOVE       ; "M" MOVE BLOCK OF MEMORY (START,FINISH,DESTINATION)
      DW  XMEMMAP    ; "N" Display extended memory Segment:Address
      DW  UP8086     ; "O" SWITCH CONTROL TO 8088, 8086 or 80286.
      DW  HBOOTCPM   ; "P" BOOT IN CPM FROM IDE HARD DISK
      DW  QUERY      ; "Q" QUERY PORT (IN OR OUT)
      DW  INPORTS    ; "R" Read ALL Input Ports
      DW  SUBS       ; "S" SUBSTITUTE &/OR EXAMINE MEMORY
      DW  TYPE       ; "T" TYPE ASCII PRESENT IN MEMORY
      DW  BEGIN      ; "U" SPARE
      DW  VERIFY     ; "V" COMPARE MEMORY
      DW  SWITCH_8086 ; "W" INPUT Port ED (switched in 8086/80286)
      DW  START      ; "X" BOOT IN MSDOS FROM HARD DISK (Not done yet)
      DW  BEGIN      ; "Y" SPARE
      DW  SIZE       ; "Z" FIND HIGHEST R/W RAM
```

```
;
;-----
```

```
;
BEGIN: LD      A, '#'                ;For quick hardware diagnostic test
      OUT     (CONSOLE_OUT),A
      LD      A,0FFH                ;Clear Printer strobe, comes up 0 on a reset
      OUT     (PRINTER_STROBE),A    ;also it turn all LED's off as a diagnostic
      LD      A,0000000B            ;FLAG PROGRESS VISUALLY FOR DIAGNOSTIC (ALL LED' ON)
      OUT     (DIAG_LEDS),A        ;LED's will go off one at a time

      LD      A,0FFH
      OUT     (SELECT),A           ;DESELECT ANY FLOPPYS ON VERSAFLOPPY FDC (If Present)
```



```

LD      A,1000000B      ;FLAG PROGRESS VISUALLY FOR DIAGNOSTIC (1 LED off)
OUT     (DIAG_LEDS),A

LD      A,0FFH
OUT     (RSET),A       ;RESET VERSAFLOPPY II FLOPPY DISK CONTROLLER (If Present)
OUT     RESET_ZFDC_PORT,A ;RESET ZFDC FLOPPY DISK CONTROLLER (If Present)

XOR     A
OUT     (Z80PORT+1),A  ;SET INTERRUPT TO PAGE 0H
LD      I,A           ;KILL THE INTERSYSTEMS Z80 CPU BOARD INT CONTROLLER (If present)

LD      A,MasterICW1   ;We need to clear the 8259A otherwise teh 8086 monitor sometimes hangs
OUT     (MASTER_PIC_PORT),A ;Initilize the 8259A PIC Controller (;EDGE triggered, 4 bytes, single Master,ICW4 needed)
LD      A,MasterICW2   ;Ints starts at 20H in RAM (IBM-PC uses 8X4 = 20H)
OUT     (MASTER_PIC_PORT+1),A
LD      A,MasterICW4   ;No slaves above, so 8259 does not expect ICW3
out     (MASTER_PIC_PORT+1),A

LD      A,1111111b     ;Allow no interrupts to 8259A with Z80.
out     (MASTER_PIC_PORT+1),A

LD      A,0H
OUT     (Z80PORT+2),A  ;SETUP MEMORY MANAGEMENT TO OVERLAP WITH
LD      A,04H
OUT     (Z80PORT+3),A ;CURRENT RAM in 64K Space

LD      A,11000000B    ;FLAG PROGRESS VISUALLY FOR DIAGNOSTIC (2 LED's off)
OUT     (DIAG_LEDS),A

ZAXXLE: LD      SP,AHEAD-4      ;SETUP A FAKE STACK
JP      MEMSZ1                ;RETURNS WITH TOP OF RAM IN [HL]
DW      AHEAD                  ;Ret will pick up this address
AHEAD: LD      SP,HL           ;[HL] CONTAINS TOP OF RAM - WORKAREA

PUSH   HL
POP    IX                      ;Store stack pointer for below in [IX]

LD     HL,MSG0                  ;Have a Stack, so we can use CALL
CALL  PRINT_STRING

CALL  INIT_S100_IO              ;Initilize the Zilog 8530 & 8255 on the S100Computers I/O Board

LD     A,11100000B             ;FLAG PROGRESS (Have a Stack with 3 LED's off)
OUT    (DIAG_LEDS),A

CALL  PRINT_TIME                ;PRINT TIME ON CRT (IF RTC BOARD PRESENT)
JP    C,NO_CLOCK
LD    HL,GAP_MSG
CALL  PRINT_STRING
CALL  PRINT_DATE                ;PRINT DATE ON CRT, then CRLF

```

```

NO_CLOCK:
    CALL    CRLF

    LD      A,1111000B      ;FLAG PROGRESS (I/O board initilized, 4 LED's Off)
    OUT    (DIAG_LEDS),A

    LD      HL,SP_MSG      ;Print Current Stack Location
    CALL    PRINT_STRING

    PUSH   IX              ;SP is stored from above in [IX]
    POP    HL
    CALL   HLSP            ;Print HL/SP
    CALL   CRLF           ;Then CRLF
    CALL   CSTS           ;CHECK IF GARBAGE AT KEYBOARD
    CALL   NZ,CI          ;If so flush it

    LD      A,1111100B      ;FLAG PROGRESS (Ready to go, 5 LED's off)
    OUT    (DIAG_LEDS),A

    LD      HL,CR_SMSG     ;lets V-Stamp chip get baud rate
    CALL   SPEAK$

    CALL   INITILIZE_IDE_BOARD ;initilize first IDE drive (if present)

    LD      A,11111100B    ;FLAG PROGRESS (Initilization done, 6 LED's off)
    OUT    (DIAG_LEDS),A

;-----THIS IS THE START ON THE MAIN MONITOR LOOP-----

START: LD      DE,START
    PUSH   DE              ;EXTRA UNBALANCED POP & [DE] WOULD END UP IN [PC]
    CALL   CRLF
    LD     C,BELL          ;A BELL HERE WILL SIGNAL WHEN JOBS ARE DONE
    CALL   CO
    LD     C,'-'
    CALL   CO
    LD     C,'>'
    CALL   CO

STARO: CALL   TI          ;Main loop. Monitor will stay here until cmd.
    AND   7FH
    JR    Z,STARO
    SUB   '@'            ;Commands @ to Z only
    RET   M
    CP   1BH            ;A-Z only
    RET   NC
    ADD  A,A
    LD   HL,TBL

```

```

ADD    A,L
LD     L,A
LD     A,(HL)
INC    HL
LD     H,(HL)
LD     L,A
LD     C,02H
JP     (HL)                ;JUMP TO COMMAND TABLE
;
;----- GO CARRY OUT COMMAND AND POP BACK TO START-----
; NOTE STRING IS HERE IN CASE A 2716 IS USED BY MISTAKE (Monitor will at least signon)

MSG0:  DB SCROLL,QUIT,NO_ENHANCEMENT,FAST,BELL,CR,LF,LF
        DB 'Z80 ROM MONITOR V4.7 (John Monahan, 3/27/2012) $'
MSG1:  DB 'HELLO JOHN THE Z80 ROM MONITOR VERSION 4.7 IS NOW RESIDENT $'

;SEND MESSAGE TO CONSOL MESSAGE IN [HL],LENGTH IN [B]

TOM:   LD     C,(HL)
        INC    HL
        CALL  CO
        DJNZ  TOM
        RET

;
PRINT_STRING:
        LD     A,(HL)                ;A ROUTINE TO PRINT OUT A STRING @ [HL]
        INC    HL                    ;UP TO THE FIRST '$'.
        CP     '$'
        RET    Z
        LD     C,A
        CALL  CO
        JR     PRINT_STRING

;ABORT IF ESC AT CONSOL, PAUSE IF ^S AT CONSOL

CCHK:  CALL  CSTS                    ;FIRST IS THERE ANYTHING THERE
        RET    Z
        CALL  CI
        CP     'S'-40H
        JR     NZ,CCHK1

CCHK2: CALL  CSTS                    ;WAIT HERE UNTIL ANOTHER INPUT IS GIVEN
        JR     Z,CCHK2

CCHK1: CP     ESC
        RET    NZ                    ;RETURN EXECPT IF ESC

;RESTORE SYSTEM AFTER ERROR

ERROR: CALL  MEMSIZ                    ;GET RAM AVAILABLE - WORKSPACE IN [HL]
        LD     SP,HL                ;SET STACK UP IN WORKSPACE AREA
        LD     C,'*'

```

```

        CALL    CO
        JP      START

;PRINT HIGHEST MEMORY FROM BOTTOM

SIZE:
        CALL    MEMSIZ           ;RETURNS WITH [HL]= RAM AVAILABLE-WORKSPACE

LFADR: CALL    CRLF

;PRINT [HL] AND A SPACE
HLSP:  PUSH    HL
        PUSH    BC
        CALL    LADR
        LD      C,SPACE
        CALL    CO
        POP     BC
        POP     HL
        RET

;PRINT A SPACE

SF488: LD      C,SPACE
        JP      CO

;CONVERT HEX TO ASCII

CONV:  AND     0FH
        ADD    A,90H
        DAA
        ADC    A,40H
        DAA
        LD     C,A
        RET

;GET TWO PARAMETERS AND PUT THEM IN [HL] & [DE] THEN CRLF

EXLF:  CALL    HEXSP
        POP     DE
        POP     HL

;SEND TO CONSOL CR/LF

CRLF:  PUSH    BC
        LD     C,LF
        CALL    CO
        LD     C,CR
        CALL    CO
        POP     BC
        RET

```

;PUT THREE PARAMETERS IN [BC] [DE] [HL] THEN CR/LF

```

EXPR3: INC      C                ;ALREADY HAD [C]=2 FROM START
        CALL    HEXSP
        CALL    CRLF
        POP     BC
        POP     DE
        POP     HL
        RET

```

;GET ONE PARAMETER

```

EXPR1: LD      C,01H
HEXSP: LD      HL,0000
EX0:  CALL    TI
EX1:  LD      B,A
        CALL  NIBBLE
        JR    C,EX2X
        ADD   HL,HL
        ADD   HL,HL
        ADD   HL,HL
        ADD   HL,HL
        OR    L
        LD    L,A
        JR    EX0
EX2X: EX      (SP),HL
        PUSH  HL
        LD    A,B
        CALL  QCHK
        JR    NC,SF560
        DEC  C
        RET   Z
SF560: JP     NZ,ERROR
        DEC  C
        JR    NZ,HEXSP
        RET
EXF:  LD      C,01H
        LD    HL,0000H
        JR    EX1

```

;RANGE TEST ROUTINE CARRY SET = RANGE EXCEEDED

```

HILOX: CALL    CCHK
        CALL    HILO
        RET    NC
        POP    DE                ;DROP ONE LEVEL BACK TO START
        RET
HILO:  INC     HL                ;RANGE CHECK SET CARRY IF [DE]=[HL]
        LD    A,H

```

```

OR    L
SCF
RET   Z
LD    A,E
SUB   L
LD    A,D
SBC   A,H
RET

```

```
;PRINT [HL] ON CONSOL
```

```

LADR: LD    A,H
      CALL  LBYTE
      LD    A,L
LBYTE: PUSH  AF
      RRCA
      RRCA
      RRCA
      RRCA
      CALL  SF598
      POP   AF
SF598: CALL  CONV
      JP    CO

```

```
;THIS IS A CALLED ROUTINE USED TO CALCULATE TOP OF RAM IS USED BY
;THE ERROR TO RESET THE STACK. Returns top of RAM in [HL]
```

```

MEMSZ:  PUSH  BC           ;SAVE [BC]
MEMSZ1:  LD    HL,0FFFFH   ;START FROM THE TOP DOWN
MEMSZ2:  LD    A,(HL)
      CPL
      LD    (HL),A
      CP   (HL)
      CPL           ;PUT BACK WHAT WAS THERE
      LD    (HL),A
      JP   Z,GOTTOP
      DEC  H           ;TRY 100H BYTES LOWER
      JR   MEMSZ2     ;KEEP LOOKING FOR RAM
GOTTOP:  POP   BC           ;RESTORE [BC]
      RET

```

```

NIBBLE:  SUB   30H
      RET   C
      CP   17H
      CCF
      RET   C
      CP   LF
      CCF
      RET   NC
      SUB  07H

```

```

        CP      LF
        RET

COPCK: LD      C, '-'
        CALL   CO

PCHK:  CALL   TI

;TEST FOR DELIMITERS

QCHK:  CP      SPACE
        RET    Z
        CP    ', '
        RET    Z
        CP    CR
        SCF
        RET    Z
        CCF
        RET

;KEYBOARD HANDELING ROUTINE (WILL NOT ECHO CR/LF)
;IT CONVERTS LOWER CASE TO UPPER CASE FOR LOOKUP COMMANDS
;ALSO ^C WILL FORCE A JUMP TO BOOT IN CP/M
;ALL OTHERE CHARACTERS ARE ECHOED ON CONSOL

TI:    CALL   CI
        CP    CR
        RET   Z
        CP    'C'-40H           ;^C TO BOOT IN CP/M
        JP    Z, FBOOT
        PUSH  BC
        LD    C, A
        CALL  CO
        LD    A, C
        POP  BC
        CP   40H               ;LC->UC
        RET   C
        CP   7BH
        RET   NC
SF754: AND   5FH
        RET

BITS1: PUSH   DE               ;DISPLAY 8 BITS OF [A]
        PUSH  BC
        LD    E, A
        CALL  BITS
        POP  BC
        POP  DE
        RET

```



```

OR    IDerdline      ;08H+40H, Pulse RD line
OUT   (IDECport),A

IN    A, (IDEAport)  ;read the LOWER byte
LD    (HL),A
INC   HL
IN    A, (IDEBport)  ;read the UPPER byte
LD    (HL),A
INC   HL

LD    A,REGdata      ;Deassert RD line
OUT   (IDECport),A
DJNZ  MoreRD16
DEC   C
JR    NZ,MoreRD16

LD    E,REGstatus    ;Check the R/W status when done
CALL  IDerd8D
BIT   0,D
JR    NZ,IDEerr1     ;Z if no errors
LD    HL,STARTCPM
LD    A, (HL)
CP    31H            ;EXPECT TO HAVE 31H @80H IE. LD SP,80H
JP    Z,STARTCPM     ;AS THE FIRST INSTRUCTION. IF OK JP to 100H in RAM
JP    ERR_LD1        ;Boot Sector Data incorrect

IDEerr1:
LD    HL,IDE_RW_ERROR ;Drive R/W Error
JP    ABORT_ERR_MSG

;    ----- SUPPORT ROUTINES -----

INITILIZE_IDE_BOARD: ;Drive Select in [A]. Note leaves selected drive as [A]
LD    A,RDcfg8255    ;Config 8255 chip (10010010B), read mode on return
OUT   (IDECtrl),A    ;Config 8255 chip, READ mode

;Hard reset the disk drive
;For some reason some CF cards need to the RESET line
;pulsed very carefully. You may need to play around
;with the pulse length. Symptoms are: incorrect data comming
LD    A,IDEReset     ;back from a sector read (often due to the wrong sector being read)
OUT   (IDECport),A   ;I have a (negative)pulse of 60 uSec. (10Mz Z80, two IO wait states).

LD    C,IDE_Reset_Delay ;~60 uS seems to work for the 5 different CF cards I have
ResetDelay:
DEC   C
JP    NZ,ResetDelay  ;Delay (reset pulse width)
XOR   A

```

```

OUT    (IDEcport),A          ;No IDE control lines asserted (just bit 7 of port C)

CALL   DELAY_15              ;Need to delay a little before checking busy status

IDEwaitnotbusy:              ;Drive READY if 01000000
LD     B,0FFH
LD     C,080H                ;Delay, must be above 80H for 4MHz Z80. Leave longer for slower drives
MoreWait:
LD     E,REGstatus          ;Wait for RDY bit to be set
CALL   IDerd8D
LD     A,D
AND    11000000B
XOR    01000000B
JR     Z,DoneNotbusy
DJNZ   MoreWait
DEC    C
JR     NZ,MoreWait
SCF                                ;Set carry to indicate an error
RET

DoneNotBusy:
OR     A                      ;Clear carry it indicate no error
RET

;Wait for the drive to be ready to transfer data.
;Returns the drive's status in Acc
IDEwdrq:
LD     B,0FFH
LD     C,0FFH                ;Delay, must be above 80H for 4MHz Z80. Leave longer for slower drives
MoreDRQ:
LD     E,REGstatus          ;wait for DRQ bit to be set
CALL   IDerd8D
LD     A,D
AND    10001000B
CP     00001000B
JR     Z,DoneDRQ
DJNZ   MoreDRQ
DEC    C
JR     NZ,MoreDRQ
SCF                                ;Set carry to indicate error
RET

DoneDRQ:
OR     A                      ;Clear carry
RET

;
;-----
; Low Level 8 bit R/W to the drive controller. These are the routines that talk
; directly to the drive controller registers, via the 8255 chip.
; Note the 16 bit I/O to the drive (which is only for SEC Read here) is done directly
; in the routine MoreRD16 for speed reasons.

```

```

IDErD8D:                ;READ 8 bits from IDE register in [E], return info in [D]
    LD    A,E
    OUT   (IDECport),A   ;drive address onto control lines

    OR    IDErdline      ;RD pulse pin (40H)
    OUT   (IDECport),A   ;assert read pin

    IN    A,(IDEAport)
    LD    D,A            ;return with data in [D]

    LD    A,E            ;<---Ken Robbins suggestion
    OUT   (IDECport),A   ;Deassert RD pin

    XOR   A
    OUT   (IDECport),A   ;Zero all port C lines
    RET

```

```

IDEWr8D:                ;WRITE Data in [D] to IDE register in [E]
    LD    A,WRCfg8255    ;Set 8255 to write mode
    OUT   (IDECtrl),A

    LD    A,D            ;Get data put it in 8255 A port
    OUT   (IDEAport),A

    LD    A,E            ;select IDE register
    OUT   (IDECport),A

    OR    IDEwrline      ;lower WR line
    OUT   (IDECport),A

    LD    A,E            ;<-- Kens Robbins suggestion, raise WR line
    OUT   (IDECport),A

    XOR   A              ;Deselect all lines including WR line
    OUT   (IDECport),A

    LD    A,RDCfg8255    ;Config 8255 chip, read mode on return
    OUT   (IDECtrl),A
    RET

```

```

;-----

```

```

;MEMORY MAP PROGRAM CF.DR.DOBBS VOL 31 P40.
;IT WILL SHOW ON CONSOL TOTAL MEMORY SUMMARY OF RAM,PROM, AND NO MEMORY
;

```

```

MEMMAP:
    CALL  ZCRLF
    LD    HL,0
    LD    B,1

```

```

MAP1: LD     E, 'R'                ;PRINT R FOR RAM
      LD     A, (HL)
      CPL
      LD     (HL), A
      CP     (HL)
      CPL
      LD     (HL), A
      JR     NZ, MAP2
      CP     (HL)
      JR     Z, PRINT
MAP2: LD     E, 'p'
MAP3: LD     A, 0FFH
      CP     (HL)
      JR     NZ, PRINT
      INC    L
      XOR    A
      CP     L
      JR     NZ, MAP3
      LD     E, '.'
PRINT: LD     L, 0
      DEC    B
      JR     NZ, NLINE
      LD     B, 16
      CALL   ZCRLF
      CALL   HXOT4
NLINE: LD     A, SPACE
      CALL   OTA
      LD     A, E
      CALL   OTA
      INC    H
      JR     NZ, MAP1
      CALL   ZCRLF
      CALL   ZCRLF
      JP     ZSTART

```

```

;16 HEX OUTPUT ROUTINE

```

```

HXOT4: LD     C, H
      CALL   HXO2
      LD     C, L
HXO2:  LD     A, C
      RRA
      RRA
      RRA
      RRA
      CALL   HXO3
      LD     A, C
HXO3:  AND    0FH
      CP     10
      JR     C, HADJ

```

```

        ADD    A,7
HADJ:  ADD    A,30H
OTA:   PUSH   BC
        LD    C,A
        CALL  ZCO                ;SEND TO CONSOL
        POP   BC
        RET

;DISPLAY MEMORY IN HEX

DISP:  CALL   EXLF                ;GET PARAMETERS IN [HL],[DE]
        LD    A,L                ;ROUND OFF ADDRESSES TO XX00H
        AND   0F0H
        LD    L,A
        LD    A,E                ;FINAL ADDRESS LOWER HALF
        AND   0F0H
        ADD   A,10H              ;FINISH TO END OF LINE
SF172: CALL   LFADR
SF175: CALL   BLANK
        LD    A,(HL)
        CALL  ZLBYTE
        CALL  HILOX
        LD    A,L
        AND   0FH
        JR    NZ,SF175
        LD    C,TAB                ;INSERT A TAB BETWEEN DATA
        CALL  ZCO
        LD    B,4H                ;ALSO 4 SPACES
TA11:  LD    C,SPACE
        CALL  ZCO
        DJNZ TA11
        LD    B,16                ;NOW PRINT ASCII (16 CHARACTERS)
        PUSH  DE                ;TEMPORLY SAVE [DE]
        LD    DE,0010H
        SBC  HL,DE
        POP   DE
T11:   LD    A,(HL)
        AND   7FH
        CP    ' '                ;FILTER OUT CONTROL CHARACTERS'
        JR    NC,T33
T22:  LD    A,'.'
T33:  CP    07CH
        JR    NC,T22
        LD    C,A                ;SET UP TO SEND
        CALL  ZCO
        INC  HL
        DJNZ T11                ;REPEAT FOR WHOLE LINE
        JR   SF172

BLANK: LD    C,' '

```


JP ZCO

;INSPECT AND / OR MODIFY MEMORY

```

SUBS: LD C,1
      CALL ZHEXSP
      POP HL
SF2E3: LD A,(HL)
      CALL ZLBYTE
      LD C,'-'
      CALL ZCO
      CALL ZPCHK
      RET C
      JR Z,SF2FC
      CP 5FH
      JR Z,SF305
      PUSH HL
      CALL EXF
      POP DE
      POP HL
      LD (HL),E
      LD A,B
      CP CR
      RET Z
SF2FC: INC HL
SF2FD: LD A,L
      AND 07H
      CALL Z,LFADR
      JR SF2E3
SF305: DEC HL
      JR SF2FD

```

;FILL A BLOCK OF MEMORY WITH A VALUE

```

FILL: CALL EXPR3
SF1A5: LD (HL),C
      CALL HILOX
      JR NC,SF1A5
      POP DE
      JP ZSTART

```

;GO TO A RAM LOCATION

```

GOTO: LD C,1 ;SIMPLE GOTO FIRST GET PARMS.
      CALL HEXSP
      CALL CRLF
      POP HL ;GET PARAMETER PUSHED BY EXF
      JP (HL)

```

; GET OR OUTPUT TO A PORT

```

QUERY: CALL ZPCHK
        CP 'O' ;OUTPUT TO PORT
        JR Z,SF77A
        CP 'I' ;INPUT FROM PORT
        JP Z,QQQ1
        LD C,'*'
        JP ZCO ;WILL ABORT IF NOT 'I' OR 'O'
QQQ1: LD C,1
        CALL ZHEXSP
        POP BC
        IN A,(C)
        JP ZBITS
;
SF77A: CALL ZHEXSP
        POP DE
        POP BC
        OUT (C),E
        RET

```

```
; MEMORY TEST
```

```

RAMTEST:CALL EXLF
SF200: LD A,(HL)
        LD B,A
        CPL
        LD (HL),A
        XOR (HL)
        JR Z,SF215
        PUSH DE
        LD D,B
        LD E,A ;TEMP STORE BITS
        CALL ZHLSP
        CALL BLANK
        LD A,E
        CALL ZBITS
        CALL ZCRLF
        LD B,D
        POP DE
SF215: LD (HL),B
        CALL HILOX
        JR SF200

```

```
;MOVE A BLOCK OF MEMORY TO ANOTHER LOCATION
```

```

MOVE: CALL EXPR3
SF21E: LD A,(HL)
        LD (BC),A
        INC BC

```

```

CALL HILOX
JR SF21E

```

```
;VERIFY ONE BLOCK OF MEMORY WITH ANOTHER
```

```

VERIFY: CALL  EXPR3
VERIO: LD   A, (BC)
      CP   (HL)
      JR   Z, SF78E
      PUSH BC
      CALL CERR
      POP  BC
SF78E: INC  BC
      CALL HILOX
      JR   VERIO
      RET

```

```
;
```

```

CERR: LD   B, A
      CALL ZHLSP
      LD   A, (HL)
      CALL ZLBYTE
      CALL BLANK
      LD   A, B
      CALL ZLBYTE
      JP   ZCRLF

```

```

ECHO: CALL CI           ;Routeen to check keyboard etc.
      CP   'C'-40H      ;Loop until ^C
      RET  Z
      CP   'Z'-40H
      RET  Z
      LD   C, A
      CALL CO
      JR   ECHO

```

```
;Display Extended memory map for 1MG RAM using IA-2 Z80 Board window registers
```

```

XMEMMAP:
LD     HL, MSG17           ;Get segment (0-F)
CALL   PRINT_STRING
LD     C, 1
CALL   ZHEXSP             ;Get 2 or 4 hex digits (count in C).
POP    HL
LD     A, L               ;Get single byte value
AND    0FH
EXX
LD     D, A               ;Store in D' for 000X:YYYY display below
SLA   A
SLA   A

```

```

SLA    A
SLA    A
OUT    (Z80PORT+2),A      ;Re-map to first 16K in segment:64K Space
LD     E,A                ;store shifted nibble in E'
LD     HL,0               ;Will store 0-FFFF for total RAM display (not actual access)
EXX
LD     D,0                ;Total display line count (256 characters, 16lines X 16 characters)

CALL   ZCRLF
LD     HL,0
LD     B,1
XMAP1: LD     A,H
AND    00111111B         ;Wrap 16K window
LD     H,A
LD     E,'R'             ;PRINT R FOR RAM
LD     A,(HL)
CPL
LD     (HL),A
CP     (HL)
CPL
LD     (HL),A           ;Save it back
JR     NZ,XMAP2
CP     (HL)
JR     Z,XPRINT
XMAP2: LD     E,'p'
XMAP3: LD     A,0FFH
CP     (HL)
JR     NZ,XPRINT
INC    L
XOR    A
CP     L
JR     NZ,XMAP3
LD     E, '.'
XPRINT: LD     L,0
DEC    B
JR     NZ,XNLINE
LD     B,16
CALL   ZCRLF
CALL   SET_WINDOW
LD     A,SPACE
JR     XN11
XNLINE: LD     A,SPACE
CALL   OTA
LD     A,E
XN11:  CALL   OTA
INC    H
INC    D                 ;Are we done yet
JR     NZ,XMAP1
CALL   ZCRLF
XOR    A

```

```

        OUT    (Z80PORT+2),A      ;Set RAM window back to the way it was
        JP     ZSTART

SET_WINDOW:                                ;Setup the unique IA-II Z80 board window to address > 64k
        EXX
        LD     C,D                ;Print seg value
        CALL  HXO2
        LD     C,':'
        CALL  CO
        CALL  HXOT4                ;Print HL' (not original HL)

        LD     A,H                ;get current H being displayed (Already pointed to first 16K window)
NOTW0:  CP     40H
        JR     NZ,NOTW1
        LD     A,E
        ADD   A,04H                ;Window for 4,5,6,7, set to H from above
        JR     DOWIN
NOTW1:  CP     80H
        JR     NZ,NOTW2
        LD     A,E
        ADD   A,08H                ;Window for 8,9,A,B set to H from above
        JR     DOWIN
NOTW2:  CP     0C0H
        JR     NZ,NOTW3                ;Must be values in between
        LD     A,E
        ADD   A,0CH                ;Window for 4,5,6,7, set to H from above
DOWIN:  OUT    (Z80PORT+2),A      ;Re-map to first 16K in segment:64K Space
NOTW3:  LD     A,H
        ADD   A,10H
        LD     H,A
        EXX
        RET                        ;Get back normal register set

```

```

;Place an 8086 a Far Jump at F000:FFF0H (FFFF0H) to 500H in RAM for the 8086/80286
;If there is a ROM there nothing will change and the 8086 reset/boot will jump
;from F000:FFF0 to the start of the ROM monitor at F000:FC00H. If however
;no ROM is present the 8086 will find the RAM code below and jump to 500H in RAM
;Whatever is at that location will then run - usually CPM86.

```

```

UP8086:  LD     A,0FCH                ;Point to 8086 Reset location
        OUT    (Z80PORT+2),A      ;Re-map to 0000H to FC00H
        LD     HL,3FF0H
        LD     (HL),0EAH
        INC   HL
        LD     (HL),0H
        INC   HL
        LD     (HL),05H
        INC   HL
        LD     (HL),0H

```

```

        INC    HL
        LD     (HL),0H
        INC    HL
        LD     (HL),0F4H          ;Put an 8086 HLT here just in case

;      LD     (HL),0B0H          ;Continously put "3" on Consol via port 01
;      INC    HL                ;Basic test for 8086 on reset
;      LD     (HL),33H
;      INC    HL
;      LD     (HL),0E6H
;      INC    HL
;      LD     (HL),01H
;      INC    HL
;      LD     (HL),0EBH
;      INC    HL
;      LD     (HL),0FAH

        XOR    A
        OUT   (Z80PORT+2),A      ;Re-map back to 0H
        JP    SWITCH_8086        ;Switch over control to the 8086

;READ ASCII FROM MEMORY

TYPE:  CALL   EXLF
SF30B: CALL   LFADR
        LD     B,56
SF310: LD     A,(HL)
        AND   7FH
        CP    SPACE
        JR    NC,SF319
SF317: LD     A,2EH
SF319: CP    7CH
        JR    NC,SF317
        LD     C,A
        CALL  ZCO
        CALL  HILOX
        DJNZ  SF310
        JR    SF30B

;      Display all active IO inputports in the system
;
INPORTS:CALL ZCRLF
        LD     B,0                ;Now loop through all ports (0-FF)
        LD     D,6                ;Display 6 ports across
        LD     E,0FFH            ;Will contain port number
LOOPIO: LD     C,E
        LD     A,E
        CP    A,SW86             ;Inputting here will switch out the Z80 to 8086/80286

```

```

JR      Z,SKIP
CP      A,SW68K           ;Also this one (68K)
JR      Z,SKIP
;
IN      A,(C)             ;Remember [ZASMB does not work with this opcode,SLR is OK]
CP      A,0FFH           ;No need for 0FF's
JR      Z,SKIP
LD      H,A               ;store port data in H for below
LD      A,E               ;Need to print port # first
CALL    LBYTE            ;Print port number
LD      C,'-'
CALL    ZCO
LD      C,'>'
CALL    ZCO
LD      A,H               ;get back port data
CALL    LBYTE            ;print it
LD      C,TAB
CALL    ZCO
DEC     D                 ;6 ports per line
JR      NZ,SKIP
LD      D,6
CALL    ZCRLF
SKIP:   DEC     E           ;Next Port
DJNZ   LOOPIO
CALL   ZCRLF
RET

```

```

;S100Computers Serial I/O Board Initilization
;Note both Zilog SCC serial ports (A & B) will be set to 19,200 Baud initially.

```

```

INIT_S100_IO:           ;First the 8255
LD      A,AinBout8255cfg ;A input, B output, C(bits 0-3) output, (bits 4-7)input
OUT     (PortCtrl_8255),A ;Config 8255 chip, Mode 0

;Then the SCC
LD      A,ACTL           ;Program Channel A
LD      C,A
LD      B,0EH            ;Byte count for OTIR below
LD      HL,SCCINIT
OTIR

;
LD      A,BCTL           ;Program Channel B
LD      C,A
LD      B,0EH            ;Byte count for OTIR below
LD      HL,SCCINIT
OTIR
RET

;
; ALL SSC's are set for 19,200 BAUD

```



```

READR: JP      ZRI                ;TO MONITOR FOR READER
HME:   JP      BIOS_JP_ERR        ;HOME          ;MOVE TO TRACK 0
SDSKE: JP      BIOS_JP_ERR        ;SELDSK
S@TRKE: JP      JP      BIOS_JP_ERR ;SET@TRK
SSECE: JP      BIOS_JP_ERR        ;SETSEC
SDMAE: JP      BIOS_JP_ERR        ;SETDMA
RDE:   JP      BIOS_JP_ERR        ;READF
WRE:   JP      BIOS_JP_ERR        ;WRITEF
LISTS: JP      LSTAT              ;LIST STATUS
SECTR: JP      BIOS_JP_ERR        ;SECTRAN FOR 2.2 SECTOR TRANSLATION TABLE

DTYPE: JP      BIOS_JP_ERR        ;UNITSL      SET UP @UNIT BYTE (DISK DENSITY)
SVE:   JP      BIOS_JP_ERR        ;SAVER SAVE N RECORDS
LDE:   JP      LOADER             ;LOADER      LOAD N SECTORS FROM TRACK 0 (& TRACK 1)

BIOS_JP_ERR:
    LD      HL, BIOS_ERR          ;"BIOS JMP longer implemented in ROM @ F800H."
    JP      ABORT_ERR_MSG

;BOOT LOADS A SECTOR TO 80H AND THEN JUMPS TO 80H
;NOTE. Two FDC Boards are supported here:-
;
;      VFDC_BOOT Boots CPM from the Versafloppy-II disk controller board
;      ZFDC_BOOT Boots CPM from the ZFDC controller board

VBOOT: XOR     A,A                ;0 = Flag as Boot from Versafloppy II FDC
        JR      BOOT_COLD
ZBOOT: XOR     A,A
        DEC     A                ;0FFH = Flag as Boot from ZFDC FDC
BOOT_COLD:
    LD      (@FDCTYPE),A         ;0 for VF, 0FFH for ZFDC

BOOT:  LD      A,11111111B        ;FLAG PROGRESS VISUALLY FOR DIAGNOSTIC
        OUT     (DIAG_LEDS),A

        LD      HL,SPEAKCPM_MSG   ;Announce on speaker
        CALL   SPEAK$
        XOR     A
        LD      (CDISK),A         ;MAKE CURRENT DISK A:
        LD      (CIOBYTE),A      ;CLEANUP IOBYTE
        LD      (@UNIT),A        ;8LOAD.Z80 (The first sector loader module) will count on this being 0H
        ;for the Versafloppy-II boots
        LD      (ZERO_L),A       ;These need to be zero's here for the CPM Loader/Versafloppy-II of my old
        LD      (ZERO_H),A       ;NON-BANKED CPM3 or CPM2.2 disks. Need to later find out why!
        LD      HL,128           ;Assume 128 byte sectors for 8" disk
        LD      (@SEC_SIZE),HL

```



```

LD      B,128
DI
LD      A,RDCMD
OUT     (CMD),A           ;Note wait states are now switched on

JR      M2
M2:    JR      MM2
MM2:   JR      Z,RD_128
LD      B,0               ;256X2
INIR    ;[C]-> [HL++],[B--]
RD_128: INIR

EI
CALL    WAITF           ;Wait states are now off
IN      A,(STATUS)
AND     A,SRMASK       ;Check sector was read OK
POP     BC
RET     Z
DEC     B
JR      NZ,READ1
XOR     A,A
DEC     A
RET     ;Return NZ if failure after 3 reads

DRINIT: CALL    SEEK           ;DRIVE INITIALIZATION
LD      HL,(@TADDR)     ;SETUP DMA ADDRESS AND BYTE COUNT
LD      A,(@SCTR)
OUT     (SECTOR),A

LD      DE,(@SEC_SIZE)  ;This will be 128 or 512 sectors
LD      C,DATA          ;8067H in BC

SWEB:  IN      A,(SELECT) ;ENABLE WAIT STATES
AND     7FH
OUT     (SELECT),A
RET

;      SEEK TRACK
SEEK:  LD      A,(@TRK)
LD      C,A
IN      A,(TRACK)
CP      C
RET     Z               ;IF SAME TRACK NO NEED TO SEEK

LD      A,(@TRK)
OUT     (DATA),A
CALL    READY_CHK       ;Critical to make sure chip is ready first!
LD      A,FSKCMD        ;Send Seeek Command to WD1791

```

```

OUT      (CMD),A
CALL    DELAY_15      ;Delay ~15ms
CALL    READY_CHK
IN      A, (TRK)
LD      C,A
LD      A, (@TRK)
CP      A,C
RET     Z
LD      HL, SEEK_ERROR_MSG
JP      ABORT_ERR_MSG

READY_CHK:
LD      BC, 0
READY_CHK1:
IN      A, (STATUS)
AND     A, 1
RET     Z
DEC     BC
LD      A,C
OR      A,B
JP      NZ,READY_CHK1      ;Wait until 1791/5 is ready
JP      WAIT3

WAITF: LD      E, 0
PUSH   BC
LD      C, 2
WAIT2: IN     A, (STATUS)
AND     1
JR      Z,DWAIT
DJNZ   WAIT2
DEC     E
JR      NZ,WAIT2
DEC     C
JR      NZ,WAIT2
POP     BC
WAIT3: IN     A, (SELECT)      ;IF BY THIS TIME NOT READY FORCE
OR      80H                  ;A HARDWARE RESET
OUT     (RSET),A
LD      HL,VF_HUNG
JP      ABORT_ERR_MSG

;      DISABLE WAIT STATES
DWAIT: POP   BC      ;TO BALANCE THE ABOVE PUSH IN WAIT
DDWAIT: IN   A, (SELECT)
OR      80H
OUT     (SELECT),A
RET

```



```

JP      NZ,ERR_NR          ;If error, just abort

LD      C,CMD_SET_DRIVE          ;Send a "Set Drive CMD" to ZFDC board
CALL    S100OUT
LD      C,0                  ;Floppy Drive #, (ZFDC Board expects a 0H, 1H, 2H or 3H)
CALL    S100OUT
CALL    WAIT_FOR_ACK          ;Return Z (and NO_ERRORS_FLAG in [A]), or NZ with error # in [A]
JP      NZ,ERR_NR          ;If error, just abort

;Drive selected and ready to read sectors. Note this code
;is written to eb compatible with the boot loader for the
;Versafloppy-II disk controller as well.

LD      A,STDSDT            ;SETUP FOR SD
LD      (@COUNT),A        ;STORE AS 26 SECTORS/TRACK

XOR     A
LD      (@TRK),A          ;Setup Boot Sector read track
INC     A
LD      (@SCTR),A
LD      (@NREC),A        ;read only 1 sector initially

LD      HL,COLD
LD      (@TADDR),HL

CALL    ZFDC_MULTI_READ_SECTOR ;Actully we will only read one sector here
JP      BOOT_SEC_READ      ;JMP to same section as for Versafloppy boot

```

ZFDC_MULTI_READ_SECTOR:

```

LD      C,CMD_SET_TRACK        ;Set Track
CALL    S100OUT
LD      A,(@TRK)
LD      C,A
CALL    S100OUT              ;Send Selected track HEX number
CALL    WAIT_FOR_ACK          ;Return Z (and NO_ERRORS_FLAG in [A]), or NZ with error # in [A]
JP      NZ,ERR_NR          ;If error, just abort

LD      C,CMD_SET_SECTOR      ;Set Sector # to side A (or for DS disks also side B)
CALL    S100OUT
LD      A,(@SCTR)
LD      C,A
CALL    S100OUT              ;Send Selected sector HEX number
CALL    WAIT_FOR_ACK          ;Return Z (and NO_ERRORS_FLAG in [A]), or NZ with error # in [A]
JP      NZ,ERR_NR          ;If error, just abort

LD      C,CMD_SEEK_TRACK      ;Later can let board do this
CALL    S100OUT
CALL    WAIT_FOR_ACK          ;Return Z (and NO_ERRORS_FLAG in [A]), or NZ with error # in [A]
JP      NZ,ERR_NR          ;If error, just abort

```

```

LD      C,CMD_RD_MULTI_SECTOR      ;Routine assumes required Drive Table,Drive,Side,Track, and sector are already sent to board
CALL    S100OUT                     ;(Note [HL]-> Sector DMA address)
LD      A,(@NREC)                   ;How many sectors
LD      C,A
CALL    S100OUT
CALL    WAIT_FOR_ACK                ;Wait for NO_ERRORS_FLAG to come back
JP      NZ,ERR_NR                   ;If error, just abort

LD      HL,(@TADDR)                 ;Set DMA address

MULTI_RD_SEC:
LD      DE,(@SEC_SIZE)              ;For CPM this will be 128 Byte sector(s)
RD_SEC:CALL S100IN                  ;Note potential to lockup here & below (but unlightly)
LD      (HL),A
INC     HL
DEC     DE
LD      A,E
OR      A,D
JR      NZ,RD_SEC

LD      A,(@NREC)                   ;How many sectors of data worth
DEC     A
LD      (@NREC),A
JR      NZ,MULTI_RD_SEC            ;Are there more

CALL    WAIT_FOR_ACK                ;Return Z (and NO_ERRORS_FLAG in [A]), or NZ with error # in [A]
RET

S100OUT:
IN      A,S100_STATUS_B             ;Send data to ZFDC output (arrive with character to be sent in C)
BIT     DIRECTION_BIT,A            ;Is ZFDC in output mode, if not wait
JR      NZ,S100OUT
BIT     DATA_OUT_RDY,A            ;Has previous (if any) character been read.
JR      Z,S100OUT                  ;Z if not yet ready
LD      A,C
OUT     S100_DATA_B,A
RET

S100STAT:
IN      A,S100_STATUS_B             ;Check if ZFDC has any data for S-100 system
BIT     DATA_IN_RDY,A             ;Anything there ?
RET     Z                          ;Return 0 if nothing
XOR     A,A
DEC     A                          ;Return NZ, & 0FFH in A if something there
RET

S100IN:
IN      A,S100_STATUS_B             ;Check if ZFDC has any data for S-100 system

```



```

        BIT    DIRECTION_BIT,A          ;Is ZFDC in input mode, if not wait
        JR     Z,S100IN                 ;If low then ZFDC board is still in input mode, wait
        BIT    DATA_IN_RDY,A
        JR     Z,S100IN
        IN     A,S100_DATA_A           ;return with character in A
        RET

WAIT_FOR_ACK:                          ;Delay to wait for ZFDC to return data. There is a timeout of about 2 sec.
        PUSH  BC                       ;This can be increased if you are displaying debugging info on the ZFDC
        PUSH  DE                       ;HEX LED display.
        LD    BC,0
        LD    E,STATUS_DELAY           ;Timeout, (about 2 seconds)
WAIT_1:  IN     A,S100_STATUS_B         ;Check if ZFDC has any data for S-100 system
        BIT    DIRECTION_BIT,A         ;Is ZFDC in input mode
        JR     Z,WAIT_2                 ;if low then ZFDC is still in input mode
        CALL  S100STAT                 ;Wait until ZFDC Board sends something
        JR     Z,WAIT_2
        CALL  S100IN                   ;Get returned Error # (Note this releases the SEND_DATA routine on the ZFDC board)
        CP    A,NO_ERRORS_FLAG        ;Was SEND_OK/NO_ERRORS_FLAG sent back from ZFDC Board
        POP   DE                       ;Balance up stack
        POP   BC
        RET                             ;Return NZ if problem, Z if no problem

WAIT_2:  DEC    B
        JR     NZ,WAIT_1                ;Try for ~2 seconds
        DEC   B                        ;Reset B to 0FFH
        DEC   C
        JR     NZ,WAIT_1
        DEC   B                        ;Reset B to 0FFH
        DEC   C
        DEC   E
        JR     NZ,WAIT_1
        XOR   A,A
        DEC   A
        POP   DE                       ;Balance up stack
        POP   BC
        RET                             ;Return NZ flag set if timeout AND 0FFH in [A]

;     LOAD A NUMBER OF SECTORS         ;Note this loader utilizes the fast multi-sec read in V2.8 of later

ZFDC_LOADER:                            ;CPM Loader with ZFDC FDC Board
        CALL  ZFDC_MULTI_READ_SECTOR   ;Note the Boot sector has by now setup the sector count etc. in low RAM
        RET

;-----
;     Module to boot MSDOS from 5" DDDS disk (Note this module has not been updated yet)
;
DOS:    LD     HL,SPEAKDOS_MSG          ;Announce on speaker
        CALL  SPEAK$

```

```

CALL    CRLF

JP      ERR_NR          ;Not done Yet

; LD      A,4           ;MSDOS.SYS STARTS AT SECTOR 4 SIDE B
; LD      (@SCTR),A
; LD      A,0
; LD      (@TRK),A      ;START ON TRACK 0
; LD      A,1
; LD      (@SIDE),A     ;START ON SIDE B
; LD      A,FFILE_SIZE ;SIZE OF DOS IN 512 BYTE SECTORS
; LD      (@NREC),A
;
; LD      A,01110100B   ;0,DD,5",SIDE 1, 0100=D:
; CALL    MDSEL
; JP      NZ,ERR_NR     ;ROUTINE TO SAY DRIVE NOT READY
; LD      A,RSVCMD      ;SEND RESTORE COMMAND
; CALL    DCMDDI
; JR      Z,DGETID
;DOS1: LD  HL,RESTORE_ERR ;RESTORE FAILED
; JP      ABORT_ERR_MSG
;
;DGETID: CALL DIDRD
; JR      NZ,DOS1
;
;GETSEC: LD HL,STARTDOS
;DGET1:  LD  C, '.'      ;to indicate on CRT sectors read
; CALL    CO
; LD      A,(@SCTR)
; OUT    (SECTOR),A
; LD      B,0           ;256 BYTES
; LD      C,DATA       ;DATA PORT
; DI      ;just in case
; CALL    SWEB         ;SET WAIT ENABLE BIT
; LD      A,RDCMD
; OUT    (CMD),A
; INIR
; INIR      ;512 BYTES TOTAL
; LD      B,0
;DWAITF: IN  A,(STATUS)
; AND    1
; DJNZ   DWAITF
;
; CALL    DDWAIT
;
; IN      A,(STATUS)   ;CHECK STATUS
; AND    0FEH
; JP      NZ,ERR_LD    ;ROUTINE TO SAY SECTOR READ ERROR
;
; LD      A,(@NREC)

```

```

;   DEC   A
;   LD    (@NREC),A
;   JP    Z,STARTDOS
;
;   LD    A,(@SCTR)
;   INC   A
;   LD    (@SCTR),A
;   CP    0AH                ;end of track yet?
;   JR    NZ,DGET1
;
;   LD    A,(@SIDE)
;   CP    1                  ;if on track 1 go to side 1 else side 0
;   JR    Z,TRK1A
;   LD    A,1                ;FLAG CURRENT SIDE IS NOW B
;   LD    (@SIDE),A
;   LD    A,01110100B       ;SWITCH TO SIDE B
;   JR    TRK1B
;TRK1A: LD    A,(@TRK)
;   INC   A
;   LD    (@TRK),A
;   LD    A,0
;   LD    (@SIDE),A         ;FLAG CURRENT SIDE IS NOW A
;   LD    A,01100100B       ;SWITCH TO SIDE A
;TRK1B: CALL MDSEL
;   JP    NZ,ERR_NR         ;ROUTINE TO SAY DRIVE NOT READY
;
;DSEC: LD    A,1
;   LD    (@SCTR),A
;
;   LD    A,(@TRK)
;   OUT   (DATA),A
;   LD    A,MSKCMD          ;SEEK TO TRACK WITH VERIFY
;   CALL  DCMDI
;   JP    Z,DDRS3
;DSEC1: LD    HL,MSGH4      ;SEEK ERROR MESSAGE
;   JP    ABORT_ERR_MSG
;
;xxxxz: HALT

;DDRS3: PUSH HL
;   CALL  DIDRD
;   POP   HL
;   JR    NZ,DSEC1
;   JP    DGET1
;
;DIDRD: LD    HL,@IDSV
;   LD    BC,600H+DATA
;   CALL  SWEB
;   LD    A,RDACMD          ;SEND READ ID COMMAND
;   OUT   (CMD),A

```

```

;      INIR
;DWAITS:  IN      A, (STATUS)
;      AND      1
;      JR      NZ,DWAITS
;      CALL    DDWAIT          ;DISABEL WAIT STATE GENERATOR
;      LD      A, (@IDSV)      ;+++++++
;      LD      B,A
;      LD      A, (@TRK)
;      CP      B              ;RETURN WITH Z IF AT RIGHT TRACK
;      RET

;MSEL:    CPL
;      OUT    (SELECT),A
;DRDYCK:  IN      A, (STATUS)
;      AND    80H
;      JP    NZ,DRDYCK
;      RET
;
;SEND TYPE 1 COMMANDS (RESTORE, SEEK, STEP)
;
;DCMDI:   LD      (@CMDSV),A    ;TEMPORLY STORE COMMAND
;      LD      A,80H
;      LD      (@ERMASK),A
;DCMDI1:  IN      A, (STATUS)   ;IS 1793 READY
;      AND    01H
;      JP    NZ,DCMDI1
;      LD      A, (@CMDSV)
;      OUT    (CMD),A
;      CALL  DELAY_15          ;DELAY REQUIRED FOR A VALID STATUS
;DEEND:   IN      A, (STATUS)   ;END OF DISK COMMANDS ROUTINE
;      AND    01H
;      JP    NZ,DEEND          ;IS 1793 STILL BUSY
;      IN      A, (STATUS)
;      LD      D,A
;      LD      A, (@ERMASK)
;      AND    D              ;CHECK FOR ERRORS
;      RET

;-----THIS IS THE MAIN ROUTINE TO GET THE TIME DATA FROM THE CMOS-RTC Chip on the MSDOS Support Board

SHOW_TIME:
LD      HL,TIME_MSG
CALL    PRINT_STRING          ;Print message up to '$'
CALL    PRINT_TIME
RET

SHOW_DATE:
LD      HL,DATE_MSG
CALL    PRINT_STRING          ;Print message up to '$'
CALL    PRINT_DATE

```

```
RET
```

```
PRINT_TIME:
```

```
CALL UPD_IN_PR      ;CHECK FOR UPDATE IN PROCESS
JP NC,RTC_2A        ;GO AROUND IF OK
JP RTC_ERROR        ;IF ERROR
```

```
RTC_2A: LD E,-2      ;-2 goes to 0 for PORT_INC_2
CALL PORT_INC_2     ;SET ADDRESS OF SECONDS
IN A,(CMOS_PORT+1) ;Get BCD value returned
LD D,A              ;SAVE IN D
CALL PORT_INC_2     ;SET ADDRESS OF MINUTES
IN A,(CMOS_PORT+1) ;Get BCD value returned
LD C,A              ;SAVE IN C
CALL PORT_INC_2     ;SET ADDRESS OF HOURS
IN A,(CMOS_PORT+1) ;Get BCD value returned
LD B,A              ;SAVE
LD E,0              ;SET E TO ZERO
CALL DisplayTime
XOR A,A              ;Clear Carry
RET                 ;BACK TO MONITOR
```

```
RTC_ERROR:          ;Indicate RTC Board is not present or Error
SCF                 ;SET CARRY FOR ERROR
RET
```

```
;Display time
```

```
; Arrive with B = HOURS IN BCD
; C = Minutes in BCD
; D = Seconds in BCD
```

```
DisplayTime:
```

```
PUSH DE
PUSH BC
LD A,B
CALL PRINT_BCD      ;Hours. Convert BCD to ASCII
LD C,':'
CALL ZCO
POP BC
LD A,C
CALL PRINT_BCD      ;Minutes. Convert BCD to ASCII
LD C,':'
CALL ZCO
POP DE
LD A,D
CALL PRINT_BCD      ;Seconds. Convert BCD to ASCII
RET
```

```
PRINT_DATE:
```

```
CALL UPD_IN_PR
```

```

        JP      NC,RTC_4A
        JP      RTC_ERROR          ;IF ERROR

RTC_4A:  LD      E,6
        CALL   PORT_INC           ;POINT TO DAY
        IN     A,(CMOS_PORT+1)
        LD     B,A                ;SAVE IN A
        CALL   PORT_INC           ;POINT TO MONTH
        IN     A,(CMOS_PORT+1)
        LD     D,A                ;SAVE IN D
        CALL   PORT_INC           ;POINT TO YEAR
        IN     A,(CMOS_PORT+1)
        LD     C,A                ;SAVE IN C
        LD     E,31H              ;POINT TO CENTURY BYTE SAVE AREA
        CALL   PORT_INC           ;
        IN     A,(CMOS_PORT+1)    ;GET VALUE
        LD     E,B                ;GET DAY BACK
        LD     B,A
        CALL   DisplayDate
        XOR    A,A                ;Clear Carry
        RET                       ;FINISHED

;Display date
;      Return B = CENTURY IN BCD
;      C = Year in BCD
;      D = Month in BCD
;      E = Day in BCD
DisplayDate:
        PUSH   DE
        PUSH   DE
        PUSH   BC
        PUSH   BC

        POP    BC
        LD     A,B
        CALL   PRINT_BCD         ;Century (19/20).  Convert BCD to ASCII
        POP    BC
        LD     A,C
        CALL   PRINT_BCD         ;Year.  Convert BCD to ASCII
        LD     C,'/'
        CALL   ZCO
        POP    DE
        LD     A,D
        CALL   PRINT_BCD         ;Month.  Convert BCD to ASCII
        LD     C,'/'
        CALL   ZCO
        POP    DE
        LD     A,E
        CALL   PRINT_BCD         ;Day.  Convert BCD to ASCII

```

```

RET

UPD_IN_PR:                ;Check we are ready to read clock
    PUSH BC
    LD BC,600             ;SET LOOP COUNT
UPDATE:                  ;ADDRESS OF [A] REGISTER
    LD A,0AH
    OUT (CMOS_PORT),A
    NOP
    NOP
    NOP
    IN A,(CMOS_PORT+1)   ;READ IN REGISTER [A]
    AND A,80H            ;IF 8XH--> UIP BIT IS ON (CANNOT READ TIME)
    JP Z,UPD_IN_PREND    ;Are we ready/done
    DEC BC
    LD A,C
    OR A,B
    JP NZ,UPDATE         ;Try again
    XOR A,A
    SCF                  ;SET CARRY FOR ERROR
    POP BC
    RET

UPD_IN_PREND:
    XOR A,A              ;Clear Carry
    POP BC
    RET                  ;RETURN

PORT_INC:
    LD A,E
    INC A                ;INCREMENT ADDRESS
    LD E,A
    OUT (CMOS_PORT),A
    RET

PORT_INC_2:
    LD A,E
    ADD 2                ;INCREMENT ADDRESS
    LD E,A
    OUT (CMOS_PORT),A
    RET

PRINT_BCD:              ;Print BCD in [A]
    PUSH AF
    PUSH AF
    RRA
    RRA
    RRA
    RRA

```



```
;
;THIS ROUTINE JUMPS OVER TO THE 8088, 8086 or 80286. Port SW86 raises S-100 PIN #55
;THIS WILL CAUSE THE 8086/80286 BOARD TO BECOME ACTIVE AND TAKE OVER THE BUS. THE
;Z80 WILL BE IN A PERMANANT HOLD STATE UNTIL PIN #55 IS AGAIN LOWERED.
```

```
SWITCH_8086:
    LD    HL,MSG14
    CALL  PRINT_STRING
    IN    A, (SW86)          ;THIS SWITCHES CPU'S with no block Move
                                ;Z80 WILL BE HELD HERE
    NOP
    NOP
    NOP
    JP    BEGIN             ;WILL DROP BACK TO REBOOT MONITOR
```

```
;THIS ROUTINE JUMPS OVER TO THE 68000 CPU Board. Port SW68K raises S-100 PIN #56
;THIS WILL CAUSE THE 68000 CPU BOARD TO BECOME ACTIVE AND TAKE OVER THE BUS. THE
;Z80 WILL BE IN A PERMANANT HOLD STATE UNTIL PIN #56 IS AGAIN LOWERED.
```

```
SWITCH_68K:
    LD    HL,MSG68K
    CALL  PRINT_STRING
    IN    A, (SW68K)       ;THIS SWITCHES CPU'S
                                ;Z80 WILL BE HELD HERE
    NOP
    NOP
    NOP
    JP    BEGIN             ;WILL DROP BACK TO REBOOT MONITOR
```

```
;
;
;
;THESE ARE ROUTINES NOT YET IMPLEMENTED
;
RI:                ;READER
POO:               ;PUNCH
PRDY:              ;PUNCH STATUS (Sent to Serial port right now)
RSTAT:             ;READER STATUS (Input from Serial port right now)
ONLIST:            ;ON LIST
OFLIST:            RET          ;OFF LIST
TRAP:  HALT
```

```
;
;
DRIVE_NR_ERR: DB    BELL,CR,LF
                DB    'Drive not Ready.',CR,LF,LF,'$'
RESTORE_ERR:  DB    BELL,CR,LF
                DB    'Restore Failed.',CR,LF,LF,'$'
BOOT_LD_ERR:  DB    BELL,CR,LF
```

```

        DB      'Read Error.',CR,LF,LF,'$'
SEEK_ERROR_MSG: DB      BELL,CR,LF
        DB      'Seek Error.',CR,LF,LF,'$'

BOOT_LD1_ERR: DB      BELL,CR,LF
        DB      'BOOT error.',CR,LF,LF,'$'
VF_HUNG:      DB      'VF Controller Hung',CR,LF,LF,'$'
BIOS_ERR:     DB      'BIOS JMP not in ROM',CR,LF,LF,'$'
BOOT_MSG0:    DB      CR,LF,'Loading CPM from $'
VF_MSG:       DB      'VF FDC.',CR,LF,'$'
ZFDC_MSG:     DB      'ZFDC FDC.',CR,LF,'$'

MENUMSG:      DB      CR,LF
        DB      'A=Memmap B=68000    C=CP/M(Z) D=Disp E=Echo F=Fill G=Goto'
        DB      CR,LF
        DB      'H=Date I=Time J=Test K=Menu L=CPM(V) M=Move N=SeqMap'
        DB      CR,LF
        DB      'O=8086 P=CPM(IDE) Q=Port R=Ports S=Subs T=Type'
        DB      CR,LF
        DB      'V=Verify W=Port EDH X=DOS(H) Z=Top @=Flush Printer'
        DB      CR,LF,LF,'$'
;
MSG14:        DB      BELL,CR,LF
        DB      '8086/80286 Active'
        DB      CR,LF,LF,'$'
MSG68K:       DB      BELL,CR,LF
        DB      '68K Active'
        DB      CR,LF,LF,'$'
MSG17:        DB      CR,LF
        DB      'Segment (0-F):$'
TIME_MSG:     DB      CR,LF,'Time:- $'
DATE_MSG:     DB      CR,LF,'Date:- $'
GAP_MSG:      DB      ' $'

IDE_RW_ERROR: DB      CR,LF
        DB      'IDE Drive R/W Error'
        DB      CR,LF,'$'
SP_MSG        DB      CR,LF,'SP=$'
SPEAKCPM_MSG: DB      'LOADING CPM $'
SPEAKDOS_MSG: DB      'LOADING DOS $'
CR_SMSG:      DB      CR,CR,CR,CR,'$'
;
        NOP
        HALT

;END

```